

Light distribution within an illuminated 50 mm diameter integrating sphere model UPK-50-F with OP.DI.MA. coating manufactured by Gigahertz-Optik

Optometers & Instruments	3 - 58
Table of Contents	
Hand Held Meter	5 - 36
Personal Dosimeter	37 - 40
Bench Top Meter	41 - 50
Pulse Shape Analyzer	51 - 54
Current to Voltage Amplifier	55 - 56
Accessories	57 - 58
Light Detectors	59 - 90
Optometer Model Depending Plug Types	62
Maximum Measurable Intensity and Resolution	63
Illuminance Detectors	63 - 65
Irradiance Detectors	66 - 67
UV Irradiance Detectors	68 - 69
Photobiological Actinic Irradiance Detectors	69 - 70
Plant Physiology Irradiance Detectors	71
High Intensity, High Temperature Irradiance Detectors	72 - 73
UV-Curing Detectors	72 - 73
360 Degree Field-Of-View Irradiance Detectors	73
Multi-Channel Illuminance & Irradiance Detectors	74 - 75
Luminous Color & Illuminance Detectors	76
Luminance & Radiance Detectors	77 - 80
Luminous Flux & Radiant Power Detectors	81
Laser Stray-light & Laser Power Detectors	82
Laser Power Detectors with Integrating Sphere	82 - 83
Laser Pulse Shape Radiant Power Detectors	84
Compact Size Modular Detectors	85
Temperature Controlled Modular Detectors	86
Modular Detectors	86
1 cm <sup>2</sup> Circular Area Modular Detectors	87 - 88
Average LED Intensity Front Adapters	87 - 88
Weather Proof Detectors	88
Light Detector Accessories	89 - 90

# Application & Product Guide - Page 1 Table of Contents

Integrating Spheres	93 - 122
Table of Contents	93 - 94
Modular Setup-able Integrating Spheres	95 - 106
Examples of Modular Integrating Sphere Set-ups	95 - 99
Barium Sulfate, OP.DI.MA. & Gold Coatings	100
Modular Integrating Sphere Component Descriptions	100 - 106
Precise Machined Integrating Spheres	107 - 115
Barium Sulfate Coated Precise Machined Spheres	108 - 110
OP.DI.MA. Coated Precise Machined Spheres	111 - 114
Gold Coated Precise Machined Spheres	114 - 115
Integrating Sphere Accessories	115 - 116
Light Sources & Light Source Accessories	117 - 121
Application Service	122
Diffuse Reflectors	123 - 130
Table of Contents	123
OP.DI.MA. Optical Diffuse Material	124 - 129
Optical Diffuse Paint	129 - 130
Optical Diffuse Gold	130
Calibration Standards & Uniform Light Sources	131 - 140
Table of Contents	131
Spectral Irradiance Standards	132 - 133
Spectral Radiant Power & Luminous Flux Standards	134
Spectral Radiance, Luminance & Uniformity Standards	135 - 138
Spectral Radiant Power Sensitivity Standards	139
Spectral Irradiance Sensitivity Standards	139
Spectral Reflectance Standards	
Spectral Reflectance Standards           Calibration Service	140
•	140 <b>141 - 156</b>
Calibration Service	140 <b>141 - 156</b> 141 - 142
Calibration Service         Table of Contents	140 <b>141 - 156</b> 141 - 142 143 - 145
Calibration Service         Table of Contents         Traceability of Gigahertz-Optic's Calibration Laboratory	140 <b>141 - 156</b> 141 - 142 143 - 145 146 - 147
Calibration Service         Table of Contents         Traceability of Gigahertz-Optic's Calibration Laboratory         Calibration & Re-Calibration of GO's Light Detectors	140 <b>141 - 156</b> 141 - 142 143 - 145 146 - 147 147
Calibration Service Table of Contents Traceability of Gigahertz-Optic's Calibration Laboratory Calibration & Re-Calibration of GO's Light Detectors Re-Calibration Service for Other Manufacturers Products	140 <b>141 - 156</b> 141 - 142 143 - 145 146 - 147 147 148 - 149
Calibration Service Table of Contents Traceability of Gigahertz-Optic's Calibration Laboratory Calibration & Re-Calibration of GO's Light Detectors Re-Calibration Service for Other Manufacturers Products Spectral Calibration of Light Sources	140 <b>141 - 156</b> 143 - 145 146 - 147 147 148 - 149 150
Calibration Service	140 <b>141 - 156</b> 141 - 142 143 - 145 146 - 147 147 148 - 149 150 150 - 151
Calibration Service	140 <b>141 - 156</b> 143 - 145 146 - 147 147 148 - 149 150 150 - 151 151
Calibration Service	140 <b>141 - 156</b> 143 - 145 146 - 147 147 148 - 149 150 150 - 151 151
Calibration Service	140 <b>141 - 156</b> 141 - 142 143 - 145 146 - 147 147 147 150 150 - 151 151 151 152 - 153
Calibration Service	140 <b>141 - 156</b> 143 - 145 146 - 147 147 148 - 149 150 150 - 151 151 151 152 - 153 154
Calibration Service	140 <b>141 - 156</b> 143 - 145 143 - 145 147 148 - 149 150 150 - 151 151 151 152 - 153 154 - 155
Calibration Service	140 <b>141 - 156</b> 141 - 142 143 - 145 146 - 147 147 150 150 150 151 151 152 - 153 154 154 - 155 155 - 156
Calibration Service	140 <b>141 - 142</b> 143 - 145 146 - 147 147 148 - 149 150 150 - 151 151 152 - 153 154 155 - 156 156
Calibration Service	140 <b>141 - 156</b> 143 - 145 143 - 145 147 148 - 149 150 150 - 151 151 152 - 153 154 154 - 155 155 - 156 156 <b>157 - 198</b>
Calibration Service         Table of Contents         Traceability of Gigahertz-Optic's Calibration Laboratory         Calibration & Re-Calibration of GO's Light Detectors         Re-Calibration Service for Other Manufacturers Products         Spectral Calibration of Light Sources         Integral Radiometric Calibration of Light Sources         Colorimetric Calibration of Light Sources         Directional Calibration of Light Sources         Spectral Sensitivity Calibration of Light Detectors         Integral Radiometric Sensitivity Calibration of Detectors         Integral Radiometric Sensitivity Calibration of Detectors         Spectral Sensitivity Calibration of Detectors         Integral Radiometric Sensitivity Calibration of Detectors         Integral Radiometric Sensitivity Calibration of Detectors         Measurement & Qualification Services	140 <b>141 - 142</b> 143 - 145 146 - 147 147 148 - 149 150 150 - 151 151 152 - 153 154 155 - 156 155 <b>157 - 198</b> 158
Calibration Service         Table of Contents         Traceability of Gigahertz-Optic's Calibration Laboratory         Calibration & Re-Calibration of GO's Light Detectors         Re-Calibration Service for Other Manufacturers Products         Spectral Calibration of Light Sources         Integral Radiometric Calibration of Light Sources         Colorimetric Calibration of Light Sources         Directional Calibration of Light Sources         Spectral Sensitivity Calibration of Light Detectors         Integral Radiometric Sensitivity Calibration of Detectors         Integral Reflectance & Transmittance Calibrations         Measurement & Qualification Services         Tutorials         Introductions	140 <b>141 - 156</b> 143 - 145 146 - 147 147 148 - 149 150 150 - 151 151 152 - 153 154 - 155 155 - 156 155 - 156 <b>157 - 198</b> 158 158 - 168
Calibration Service         Table of Contents         Traceability of Gigahertz-Optic's Calibration Laboratory         Calibration & Re-Calibration of GO's Light Detectors         Re-Calibration Service for Other Manufacturers Products         Spectral Calibration of Light Sources         Integral Radiometric Calibration of Light Sources         Colorimetric Calibration of Light Sources         Directional Calibration of Light Sources         Spectral Sensitivity Calibration of Light Detectors         Integral Radiometric Sensitivity Calibration of Detectors         Integral Radiometric Sensitivity Calibration of Detectors         Spectral Sensitivity Calibration of Detectors         Integral Radiometric Sensitivity Calibration of Detectors         Integral Radiometric Sensitivity Calibration of Detectors         Integral Reflectance & Transmittance Calibrations         Measurement & Qualification Services         Tutorials         Introductions         Properties and Concepts of Light and Color	140 <b>141 - 156</b> 143 - 145 143 - 145 147 148 - 149 150 150 - 151 151 152 - 153 154 - 155 155 - 156 156 <b>157 - 198</b> 158 - 168 158 - 168
Calibration Service         Table of Contents         Traceability of Gigahertz-Optic's Calibration Laboratory         Calibration & Re-Calibration of GO's Light Detectors         Re-Calibration Service for Other Manufacturers Products         Spectral Calibration of Light Sources         Integral Radiometric Calibration of Light Sources         Colorimetric Calibration of Light Sources         Directional Calibration of Light Sources         Spectral Sensitivity Calibration of Light Detectors         Integral Radiometric Sensitivity Calibration of Detectors         Integral Photometric Sensitivity Calibration of Detectors         Integral Photometric Sensitivity Calibration of Detectors         Spectral Reflectance & Transmittance Calibrations         Measurement & Qualification Services         Introductions         Properties and Concepts of Light and Color         Measurement of Light with Integral Light Detectors	140 <b>141 - 156</b> 143 - 145 143 - 145 147 148 - 149 150 150 - 151 151 151 152 - 153 154 - 155 155 - 156 156 <b>157 - 198</b> 158 169 - 180 181 - 182
Calibration Service         Table of Contents         Traceability of Gigahertz-Optic's Calibration Laboratory         Calibration & Re-Calibration of GO's Light Detectors         Re-Calibration Service for Other Manufacturers Products         Spectral Calibration of Light Sources         Integral Radiometric Calibration of Light Sources         Colorimetric Calibration of Light Sources         Directional Calibration of Light Sources         Spectral Sensitivity Calibration of Light Detectors         Integral Radiometric Sensitivity Calibration of Detectors         Integral Radiometric Sensitivity Calibration of Detectors         Integral Reflectance & Transmittance Calibrations         Measurement & Qualification Services         Properties and Concepts of Light and Color         Measurement of Light with Integral Light Detectors         Integrating Spheres	140 <b>141 - 156</b> 143 - 145 143 - 145 147 148 - 149 150 150 - 151 151 152 - 153 154 - 155 155 - 156 155 <b>157 - 198</b> 158 158 158 - 168 169 - 180 181 - 182 183 - 193

## Page 2 - Application & Product Guide

## Alphabetical Listing of Product Part Numbers

A 8.4			110		01		105 100	111/ 0704	<u> </u>
AM	00	LS-OK30	118	PRW-0505	81	UMPA-0.5/11	105 - 106	UV-3701	69
BHO	90	LS-OK30-FH	118	PS-3701	71	UMPA-0.5/11RD	105 - 106	UV-3702	69
BN-0001	133	LS-OK30-FHI	118	PS-3702	71	UMPA-0.5/F	105 - 106	UV-3703	69
BN-0102	135	LS-OK30-MIR	118	PS-3703	71	UMPA-1.0/F	105 - 106	UV-3704	69 - 70
BN-0104	134	LS-OK30-VA	118	PT-9610	33 - 34	UMPA-1.5/LGA13	105 - 106	UV-3706	69 - 70
BN-9101	133	LS-OK45	119	RCH-006	72 - 73	UMPA-2.0/AXL	105 - 106	UV-3708	69 - 70
BN-DSI-33	139	LS-OK45-LG	119	RCH-008	72 - 73	UMPA-2.0/LED5	105 - 106	UV-3709	69 - 70
BN-DSR-100	139	LSM-9901	81	RCH-009	72 - 73	UMPA-4.0/QD1.9	105 - 106	UV-3710	69
BN-LH250	132	MD-37-GP6	86	RCH-106	72 - 73	UMPA-4.0/QD3.0	105 - 106	UV-3711	69
BN-Rxx-D2	140	MD-37-GAP	86	RCH-108	72 - 73	UMPA-5.0/LED5	105 - 106	UV-3716	69
BN-Rxx-SQ	140	MD-37-IGA1	86	RCH-109	72 - 73	UMPA-5.0/SH	105 - 106	UV-3717	69
BN-ULS-K190	138	MD-37IGA3	86	RCH-506	72 - 73	UMPA-5.0/SH-CM	105 - 106	UV-3718	69
BN-ULS-M	136 - 137	MD-37-SC1	86	RCH-508	72 - 73	UMPB-IL	104	UV-3719	69
CT-3701	76	MD-37-SU13	86	RCH-509	72 - 73	UMPB-PM	104	VAM-45	119
CT-4501	76	MD-37-SU133	86	ROD-360	73	UMPB-SM	104	VL-1101	63
FWM-12/2	119	MD-37-SU100	86	RW-1103	66	UMPD-37	104	VL-3701	64
HCT-99	35 - 36	MD-37Z-C11	86	RW-1104	66	UMPD-45	104	VL-3702	64
K-FOV	147	MD-37Z-DR11	86	RW-1105	66	UMPF-LSOK30	104	VL-3704	64
K-xx-C	147	MD-37Z-H7	86	RW-3701	67	UMPF-LSOK45	104	VL-3705	64
K-xx-l	146	MD-37Z-H7xx	86	RW-3702	67	UMPF-xx	102	WPD-01	88
K-xx-S	146	ODG95	130	RW-3703	67	UMBK-250	100	WG	90
K-xx-SR	146	ODMxx-B	126 - 127	RW-3704	67	UMPP-xx	103	WQ	90
KDD-S	152	ODM98-F	127	RW-3705	67	UMPR-xx	103	<b>X1</b> 1	9 - 12
KDW-P	154 - 155	ODMxx-P	126 - 127	SRT-M37	80	UMSS-BT150	101	X-2000	37 - 40
KDW-R	154	ODMxx-MP	127 - 128	SMC-01	12	UMSS-BT210	101	<b>X9</b> 1	13 - 14
KDW-S	152 - 153	ODP97	129 - 130	TD-1101	86	UMSS-BT300	101	<b>X9</b> <sub>2</sub>	15 - 16
KF-xx	147	P-2000	41 - 44	TD-1102	86	UMSS-BT500	101	<b>X9</b> ₃	17 - 18
KLD-S	148 - 149	P-9202	55 - 56	TD-1103	86	UMSS-BT1000	101	X94	19 - 20
KLW-CT	151	P-9710-1	5 - 8	TD-11RW03	66	UMSS-BT1700	101	X96	21 - 22
KLW-ID	151	P-9710-2	5 - 8	TD-11RW04	66	UMSS-HF300	102	<b>X9</b> 7	23 - 24
KLW-P	150 - 151	P-9801	45 - 48	TD-11RW05	66	UMSS-HF500	102	X98	25 - 26
KLW-R	150	P-9802	49 - 50	TD-11UV01	68	UMSS-HF1000	102	<b>X9</b> 10	27 - 28
KLW-S	148 - 149	PD-1101	85	TD-11UV02	68	UMSS-HF1700	102	<b>X9</b> 11	29 - 30
KRW-S	155 - 156	PD-1102	85	TD-11VL01	65	UMSS-SM14	101	<b>X9</b> 12	31 - 32
KTW-S	155 - 156	PD-1103	85	TP-4501	76	UMSS-SMT	101	XD-9501	74 - 75
LC	90	PD-1104	85	TR-9600	51 - 54	UMSS-SMV	101	XD-9502	74 - 75
LCRT-2000	120	PD-1105	85	UFC	116	UPB-50-L	108	XD-9503	74 - 75
LDM-9810	77 - 78	PD-1106	85	ULT-18	115	UPB-100-F	108	XD-9504	74 - 75
LDM-9811	77 - 78	PD-1107	85	UMBB-100	100	UPB-150-F	109	XD-9505	74 - 75
LDM-9901	79	PD-1108	85	UMBB-150	100	UPB-250-F	109	XD-9506	74 - 75
LP-0101	82 - 83	PD-1109	85	UMBB-210	100	UPB-500-F	110	XD-9509	74 - 75
LP-0102	82 - 83	PD-16BLH	77 - 78	UMBB-300	100	UPK-30-L	111	XD-9510	74 - 75
LP-0103	82 - 83	PD-16RTH	77 - 78	UMBB-500	100	UPK-50-F	111 - 112	XD-9511	74 - 75
LP-0102	82 - 83	PD-16RTHA	77 - 78	UMBB-1000	100	UPK-50-L	111 - 112		
LP-9901	82	PD-16RW05	77 - 78	UMBB-1700	100	UPK-50-ULS	111 - 112		
LP-9910	83	PD-16VL01	77 - 78	UMBG-100	100	UPK-100-F	112		
LP-9920	83	PD-9302-RW	87 - 88	UMBG-150	100	UPK-100-L	112		
LP-9930	83	PD-9302-VL	87 - 88	UMBG-300	100	UPK-150-F	113		
LPPA-9901	84	PD-9303-COS	87 - 88	UMBK-190	100	UPK-190	113		
LH-xx	117,118,	PD-9304	87 - 88	UMBK-460	100	UPK-250	114		
LH-xx-UV	137	PD-9306	87 - 88	UMLA-1.5B	106	UPG-75-F	114		
LPS-250	120	PD-9310	65	UMLA-300	106	UPG-100-F	115		
LS-CB	119	PD-9311	87 - 88	UMLA-500	106	UV-1101	68		
	119	10-0011	07 - 00	SINEA-300	100		00		

## **Table of Contents**

## Optometers & Instruments: Radiometers, Photometers, Color Meters, Laser Power/Noise Meters

**Optometer** is the term Gigahertz-Optik uses to describe a optical radiation measurement instrument that is universally adaptable to any light measurement application. The light detector(s) connected to the instrument determines the meter designation and the units of measurement. To meet the demands of a wide range of industrial, medical, research and environmental applications single and multi-channel optometers with advanced features for mobile or bench-top use are offered. **In-** struments (Radiometers, photometers & color meters) are combinations of meters and specific light detectors selected for a given application. These dedicated systems are simple to use and save costs since only required features are provided.

Contact us for assistance in helping you select the right equipment for your application or for full custom product service.

## **Table of Contents**

Model	Description	on Type Measurements Modes							Interface	Page
		Hand Held				Pulse				
		Bench Top	Average	Dose	Logger	Energy	Shape	Peak		
P-9710-1	Universal Optometer	HH, BT			$\checkmark$				RS232	5-8
P-9710-2	Universal Optometer	HH, BT			$\checkmark$				RS232	5-8
<b>X1</b> 1	Universal Optometer	НН							USB	9-12
<b>X9</b> 1	Illuminance & Luminance Light Meter	НН							RS232	13-14
<b>X9</b> 2	UV-Curing High Power Irradiance Meter	НН							RS232	15-16
<b>X9</b> 3	Laser Power & Laser Stray-light Meter	НН							RS232	17-18
<b>X9</b> 4	Radiant Power & Luminous Flux Meter	НН							RS232	19-20
<b>X9</b> 6	UV-A, UV-B & UV-B <sub>311</sub> Irradiance Meter	HH	$\checkmark$						RS232	21-22
<b>X9</b> 7	Irradiance Meter	HH							RS232	23-24
X98	UV-A Irradiance & Illuminance Contrast/Dose Meter	HH	$\checkmark$	$\checkmark$					RS232	25-26
<b>X9</b> 10	dBM & Radiant Power Meter	HH							RS232	27-28
<b>X9</b> 11	UV-C <sub>254nm</sub> Irradiance Meter	НН							RS232	29-30
<b>X9</b> 12	ACGIH/ICNIRP Actinic Irradiance Meter	HH		$\checkmark$					RS232	31-32
PT-9610	Laser Power & Noise Analyze Meter	HH/BT								33-34
HCT-99	Luminous Color & Illuminance Meter	HH	$\checkmark$						USB	35-36
X-2000	Personal Dosimeter	Mobile		$\checkmark$					RS232	37-40
P-2000	Universal 2-Channel Optometer	BT	$\checkmark$		V				RS232/ IEEE488	41-44
P-9801	Universal 8-Channel Optometer	BT	$\checkmark$	$\checkmark$					RS232/ IEEE488	45-48
P-9802	36-Channel Optometer	BT	$\checkmark$						RS232	49-50
TR-9600	High-speed Pulse Shape Analyzer Meter	BT	V				V	V	RS232/ IEEE488	51-54
P-9202	Current to Voltage Amplifier	BT								55-56
Accessor	ies : Carrying Cases	1	1	ı	1	1			1	57

Page 4



## 🕞 Gigahertz-Optik

## **Optometers & Instruments - Page 5**

P-9710-1 / P-9710-2 Compact Optometer

- $\ensuremath{\mathbb{C}}$  Compact Single-Channel Meter for Service and Laboratory Use
- © Universal Use in any Light Measurement Application
- $\ensuremath{\mathbb{C}}$  Calibration Data Connector for Simple & Unlimited Detector Exchange
- $\ensuremath{\mathbb{C}}$  Measurement of DC, AC and Flash Signals
- © Short Slew-Rate for Fast Measurements
- $\bigcirc$  100  $\mu$ s Fast Sampling Rate
- $\odot$  Adjustable Integration Time from 100  $\mu$ s to 6 s
- © Wide Detector Signal Dynamic Range from 0.1 pA to 2 mA
- © RS232 Interface for Remote Control Operation
- © Optional Windows Software

### Associated Parts / Service:

Chapter Detector Heads Chapter Integrating Spheres Chapter Calibration

The P-9710 Optometer is a highly efficient single-channel instrument designed for multipurpose use in any photometric and radiometric application.

In spite of its compact size it offers many high-level features complimenting sixteen different measurement modes. These functions plus portability enable the P-9710 to be characterized as both a laboratory grade instrument and a field service meter.

#### Calibration Data Connector:

A unique feature of the P-9710 is its detector head calibration data connector. All data pertaining to a detector including the model and serial number are stored in the connector. When plugged into the meter, this data is automatically transmitted and the



system is ready to go. This guarantees faultless handling of the instrument when used with any number of differ-

#### ent detector heads. Wide Dynamic Range:

The P-9710's wide signal range of 0.1 pA to 2 mA covers the dynamic range of most current semiconductor photodiodes for nearly unrestricted use in any light measurement application. **Fast Measurements:** 

The P-9710 offers a fast signal input with 2 to 10 ms slew-rate (gain dependent). Its fast  $100\mu$ s sample rate allows use of the P-9710 as a fast data logger. Another key feature for individual application set-ups is an adjustable integration time (calculated average) of up to 6 seconds.

#### **Precision Measurement:**

The P-9710 offers a linear 12-bit ADC input with 8 manually or automatically selected gain ranges with a maximum error over this large dynamic range 0.2 %.

#### **Remote Control:**

A bi-directional RS232 serial interface allows external remote control. Optional Windows based software is available for a quick turn-key solution or user generated programming is possible using the complete command set supplied. End-user recalibration by adjustment of the factory programmed calibration factors is possible using the OS CAL software via the RS232 interface or manually by menu function.

#### **Process Integration:**

An optional relay switch board is available for activation by the P-9710 in process control applications. A 'low-okhigh' indication t h r o u g h

menu con-

trolled set-up of the limit values is simple.

## Multiple Applications:

The P-9710 mates with most of



GO's detector heads to cover any photometric and radiometric measurement quantity.

### Mobility:



The hand-held P-9710 is battery (rechargeable) or AC operated. A tough hard-shell case

holds one, two or more detector heads for secure portability in service use.

#### Numerous Functions:

The unit's many functional modes of operation includes CW, dose, pulse energy, datalogger measurements and many more. If the sixteen different operation modes do not include the one you need we do offer custom design modifications.

### Two Different Models:

<u>The P-9710-1</u> is the right choice for most kinds of light measurement applications. Its short range dependent slew-rate allows the measurement of fast changing high power level signals. In the pulse energy mode the energy of single pulses > 20 ms in pulse length can be measured.

<u>The P-9710-2</u> is required if the energy of a single pulse or pulse-chain of pulse lengths  $> 1 \mu$ s must be measured. The 20 ms slew-rate is independent of the gain range.

Other than the difference in pulse width measurement capa-



bility both versions offer the same functionality and technical qualities.

100x
measure
measure
meanue
0e-13 A
A Ckar
A Clear



## Page 6 - Optometers & Instruments

## P-9710-1 / P-9710-2 Applications

Features like multiple functional modes, bench-top laboratory level specs and calibration data connector for error-free detector interchange make the P-9710 the

right instrument for many fieldservice, laboratory and process applications. To complete the system, one or more of GO's wide range of photometric and

#### Illuminance and Luminance Photometer

Because of it's wide dynamic range the P-9710 is suitable for high-level photometric applications. In combination with the VL-3701-2 detector, illuminance levels from 100 mlx (1 mlx resolution) to 1,000 klx can be meas-

nance detector head extends the application range of the P-9710. It's

ured. The LDM-9810-2 lumi-

three selectable viewing angles of 20', 1° and 6° plus it's brilliant ocular view allow the precise lo-

cation of the measurement area of interest. Both detector heads offer a low CIE standard V(Lambda) photometric matching uncertainty  $f_1$ ' equal to or less than 3% (DIN Class A).

tial UV hazard. Typical spectral

weighting functions for the

acutely harmful effects of optical

radiation are ACGIH, Erythema

The flexible P-9710 with the UV-

3704-2 (erythema), UV-3708-2

(ACGIH) irradiance detectors

and the LDM-9811 (Blue-Light

Hazard, Retinal thermal hazard)

radiance detector offer all re-

quired functional modes and

features for accurate UV hazard

and Blue-Light Hazard.

measurement.

#### **UV-Hazard Meter**

The adverse effects of overexposure to incoherent optical radiation on skin and eye is being afforded increasing attention. The reasons can be attributed to rising ultraviolet levels in sunlight and the widespread use of high powered lamps in light therapy, cosmetics, UV curing, UV surface inspection, UV sterilization and others. A growing number of regulations exist describing how to measure, assess and classify light sources according to poten-

### Laser Stray-Light Meter

Laser are very useful tools in many measurement and production applications due to the attributes of high power, monochromatic and directional beam radiation. But laser radiation is also a health risk to the human eye. Laser stray-light (indirect or scattered) may even be a risk due to these high power levels. Standard EN 60825-1/11.01 describes these risks and measurements for hazard classification. The common tool used to measure laser stray-light employs detectors such us the LP-9901 with a 7 mm dia. free aperture which mimics the open

pupil. The functional operation modes of P-9710 such as peak hold, data-logger & energy pulse support these measurement 🌆

#### **Radiant Power and Laser Power Meter**

Light sources with diverging (non collimated) beams such as LED's. laser diodes & dispersed laser beams measured with flat surface photodiodes may cause high measurement uncertainties due to differing incident angles and polarization. The re-reflected light from the detector surface can cause additional problems by interference effects in the



500 mm diameter for use with the P-9710.



LED Luminous Flux Meter >> Section Tutorials

LED Luminous Intensity Meter >> Section Tutorials

radiometric detectors must be selected for use with the P-9710.

#### Our Light Measurement Guide ,available in our catalog

#### **Universal Light Meter**

The P-9710's calibration data connector that you ensures never have to remember to up-date the meter set-up when changing detector heads. This feature becomes very important if the P-9710 is to be used in multiple applications involving different

detector heads. With so many modes of operation available,

#### Effective Luminous Intensity Meter

To increase the intensity of light sources with limited average power they are used in flash mode which allows much higher peak powers than in CW mode. If the light flash is used for increased visual acuity, the flash peak power and the CW peak power do not show a linear correlation. Because of this evaluation of the effective intensity of pulsed light signals is done according to the Schmidt-Clausen method using with two different

## VIS-NIR Radiometer / Pvrometer

Radiometric measurements, such as irradiance (W/m<sup>2</sup>). in the visible and near infrared part of the optical radiation spectrum are getting more attention since more VIS & NIR sources are being used in sensor, photomedicine, photocuring and other applications.

Gigahertz-Optik offers different types of detector heads for use with the P-9710 for irradiance measurements in the visible (400

#### Flash Energy Meter

Short pulse length flash lamps, normally associated with photographic strobes, are also used in ophthalmology and UV-curing processes. Measurement of the energy in a single light flash or in a pulse train of light flashes is typically done using light meters that store the detected signal in a capacitive circuit. In applications with very different pulse

UV Curing Meter >> Section Tutorials

Power Meter for Telecom Application >> Section Tutorials

Detector Heads for use with P-9710 >> Section Light Detectors

and on our website, offers additional tutorials and application notes relating to the Measurement of Light and Measurement with Light.



photetherapy plant phyticity

this is often the case. The P-9710 is the right choice when maximum versatility is a requirement.

time constants C for daylight

observation (0.1 s for light



to 800 nm), VIS/NIR (400-1100

nm). NIR/IR (800-1800 nm) in-

cluding specific spectral ranges

within the 400 to 1800 nm region.

600

800

400

energy levels, common to light

measurement, these meters are

not very linear and difficult to

calibrate. The P-9710 performs

flash measurements using the

extended pulse sampling

method (EPSM) offering higher

linearity for flashes  $\geq 1\mu$ s. Cali-

bration with DC calibration

source standards ensure much

lower calibration uncertainties

200

nm

 $N/m^2$ 





## P-9710-1 & -2, Operation Function Modes & Specifications

### **Operation Modes:**

Because of it's unique electronic design and it's powerful microprocessor the P-9710 optometer is more than just a simple instrument for light intensity readings.

#### **CW Measurement**

CW mode is used to measure continuous DC or AC signals at the selected integration time from 100  $\mu$ s to 6 s. The reading, units of measurement and the

### **CW Offset**

A constant offset value, such as an ambient light level, can be

#### **CW Minimum or CW Maximum**

Min. or max. value attained during the measurement period is displayed along with the current

#### Peak Minimum or Maximum, Peak to Peak

These modes allow analysis of signal stability within the selected integration interval (e.g. flicker of light sources). The min., max. or p-p values are displayed to-

#### I-Effective

Evaluation of the effective luminous intensity of a single light flash according to the Schmidt-Clausen method. The measurement is manually started by pressing the 'run' button. The integration time is selected in the

### **Pulse Energy**

Energy measurement of a single pulse or a series of pulses within a selected measurement time. The measurement time is selected in the 'set-up/pulse measurement time' menu function.

#### **Pulse Offset**

A pre-set offset value, such as an ambient light level, can be subtracted from the I-Effective and Pulse Energy reading. 'Static Offset' subtracts a constant

value. 'Continuous Offset' subtracts the actual measured value

Sixteen different modes of op-

eration (functions) in combina-

tion with variable measurement

parameter set-up capabilities

makes the P-9710 one of the

selected wavelength as applica-

ble for the connected detector

are displayed on the LCD. Man-

ual or auto-range operation as

entered for subtraction from the

reading. during a measurement

period (deleted by pressing

gether with the CW average

value. Only signals longer that

the gain dependent slew-rate

(see table below) can be meas-

'set-up/pulse measurement time'

menu function. The time con-

stant C for daylight (0.1 s) and

night time observation (0.2 s)

can be selected in the 'set-up/IF

Pressing the 'run' button starts

the measurement . In auto-range

mode 'UL/ OL' (under/over-load)

is displayed if a gain change is

time constant' menu function.

CW measured value

'reset' button).

ured.

necessary.

selected

most flexible and powerful meters available. It can be found in both manual and remote control use in process control, long-term stability monitoring, service, teaching and R&D applications. This page shows the currently available functions and specifications. Custom design for user specified functions is available .

#### Ratio relative (%), log. (dB), factor

Measurement of the ratio bet- ween a reference value and the actual measured value. Dis-	played as relative ratio (%) or logarithm ratio/attenuation (dB or dBm) or ratio factor.
Reference	
The reference value is used for ratio measurements (see Ratio function). The ref. value can be set to 1 with the selected unit such as 1 W, 1 A. A CW measurement value can	be stored as reference value. A manually entered value can be used as reference. The reference value '1.000 mW' can be used to measure attenua- tion in dBm.
Hold	
Beside the actual measurement value a current reading can be	'frozen' by pressing 'reset' but- ton.
CW Level Check	
Compares the measured CW va- lue with stored pre-set lower and upper limit values. The actual measurement value and it's sta- tus is displayed. The limit values	the RS232. The relay board P- 9710Z-02 can be remote con- trolled to indicate the status by external lamps or integrate the meter in process control applica-
can be entered manually or via	tion.
can be entered manually or via Dose (Integrated Energy)	tion.
	tion. matically stopped at a preset max. dose measurement time (1 s to 1,000 h) or a max. dose value. The actual measurement status can be displayed.
<b>Dose (Integrated Energy)</b> Measurement values are accumulated at a logging rate of 1 s and displayed as dose. The measurement can be manually	matically stopped at a preset max. dose measurement time (1 s to 1,000 h) or a max. dose value. The actual measurement
Dose (Integrated Energy) Measurement values are accu- mulated at a logging rate of 1 s and displayed as dose. The measurement can be manually started and stopped or be auto-	matically stopped at a preset max. dose measurement time (1 s to 1,000 h) or a max. dose value. The actual measurement
Dose (Integrated Energy) Measurement values are accu- mulated at a logging rate of 1 s and displayed as dose. The measurement can be manually started and stopped or be auto- Automatic Data Logger Up to 12,288 measurement val-	matically stopped at a preset max. dose measurement time (1 s to 1,000 h) or a max. dose value. The actual measurement status can be displayed.
Dose (Integrated Energy) Measurement values are accu- mulated at a logging rate of 1 s and displayed as dose. The measurement can be manually started and stopped or be auto- Automatic Data Logger Up to 12,288 measurement val- ues can be stored with a sam-	matically stopped at a preset max. dose measurement time (1 s to 1,000 h) or a max. dose value. The actual measurement status can be displayed.
Dose (Integrated Energy) Measurement values are accu- mulated at a logging rate of 1 s and displayed as dose. The measurement can be manually started and stopped or be auto- Automatic Data Logger Up to 12,288 measurement val- ues can be stored with a sam- Manually Data Logger Up to 150 individual data records	matically stopped at a preset max. dose measurement time (1 s to 1,000 h) or a max. dose value. The actual measurement status can be displayed. pling rate of 0.1 to 6000 s. be stored by pressing the run
Dose (Integrated Energy) Measurement values are accu- mulated at a logging rate of 1 s and displayed as dose. The measurement can be manually started and stopped or be auto- Automatic Data Logger Up to 12,288 measurement val- ues can be stored with a sam- Manually Data Logger Up to 150 individual data records (meas. values & parameters) can	matically stopped at a preset max. dose measurement time (1 s to 1,000 h) or a max. dose value. The actual measurement status can be displayed. pling rate of 0.1 to 6000 s. be stored by pressing the run
<ul> <li>Dose (Integrated Energy)</li> <li>Measurement values are accumulated at a logging rate of 1 s and displayed as dose. The measurement can be manually started and stopped or be auto-</li> <li>Automatic Data Logger</li> <li>Up to 12,288 measurement values can be stored with a sam-</li> <li>Manually Data Logger</li> <li>Up to 150 individual data records (meas. values &amp; parameters) can</li> <li>Manual Calibration Data</li> </ul>	matically stopped at a preset max. dose measurement time (1 s to 1,000 h) or a max. dose value. The actual measurement status can be displayed. pling rate of 0.1 to 6000 s. be stored by pressing the run button
<ul> <li>Dose (Integrated Energy)</li> <li>Measurement values are accumulated at a logging rate of 1 s and displayed as dose. The measurement can be manually started and stopped or be auto-</li> <li>Automatic Data Logger</li> <li>Up to 12,288 measurement values can be stored with a sam-</li> <li>Manually Data Logger</li> <li>Up to 150 individual data records (meas. values &amp; parameters) can</li> <li>Manual Calibration Data</li> <li>Individual calibration correction</li> </ul>	matically stopped at a preset max. dose measurement time (1 s to 1,000 h) or a max. dose value. The actual measurement status can be displayed. pling rate of 0.1 to 6000 s. be stored by pressing the run button
<ul> <li>Dose (Integrated Energy)</li> <li>Measurement values are accumulated at a logging rate of 1 s and displayed as dose. The measurement can be manually started and stopped or be auto-</li> <li>Automatic Data Logger</li> <li>Up to 12,288 measurement values can be stored with a sam-</li> <li>Manually Data Logger</li> <li>Up to 150 individual data records (meas. values &amp; parameters) can</li> <li>Manual Calibration Data</li> <li>Individual calibration correction</li> <li>Remote Control</li> </ul>	matically stopped at a preset max. dose measurement time (1 s to 1,000 h) or a max. dose value. The actual measurement status can be displayed. pling rate of 0.1 to 6000 s. be stored by pressing the run button data can be manually entered

## **Specifications:**

### **Dimensions:**



before the pulse measurement is started. Subtraction selection is made in 'pulse offset' menu.

## no and Uncertainty Charifie

Range and	Range and Uncertainty Specifications							
Range (A/V)	Range max. signal	Slew-Rate (10-90%) P-9710-1 / -2		Error (with offset compensation) 1 year 23°C +/-5°C +/-(% of reading + % of range)	Gain (A/V) Analog Output			
P-9710-1	& P-9710-2	P-9710-1	P-9710-2	P-9710-1 & P-9710-2				
1 x 10⁻³	2.000 mA	2 ms	20 ms	0.2 % + 0.05 %	1 x 10 <sup>-3</sup>			
1 x 10 <sup>-4</sup>	200.0 µA	2 ms	20 ms	0.2 % + 0.05 %	1 x 10 <sup>-3</sup>			
1 x 10⁻⁵	20.00 µA	3 ms	20 ms	0.2 % + 0.05 %	1 x 10⁻⁵			
1 x 10⁻ <sup>6</sup>	2.000 µA	3 ms	20 ms	0.2 % + 0.05 %	1 x 10⁻⁵			
1 x 10 <sup>-7</sup>	200.0 nA	4 ms	20 ms	0.2 % + 0.05 %	1 x 10 <sup>-7</sup>			
1 x 10⁻ <sup>8</sup>	20.00 nA	4 ms	20 ms	0.2 % + 0.05 %	1 x 10 <sup>-7</sup>			
1 x 10 <sup>-9</sup>	2.000 nA	10 ms	20 ms	0.2 % + 0.05 %	1 x 10 <sup>-9</sup>			
1 x 10 <sup>-10</sup>	200.0 pA	10 ms	20 ms	0.2 % + 0.05 %	1 x 10 <sup>-9</sup>			

## P-9710-1 & P-9710-2, Specification & Ordering Information

## Specification:

Signal Input	
Detector Input	Photocurrent to voltage converter amplifier with following voltage to voltage amplifier (x10). 8 decade stepped gain ranges with max. gain signal values from 2.000 mA to 200.0 pA. Manual or automatic range switching. 12 bit ADC with up to 14 bits at longer integration times.
Signal Processing	A/D converter with 100 $\mu$ s time interval. Longer integration (100 $\mu$ s to 6s) through averaging of multiple measurements.
Frequency Range	Signal conversion from 0.166 Hz (6s integration time setting) to >300 MHz
Zero Setting	Gain independent offset subtraction of unwanted ambient light signal.
Detector Connector	9 pin DSUB-socket . Detector heads with calibration data connector (type -2).

Function	
Parameter Settings	Menu controlled parameter set-up. Retention of the last settings in continuous memory. 10 function buttons.
Measurement Quantity	Ampere calibrated with DKD calibrated current source. Current signal multiplied with calibration correction factor to display absolute photometric or radiometric quantities. Calibration data stored in calibration data connector of the detector heads manually entered into the meter storage.
Dose Measurement	Integration of the measurement signal with 1 s sampling rate. Adjustable max. measurement time from 1 s to 1000 h. Adjustable maximum dose limit value. Current status display function.
Data Logger	Storage of up to 12,288 readings. Adjustable sampling rate from 0.1 to 6000 seconds. Manual recording mode. Display of readings stored in the flash Eproms on the display or on computer using the RS232 interface and software.
Analog Output	Gain dependent: 0 - 200 mV or 0 - 2 V (10 k $\Omega$ internal resistance). Integrated into RS232 connector.

General	
Display	2 x 16 character LCD with switch-able LED backlight.
Operating Temperature	5 to 40°C (41 to 104°F) (75 % rel. H, non-condensing). Storage Temperature: 0 to 50°C (32 to 122°F).
Dimensions/Weight	195 x 100 x 40 mm / 500 g (7.7 x 3.9 x 1.6 in /1.1 lb).
Serial Port Settings	RS232 (9600 baud, 8 data bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector
Power supply	Battery or AC operation. Built-in rechargeable lead battery, 6V,0.5 Ah. Approx 6 h with display illumination. Battery charge under 8 % is displayed. Operation from AC plug-in power supply 230V/50 Hz (other values on request) with specific U/I recharge characteristic.

## Interface RS232

9600 Baud, 8 data bit, 1 stop bit, no parity. TRIAD01 / 5 pin connector with integrated analogue output.

## Detector Head / Measurement Output

Detector Heads	All available detector heads with –2 type calibration data connector. See chapter 'detector heads' to select the detector head for your application.
Data Connector	Storage of sensor data such as detector model number, serial number, calibration data. Calibration data of integral sensitivity or spectral sensitivity with or without accessory. Selection of the calibration data or the wavelength in the menu function of the P-9710. Automatic data transfer if detector head is connected to the meter.

<b>Ordering Info</b>	Ordering Information					
P-9710-1	Optometer with gain dependent slew-rate, rechargeable battery with plug-in power supply and manual					
P-9710-2	Optometer with gain independent slew-rate, rechargeable battery with plug-in power supply and manual					
Detector Heads	All Gigahertz-Optik detector heads with -2 type calibration data connctor (example VL-3701-2)					
P-9710Z-01	RS232 Interface Cable to connect P-9710 to a PC (9 pin serial connector) or P-9710Z-02 Relay Motherboard					
P-9710Z-02	Relay Motherboard (power supply and housing not supplied)					
P-9710Z-03	PCI I/O Interface Card					
P-9710Z-04	Plug for the RS232/analog-output signal socket of the P-9710 optometer					
P-9710Z-1/2	Adapter cable to connect detector with BNC-type connectors to P-9710					
P-9710Z-2/1	Adapter cable to connect detector with calibration data connector (-2) to meters with BNC-type socket input					
OS-P9710	Software for remote control of the P-9710-1, including OS-CAL.					
OS-CAL	Software to enter calibration data via the P-9710 meter into -2 type data connector					
BHO-01	Hard-shell Case for P-9701 with detector heads and accessories					
BHO-02	Hard -shell Case for P-9710 with LDM-98xx detector head and accessories					
BHO-08	Hard -shell Case 450x320x150 mm/17,7x12,5x5,9 in; (length x width x height) for individual use with P-9710 and accessories					
BHO-09	Hard -shell Case 350x260x120 mm/13,7x10,2x4,7 in; (length x width x height) for individual use with P-9710 and accessories					



## 🕃 Gigahertz-Optik

## Optometers & Instruments - Page 9

## X11 4-Channel Hand-held Optometer

- © Hand-held Four-Channel Meter for Field Service and Laboratory Use
- $\ensuremath{\mathbb{C}}$  Universal Use in any Light, Light Color and Radiation Measurement Application
- © Measurement of DC and AC Signals
- $\odot$  Signal Range from 0.1 pA to 20  $\mu$ A or 1 pA to 200  $\mu$ A with 6 Gain Ranges
- © 1 ms bis 1 s Sampling Rate
- © Adjustable Integration Time from 1 ms to 1s
- © CW, Dose and Color Operation Modes
- © USB Interface for Remote Control Operation
- © Battery & AC Operation (via USB)

Associated Parts / Service: Chapter Detector Heads Chapter Integrating Spheres Chapter Calibration



The X11 (Xone-one) optometer is one of the most versatile handheld light measurement instruments available.

It combines a powerful electronic design packaged in a lightweight ergonomic housing. It's compact size makes it ideal for field service applications. However, it's other unique features like a USB interface and multiapplication capability with an excellent price-quality-ratio qualify it as a laboratory grade instrument as well.

#### Four Input Channels:

A unique feature of the X11 is it's capability to operate detector



X11 with XD-9506 dual channel ACGIH Skin detector head

heads with up to 4 sensors. All 4 signals or combinations of them are shown on it's four line display with on/off backlighting.

#### Multi-application Capability:

The flexibility to combine the X11 with all Gigahertz-Optik detector heads enable it to be used in a



CT-4501 color & illuminance detector with luminance accessory wide application range of radiometric, photometric and colorimetric measurements.

#### Multiple Detector Meter:

When more than one detector head is used with the X11 meter simple and faultless selection of the calibration data is accomplished from the menu mode.

#### Precise Measurements:

The X11 offers a high linearity 12-

bit ADC input with 6 manually or automatically selected gain ranges. The max. error within this wide dynamic range is 0.2 %. The amplifier is connected to the four signal inputs by an electronic switch.

#### Two Versions:



X11 with XD-9502 & XD-9506 detector for UV-A/white light ratio and ACGIH Skin protection measurements of UV sources for NDT testing of surface cracks.

The X11 is available in two versions for low or high signal applications.

- X11–LS up to 20 µA with 0.1 pA max. resolution
- X11-HS up to 200 µA with 1.0 pA max. resolution

Both versions feature a short slew-rate of typically 3 ms, a max. sampling rate of 1 ms and an adjustable integration time from 1 ms to 1 s.

### Simple Operation:

Operating the X11 is simple. Once it is set-up, all settings are stored and recalled on next power-up unless reprogrammed. Measurement values are displayed in absolute quantities for the particular detector connected. The meter set-up is supported by an easy to use menu. The menu allows selection of the operating mode, the detector and measurement parameter.

#### Functions:

The X11 offers a **CW mode** for DC or AC signals plus dose, color and remote control operation. In **dose mode** a measurement time of up to 256 hours can be selected.

In **color mode** with the CT-4501 detector, x,y chromaticity coordinates, color temperature and illuminance are measured. Additional accessories can be attached for the measurement of luminance, luminous flux and luminous intensity.

A USB interface allows remote



**control** operation of the meter (DLL file supplied).

### Battery and AC Operation:

For on-site applications the X11 is operated by two standard 1.5 V AA batteries for a life-time of up to 500 hours.

In remote control operation the meter is powered through the USB bus for time and battery independent use.

#### **Custom Label & Instrument:**

The X11 can also be custom labeled and/or detectors designed to individual customer specifications. Contact the factory for more information.







## X11 Applications

Because of it's multiple function capabilities, high level specs and compact size the X11 is the right instrument for many field-service, laboratory and guality control

#### Precise Illuminance & Luminance Meter with USB Interface

Facilities that integrate daylight into their lighting strategy need to check and monitor the lighting design over time. An efficient tool for long term data logging is a laptop computer with a USB interface remote controlled instrument.

The X11 with VL-3704 & LDM-

applications.

In combination with Gigahertz-Optik's wide range of detector heads the X11 can be used for photometric, radiometric and

colorimetric measurements. The following pages offer typical X11 application's. Our **Light Measurement Guide**, shown in our catalog

9801 detector heads form a DIN Quality Class B qualified illuminance and luminance meter with a USB interface. Along with the photometric detectors other detectors for light color, UV, VIS, and NIR can be combined with the X1 1. and website offers additional tutorials and application notes dealing with the Measurement of Light and Measurement with Light.



## UV Hazard (DGZfP-Merkblatt EM6) & Contrast (DIN EN 1956, ASTM and MIL Standard) Qualification of UV Radiation Sources used in Nondestructive Testing for Surface Defects



UV radiation sources are used to stimulate fluorescence in the Liquid Penetration Method, used in NDT to detect surface cracks in nonporous materials.

The ideal emission spectrum of these sources is high intensity UV-A radiation with no white light and very low levels of shorter wave UV-B and UV-C.

White light reduces the contrast of the fluorescence emitted from the defect while UV-C and UV-B radiation increase the risk for skin and eye damage. Any spectral leakage of the deeper UV and white light blocking filters used with these lamps due to age and use create two risks:

1.reduced contrast between fluorescence and background 2.increased UV hazard risk for

operators skin and eye Consequently periodical measurement of the UV sources with respect to UV hazard and contrast is needed.

#### Contrast Measurement:

DIN EN 1956, ASTM and MIL Standards exist that describe the general conditions and standard practices for the test examina-

### **Light Color Meter**

All Gigahertz-Optik optometers are characterized by their universal nature in photometric and radiometric measurement applications. The X11 offers the additional capability of performing colorimetric measurements of light sources as well.

Combined with the CT- 4501 de-

tions, including the procedures to be followed. The minimum requirements for the illumination or irradiation conditions, test procedures to be used for checking the specified levels and suitable measurement equipment specifications are also covered.

The XD-9502 detector head is a great choice for the contrast measurement. A precise illuminance detector with a f1' photopic error of less than 6 % and a solar blind UV-A detector are combined in one housing for quick and simple measurements. Both sensors are traceably calibrated to the ISO EN 17025 accredited part of Gigahertz-Optik's calibration laboratory for optical radiation measurement quantities

#### UV Hazard Measurement:

The assessment of UV radiation under the aspect of UV hazard is the subject of the new **DG2fP-Merkblatt EM6** regulation. EM6 specifies that all UV sources used in fluorescence penetrant test applications must be classified and regularly tested. The protective measures taken for the operators depend on the safety classification.

The classification criteria are the UV hazard effective irradiation  $E_{\text{eff}}$  based on the ACGIH/ICNIRP (American Conference of Governmental Industrial Hygienists / International Commission on Nonlonizing Radiation Protection) re-

tector head the X11 not only

measures the x,y chromaticity

values but also color tempera-

ture and illuminance in Ix or fc

(luminance, luminous intensity

and luminous flux with attach-

The CT-4501 is a precision 4-

cell color detector which offers a

ments).



gulation. In stationary testers EM6 states a potential risk to the skin only, because of built-in eye protection devices. The risk to the eye due to stray light is low because of its diffuse character. **The XD-9506 detector head** is designed with two sensors (ACGIH-UV-B/C 250 to 325 nm and ACGIH-UV-A<sub>skin</sub> 325 to 400 nm) to avoid any cross-talk between UV-A & UV-B/UV-C radia-

tion. This cross-talk is a typical problem for single channel detectors when measuring UV-A rich sources.

**The X11** is the right meter for both applications. In combination with the XD-9506 it displays the UV-A and UV-B effective irradiance as well as the total ACGIH effective irradiance.

full X<sub>short</sub>, X<sub>long</sub>, Y and Z spectral characteristic allowing the measurement of blue-enhanced light sources and tube lamps with low measurement uncertainty. The low profile detector height of only 20 mm qualifies it for ANSI Lumen measurements.



ACGIH/ICNIRP Characteristic

### **Triple PAR Meter**

Photosynthesis is one of the most important biochemical processes on the planet. In the process of photosynthesis green plants absorb carbon dioxide from the atmosphere and water from the soil, combining them with the aid of radiation energy to build sugar, releasing oxygen and water into the atmosphere.

To understand and control the interrelation of optical radiation and plants precise and predictable measurement is needed. Most commercially available instruments measure the photosynthetic active radiation PAR.

synthetic active radiation PAR, which covers the visible part of the optical spectrum from 400 to

700 nm. But optical radiation outside the visible spectrum also effects plant growth. To cover this entire spectral range of interest Gigahertz-Optik offers the TP-4501 "Triple PAR" detector head which includes one PAR sensor plus one sensor each for the shorter, 320 to 500 nm, and longer wavelength range from 590 to 900 nm. A fourth illuminance cell allows comparison of light intensity to the human eye response. The X11 optometer displays all four values at once. Dose measurement over a setable time period of up to 100 hours is possible.



### Universal Meter for Photometry, Radiometry and Colorimetry

Light is everywhere and many companies are involved in making light or using it. Typical examples are light source manufacturers including traffic lights, endoscopes and light guides. The best known measurement quantity used to qualify light is illuminance measured in lx or fc. But in today's situation where the color and color temperature of light are qualifying characteristics, where the luminance contrast on monitors in medical diagnostic applications needs to be regularly qualified, where intense light sources create potential risk for UV and blue-light hazard, simple lightmeters no longer do the job.

The X11 with all its available detector heads and accessories is the right answer for all who need to measure more than simply light intensity.

#### X11 Light Meter:

Combined with a VL-3704 & LDM-9901 detector head, spectrum independent light source measurements of illuminance & luminance can be precisely accomplished.

X11 Light & Light Color Meter: Together with the CT-4501 de-



tector head the X11 measures x,y chromaticity values, color temperature and illuminance. The 4-cell detector head technology ensures low measurement uncertainty in most situations.

Combined and calibrated with an integrating sphere the X11 allows the measurement of luminous flux & light color parameters.

#### X11 UV Hazard Meter:

Gigahertz Optik offers detector heads for UV-A, UV-B, UV-C, blue-light hazard, ACGIH and Erythema measurements.

#### X11 Universal Meter:

All applications described and several more based on GO's wide variety of detector heads and accessories require only one X11 optometer.

## Functions:

The X11 optometer offers several modes of operation fulfilling it's multipurpose use capability. Because of it's ability to operate detector heads with up to four cells, the X11 is the right meter for all Gigahertz-Optik multi-cell

#### **CW Measurement**

CW mode is used to measure continuous DC or AC signals at the selected integration time from 1 ms to 1s. Both the measurement value and the measurement guantity is displayed.

#### **Dose Measurement (Integrated Energy)**

Measurement values are accumulated with a logger rate of 1 s and displayed as dose. The measurement can be manually detectors. Not only does the meter work for single value display functions, special operational modes when in use with the CT-4501 tristimulus color detector head and the 2-cell ACGIH<sub>skin</sub> detector head XD-9506 are in-

For multi-cell detector heads the readings and units of each cell are displayed on a single line. Selectable manual and auto-ranging operation.

Measurement (Integrated Energy)

started and stopped or be automatically stopped at a pre-set max. dose measurement time (1 s to 256 h).

Light Color Measurement (with CT-4501)

Combined with the CT- 4501 detector head, the X11 measures x,y or u'/v' chromaticity values, color temperature and illuminance in lux or foot-candles.

With accessory attachments and additional calibrations, measurement of luminance (front lens), luminous flux (integrating sphere) and luminous intensity (calibration at a given distance) is possible.

The chromaticity color values, color temperature and the light intensity of the accessory dependent measurement quantity are all simultaneously displayed. cluded. The USB mode enables the X11 to be used in data logger and full remote control operations.

All available functions at the time of printing this catalog are described. If you do not see a fea-

## ACGIH<sub>skin</sub> Irradiance Measurement (XD-9506)

Assessment of UV radiation sources characterized as 'UV-A rich' requires 2-cell detector head technology as offered by the XD-9506. The ACGIH effec-

#### **Detector Selection**

The calibration data of all detector heads ordered with the X11 are stored in the meter's calibration data eeprom. The detector

#### **Accessory Selection**

The calibration data of any accessory components ordered and calibrated with the detector heads are stored in the X11 meter's calibration data eeprom.

#### **Remote Control Operation**

On X11 USB connection to a computer the meter will automatically activate itself for remote ture or function you require or if custom labeling of the X11 based on a specific application is of interest, please contact the factory to discuss our custom design services.

tive UV-A and UV-B+UV-C irradiance values are displayed together with the SUM signal which represents the effective ACGIH 'weighted' irradiance.

connected to the meter is simply selected in the menu mode and all associated calibration data is applied.

The calibration data for the connected detector head /component combination are applied when selected in the menu mode.

control operation via the USB interface. All meter buttons are de-activated.

## X11 Specifications & Ordering Information

## Specifications X11 Meter

Signal	anut						
Signal Input           Detector Input         Photocurrent to voltage converter amplifier with following voltage to voltage amplifier (x10). 6 decade stepped g ranges with max. gain signal values from 20 µA to 200.0 pA (X11 LS) or 200 µA to 2.000 nA (X11 HS) model . Manua automatic range switching. 12 bit ADC with up to 14 bit at longer integration times.							
Signal Pr	ocessing		converter with 1 ms time interval. Longer integration (1 ms to		g of multiple measurements.		
0	cy Range	Sign					
Zero Sett	, 0	Ű					
	Connecto		independent offset subtraction of unwanted ambient light si MDSM9-socket (type –4)	9.1			
Function		. [= ]= .					
		Mar	e entrelled percenter est up. Detertion of the lest estimate		O function buttons		
	er Settings		a controlled parameter set-up. Retention of the last settings i				
	ment Qua	disp	ere calibrated with DKD calibrated current source. Current ay measurement values in photometric, radiometric or colori				
Dose Me	asuremer	nt Adju	stable max. measurement time from 1 s to 256 h.				
General							
Display			graphic display 97x32 pixel. Display size 14.3 mm x 35.8 mr iaracters.	n. Switch able LED bao	cklight. 4 display lines with each		
Operatin	g Tempera	ature 10 to	40 °C (50 to 104 ° F) (75 % rel. H, non-condensing). Storage	e Temperature: 0 to 50	°C (32 to 122 °F)		
	ons/Weigl		: 63 x 30 mm / 150 g (5.7 x 2.5 x 1.2 in / 0.33 lb)				
	t Settings	USB					
Power su	lpply	2 x b	attery size AA (2.2 to 3.2 V); USB operation bus powered				
Interfac	e						
USB		HID					
Detecto	r Head / I	Measuremer	t Output				
Detector	Heads		railable detector heads with -4 type connector. See chapte cation.	r 'detector heads' to s	elect the detector head for your		
Range S	pecificati	ions X11-LS			Dimension		
Range (A/V)	Range max.	Slew-Rat (10 - 90%		Permissible Detec- tor Capacitance	- 63 mm		
1x10-5	20.00 µA	A 3 ms	0.2 % + 0.05 %	2 nF	Gigahertz-Optik		
1x10-6	2.000 µA		0.2 % + 0.05 %	2 nF	X11 Optometer		
1x10-7	200.0 nA		0.2 % + 0.05 %	10 nF			
1x10-8	20.00 nA		0.2 % + 0.05 %	10 nF			
1x10-9	2.000 nA		0.2 % + 0.05 %	10 nF			
1x10-10	200.0 pA	A 30 ms	0.2 % + 0.05 %	10 nF			
Range S	pecificat	ions X11-HS					
Range (A/V)	Range max.	Slew-Rat (10 - 90%		Permissible Detec- tor Capacitance			
1x10-4	200.0 µA	A 3 ms	0.2 % + 0.05 %	2 nF			
1x10-5	20.00 µA		0.2 % + 0.05 %	2 nF			
1x10-6	2.000 µA	A 3 ms	0.2 % + 0.05 %	10 nF			
1x10-7	200.0 nA		0.2 % + 0.05 %	10 nF	30 mm		
1x10-8	20.00 nA	A 3 ms	0.2 % + 0.05 %	10 nF			
1x10-9	2.000 nA	A 3 ms	0.2 % + 0.05 %	10 nF			
Ordering	g Informa						
X11-LS			r low signal applications4 type connector. Including 2 x A				
X11-HS			r high signal applications4 type connector. Including 2 x A	A type batteries, USB	DLL, USB cable and manual		
OS-X1			emote control operation of the X11				
BHO-01   Carrying case for X1 <sub>1</sub> with 37-type detectors and one LDM-9901 detector							
BHO-04 BHO-05		, ,	e for X1 <sub>1</sub> with 37-type detectors and accessory e for X1 <sub>1</sub> with RCH-0xx and RCH-1xx type detectors				
		Jun ying Uds	יוסר אדן שונד רוסד סאג מווע רוסד דאג נצףפ עפופטנטוא				

BHO-05Carrying case for X11 with RCH-0xx and RCH-1xx type detectorsBHO-06Carrying case for X11 with one CT-4501 or TP-4501 detector

Detector Heads See chapter 'detector heads' to select the detector and detector accessories for your application

## 🕞 Gigahertz-Optik

## Optometers & Instruments - Page 13

X91 Hand-held Light Meter

- Illuminance Range: 0.5 to 199.999 lx with 0.01 lx resolution ©
- Luminance Range: 2.5 to 199.999 cd/m<sup>2</sup> with 0.05 cd/m<sup>2</sup> resolution  $\bigcirc$
- © Precise Photometric Matching Detectors
- © DIN Class B Parameters
- © Compact Size & Ergonomic Design for Mobile Use

F

- © Large Size Display
- © High Reliability
- © Economical Price
- © Battery Operation
- © RS232 Interface
- © OEM Labeling

#### Light Measurement

The most common methods for qualifying light intensity are measuring illuminance in lux or foot-candles and luminance in cd/m2 or foot-lam-

berts. Illuminance E, in lx or fc describes the 🧲 luminous flux per unit area falling on a surface. Luminance L, measured in cd/m<sup>2</sup> or fL <

describes the brightness of an illuminant or illuminated area.

Light meters with illuminance and luminance detectors are the traditional instruments used in most lighting applications.

The wide variety of light sources available today creates problems for light meters calibrated specifically for use with tungsten lamps. Illumination generated by tube lamps with mercury line spectra must also be measured as well as the luminance contrast of monitors used in medical

X9 1 Comparison to DIN 5032 Class Limits (%)	Illumir	ance Luminance		nance	
Characteristics	Symbol	X91	DIN	X91	DIN
Calibration Uncertainty	U <sub>kal</sub>	1.1	3	1.5	4
V(λ) Match	f <sub>1</sub>	5	6	5	6
UV Response	u	0.01	2	0.01	2
IR Response	r	0.01	2	0.01	2
Directional Response	f <sub>2</sub>	3	3	-	-
Linearity	f <sub>3</sub>	0.2	2	0.2	2
Display Unit	f <sub>4</sub>	0.1	4.5	0.1	3
Fatigue (at 1 klx)	f <sub>5</sub>	0.1	1	0.1	1
Temperature Dependence	f <sub>6</sub>	1	10	1	10
Modulated Light	f <sub>7</sub>	0.1	0.5	0.1	0.5
Range Change	f <sub>11</sub>	0.2	1	0.2	1



diagnostics for example. For this reason current DIN and EN regulations specify that light meters must have a maximum permissible error  $f_{tot}$  of ±10%. According to DIN-5032 Part 7 these are regarded as DIN class B instruments. This quality designation is necessary because class C instruments - incidentally many photometers on the market are not certified at all - that are used to measure different types of light sources such as standard illuminant A incandescent lamps,



would yield large uncertainties of measurement.

## X91 Light Meter

Besides it's precision measurement capability the X91's ('Xnineone') most outstanding feature is its easy handling. The LCD characters are 9 mm high for easy viewing. The compact X91 is handheld and battery operated. As part of the X9 family it offers a moderate priceperformance ratio. This makes it the ideal light measurement tool for safety engineers, service technicians, lighting designers, ISO-certificated companies or anyone who's measured results are subject to audit.

### X91 Illuminance Meter:

The VL-3704-4 Illuminance detector is fitted with a precise photometric correction filter and

cosine diffuser. Its short height of only 20 mm allows measurement close to the reference level.

### X91 Luminance Meter:

The LDM-9901-4 Luminance detector offers a field of view of 1° and a measurement range from 40 cm to infinity. To target the object to be measured, the LDM-9901 has notch and bead sight, which has marks for close-range and distance work.

#### **Custom Labeling:**

All meters in the X9 family are ready for customization including front panel, modes & detectors. Contact the factory for details.

### Operation

The X91 is simple to operate. To measure, connect the detector and switch on the meter.

#### **CW Measurement**

CW mode is used to measure continuous DC or AC signals .

#### **Peak Hold Measurement**

Peak Hold mode is used to search for "hot-spot" light intensity. The peak reading is frozen on the display.



## X91 Specifications& Ordering Information

## Specifications: X91 Meter

Signal I	nput								
								o voltage amplifier (x10). 7 decade stepped gain tomatic range switching. 12 bit ADC with up to 14	
Signal Processing A/D converter with 20 ms time interval. 500 m					ms inte	earation	through ave	eraging of multiple measurements	
Frequency Range Signal conversion from 0.166 Hz to >300 MHz						ogradion	anough av		
	r Connector		÷			ication if	meter switc	ched ON (VL-3704-4 and LDM-9901-4 only).	
			o piirit						
Range S	Specificatio		1		Dimension:				
Range (A/V)	-				ector	- 65 mm -			
1x10-4	200.0 µA	30	ms	0.2 %* + 0.05 %	2	nF			
1x10-5	20,00 µA	30	ms	0.2 %* + 0.05 %	2	nF			
1x10-6	2,000 µA	30	ms	0.2 %* + 0.05 %	2	nF			
1x10-7	200,0 A	30	ms	0.2 %* + 0.05 %	10	) nF	67 <sup>00</sup> m		
1x10-8	20,00 nA	30	ms	0.2 %* + 0.05 %	10	) nF		VL-3704-4 LDM-99	
1x10-9	2,000 nA	30	ms	0.2 %* + 0.05 %	10	) nF			
1x10-10	200,0 pA	30	ms	0.2 %* + 0.05 %	10	) nF	∘□∘ _	= 22 mm	
Measurement Quantity Ampere calibrated with D display illuminance in Ix a					urrent s	source.	Current sigr	is. nal multiplied with calibration correction factor to antity shown in display. Calibration data stored in	
Peak Ho	old Measurer			neasurement value frozen in display.	. Erased	d with re	set button. I	Peak mode indicate in display.	
General	I								
Display			6 character LCD. Character height 9 mm. Indication of measurement quantities lx and cd/m <sup>2</sup> , battery low, peak, stop						
Operatin	ng Temperat	ure	5 to 40 °C (41 to 104 ° F) (75 % rel. H, non-condensing). Storage Temperature: 0 to 50°C (32 to 122 °F).						
Dimensi	ions/Weight		120 x 65 x 22 mm / 150 g (4.7 x 2.6 x 0.9 in / 0.33 lb).						
Power			9 V one-piece battery. Operation time about 100 h. Operation from a AC plug-in power supply 230V/50 Hz on option, erases battery operation.						
Interfac	e								
RS232			9600 B	aud, 8 8D, 1S,N. 8 pin plug Hirose,	type 32	260-8S1.	Power supp	ply operation recommended for remote control.	
			L-3704	-4 Illuminance Detector Head		.DM-990		LDM-9901 Sighting Principle	
71	asurement F	Range	0.5 t	o 999.999 lx (S/N ratio = 50)	0	Distance	Spot dia.	notch bead	
Max. Res	solution		0.01			(m)	(mm)	eye	
Detector	r Dimensions	S		37 mm dia Height 20 mm; Cos.		0.5	≈ 31	spot size	
				ser dia. 7 mm; Cable length 2 m		0.7	≈ 35		
Calibrati	on		lx or	fc, Factory cal certificate		1	≈ 41		
Specific	cations: X9	with I	D-990	1-4 Luminance Detector Head	n L	3	≈ 81	measurement distance	
	asurement F			2.5 to 999.999 cd/m <sup>2</sup> (S/N ratio = 50)		5	≈ 120		
Max. Res		Jango		cd/m <sup>2</sup>	$\dashv$ [	10	≈ 220		
Field of view			1.1°,		$+$ $\lceil$	50	≈ 1000		
Measurement Distance		nce		n to infinity	$+$ $\lceil$	100	≈ 2000		
	r Dimension:			diameter 22 mm; Cable length 1 m	$\dashv$				
Calibration		-		n <sup>2</sup> . Factory cal. certificate				Measurement Distance0.7 m1.4 m	
Orderie	g Informati	00							
Vrdering X9 1			1 8 0	d/m2 without detector boads. Incl. ha	andhoo	k and he	ttery Dotor	ctor calibration data stored in memory	
X9 1 US	-								
3103	LIGH	ii ivietel	IC & C	um- without detector neads. INCI. Na	anubuu	n ai lu Di	anery. Dete	ctor calibration data stored in memory	

X9 1 US	Light Meter fc & cd/m <sup>2</sup> without detector heads. Incl. handbook and battery. Detector calibration data stored in memory
VL-3704-4	Illuminance detector. Calibration certificate. ITT-type connector
LDM-9901-4	Luminance detector. Calibration certificate. ITT-type connector
VL-37Z-01	Stand/holder for VL37xx detectors. With bubble and three height adjustable feet. Required to mount detectors to tripods.
VL-37Z-02	Tripod with max. 125 cm height. Without detector mount VL-37Z-01.
LDM-99Z-01	Adapter plate with bubble level to mount and align the LDM-9901 luminance detector onto standard tripods.
LDM-99Z-02	Ambient light shade made by elastic rubber to place the LDM-99 direct on the monitor face.
X9Z-01	RS232 interface cable to connect the X9 meters with 9 PIN SUB-D PC standard socket.
X9Z-02	External power unit for the X9 meters including meter modification (cancels battery operation)
BHO-04	Hard case to carry and store the X9 1 with one VL-3704 and LDM-9901

## 🕞 Gigahertz-Optik

## Optometers & Instruments - Page 15

A come il

X9<sub>2</sub> Hand-held UV Curing Irradiance Meter

(9)

- © Hand Held Single Channel Irradiance Meter
- © Signal Range 0.1 mW/cm<sup>2</sup> to 40.000 mW/cm<sup>2</sup>
- © UV-A, BLUE and Broadband UV Spectral Responses
- © Low Profile 8 mm High Flexible and Rigid Detector Heads
- © High Operating Temperature to 100 ° C
- © Cosine Corrected Field of View
- © Power Density Measurement Mode with Snapshot Hold Function
- © Dose Measurement Mode
- © Easy to Use
- © ISO/IEC/EN 17025 Traceable Calibration
- © RS232 Interface

#### **UV Radiation Intensity**

UV curing is a process in which photocureable chemicals applied to substrates are irradiated with high energy UV or Visible radiation for curing. This energy accelerates polymerization (cross-linking) and consequently the hardening or drying process. The irradiated energy needs to be controlled, since too low a dose will not cure the product, whereas too high a dose may damage or dry-out the surface layer of glues.

UV curing technology is used in the manufacturing process of many products we use everyday. Some examples are CD's, wood and tile flooring, magazine covers and inks on cans & other packaging.

Within the context of "Total Quality Management" it is appropriate to regularly check the proportion of radiation from UV sources that effects the polymerization process. The intense UV radiation generated by these sources combined in some cases with high heat levels, can lead to rapid degradation and large drift factors in conventionally constructed UV measurement devices. Unreliable process control measurements can result.

### X92 Meter

Besides it's precision measurement capability the X92 ('Xninetwo') meter's most outstanding feature is its easy handling. To measure, the user simply switches on the meter and selects either the CW (W/cm<sup>2</sup>) or Dose (J/cm<sup>2</sup>) mode. The LCD characters are 9 mm high for easy viewing. The X92 is a compact handheld battery operated instrument.

#### Large Dynamic Range:

A novel detector design in combination with 7 decade linear electronics allows the X92 to offer a wide measurement range from 5 to 40.000 mW/cm2 with 0.1



mW/cm<sup>2</sup> resolution!

Direct intense ultraviolet and heat radiation are absorbed and attenuated by a passive and therefore long term stable RADIN



designed to measure in remote inaccessible locations sensor element. The filter and photodiode, which are kept outside of the hot zone, only receive attenuated radiation passing through the RADIN at the end of the UV light guide.

Two different style detectors (see chapter detector heads) are available:

### RCH-0 Flexible Light-guide

The RCH-0 series heads are designed with a flexible 50 cm (20 in.) long light-guide protected by flexible stainless steel sheathing. **RCH-1 Rigid Light-guide** 

The RCH-1 series heads are designed with a rigid 22 cm (8.7 in.) light-guide protected by a rigid stainless steel tube.



#### Flood and Spot Sources:

A large dynamic range plus optional adapters allow the X92 to measure flood and spot sources. The low 8 mm (0.32 in.) height of the sensor element enables irradiance measurements verv close to the target surface. A 9 mm dia. (0.35 in.) measurement aperture accepts adapters for LUMATEC\*) 3, 5 and 8 mm dia. light-guides.

#### UVA, BLUE and UV Broadband Spectral Responses

Both detector models are available for different wavelength ranges corresponding to various photo-initiator and curing technologies.



#### **Traceable Calibration**

Calibration is traceable to the ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities.

### Custom Labeling:

All meters in the X9 family are ready for custom design and labeling. Customization may include the meter front label, function/mode set-up, detector heads, manuals and calibration certificates. Contact the factory for more details. \*) Lumatec-Deisenhofen

Germany

#### Operation

The X92 is simple to operate. To measure, connect the detector and switch on the meter.

#### CW Measurement

CW mode is used to measure continuous DC or AC signals.

#### **Dose Measurement**

Measurement values are accumulated at a logger rate of 1 s and displayed as a dose. The measurement is manually started and stopped.

#### **Stop/Run Function**

Current reading can be 'frozen' by pressing 'stop' button.

## X92 Specification & Ordering Information

### Specification: X92 Meter

Signal Input	
Detector Input	Photocurrent to voltage converter amplifier with following voltage to voltage amplifier (x10). 7 decade stepped gain ranges with max. gain signal values from 200.0 $\mu$ A to 200.0 pA . Automatic range switching. 12 bit ADC with up to 14 bits at longer integration times.
Signal Processing	A/D converter with 20 ms time interval. 500 ms integration through averaging of multiple measurements.
Frequency Range	Signal conversion from 0.166 Hz to >300 MHz
Detector Connector	9 pin MDSM9 socket.

## **Range Specifications**

hange opecifications						
Range (A/V)	Max. Input Value		Slew-Rate (10 - 90%)	Error (with offset compensation) 1 year, 23°C ±5°C ±(% of reading + % of range),	Permitted Detector Capacitance	
1x10-4	200.0 µ	ιA	30 ms	0.2 %* + 0.05 %	2 nF	
1x10-5	20,00 µ	ιA	30 ms	0.2 %* + 0.05 %	2 nF	
1x10-6	2,000 µ	ιA	30 ms	0.2 %* + 0.05 %	2 nF	
1x10-7	200,0	A	30 ms	0.2 %* + 0.05 %	10 nF	
1x10-8	20,00 r	۱A	30 ms	0.2 %* + 0.05 %	10 nF	
1x10-9	2,000 r	۱A	30 ms	0.2 %* + 0.05 %	10 nF	
1x10-10	200,0 p	ЪА	30 ms	0.2 %* + 0.05 %	10 nF	
Function						
Parameter Se	ettings	Rete	Retention of the last settings in continuous memory. 3 function buttons.			
Measuremen	t Quantity	mul <sup>i</sup> cm <sup>2</sup> ada	tiplied with cali	with DKD calibrated current source bration correction factor to display in ctors for full aperture and 3, 5 and 8 in menu mode. Calibration data sto rr.	rradiance in mW/ 3 mm light guide	
General						
			6 character LCD. Character height 9 mm. Indication of measurement quantities lx and cd/m <sup>2</sup> , battery low, peak, stop			
			5 to 40 °C (41 to 104 ° F) (75 % rel. H, non-condensing). Storage Temperature: 0 to 50°C (32 to 122 °F).			
Dimensions/	Weight	120	120 x 65 x 22 mm / 150 g (4.7 x 2.6 x 0.9 in / 0.33 lb).			
Power		9 V one-piece battery. Operation time about 100 h. Operation from a AC				

RS232 9600 Baud, 8 8D, 1S,N. 8 pin plug Hirose, type 3260-8S1. Power supply operation recommended for remote control.

300 320 340 360 380 400 420 440 460 480 500 520 540 wavelength ( nm )
BLUE (09)
1 0 0 0 0 0 0 0 0 0 0 0 0 0
Brodband UV (06)
Apysuodan ja

UVA (08)

Spectral Sensitivity:

## 0 250 270 290 310 330 350 370 390 410 430 450 470 wavelength (nm)

Light Guide adapter								
Light Guide Adapter Dimension (mm)								
Model:	Eff. size	d1	d2	h				
RCH-Z-01	8 mm	10h7	9	10				
RCH-Z-02	5 mm	7h7	6	10				
RCH-Z-03	3 mm	5h7	4	10				

(92 with RCH-0 or RCH-1 Detector Head:								
UVA Detector	Max. irradiance	35,000 mW/cm <sup>2</sup>	Max. resolution	0.1 mW/cm <sup>2</sup>				
BLUE Detector	Max. irradiance	35,000 mW/cm <sup>2</sup>	Max. resolution	0.1 mW/cm <sup>2</sup>				
Broadband UV Detector	Max. irradiance	35,000 mW/cm <sup>2</sup>	Max. resolution	0.1 mW/cm <sup>2</sup>				
RCH-0	Flexible light-guide.		Light-guide length	50 cm (20 in)				
RCH-1	Rigid light-guide		Light-guide length	22 cm (8.6 in)				
Temperature Range	RADIN Sensor	100 °C (212°F)	Detector	5-40°C (41 - 104°F)				
Size	RADIN Sensor	8 mm x 37 mm Ø	Complete length	100 cm (39 in)				

plug-in power supply 230V/50 Hz on option, erases battery operation.

## **Ordering Information**

Interface

X9 2	Optometer with handbook and battery. Detector calibration data stored in memory
RCH-008-4	Low-profile UVA detector with flexible light-guide. Calibration certificate. ITT-type connector
RCH-009-4	Low-profile BLUE detector with flexible light-guide. Calibration certificate. ITT-type connector
RCH-006-4	Low-profile UV-broadband detector with flexible light-guide. Calibration certificate. ITT-type connector
RCH-108-4	Low-profile UVA detector with rigid light-guide. Calibration certificate. ITT-type connector
RCH-109-4	Low-profile BLUE detector with rigid light-guide. Calibration certificate. ITT-type connector
RCH-106-4	Low-profile UV-broadband detector with rigid light-guide. Calibration certificate. ITT-type connector
RCH-Z-01	8 mm type Lumatec Light-guide Adapter. Calibration data stored in meter memory
RCH-Z-02	5 mm type Lumatec Light-guide Adapter. Calibration data stored in meter memory
RCH-Z-03	3 mm type Lumatec Light-guide Adapter. Calibration data stored in meter memory
X9Z-01	RS232 interface cable to connect the X9 meter with 9PIN SUB-D PC standard socket
X9Z-02	External AC power unit for the X9 meter including meter modification (cancels battery operation)
BHO-05	Hard case to carry and store the X9 2 and one RCH-0 or one RCH-1 detector

## Gigahertz-Optik

## Optometers & Instruments - Page 17

X93 Hand-held Laser Power and Laser Stray-light Meter

- © Hand-held Single Channel Laser Power Meter
- $\ensuremath{\mathbb{C}}$  Low Profile Detector 100 mW max.
- © Compact Integrating Sphere Detector 500 mW max.
- © 7 mm dia. Aperture Laser Stray-light Detector
- $\ensuremath{\mathbb{C}}$   $\ensuremath{\,\text{Wavelength}}$  Range from 400 to 1100 nm
- © Simple Wavelength Selection
- © CW Snapshot Hold Function
- © Peak Hold Function
- $\textcircled{C} \quad \textbf{Economical Price}$
- © Battery Operation
- © RS232 Interface

#### Laser Power Measurement

Lasers with low to medium power levels in the wavelength range from 400 to 1100 nm are well established in metrology applications. To quantify laser power three different measurement geometries exist.

### **Collimated Lasers**

Lasers with quasi-parallel light bundles are typically measured using a flat-field detector with an active area larger than the laser beam diameter. There is some measurement error risk with flat field detectors due to polarization effects, re-reflection from the detector surface or windows and misalignment of the beam on the detector.



#### Non-collimated Lasers

Lasers with divergent light bundles (beams), such as laser diode array bars, are difficult to measure with a flat-field detector because of the different angles of incidence. The power output of these lasers is typically measured with detectors combined with an integrating sphere to collect all incoming radiation independent of the angle of



incidence.

Due to its unique design and the multiple reflections produced, integrating spheres offer:

- High attenuation permitting higher power measurements
- Reduction of polarization effects inaccuracies as found with flat-field detectors
- Flexibility with less aiming problems since sphere port diameter can be enlarged by increasing the sphere diameter to allow measurement of larger diameter beams

#### Laser Stray-light

Although very useful, laser radiation can pose a health risk to the human eye. Even stray-light from lasers may be hazardous due to the typically high power levels found. The EN 60825 standard describes the risk and measurement methods for risk classification. Laser stray-light can be assessed with the use of a detector head with a 7 mm dia. free aperture to mimic the open pupil. X93 Meter

Besides it's precise measurement capability the X93 meter's most outstanding feature is its easy handling. To measure, the user simply switches on the meter and selects the wavelength corresponding to the laser wavelength. The LCD characters are 9 mm high for easy viewing. The X93 is a compact handheld battery operated instrument.

## LP-9901 Flat Field Detector

A 7 mm diameter aperture makes this low profile design detector useful for laser power and laser stray-light measurement over a useful wavelength range from 400 to 1100 nm. The wavelength dependent laser power measurement range is 1  $\mu$ W to 100 mW with 0.02 resolution at 633 nm.

The wavelength dependent laser stray-light measurement range is 2.5  $\mu$ W/cm<sup>2</sup> to 250 mW/cm<sup>2</sup> with 0.05  $\mu$ W/cm<sup>2</sup> resolution at 633 nm.



### LP-9910 Sphere Detector

With a free measurement aperture of 12.7 (0.5 in.) and an acceptance angle of +/- 45° this detector is well suited to measure collimated and noncollimated radiation beams from lasers, laser diodes, laser diodes with lens attachments and narrow beam diverging light emitting diodes. It's high precision Siphotodiode with a compact 50 mm diameter integrating sphere offers a useful wavelength range from 400 to 1100 nm with a power range from 0.5 W to 100 mW with 0.01  $\mu$ W resolution at 633 nm



Traceable Calibration Calibration is traceable to the



ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities.

#### **Custom Label:**

All meters in the X9 family are ready made for custom design and labeling. Customization may include the meter front panel, function/mode set-up, detector heads, manuals and calibration certificates. Contact the factory for details and applications assistance.

#### Operation

The X93 is simple to operate. To measure, connect the detector and switch on the meter.

#### **CW Measurement**

CW mode is used to measure continuous DC or AC signals.

#### Power/Stray-light Meas.

Laser power in mW must be selected if the laser beam under fills the detectors area. Laser stray-light in mW/cm<sup>2</sup> must be selected if the laser beam over fills the detectors area.

#### Auto/Manual Gain Ranging

Select manual ranging when the power range in production control applications stays at the same level to avoid time delays in auto-ranging mode.

#### **Peak Hold Measurement**

Peak Hold mode is used to search for "hot-spots" light intensities. The peak intensity measured is frozen on the display.

#### **Stop/Run Function**

Current reading can be 'frozen' by pressing 'stop' button.



## X9<sub>3</sub> Specifications & Ordering Information

## Specifications: X93 Meter

Signal Inpu	ut			
Detector Input Photocurrent to voltage converter amplifier with following voltage to with max. gain signal values from 200.0 $\mu$ A to 200.0 pA . Automatic integration times.				
Signal Proce	essing	A/D converter with 20	raging of multiple measurements.	
Frequency F	-		n 0.166 Hz to >300 MHz	
Detector Co	onnector	9 pin MDSM9 socket		
Range Spec	cification	S		
Range (A/V)	Max. Ir Valu		Error (with offset compensation 1 year, 23°C ±5°C ±(% of reading + %	
1x10-4	200.0	μA 30 ms	0.2 % + 0.05 %	2 nF
1x10-5	20,00		0.2 % + 0.05 %	2 nF
1x10-6	2,000		0.2 % + 0.05 %	2 nF
1x10-7	200,0		0.2 % + 0.05 %	10 nF
1x10-8	20,00		0.2 % + 0.05 %	10 nF
1x10-9	2,000		0.2 % + 0.05 %	10 nF
1x10-10	200,0	pA 30 ms	0.2 % + 0.05 %	10 nF
Function				
Parameter S	0		t settings in continuous memory. 3 function butto	
Measureme	nt Quantii		I with DKD calibrated current source. Current sig ver in mW or the irradiance in mW/cm <sup>2</sup> . Calibratic	nal multiplied with calibration correction factor to dis- on factors stored in meter.
General				
Display		6 character LCD. (	Character height 9 mm. Indication of appropriate i	measurement quantities, battery low, peak, stop
Operating T	emperatu	re 5 to 40 °C (41 to 1	04 ° F) (75 % rel. H, non-condensing). Storage Te	emperature: 0 to 50°C (32 to 122 °F).
Dimensions	/Weight	120 x 65 x 22 mm	/ 150 g (4.7 x 2.6 x 0.9 in / 0.33 lb).	
Power		9 V one-piece bat erases battery ope		m a AC plug-in power supply 230V/50 Hz on option
Interface				Spectral Sensitivity
		8 8D, 1S,N. 8 pin plug led for remote control.	Hirose, type 3260-8S1. Power supply operation	
X93 with De	etector H	ead LP-9901 and LP-	9910	Ī   / \
X93 with LF				April 1997 April 1997 1907
typ. max. va	lue*	30 mW at 900 nm	, 100 mW at 633 nm	- 0,5 -
typ. max. res	solution*	0.00002 mW*		
wavelength	range	400 – 1100 nm, c	alibrated in 10 nm increments	
measureme	nt apertur	e 7 mm diameter		
dimensions		8 mm height, 37 r	nm diameter, handle length 100 mm	400 500 600 700 800 900 1000 1100 wavelength ( nm )
X93 with LP	<b>-9910-4</b>			LP-9901
typ. max. va	lue*	100 mW*		
typ. max. resolution*		0.00001 mW*		1-
wavelength range		400 – 1100 nm, laser wavelength*	calibrated in 10 nm increments and additional *	191 191
measurement aperture		e 12.7 mm diamete	r	
dimensions		50 mm sphere dia	ameter	
*) values ma 594, 612, 63			458, 473, 476, 488, 496, 514, 532, 543, 568,	
				400 500 600 700 800 900 1000 1100 wavelength (nm )

LP-9910

Ordering I	nformation
X9 3	Optometer with handbook and battery. Detector calibration data stored in memory
LP-9901-4	Low-profile detector head. Calibration in mW from 400-1100 nm in 10 nm increments and calculated irradiance in mW/cm <sup>2</sup> . Calibration certificate. ITT-type connector
LP-9910-4	Integrating sphere detector head. Calibration in mW from 400-1100 nm in 10 nm increments. Calibration certificate. ITT-type connector
X9Z-01	RS232 interface cable to connect the X9 meter with 9 PIN SUB-D PC standard socket
X9Z-02	External AC power unit for the X9 meter including meter modification (cancels battery operation)
BHO-05	Hard case to carry and store the X9 3 with one LP-9901-4

## 🕒 Gigahertz-Optik

## Optometers & Instruments - Page 19

X94 Hand-held Radiant Power and Luminous Flux Meter

- © Luminous Flux Meter for Spot Sources
- (C) Measurement Range: 0.0025 to 10.000 Im
- © Radiant Power Meter for Spot Sources
- © Measurement Range: 0.0005 to 1.000 mW
- © Beam Shape Independent Measurement
- Compact Integrating Sphere with 12.5 mm dia.  $\bigcirc$ **Measurement Aperture**
- © CW Snapshot Hold Function
- © Easy to Use
- $\bigcirc$ **Economical Price**
- © Battery Operation
- RS232 Interface (C)



#### **Total Radiant Power**

The total output of optical radiation emitted by a source is an important quantity for the determination of its efficiency. In many applications the intensity of that source is concentrated down to a spot. Typical examples are light emitting diodes (LED's), optical fiber bundles, endoscopes, spot lamps, etc. Since the beam is not really collimated, an integrating element is needed to collect the radiation emitted from many different directions.

#### **Direction Independency**

Integrating spheres measure the total intensity of optical radiation entering the sphere entrance port independent of the beam geometry.



Diffuse multiple reflections within the sphere's interior suppresses unwanted effects created by the angle of incidence like the forma-

sensitivity

<u>-</u>

tion of shadows, polarization, reflections or modes

### **Photometry and Radiometry**

The total emitted radiation of a light source can be measured in the radiometric quantity watts (W) or photometric quantity lumens (Im). The photometric quantity is used if the measurement values are to be compared to human visual impressions . X94 Meter

Beside it's precise measurement capability the X94 meter's ("Xninefour") most outstanding feature is its easy handling. To measure, the user simply connects the detector and switches on the meter. The LCD characters are 9 mm high for easy viewing. The X94 is a compact handheld battery operated instrument.

### Integrating Sphere Detectors

Two different detector heads are available for use with the X94 for luminous flux and radiant power measurements. Both are based on the UP-50-L integrating sphere manufactured by Gigahertz-Optik. The hollow 50 mm diameter spheres are coated with barium sulfate. The mounted detectors are baffled to avoid direct irradiation from the light source under test. The measurement port aperture is 12.5 mm in diameter with an acceptance angle of 90°. Threaded adapters around the port can be used to mount the test source. A M6 threaded post mount hole is provided.

### LSM-9901 Detector Head

To measure luminous flux a photometric detector is mounted to the sphere and both calibrated in lumens. To ensure low measurement uncertainty when measuring light sources with different light spectra, the detector head offers a precise photometric match to the CIE standard (DIN 5032 T3 Class B).





photometric function of LSM-9901-4



radiometric function of PRW-0505-04

The measurement range is 0.0025 to 10,000 lm with a max. resolution of 0.00005 lm.

### **PRW-0505 Detector Head**

To measure radiant power a radiometric detector is mounted to the sphere and both calibrated in W. With this system the radiant power from broadband sources or quasi monochromatic sources can be measured within the wavelength range from 400 to 1000 nm. The measurement range spans from 0.0005 to 1000 mW with a max. resolution from 0 00001 mW

#### **Traceable Calibration**

The calibration is traceable to the ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities.

#### **Custom Labeling:**

All meters in the X9 family are ready made for custom design and labeling. Customization may

include the meter front panel, function/mode set-up, detector heads, manuals and calibration certificates

Contact the factory for details and application assistance.

#### Operation

The X94 is simple to operate. To measure, connect the detector and switch on the meter.

### **CW Measurement**

CW mode is used to measure continuous DC or AC signals .

#### **Stop/Run Function**

Current reading can be 'frozen' by pressing 'stop' button.



## X94 Specifications and Ordering Information

## Specifications: X94 Meter

Signal I	nnut						
Detector	-	Photo	ourrent to voltage converter ampli	ifier with follow	ing voltage to voltage amplifier (x10). 7 decade stepped gain		
Delector	input				200.0 pA . Automatic range switching. 12 bit ADC with up to 14		
			t longer integration times.	µ, (0)			
Signal Pr	rocessing	A/D c	onverter with 20 ms time interval. 50	00 ms integratio	on through averaging of multiple measurements.		
Frequen	cy Range	Signa	l conversion from 0.166 Hz to >300	MHz			
Detector	Connector	9 pin	MDSM9 socket.				
Range S	pecification	ns			Spectral Sensitivity		
Range					Cap front page of VO, detablast		
(A/V)	Value	(10 - 90%)		Detector	See front page of X94 datasheet		
1x10-4	200.0 µA	30 ms	± (% of reading + % of range), 0.2 %* + 0.05 %	Capacitance 2 nF	Dimensions:		
1x10-4	200.0 μA 20,00 μA	30 ms	0.2 % + 0.05 %	2 nF			
1x10-5	2,000 μA	30 ms	0.2 % + 0.05 %	2 nF	65 mm		
1x10-7	200,0 A	30 ms	0.2 %* + 0.05 %	10 nF	C Gigahertz-Optik		
1x10-8	20,00 nA	30 ms	0.2 %* + 0.05 %	10 nF	X94 power / flux meter		
1x10-9	2,000 nA	30 ms	0.2 %* + 0.05 %	10 nF			
1x10-10	200,0 pA	30 ms	0.2 %* + 0.05 %	10 nF			
Function	n	·		·	120 mm		
Paramet	er Settings		on of the last settings in continuou	us memory. 3			
			n buttons.		menul vener		
Measure	ement Quanti		es calibrated with DKD calibrated c signal multiplied with calibration		onioff stop		
			o display luminous flux in Im or rad				
			asurement quantity shown in displa				
		data st	ored in calibration storage of the me	eter.			
General	ļ				0 0 22 mm		
Display			acter LCD. Character height 9 mm				
1		approp stop	riate measurement quantities, batte	ery Iow, peak,	E E E E E E E E E E E E E E E E E E E		
Operatin	ig Temperatu		°C (41 to 104 ° F) (75 % rel. H, non-	-condensina)			
- poradiri	.g . o porate		e Temperature: 0 to 50°C (32 to 122				
Dimensi	ons/Weight	120 x 6	65 x 22 mm / 150 g (4.7 x 2.6 x 0.9 in / 0.33 lb).				
Power			ne-piece battery. Operation time				
			on from a AC plug-in power suppon, erases battery operation.	ly 230V/50 Hz			
Interfe -							
Interfac RS232	-	8 8D 19 M	. 8 pin plug Hirose, type 3260-8S1.	Power supply	$\left(\begin{array}{cc} \ominus & \left( \begin{pmatrix} \cdot \\ \cdot \end{pmatrix} \right) & \ominus \end{array}\right)$		
110202			ed for remote control.	i owei supply			
Specific	ation: X94 v						
•	asurement R		0.0025 to 10,000 lm with 0.00005 lm	resolution			
51	gth Range	0	380 nm to 780 nm, photometric cha				
	ement Port Ap		2.5 mm diameter				
Calibratio			m with factory cal. certificate				
Specific	ation: X91 v		,				
	asurement R		0.0005 to 1,000 mW with 0.00001 m	W resolution			
	gth Range	÷	100-1050 nm, radiometric character				
	ement Port Ap	certure 7	2.5 mm diameter				
Calibratio	on	r	nW with factory cal. certificate				

Ordering Information					
X9 4	Optometer with handbook and battery with detector(s) calibration data stored in memory				
PRW-0505-4	Radiant power detector with integrating sphere. Calibration certificate. ITT-type connector				
LSM-9901-4	Luminous flux detector with integrating sphere. Calibration certificate. ITT-type connector				
X9Z-01	RS232 interface cable to connect the X9 meters with 9PIN SUB-D PC standard socket				
X9Z-02	External AC power unit for the X9 meter including meter modification (cancels battery operation)				
BHO-01	Hard case to carry and store the X9 4 with detector head				

## 🕒 Gigahertz-Optik

## Optometers & Instruments - Page 21

## X96 Hand-held UV-A, UV-B & UV-B311 Irradiance Meter

- © Hand-held Dual-channel Meter for Field Service and Laboratory Use
- © True Broadband UV-A and UV-B Sensitivity
- © Calibration for Narrowband UV-B<sub>311</sub> UV Sources
- © Cosine Corrected Field of View
- © CW Measurement Mode for DC and AC Light
- © Snapshot Hold Function
- © Dose Measurement Mode
- © Easy to Use
- ${\small \bigcirc} \ \ \, {\rm Economical \ Price}$
- © Battery Operation
- © RS232 Interface

#### UV-A & UV-B Phototherapy

UV is widely used by dermatologists in the treatment of certain skin diseases like Psoriasis and Vitiligo. Whole body exposure booths and hand and foot units employing light sources which emit broadband UV-A, UV-B, narrowband 311 nm UVB and combinations of UV-A and UV-B are used to irradiate the patient. In PUVA phototherapy, also called photochemotherapy, UV-A is applied in combination with a photosensitizing agent which is taken in pill form or applied topically to the skin. This medication called psoralen, giving rise to the acronym PUVA, makes the skin more sensitive and responsive to the UV-A (315-400 nm) wavelenaths.

Due to the risks of premature skin ageing and skin cancer from prolonged exposures, also with consideration to skin type, PUVA is only recommended for moderate to severe cases of Psoriasis. As a side note, psoralen is also being used as a photosensitizer in UV sterilization of blood.

UV-B broadband treatment is normally administered without a photosensitizing agent. It is considered safer than UV-A for wavelengths between approx. 290 to 315 nm, since it does not penetrate as deeply into the skin and is more energetic allowing shorter overall exposure times. However, it is generally accepted that wavelengths below 290 nm produce more erythema which can actually inhibit the therapeutic effects of the longer wavelengths.

As a result, narrowband UV-B sources emitting at predomi-

nantly 311-312 nm, have been developed. These TL-01 sources emit in the wavelength zone of most effectiveness while producing less erythemal hazard than broadband UV-B sources.

A TL-12 UV-B source with a slightly wider emission band between 280-350 nm, peaking at about 305 nm is also in use. For more information contact the National Psoriasis Foundation and the American and European Academies of Dermatology.

Dose, used here as irradiance accumulated over time, is normally measured in phototherapy applications.

Ultraviolet radiation is also used for photobiological studies like SPF testing. Again, the wavelength ranges of interest are typically UV-A, UV-B and UV-B311.

Radiometers with a precise spectral match to the spectral ranges of interest with low crosstalk between UV-A and UV-B are required for accurate dosimetry and quantification. A cosine corrected field of view, simple operation for inexperienced users and an attractive price level



#### are also desirable. **X96 Meter**

Beside it's precise measurement capability the X96 meter's ("Xninesix") most outstanding feature is its easy handling. To measure, the user simply switches on the meter and selects either the CW (W/cm<sup>2</sup>) or Dose (J/cm<sup>2</sup>) mode. The LCD characters are 9 mm high for easy viewing. The X96 is a compact handheld battery operated instrument.

#### XD-9501-4 Detector Head

The irradiance detector head houses separate UV-A and UV-B detectors whose spectral sensitivity and cosine corrected field of view meet accepted UV-A & UV-B spectral standards.

- The spectral sensitivity characteristic of the UV-A and UV-B detectors was developed by computer simulation using several sample filter and detector combinations. The optimum spectral functions were chosen after calculating the measurement uncertainty of each of these detector/filter/ diffusers for a group of sample radiation sources. This method of characterizing the performance of integral measuring UVmeters was developed by the "Thematic Network for Ultraviolet Measurements" funded by the Standards, Measurements and Testing program of the Commission of the European Communities (see tutorials).
- Cosine correction of the detectors is of equal importance in achieving low measurement uncertainties.

#### Traceable Calibration

Instrument calibration is trace-

able to the ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities.

And

Calibration of UV-A and UV-B irradiance sensitivity as well as an additional narrowband UV-B calibration at 311 nm for TL-01 type sources is supplied. Individually measured plots of the UV-A and UV-B spectral sensitivities are provided as part of the calibration certificate.

#### **Custom Labeling:**

All meters in the X9 family are ready made for custom design and labeling. Customization may include the meter front panel, function/mode set-up, detector heads, manuals and calibration certificates.

Contact the factory for details and applications assistance.

#### Operation

The X96 is simple to operate. To measure, connect the detector and switch on the meter.

### **Detector Selection**

Selection of the UV-A, UV-B or UV-B<sub>311</sub> detector is easily done in the menu mode.

#### **CW Measurement**

CW mode is used to measure continuous DC or AC signals .

#### **Dose Measurement**

Measurement values are accumulated at a logger rate of 1 s and displayed as dose. The measurement is manually started and stopped.

### Stop/Run Function

Current reading can be 'frozen' by pressing 'stop' button.



## X96 Specifications & Ordering Information

## Specifications: X96 Meter

Signal Input						
		n signal values from 2	amplifier with following voltage to voltage amplifier (x10). 7 de 200.0 $\mu$ A to 200.0 pA . Automatic range switching. 12 bit ADC			
		with 20 ms time inter	val. 500 ms integration through averaging of multiple measure	ements.		
Frequency Range	Frequency Range Signal conver		>300 MHz			
Detector Connecto	or 9 pin MDSM9	socket . Connected of	detector identification if meter switched ON (VL-3704-4 and LE	0M-9901-4 only).		
Range Specificati	ons					
Range (A/V)	Max. Input Value	e Slew-Rate (10 - 90%)	Error (with offset compensation) 1 year, $23^{\circ}C \pm 5^{\circ}C \cdot \pm (\% \text{ of reading } +\% \text{ of range}),$	Permitted Detector Capacitance		
1x10-4	200.0 µA	30 ms	0.2 %* + 0.05 %	2 nF		
1x10-5	20,00 µA	30 ms	0.2 %* + 0.05 %	2 nF		
1x10-6	2,000 µA	30 ms	0.2 %* + 0.05 %	2 nF		
1x10-7	200,0 A	30 ms	0.2 %* + 0.05 %	10 nF		
1x10-8	20,00 nA	30 ms	0.2 %* + 0.05 %	10 nF		
1x10-9	2,000 nA	30 ms	0.2 %* + 0.05 %	10 nF		
1x10-10	200,0 pA	30 ms	0.2 %* + 0.05 %	10 nF		
Functions						
Parameter Settings	Retention of	of the last settings in c	ontinuous memory. 3 function buttons.			
Measurement Qua		librated with DKD calibrated current source. Current signal of UV-A and UV-B detector multiplied with calibra- tion factor to display irradiance in mW/cm <sup>2</sup> .				
General	÷					
Display	6 characte	r LCD. Character heig	ght 9 mm. Indication of appropriate measurement quantities ,	battery low, peak, stop		
Operating Tempera	ature 5 to 40 °C	(41 to 104 ° F) (75 % rel. H, non-condensing). Storage Temperature: 0 to 50°C (32 to 122 °F).				
Dimensions/Weigl	nt 120 x 65 >	(22 mm / 150 g (4.7 x	( 2.6 x 0.9 in / 0.33 lb).			
Power		piece battery. Operation time about 100 h. Operation from a AC plug-in power supply 230V/50 Hz on option, attery operation.				
Interface		· · · ·				
RS232 9600 Bau	ud, 8 8D, 1S,N. 8	pin plug Hirose, type	3260-8S1. Power supply operation recommended for remote	control.		
X96 with XD-9501	-4					
typ. UV-A measure	ment range	0.0005 to 20.000 mW/cm <sup>2</sup> with max. 0.00001 mW/cm <sup>2</sup> resolution				
typ. UV-B measure	ment range	0.00015 to 60.000 mW/cm <sup>2</sup> with 0.00003 mW/cm <sup>2</sup> resolution				
Dose range for UV	-A and UV-B	0.00001 J/cm <sup>2</sup> to 100.000 J/cm <sup>2</sup>				







spectral sensitivity characteristic



250 260 270 280 290 300 310 320 330 340 350 360 370 380 390 400 410 420 wavelength ( nm )

Ordering Infor	Ordering Information					
	UV-A, UV-B and UV-B311 irradiance and dose meter. Detector calibration data stored in memory . Includes detector head, XD-9501-4 battery , handbook and hard case.					
X9Z-01	RS232 interface cable to connect the X9 meter with 9PIN SUB-D PC standard socket					
X9Z-02	External AC power unit for the X9 meter including meter modification (cancels battery operation)					

## 🕒 Gigahertz-Optik

## Optometers & Instruments - Page 23

X97 Hand-held Irradiance Meter

- $\bigcirc$ Hand-held Single Channel Irradiance Meter
- © Wide Range of UV-VIS-NIR Polychromatic Irradiance Detector Heads
- © Measurement of DC and AC Signals
- © Peak Value Hold Function
- © Signal Range from 0.1 pA to 200 µA with 7 Gain Ranges
- © Automatic or Manual Gain Range Selection
- © Easy to Use
- © Offset Compensation
- © Compact Size
- **Battery Operation**  $\bigcirc$
- © **RS232** Interface

#### **Optical Radiation**

Optical radiation describes that segment of electromagnetic radiation from  $\lambda$ =100 nm to  $\lambda$ =1 mm. Optical radiation can be measured using quantities related to radiation physics (radiometry), light engineering (photometry), photobiology, plant physiology and others. The application determines which quantities are appropriate.

#### Radiometry

Radiometry involves the metrological evaluation of optical radiation in physical radiation measurement quantities.

#### **Polychromatic Radiometry**

The most important aspect of radiometry is that radiation intensity is observed independently of wavelength. This distinguishes absolute radiometry from the actively weighted quantities such as those used in photometry, photobiology, plant physiology, etc., which is effective radiometrv.

For this reason, radiation detectors for radiometric measurements covering a broadband wavelength range, like UV-A, VISIBLE for instance, must have a flat spectral sensitivity shape within the specified wavelength range.

Unfortunately only "thermal detectors" have this property. But their wide spectral bandwidth and low sensitivity prohibit their use in many applications so filter-corrected semiconductor detectors are more commonly used

### Irradiance E

Irradiance refers to the radiant power impinging on a particular surface from one or more sources of optical radiation. Irradiance is measured horizon-



tally and vertically in the units of watts per square meter (W/m<sup>2</sup>). Irradiance is the most commonly measured quantity in optical radiation measurement applications. Due to ageing of the radiation source, irradiance levels need to be constantly checked if a minimum irradiance value needs to be maintained

#### **Cosine Field of View**

When the incident optical radiation is not parallel, which in practice is normal, a cosine diffuser must be used to correct the



measurement geometry for irradiance detector heads.

#### Polychromatic Irradiance **Detector Heads**

Gigahertz-Optik manufactures a wide range of detector heads for polychromatic irradiance measurements with respect to a defined spectral response function. Detector heads are offered for the ultraviolet range (UV-A, UV-B, UV-C) as well as for the visible and near infrared range.

One or more of these detector heads can be combined with one of Gigahertz-Optik's broad range of optometers.

### X97 Meter

For end-users whose application requires just one detector head and does not need multimeter level functional ability in their optometer, the X97 ("Xnineseven") Irradiance Meter is an economical alternative.

Besides it's precise measurement capability the X97 meter's most outstanding feature is its easy handling. To measure, the user simply connects the detector head and switches on the meter. The LCD characters are 9



mm high for easy viewing. The X97 is a compact handheld batterv operated instrument.

### **Traceable Calibration**

Calibration is traceable to the ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities. Calibration includes detector irradiance sensitivity and an individually measured plot of spectral sensitivity with the calibration certificate.

#### **Custom Labeling:**

All meters in the X9 family are ready made for custom design and labeling. Customization may include the meter front panel, function/mode set-up, detector heads, manuals and calibration certificates. Contact the factory for details and assistance.

#### Operation

The X97 offers simply operation. To measure, switch on the meter with the connected detector.

### **CW Measurement**

CW mode is used to measure continuous DC or AC signals

#### **Peak Hold Measurement**

Peak Hold mode is used to search for "hot-spots" light intensities. The peak intensity measured is frozen on the display.

#### **Stop/Run Function**

Current reading can be 'frozen' on display by pressing 'stop' button

#### Auto/Manual Gain Ranging

Select manual ranging when the power range in production control applications stays at the same level to avoid time delays in auto-ranging mode.





## X97 Specifications & Ordering Information

## Specifications: X97 Meter

Signal Inpu	ıt							
Detector Input		Photocurrent to voltage converter amplifier with following voltage to voltage amplifier (x10). 7 decade stepped gain ranges with max. gain signal values from 200.0 $\mu$ A to 200.0 pA . Automatic range switching. 12 bit ADC with up to 14 bits at longer integration times.						
				500 ms integration through averaging of mult	iple measurements.			
		Signal conversion from	n 0.166 Hz to >30	0 MHz.				
Detector Co		9 pin MDSM9 socket.						
Range Spec	1							
Range Max. In				rror (with offset compensation) °C $\pm$ 5°C $\pm$ (% of reading + % of range),	Permitted Detector Capacitance			
(A/V)         Value           1x10-4         200.0 μA		( /	i year, 23	0.2% + 0.05%	2 nF			
1x10-4	200.0	1		0.2 % + 0.05 %	2 nF			
1x10-6	2,000	1		0.2 % + 0.05 %	2 nF			
1x10-7	200,0	1		0.2 % + 0.05 %	10 nF			
1x10-8	20,00	nA 30 ms		0.2 % + 0.05 %	10 nF			
1x10-9	2,000	nA 30 ms		0.2 % + 0.05 %	10 nF			
1x10-10	200,0	pA 30 ms		0.2 % + 0.05 %	10 nF			
Function								
Parameter S	Settings	Retention of the las	t settings in contin	nuous memory. 3 function buttons.				
Measureme	nt Quanti	y Amperes calibrated play irradiance in m		ted current source. Current signal multiplied	I with calibration correction factor to di			
General								
		6 character LCD. Character height 9 mm. Indication of appropriate measurement quantities , battery low, peak, stop						
Display			*					
	emperatu		*	mm. Indication of appropriate measuremen I, non-condensing). Storage Temperature: 0				
Operating T		re 5 to 40 °C (41 to 10 120 x 65 x 22 mm	04 ° F) (75 % rel. ⊢ / 150 g (4.7 x 2.6 )	I, non-condensing). Storage Temperature: 0 x 0.9 in / 0.33 lb).	to 50°C (32 to 122 °F).			
Display Operating To Dimensions Power		re 5 to 40 °C (41 to 10 120 x 65 x 22 mm	04 ° F) (75 % rel. H / 150 g (4.7 x 2.6 tery. Operation tin	I, non-condensing). Storage Temperature: 0	to 50°C (32 to 122 °F).			
Operating To Dimensions Power Interface	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope	04 ° F) (75 % rel. H / 150 g (4.7 x 2.6 tery. Operation tin gration.	I, non-condensing). Storage Temperature: 0 x 0.9 in / 0.33 lb). ne about 100 h. Operation from a AC plug-	to 50°C (32 to 122 °F).			
Operating To Dimensions Power Interface	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope	04 ° F) (75 % rel. H / 150 g (4.7 x 2.6 tery. Operation tin gration.	I, non-condensing). Storage Temperature: 0 x 0.9 in / 0.33 lb).	to 50°C (32 to 122 °F).			
Operating To Dimensions Power Interface	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug	04 ° F) (75 % rel. H / 150 g (4.7 x 2.6 tery. Operation tin gration.	I, non-condensing). Storage Temperature: 0 x 0.9 in / 0.33 lb). ne about 100 h. Operation from a AC plug-	to 50°C (32 to 122 °F).			
Operating To Dimensions Power Interface RS232 96 (97 with De	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug	04 ° F) (75 % rel. H / 150 g (4.7 x 2.6 tery. Operation tin gration.	I, non-condensing). Storage Temperature: 0 x 0.9 in / 0.33 lb). ne about 100 h. Operation from a AC plug-	to 50°C (32 to 122 °F).			
Operating To Dimensions Power Interface RS232 96 (97 with De Model No:	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp	04 ° F) (75 % rel. H / 150 g (4.7 x 2.6 tery. Operation tin ration.	I, non-condensing). Storage Temperature: 0 x 0.9 in / 0.33 lb). ne about 100 h. Operation from a AC plug- D-8S1. Power supply operation recommended	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on option d for remote control.			
Dimensions Power Interface RS232 96 (97 with De Model No: JV-3701-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31)	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation time ration. Hirose, type 3260 ponse Function	I, non-condensing). Storage Temperature: 0 x 0.9 in / 0.33 lb). ne about 100 h. Operation from a AC plug- D-8S1. Power supply operation recommended Measurement Range in mW/cm <sup>2</sup> *	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on optio d for remote control. max. Resolution in mW/cm <sup>2</sup> *			
Operating Tr Dimensions Power Interface RS232 96 (97 with De Model No: JV-3701-4 JV-3702-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31) UV-B (28)	04 ° F) (75 % rel. H / 150 g (4.7 x 2.6 tery. Operation tin ration. Hirose, type 3260 ponse Function 5-400 nm)	A, non-condensing). Storage Temperature: 0 x 0.9 in / 0.33 lb). ne about 100 h. Operation from a AC plug- D-8S1. Power supply operation recommended Measurement Range in mW/cm <sup>2</sup> * 0.0005 to 1700	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on optio d for remote control. max. Resolution in mW/cm <sup>2</sup> * 0.00001			
Operating Tr           Dimensions           Power           Interface           RS232         96           (97 with De           Model No:           JV-3701-4           JV-3702-4           JV-3703-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31: UV-B (28) UV-C (25)	04 ° F) (75 % rel. H / 150 g (4.7 x 2.6 tery. Operation tin ration. Hirose, type 3260 ponse Function 5-400 nm) 0-315 nm)	A, non-condensing). Storage Temperature: 0 x 0.9 in / 0.33 lb). ne about 100 h. Operation from a AC plug- 	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on optio d for remote control. max. Resolution in mW/cm <sup>2</sup> * 0.00001 0.00002			
Operating Tr           Dimensions           Power           Interface           RS232         96           (97 with De           Model No:           JV-3701-4           JV-3703-4           JV-3704-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31) UV-B (28) UV-C (25) UV-Erg	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation timeration. Hirose, type 3260 ponse Function 5-400 nm) 0-315 nm) 0-280 nm) ythema	A, non-condensing). Storage Temperature: 0 x 0.9 in / 0.33 lb). ne about 100 h. Operation from a AC plug- D-8S1. Power supply operation recommended Measurement Range in mW/cm <sup>2</sup> * 0.0005 to 1700 0.001 to 10000 0.0005 to 2500 0.0005 to 1700	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on optio d for remote control. max. Resolution in mW/cm <sup>2</sup> * 0.00001 0.00001 0.00001			
Operating Tr Dimensions Power RS232 96 <b>(97 with De</b> Model No: JV-3701-4 JV-3702-4 JV-3703-4 JV-3704-4 JV-3706-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31) UV-B (28) UV-C (25) UV-E resp Billing	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation time ration. Hirose, type 3260 ponse Function 5-400 nm) 0-315 nm) 0-280 nm) ythema ubin	I, non-condensing). Storage Temperature: 0         x 0.9 in / 0.33 lb).         ne about 100 h. Operation from a AC plug-         0-8S1. Power supply operation recommended         Measurement Range in mW/cm <sup>2*</sup> 0.0005 to 1700         0.0005 to 2500         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on optio d for remote control. max. Resolution in mW/cm <sup>2</sup> * 0.00001 0.00001 0.00001 0.00001			
Operating To Dimensions Power Interface RS232 96 (97 with De Model No: JV-3701-4 JV-3702-4 JV-3702-4 JV-3703-4 JV-3706-4 JV-3708-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31: UV-B (28) UV-C (25) UV-En Bilin ACGIH	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation time ration. Hirose, type 3260 boonse Function 5-400 nm) 0-315 nm) 0-280 nm) ythema ubin (ICNIRP)	I, non-condensing). Storage Temperature: 0         x 0.9 in / 0.33 lb).         ne about 100 h. Operation from a AC plug-         D-8S1. Power supply operation recommended         Measurement Range in mW/cm <sup>2*</sup> 0.0005 to 1700         0.0005 to 2500         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 100         0.0005 to 5000	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on optio d for remote control. max. Resolution in mW/cm <sup>2</sup> * 0.00001 0.00001 0.00001 0.00001 0.00001			
Operating Tr Dimensions Power Interface RS232 96 (97 with De Model No: JV-3701-4 JV-3702-4 JV-3702-4 JV-3703-4 JV-3704-4 JV-3706-4 JV-3708-4 JV-3709-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31: UV-B (28) UV-B (28) UV-C (25) UV-Erg Billir ACGIH	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation time ration. Hirose, type 3260 bonse Function 5-400 nm) 0-315 nm) 0-280 nm) ythema ubin (ICNIRP) ht Hazard	I, non-condensing). Storage Temperature: 0         x 0.9 in / 0.33 lb).         ne about 100 h. Operation from a AC plug-         D-8S1. Power supply operation recommended         Measurement Range in mW/cm <sup>2</sup> *         0.0005 to 1700         0.0005 to 2500         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 1500         0.0005 to 500	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on optio d for remote control. max. Resolution in mW/cm <sup>2</sup> * 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001			
Operating Tr Dimensions Power RS232 96 (97 with De Model No: JV-3701-4 JV-3702-4 JV-3702-4 JV-3703-4 JV-3704-4 JV-3706-4 JV-3708-4 JV-3709-4 JV-3710-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31) UV-B (28 UV-B (28 UV-C (25 UV-En Billin ACGIH Blue-Ligl UV-A (32)	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation timeration. Hirose, type 3260 ponse Function 5-400 nm) 0-315 nm) 0-280 nm) ythema tubin (ICNIRP) ht Hazard 0-400 nm)	I, non-condensing). Storage Temperature: 0         x 0.9 in / 0.33 lb).         ne about 100 h. Operation from a AC plug-         D-8S1. Power supply operation recommended         Measurement Range in mW/cm <sup>2</sup> *         0.0005 to 1700         0.0005 to 2500         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 100         0.0005 to 5000         0.0005 to 500         0.0005 to 2000	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on option d for remote control. max. Resolution in mW/cm <sup>2*</sup> 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001			
Dimensions Power RS232 96 <b>(97 with De</b> Model No: JV-3701-4 JV-3702-4 JV-3703-4 JV-3704-4 JV-3706-4 JV-3708-4 JV-3708-4 JV-3709-4 JV-3710-4 JV-3711-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31) UV-B (28 UV-C (25 UV-C (25) UV-C (25	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation time ration. I Hirose, type 3260 ponse Function 5-400 nm) 0-280 nm) 0-280 nm) ythema rubin (ICNIRP) ht Hazard 0-400 nm) 0-320 nm)	I, non-condensing). Storage Temperature: 0         x 0.9 in / 0.33 lb).         ne about 100 h. Operation from a AC plug-         D-8S1. Power supply operation recommended         Measurement Range in mW/cm <sup>2*</sup> 0.0005 to 1700         0.0005 to 2500         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 500         0.0005 to 500         0.0005 to 500         0.0005 to 2000         0.0005 to 100	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on option d for remote control. max. Resolution in mW/cm <sup>2</sup> * 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001			
Operating Tr           Dimensions           Power           Interface           RS232         96           (97 with De           Model No:           JV-3701-4           JV-3702-4           JV-3703-4           JV-3704-4           JV-3706-4           JV-3708-4           JV-3709-4           JV-3710-4           JV-3710-4           JV-3711-4           JV-3711-4           JV-3716-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31) UV-B (28) UV-C (25) UV-Er Bilir ACGIH Blue-Ligl UV-A (32) UV-B (28) UV-B (28) UV-B (28) UV-B (28) UV-A (30)	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation time ration. Hirose, type 3260 ponse Function 5-400 nm) 0-315 nm) 0-280 nm) ythema ubin (ICNIRP) ht Hazard 0-400 nm) 0-320 nm) 5-400 nm)	I, non-condensing). Storage Temperature: 0         x 0.9 in / 0.33 lb).         ne about 100 h. Operation from a AC plug-         D-8S1. Power supply operation recommended         Measurement Range in mW/cm <sup>2*</sup> 0.0005 to 1700         0.0005 to 2500         0.0005 to 1700         0.0005 to 1700         0.0005 to 500         0.0005 to 5000         0.0005 to 500         0.0005 to 2000         0.0015 to 1000         0.0005 to 2000	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on option d for remote control. max. Resolution in mW/cm <sup>2*</sup> 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00003 0.00001			
Dimensions           Dimensions           Power           Interface           RS232         96           (97 with De           Aodel No:           JV-3701-4           JV-3702-4           JV-3703-4           JV-3706-4           JV-3708-4           JV-3709-4           JV-3710-4           JV-3710-4           JV-3710-4           JV-3710-4           JV-3710-4           JV-3711-4           JV-3716-4           JV-3717-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31) UV-B (28 UV-C (25 UV-Er Bilir ACGIH Blue-Lig UV-A (32) UV-A (30) UV-A (31)	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation time ration. Hirose, type 3260 bonse Function 5-400 nm) 0-315 nm) 0-315 nm) 0-280 nm) ythema ubin (ICNIRP) ht Hazard 0-400 nm) 0-320 nm) 5-400 nm)	I, non-condensing). Storage Temperature: 0         x 0.9 in / 0.33 lb).         ne about 100 h. Operation from a AC plug-         D-8S1. Power supply operation recommended         Measurement Range in mW/cm <sup>2</sup> *         0.0005 to 1700         0.0005 to 2500         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 5000         0.0005 to 5000         0.0005 to 5000         0.0005 to 2000         0.0015 to 1000         0.0005 to 2000         0.0005 to 2000         0.0005 to 1700	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on option d for remote control. max. Resolution in mW/cm <sup>2*</sup> 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001			
Diperating Tr Dimensions Power RS232 96 (97 with De Model No: JV-3701-4 JV-3702-4 JV-3702-4 JV-3703-4 JV-3704-4 JV-3706-4 JV-3709-4 JV-3710-4 JV-3711-4 JV-3711-4 JV-3716-4 JV-3717-4 RW-3701-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31: UV-B (28 UV-C (25 UV-En Bilir ACGIH Blue-Lig UV-A (32: UV-A (31: BLUE (40	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation timeration. Hirose, type 3260 ponse Function 5-400 nm) 0-315 nm) 0-280 nm) ythema tubin (ICNIRP) ht Hazard 0-400 nm) 0-320 nm) 5-400 nm) 5-400 nm)	I, non-condensing). Storage Temperature: 0         x 0.9 in / 0.33 lb).         ne about 100 h. Operation from a AC plug-         D-8S1. Power supply operation recommended         Measurement Range in mW/cm <sup>2*</sup> 0.0005 to 1700         0.001 to 10000         0.0005 to 2500         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 100         0.0005 to 100         0.0005 to 5000         0.0005 to 500         0.0005 to 2000         0.0005 to 2000         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 100	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on option d for remote control. max. Resolution in mW/cm <sup>2*</sup> 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001			
Diperating To Dimensions Power RS232 96 (97 with De Model No: JV-3701-4 JV-3702-4 JV-3703-4 JV-3704-4 JV-3704-4 JV-3706-4 JV-3708-4 JV-3708-4 JV-3709-4 JV-3710-4 JV-3711-4 JV-3716-4 JV-3717-4 RW-3702-4	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31) 0 UV-B (28) UV-C (25) 0 UV-C (25) 0 UV-A (31) 0 UV-A (30) 0 UV-A (31) 0 UV-A (31)	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation time ration. Hirose, type 3260 ponse Function 5-400 nm) 0-280 nm) ythema tubin (ICNIRP) ht Hazard 0-400 nm) 0-320 nm) 5-400 nm) 0-500 nm) 0-500 nm)	I, non-condensing). Storage Temperature: 0           x 0.9 in / 0.33 lb).           ne about 100 h. Operation from a AC plug-           D-8S1. Power supply operation recommended           Measurement Range in mW/cm <sup>2*</sup> 0.0005 to 1700           0.0005 to 2500           0.0005 to 1700           0.0005 to 1700           0.0005 to 1700           0.0005 to 500           0.0005 to 500           0.0005 to 500           0.0005 to 2000           0.0005 to 2000           0.0005 to 100           0.0005 to 1700           0.0005 to 2000           0.0005 to 1700           0.0005 to 1700           0.0005 to 100	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on optio d for remote control. max. Resolution in mW/cm <sup>2*</sup> 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001			
Operating To Dimensions Power Interface RS232 96	Weight	re 5 to 40 °C (41 to 10 120 x 65 x 22 mm 9 V one-piece bat erases battery ope 8 8D, 1S,N. 8 pin plug ead Spectral Resp UV-A (31) 0 UV-B (28) UV-C (25) 0 UV-C (25) 0 UV-A (31) 0 UV-A (30) 0 UV-A (31) 0 UV-A (31)	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation timeration. Hirose, type 3260 ponse Function 5-400 nm) 0-315 nm) 0-280 nm) ythema tubin (ICNIRP) ht Hazard 0-400 nm) 0-320 nm) 5-400 nm) 5-400 nm)	I, non-condensing). Storage Temperature: 0         x 0.9 in / 0.33 lb).         ne about 100 h. Operation from a AC plug-         D-8S1. Power supply operation recommended         Measurement Range in mW/cm <sup>2*</sup> 0.0005 to 1700         0.001 to 10000         0.0005 to 2500         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 100         0.0005 to 100         0.0005 to 500         0.0005 to 500         0.0005 to 2000         0.0005 to 2000         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 100	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on optio d for remote control. max. Resolution in mW/cm <sup>2</sup> * 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001			
Operating Tr Dimensions Power Interface RS232 96 K97 with De Model No: JV-3701-4 JV-3702-4 JV-3702-4 JV-3703-4 JV-3706-4 JV-3708-4 JV-3708-4 JV-3709-4 JV-3710-4 JV-3710-4 JV-3711-4 JV-3717-4 RW-3702-4	Weight	re         5 to 40 °C (41 to 10           120 x 65 x 22 mm           9 V one-piece bat erases battery ope           8 8D, 1S,N. 8 pin plug           ead           Spectral Resp           UV-A (31)           UV-B (28)           UV-C (25)           UV-C (25)           Blue-Ligi           UV-A (32)           UV-A (31)           BLUE (40)           RED (700)           VISIBLE (4)	04 ° F) (75 % rel. F / 150 g (4.7 x 2.6 tery. Operation time ration. Hirose, type 3260 ponse Function 5-400 nm) 0-280 nm) ythema tubin (ICNIRP) ht Hazard 0-400 nm) 0-320 nm) 5-400 nm) 0-500 nm) 0-500 nm)	I, non-condensing). Storage Temperature: 0         x 0.9 in / 0.33 lb).         ne about 100 h. Operation from a AC plug-         D-8S1. Power supply operation recommended         Measurement Range in mW/cm <sup>2*</sup> 0.0005 to 1700         0.0005 to 2500         0.0005 to 1700         0.0005 to 1700         0.0005 to 1700         0.0005 to 500         0.0005 to 500         0.0005 to 500         0.0005 to 2000         0.0005 to 2000         0.0005 to 1700         0.0005 to 100         0.0005 to 100         0.0005 to 1700         0.0005 to 100         0.0005 to 100	to 50°C (32 to 122 °F). in power supply 230V/50 Hz on optio d for remote control. max. Resolution in mW/cm <sup>2</sup> * 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001 0.00001			

Ordering Information					
X9 7	Optometer with handbook and battery. Calibration data of the detector ordered with the meter are stored in memory.				
Detector Head	One of any Gigahertz-Optik irradiance detector heads with ITT type (-4) connector.				
X9Z-01	RS232 interface cable to connect the X9 meters with 9PIN SUB-D PC standard socket.				
X9Z-02	External power unit for the X9 meters including the meter modification. Battery operation will be canceled.				
BHO-04	Hard case to carry and store the X9 7 with one 37 type detector.				

## 🕞 Gigahertz-Optik

## **Optometers & Instruments - Page 25**

## X98 Hand-held UV-A Irradiance & Illuminance Meter

- © Hand-held Dual-channel Meter for Field Service and Laboratory Use
- © Dual Cell UV-A Irradiance and Illuminance Detector Head
- $\ensuremath{\mathbb{C}}$  0.0002 to 900 mW/cm² & 0.01 to 199,999 Ix measurement range
- © Cosine Corrected Field of View
- © CW Measurement Mode for DC and AC Light
- © Snapshot Hold Function
- © Dose Measurement Mode
- © Quick & Easy Handling
- © Economical Price
- © RS232 Remote Control and Data Collection

Combining a UV-A irradiance and photometric illuminance detector into one instrument is highly useful in two applications: 1) Liquid Penetrant Testing using the dye penetration examination process is a widely used method for the detection of surface cracks in nonporous metal and non-metal materials in NDT. For highest sensitivity, a fluorescent dve is used as the penetrating liquid and the test is carried out under UV-A ultraviolet 'blacklight' light sources. To reliably test with fluorescent agents, an adequate level of UVirradiance containing a very low proportion of white (visible) light must be generated at the object under test to ensure proper contrast

**DIN EN 1956, ASTM and MIL Standards** exist that describe the general conditions and standard practices for the penetrant test examinations, including the procedures to be followed.

The minimum requirements for the illumination or irradiation conditions, test procedures to be used for checking these levels and suitable measurement equipment specifications are also covered.

#### 2) Photostability

The current ICH (International Conference for Harmonization) guidelines specify that drug and drug products must be phototested to ensure that exposure to light does not cause photochemical degradation of the product or packaging. The product under test must receive a **measured** dose of both UV-A (200 watt-hours per square meter) and Visible (1.2 million lux-hours) optical radiation exposure. This requires both radiometric and photometric measurements in terms of illuminance in lux and UV-A (315 to 400 nm) irradiance in W/m<sup>2</sup> multiplied by exposure time in hours.

UV-A fluorescent and Xenon or Metal Halide simulated ID65 light sources are the only sources specified in the ICH guidelines.

Most often the phototesting is performed in a photostability chamber with long fluorescent light sources mounted above the products under test. Since this is an extended source type of measurement rather than a point source configuration, the detector angular sensitivity should be cosine corrected using a diffuser. This way the incoming light signals are properly weighted according to the cosine of the angle of incidence.

Profiling the photostability chamber for uniformity over the exposure plane is an important procedure since products placed in different areas inside the chamber should be uniformly exposed to the same light levels.

#### X98 Meter

Besides it's precise measurement capability the X98 meter's ("Xnine eight") most outstanding



feature is its easy handling. To measure, the user simply switches on the meter and selects either the CW (lx or W/cm<sup>2</sup>) or Dose (lxs or J/cm<sup>2</sup>) mode. The LCD characters are 9 mm high for easy viewing. The X9<sub>8</sub> is a compact handheld battery operated instrument.

### **XD-9502 Detector Head**

The compact detector housing integrates two precision light detectors, one for illuminance and one for UV-A irradiance. **The photometric detector** (Ix) satisfies the requirements of DIN quality class B (DIN 5032 Part 7), and is suitable for use as a qualified industrial measuring instrument. This qualification governs

the acceptable tolerances of the photometric response function (V  $(\lambda)$ ) and the accuracy of the



## cosine function in particular.

The UV-A detector offers a spectral sensitivity characteristic according to DIN 5031 and the CIE, where the UV-A range is defined from 315 to 400 nm. The detector design effectively blocks the neighboring UV-B and visible light regions. The detector head is cosine corrected with a diffuser.

#### Traceable Calibration

Calibration is traceable to the ISO EN 17025 accredited part of



Len D

X9,

Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities.

#### Custom Label:

All meters in the X9 family are ready made for custom design and labeling. Customization may include the meter front panel, function/mode set-up, detector heads, manuals and calibration certificates. Contact the factory for details and assistance. the company for more details.

#### Operation

The X9s is simple to operate To measure, connect the detector and switch on the meter.

#### **Detector Selection**

Selection of the photometric or UV-A detector is easily done in the menu mode.

#### **CW Measurement**

CW mode is used to measure continuous DC or AC signals .

#### **Dose Measurement**

Measurement values are accumulated at a logger rate of 1 s and displayed as dose. The measurement is manually started and stopped.

### **Stop/Run Function**

Current reading can be 'frozen' by pressing 'stop' button.



## X98 Specifications& Ordering Information

### Specifications: X98 Meter

Signal Input							
Detector Input	w ir	<i>i</i> ith max. gain ntegration time	signal values from : s.	200.0 µA to 20	following voltage to voltage 0.0 pA . Automatic range s	switching. 12 bit ADC	with up to 14 bits at long
Signal Processing	g A	/D converter v	vith 20 ms time inte	rval. 500 ms in	tegration through averaging	g of multiple measure	ements.
Frequency Range	e S	ignal conversi	on from 0.166 Hz to	o >300 MHz			
Detector Connect	tor 9	pin MDSM9 s	ocket . Connected	detector identi	fication if meter switched C	N (VL-3704-4 and LC	M-9901-4 only).
Range Specifica	tions						
Range (A/V)	Max	. Input Value	Slew-Rate (10 - 90%)	1 year, 2	Error (with offset compen $3^{\circ}C \pm 5^{\circ}C. \pm (\% \text{ of reading})$		Permitted Detector Capacitance
1x10-4		200.0 µA	30 ms		0.2 %* + 0.05 %		2 nF
1x10-5		20,00 µA	30 ms		0.2 %* + 0.05 %		2 nF
1x10-6		2,000 µA	30 ms		0.2 %* + 0.05 %		2 nF
1x10-7		200,0 A	30 ms		0.2 %* + 0.05 %		10 nF
1x10-8		20,00 nA	30 ms		0.2 %* + 0.05 %		10 nF
1x10-9		2,000 nA	30 ms		0.2 %* + 0.05 %		10 nF
1x10-10		200,0 pA	30 ms		0.2 %* + 0.05 %		10 nF
General Display Operating Tempe Dimensions/Weig Power Interface RS232 9600 Ba	ght	6 character 5 to 40 °C (4 120 x 65 x 2 9 V one-pie erases batte	LCD. Character hei 11 to 104 ° F) (75 % 22 mm / 150 g (4.7 ce battery. Operati ary operation.	ight 9 mm. Indi rel. H, non-coi x 2.6 x 0.9 in / on time about	W/cm <sup>2</sup> and illuminance in b cation of measurement quandensing). Storage Temper 0.33 lb). 100 h. Operation from a A wer supply operation record	antities lx and cd/m², rature: 0 to 50°C (32 t AC plug-in power su	o 122 °F). pply 230V/50 Hz on optic
X98 with Detecto	or Hea	ad					
typ. UV-A measur	emen	t range	0.025 to 900 mW/cm <sup>2</sup> with max. 0.00005 mW/cm <sup>2</sup> resolution				
yp. Illuminance n	neasu	rement range	0.2 to 999,000 lx with 0.004 lx resolution				
Dose range			0.00001 to 900.00	00 lxs and 0.00	001 J/cm <sup>2</sup> to 900,000 J/cm	2	
Spectral sensitiv	vitv cl	naracteristic	<u> </u>		Dimensions		
1 - Alvistisus 1 -	$\sim$	UV-A		ν(λ)	65 mm	- 	46,00 mm     46,00 mm



22 mm

۲

23 mm

wavelength (nm) spectral sensitivity characteristic of both X98 detectors

550

600 650 700

750

0 250 300

X9 8

X9Z-01

X9Z-02

350

400

450 500

**Ordering Information** Illuminance & UV-A Irradiance Meter including detector head . Detector calibration data stored in memory . Includes battery and handbook. RS232 interface cable to connect the X9 meter with 9 PIN SUB-D PC standard socket External AC power unit for the X9 meter including meter modification (cancels battery operation)

BHO-04 Hard case to carry and store the X9 8 with detector

## **Gigahertz-Optik**

## Optometers & Instruments - Page 27

X910 Integrating Sphere Power Meter for Telecommunication Testing

Fiber Connector Option

- Hand-held Meter for Field Service and Laboratory Use  $\bigcirc$
- © Compact Integrating Sphere Detector for
  - © No Beam Misalignment Error
  - © No Polarization Effected Error
  - © No Beam ,Bounce-Back' Error
  - © No Detector Saturation
  - © Economical Price
- © Dynamic Range from 10 dBm to -60 dBm
- (C) Spectral Range 400 to 1100 & 850 to 1700 nm
- C **Battery Operation (Optional AC Power Operation)**
- **RS232 Interface** (C)



#### **Radiant Power Measurement**

Measurement of the power output of laser diodes or fibers is a daily routine in the field of telecommunication component testina

#### **Bare Detector Issues**

Optical power meters with a bare detector directly receiving signal offer high sensitivity but at a cost. Potential measurement inaccuracies caused by the effects of polarization, local saturation, signal 'bounce-back' and beam misalignment can occur. Also, the use of large size photodiodes, required to reduce source to detector misalignment, increases cost.

#### **Reflectance & Polarisation**



#### **Bounce-Back**



### Large Detector Area



#### **Integrating Sphere Detectors**

A welcome alternative is the integrating sphere known in the world of photonics for its ability to reliably and accurately measure total flux from fibers, laser diodes, lasers, LEDs and any other light source.

### The diffuse multiple reflec-



tions from the inner wall of the sphere suppresses the disturbance effects created by the angle of incidence which can form shadows, reflections, modes, etc

The sphere is able to collect all of the source optical radiation output independent of beam geometry.

Since all of the incoming signal is captured and reflected inside the sphere multiple times before reaching the baffled detector mounted to it, the adverse effects of polarization, local saturation, signal 'bounce-back' and beam misalignment are reduced. **Small Size Detector** 

Due to the low attenuation property of compact integrating spheres, they can be used with photodiodes with a small active area. In combination with InGaAs photodiodes for the 850 to 1700 nm range, this brings the sphere detector price down in the range of large bare detectors! **Bare Laser Diodes** 

Because of the large divergent beam of laser diodes, bare detectors can not be used to measure the total power of bare laser diodes. Gigahertz-Optik's X910 (Xnine ten) offers an economically priced instrument capable of all types of telecommunications testing in the areas of QC, fiber assembly/test, multimode LAN, patchcord, network installs and general laser diode, fiber and LED power measurements. X910 Meter

Besides it's precise measurement capability the X910 meter's most outstanding feature is its easy handling. To measure, the user simply switches on the meter and selects the wavelength corresponding to the test laser wavelength. The LCD characters are 9 mm high for easy viewing. The X910 is a compact handheld battery operated instrument. AC option is available.

#### LP-01 Sphere Detectors

The LP-01 sphere detectors employ a 30 mm diameter integrating sphere machined out of OP.DI.MA. Gigahertz-Optik's unique white diffuse plastic. OP.DI.MA. offers optimum light throughput for high sensitivity, a nearly perfect diffuse reflection for best diffuse radiation distribution and long term stability. The sphere is housed in a rugged aluminum casing for protection and allows mounting to an optical post or bench. The sphere comes with an open 5 mm dia. measurement port.

#### Model LP-0101

Is supplied with a Indium Gallium Arsenide photodiode which covers the spectral range from 850 to 1700 nm. The use of a small

area diode allows an economical price

And

X9

#### Model LP-0103

Is supplied with a Silicon photodiode which covers the spectral range from 400 to 1100 nm.

## **Fiber Connectors**

Fiber optic connector adapters for FC, ST, SC connections are available as an option.

#### **Traceable Calibration**

Calibration is traceable to the ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities. Each detector head is calibrated in 10 nm steps within its specified wavelength range.

### **Custom Labeling:**

All meters in the X9 family are ready made for custom design and labeling. Customization may include the meter front panel, function/mode set-up, detector heads, manuals and calibration certificates. Contact the factory for details and assistance.

#### Operation

The X98 is simple to operate to measure, connect the detector and switch on the meter.

#### **CW Measurement**

CW mode is used to measure continuous DC or AC signals in dBm or mW.

### Wavelength Selection

A calibration table with spectral sensitivity data in 10 nm steps within the detectors specified spectral range allows simple wavelength selection.

#### **Stop/Run Function**

Current reading can be 'frozen' by pressing 'stop' button.



## X910 Specifications & Ordering Information

## Specifications: X910 Meter

Signal Inpu	ıt								
Detector Inp	out		gain signal v			10). 7 decade stepped gain ranges bit ADC with up to 14 bits at longer			
Signal Proce	essing	A/D conve	rter with 20 r	ter with 20 ms time interval. 500 ms integration through averaging of multiple measurements.					
Frequency F	Range	Signal con	version from	0.166 Hz to >300 MHz					
Detector Co	nnector	9 pin MDS	M9 socket .	Connected detector identificat	ion if meter switched ON (VL-3704-4	4 and LDM-9901-4 only).			
Range Spec	cification	S							
Range (A/V)	Max. Ir Valu		Slew-Rate         Error (with offset co (10 - 90%)           1 year, 23°C ±5°C ±(% of re-			Permitted Detector Capacitance			
1x10-4	200.0	μA	30 ms	0.2 %	+ 0.05 %	2 nF			
1x10-5	20,00	μA	30 ms	0.2 %	+ 0.05 %	2 nF			
1x10-6		2,000 µA 3			+ 0.05 %	2 nF			
1x10-7	200,0		30 ms		+ 0.05 %	10 nF			
1x10-8	20,00		30 ms		+ 0.05 %	10 nF			
1x10-9	2,000		30 ms		+ 0.05 %	10 nF			
1x10-10	200,0	рА	30 ms	0.2 %	+ 0.05 %	10 nF			
unction									
Parameter S Measureme	-	ty Ampere	calibrated w	settings in continuous memory vith DKD calibrated current sc I power in dBm.	y. 3 function buttons. burce. Current signal multiplied with	calibration correction factor to dis			
<b>General</b> Display		6 chara	acter LCD. C	haracter height 9 mm. Indicatio	on of measurement quantities lx and	l cd/m², battery low, peak, stop			
Dperating Te	emperatu			0	nsing). Storage Temperature: 0 to 50				
Dimensions				<sup>′</sup> 150 g (4.7 x 2.6 x 0.9 in / 0.33		× /·			
Power	vvcigrit				h. Operation from a AC plug-in po	ower supply 230V/50 Hz on option			
ower			battery oper						
Measuremei <b>_P-0101</b> Measuremei				iameter 700 nm, calibrated in 10 nm in 0 dBm. with max. 0.01 dBm re:					
LP-0103			400 – 1	100 nm, calibrated in 10 nm ind	crements				
Measureme	nt range	at 900 nm	-60 to 1	0 dBm. with max. 0.01 dBm re	solution				
Spectral Se	ensitivity	LP-0101	<u>.</u>		Spectral Sensitivity LP-0103				
1 - Åj vij vij vij vij vij vij vij vij vij vi	1025	1125 1250	1375 1500	1625 1750	9.00E-04 0.00E-				
Ordering Ir	ormatic	wavelength	n ( nm )		Wavel	length (nm)			
X9 10	,		r with stores	l calibration data of ordorod do	etector head, handbook, battery				
LP-0101-4					y calibration certificate. ITT type con	nector (-4)			
_P-0101-4 _P-0103-4					pration certificate. ITT type connecto				
UFC-II/FC			for integrati	,	station continuate. It is type confident	· \ ·/·			
JFC-II/ST			for integrati						
JFC-II/SC		1	for integrati	0 1					
(9Z-01			0	0 1	PIN SUB-D PC standard socket				
x92-01 X9Z-02					er modification (cancels battery ope	eration)			
BHO-08		Hard-shell			eeameaterr (earloos battery ope				
BHO-09		Hard-shell							
BHO-09 Hard-shell			2400						

## 🕃 Gigahertz-Optik

## Optometers & Instruments - Page 29

## X911 Hand-held UV-C Irradiance Meter

- © Hand-held Single Channel UV-C Irradiance Meter
- © Measurement Range 0.05 to 1000 mW/cm<sup>2</sup> with 0.001 mW/cm<sup>2</sup> Resolution
- © Solar Blind UV-C Sensitivity
- © NIST Traceable Calibration at 254 nm
- © Solid-state Detector with Cosine Corrected Field of View
- © CW Mode with Snapshot Hold Function
- © Dose Measurement Mode
- © Easy to Use
- © Battery Operation
- © RS232 Remote Control Operation

#### **UV-C Radiation**

Short wavelength high energy ultraviolet radiation in the UV-C spectral range from 100 to 280 nm is used in the *germicidal/ bactericidal sterilization* of air and water. UV-C at 253.7 nm is also employed in *eprom erasure* and the *cleaning* of sensitive surfaces in the semiconductor industry. *UV curing* is another area where UV-C is applied.

#### **UV-C Light Sources**

Due to its high and pre-dominantly monochromatic output at 253.7 nm, *low pressure mercury* is the light source of choice in these applications. Medium and high pressure Hg as well as metal halide and other broadband UV sources are also used, especially in UV curing.

#### **Light Source Life-time**

The life time of high power UV-C sources is limited. Therefore the UV-C intensity must be monitored periodically to control the process condition.

#### **UV-C Detectors**

Optical radiation detectors used in UV-C applications are subject to extreme stress due to the high energy UV-radiation involved. Special precautions are needed to ensure that the detector's life is longer than that of the light source.

Also, detector sensitivity must focus on the specified source spectra using UV resistant components.

#### **Detector Stability**

Radiometric detectors used for UV-C measurement and monitoring must be designed to remain stable with minimal degradation from long term exposure to the high irradiance and energy levels typically found in this application. UV-C Isolation

The detector must be able to isolate the UV-C radiation and not allow any out-of-band signal to contaminate the reading.

## Cosine Field of View

A precise cosine corrected field of view, simple operation for inexperienced users and an attractive price level are also desirable.

#### X911 Meter

Besides it's precise measurement capability the X911 (Xnine eleven) meter's most outstanding feature is its easy handling. To measure, the user simply connects the detector head and switches on the meter. The LCD characters are 9 mm high for easy viewing. The X911 is a compact handheld battery operated instrument. AC option is available.

#### UV-3718 Detector Head

A new technology solid-state solar blind photodiode detector was chosen for use in the UV-3718 detector head because of its UV stability and solar blind spectral sensitivity characteristic. The UV sensitivity of the detector is limited to 265 nm focusing response to the 254 nm spectral range.

Also, the detector employs a carefully designed diffuser to

provided a precise cosine correction of the detector, which is of equal importance in maintaining low measurement uncertainties.

#### Traceable Calibration

Calibration is traceable to the ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities and NIST standards.

Calibration of the detectors irradiance sensitivity at 254 nm as well as an individually measured plot of spectral sensitivity is part of the calibration certificate.

#### Custom Labeling:

All meters in the X9 family are ready made for custom design and labeling. Customization may include the meter front panel, function/mode set-up, detector heads, manuals and calibration certificates. Contact the factory for details and assistance.

### Operation

The X911 is simple to operate To measure, connect the detector and switch on the meter.

#### **CW Measurement**

CW mode is used to measure continuous DC or AC signals .

#### **Dose Measurement**

Measurement values are accumulated at a logger rate of 1 s and displayed as dose. The measurement is manually started and stopped.

#### **Peak Hold Measurement**

Peak Hold mode is used to search for "hot-spot" light intensities. The peak intensity measured is frozen on the display.

### **Stop/Run Function**

Current reading can be 'frozen' by pressing 'stop' button.







32 mm

37 mm

## X911 Specifications & Ordering Information

### Specifications: X98 Meter

Signal Inpu	it								
V		Photocurrent to with max. gain s integration times	notocurrent to voltage converter amplifier with following voltage to voltage amplifier (x10). 7 decade stepped gain ranges th max. gain signal values from 200.0 $\mu$ A to 200.0 pA . Automatic range switching. 12 bit ADC with up to 14 bits at longer tegration times						
				ns time interval. 500 ms integration through averaging of multiple	measurements.				
· · · · · · · · · · · · · · · · · · ·				0.166 Hz to >300 MHz.					
		9 pin MDSM9 so	ocket.						
Range Spec	cification	S							
Range Max. Input (A/V) Value			-	Error (with offset compensation) 1 year, $23^{\circ}C \pm 5^{\circ}C \pm (\% \text{ of reading } + \% \text{ of range})$ ,	Permitted Detector Capacitance				
1x10-4	200.0	μA 30 m	s	0.2 % + 0.05 %	2 nF				
1x10-5	20,00	μA 30 m	s	0.2 % + 0.05 %	2 nF				
1x10-6	2,000	μA 30 m	S	0.2 % + 0.05 %	2 nF				
1x10-7	200,0	0 A 30 m	s	0.2 % + 0.05 %	10 nF				
1x10-8	20,00	nA 30 m	s	0.2 % + 0.05 %	10 nF				
1x10-9	2,000		s	0.2 % + 0.05 %	10 nF				
1x10-10	200,0	pA 30 m	S	0.2 % + 0.05 %	10 nF				
Function									
Parameter S	ettings	Retention of t	he last s	settings in continuous memory. 3 function buttons.					
Measureme	nt Quantit	y Ampere calib play irradianc		ith DKD calibrated current source. Current signal multiplied with //cm <sup>2</sup> .	calibration correction factor to dis				
General									
Display		6 character L	CD. Character height 9 mm. Indication of measurement quantities Ix and cd/m², battery low, peak, stop						
Operating T	emperatu	re 5 to 40 °C (4	41 to 104 ° F) (75 % rel. H, non-condensing). Storage Temperature: 0 to 50°C (32 to 122 °F).						
Dimensions	/Weiaht	120 x 65 x 2	22 mm / 150 g (4.7 x 2.6 x 0.9 in / 0.33 lb).						
Power	, 0		e batte	ry. Operation time about 100 h. Operation from a AC plug-in p	ower supply 230V/50 Hz on optio				
Interface		1							
RS232 96	00 Baud,	8 8D, 1S,N. 8 pir	n plug H	lirose, type 3260-8S1. Power supply operation recommended for	remote control.				
Specificatio	ons: X911	with UV-3718 L	JV-C De	etector Head					
				1000 mW/cm <sup>2</sup> with 0.001 mW/cm <sup>2</sup> resolution					
Dose Measu		Ŷ	0.0000	1 J/cm <sup>2</sup> to 100.000 J/cm <sup>2</sup>					
Detector Din	nensions		Dia. 37	mm dia Height 32 mm; Cos. diffuser dia. 7 mm; Cable length 2	2 m				
Spectral Se	ensitivity	UV-3718		Dimensions					
				+ 65 mm+					





Ordering Infor	Ordering Information					
X9 11	UV-C irradiance and dose meter. Calibration data stored in memory. Includes battery and handbook.					
UV-3718-4	UV-C irradiance detector head with factory calibration certificate. ITT type connector (-4).					
X9Z-01	RS232 interface cable to connect the X9 meter with 9PIN SUB-D PC standard socket					
X9Z-02	External AC power unit for the X9 meter including meter modification (cancels battery operation)					
BHO-04	Hard Carrying Case					

## Optometers & Instruments - Page 31

X912 Hand-held UV Hazard Meter

- © Hand-held Single Channel UV Hazard Meter
- © ACGIH Effective Irradiance Measurement
- © Measurement Range 0,5 to 999 999  $\mu$ W/cm<sup>2</sup> with 0,01  $\mu$ W/cm<sup>2</sup> Resolution
- © Traceable Calibration of ACGIH Sensitivity
- © Solid-state Detector with Cosine Corrected Field of View
- © CW Mode with Snapshot Hold Function
- © Dose Measurement Mode
- © Easy to Use
- $\ensuremath{\mathbb{C}}$  Battery Operation, AC option available
- © RS232 Remote Control Operation



#### **UV Hazard**

Ultraviolet and blue-light optical radiation pose a potential health hazard for both human skin and eyes. Common sun burn, photokeratitis (welder's eye) and burning of the retina or cornea are examples of injuries caused by overexposure to this radiation.

**Higher Awareness of UV Risk** Because of the dramatic increase in global solar UV radiation and the cumulative nature of the harmful effects, the additional risk of UV exposure by artificial sources is a concern.

The efficiency of protective devices like sun creams, UV blocking fabrics and sunglasses are the subjects of study.

#### UV Hazard Risk Assessment

Photobiologists, industrial hygienists, health and safety officers measure UV irradiance (W/ $m^2$ ) and irradiance dose (J/ $m^2$ ) of all types of UV sources in the lab, field and in the work place in order to ensure safety and to study both the harmful and helpful effects. It is important to note that UV levels and subject exposure times typically vary so datalogging over some time period is commonly employed.

#### ACGIH / ICNIRP Spectral Weighting Functions

The spectral weighting function for the acutely harmful effects of UV radiation, was developed by the American Conference of Governmental Industrial Hygienists (ACGIH) and the International Commission on Non-Ionising Radiation Protection (ICNIRP).

If one examines the spectral curve describing this function, it can be seen that the spectral effectiveness in the UV-C and UV-B ranges is drastically higher than in the UV-A range. The reason for this is that the function was derived from those relating optical radiation to erythema (skin reddening) and photokeratoconjunctivitis (corneal inflammation). Threshold Limit Values given for the maximum permissible exposure of the skin define the range of wavelengths as 200 (180) to



**ICNIRP** Nominal Function

400 nm in reference to the ACGIH-ICNIRP function. The limits of maximum permissible exposure for the eye in the range 200 (180) to 400 nm and 315 to 400 nm (UV-A) are defined separately. By definition ACGIH-ICNIRP UV-C/B is measured in effective irradiance according to the spectrally weighted function and the UV-A level is assessed by measurement of the total UV-A irradiance (no spectral weighting function) for UV-A rich sources.

#### X912 Meter

Besides it's precise measurement capability the X912 (Xnine twelve) meter's most outstanding feature is its easy handling. To measure, the user simply connects the detector head and switches on the meter. The LCD characters are 9 mm high for easy viewing. The X912 is a compact handheld battery operated instrument.

#### UV-3708 Detector Head

The UV-3708 detector permits direct measurement of effective irradiance according to ACGIH/ ICNIRP guidelines. It's designed with particular attention to the recreation of the specified spectral sensitivity curve in the range from 300 to 350 nm with its verv steep edge. In order to correctly evaluate irradiance, the detector head has a cosine diffuser. For applications concerning exposure of the eye to UV radiation, the UV-3708 detector head is used together with an additional detector head for UV-A.

#### Traceable Calibration

Calibration is traceable to the ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities and NIST standards.

Calibration of the detectors irradiance sensitivity as well as an individually measured plot of spectral sensitivity is part of the calibration certificate.

#### **Custom Labeling:**

All meters in the X9 family are ready made for custom design and labeling. Customization may include the meter front panel, function/mode set-up, detector heads, manuals and calibration certificates. Contact the factory for details and application assistance.

#### Operation

The  $X9_{11}$  is simple to operate To measure, connect the detector and switch on the meter.

#### **CW Measurement**

CW mode is used to measure continuous DC or AC signals .

#### **Dose Measurement**

Measurement values are accumulated at a logger rate of 1 s and displayed as dose. The measurement is manually started and stopped.

#### **Peak Hold Measurement**

Peak Hold mode is used to search for "hot-spot" light intensities. The peak intensity measured is frozen on the display.

#### Stop/Run Function

Current reading can be 'frozen' on display by pressing 'stop' button.



## X912 Specification & Ordering Information

### Specification: X912 Meter

Signal Inp	ut						
Detector Input		Photocurrent to voltage converter amplifier with following voltage to voltage amplifier (x10). 7 decade stepped gain ranges with max. gain signal values from 200.0 $\mu$ A to 200.0 pA . Automatic range switching. 12 bit ADC with up to 14 bits at longer integration times.					
Signal Processing		A/D converter with 20	ms time interval. 500 ms integration through averaging of multiple n	neasurements.			
Frequency Range		Signal conversion from	m 0.166 Hz to >300 MHz.				
Detector Connector		9 pin MDSM9 socket.					
Range Spe	cification	3					
Range	Max. In	put Slew-Rate	Error (with offset compensation)	Permitted Detector			
(A/V)	Valu	e (10 - 90%)	1 year, $23^{\circ}C \pm 5^{\circ}C \pm (\% \text{ of reading} + \% \text{ of range})$ ,	Capacitance			
1x10-4	200.0		0.2 % + 0.05 %	2 nF			
1x10-5	20,00		0.2 % + 0.05 %	2 nF			
1x10-6	2,000	uA 30 ms	0.2 % + 0.05 %	2 nF			
1x10-7	200,0	A 30 ms	0.2 % + 0.05 %	10 nF			
1x10-8	20,00		0.2 % + 0.05 %	10 nF			
1x10-9	2,000	nA 30 ms	0.2 % + 0.05 %	10 nF			
1x10-10	200,0	pA 30 ms	0.2 % + 0.05 %	10 nF			
Measureme General	ent Quantity	y Amperes calibrated play effective irradi	d with DKD calibrated current source. Current signal multiplied with ance in $\mu$ W/cm <sup>2</sup> .	calibration correction factor to c			
Display		6 character LCD. Character height 9 mm. Indication of effective irradiance and dose, battery , battery low, peak, stop					
Operating 1	emperatur	e 5 to 40 °C (41 to 104 ° F) (75 % rel. H, non-condensing). Storage Temperature: 0 to 50°C (32 to 122 °F).					
Dimension	s/Weight	120 x 65 x 22 mm / 150 g (4.7 x 2.6 x 0.9 in / 0.33 lb).					
Power		<ul> <li>9 V one-piece battery. Operation time about 100 h. Operation from a AC plug-in power supply 230V/50 Hz on option cancels battery operation.</li> </ul>					
Interface		0.0D 10.NL 0	Hirose, type 3260-8S1. Power supply operation recommended for				
	600 Baud,	8 8D, 15,1N. 8 pin piug	Thirdse, type 3200-031. Fower supply operation recommended for	remote control.			
RS232 9 Specificati	ons: X912	with UV-3708 ACGI	HUV-Hazard Detector Head				
RS232 9 <b>Specificati</b> Typ. eff. Irra	ons: X912 diance Me	with UV-3708 ACGII	<b>1 UV-Hazard Detector Head</b> $0.5 \mu$ W/cm <sup>2</sup> to 999 999 $\mu$ W/cm <sup>2</sup> eff. with 0.01 $\mu$ W/cm <sup>2</sup> eff. resolution				
RS232 9 <b>Specificati</b> Typ. eff. Irra Dose Meas	ons: X912 diance Me urement Ra	with UV-3708 ACGII	H UV-Hazard Detector Head           0,5 μW/cm²         to 999 999 μW/cm² eff. with 0.01 μW/cm² eff. resolution           0.00001 J/cm² eff. to 100,000 J/cm² eff.	n			
RS232 9 Specificati	ons: X912 diance Me urement Ra	with UV-3708 ACGII	<b>1 UV-Hazard Detector Head</b> $0.5 \mu$ W/cm <sup>2</sup> to 999 999 $\mu$ W/cm <sup>2</sup> eff. with 0.01 $\mu$ W/cm <sup>2</sup> eff. resolution	n			



65 mm	
Gigahertz-Optik X912UV-Hazard Meter	
r Internation Internation Internation Internation Internation	120 mm

 $\bigcirc$ 

UV-3708

Ordering Information				
X9 12	UV-Hazard irradiance and dose meter. Calibration data stored in memory. Includes battery and handbook.			
UV-3708-4	UV-Hazard ACGIH/ICNIRP irradiance detector head with factory calibration certificate. ITT type connector (-4).			
X9Z-01	RS232 interface cable to connect the X9 meter with 9PIN SUB-D PC standard socket			
X9Z-02	External AC power unit for the X9 meter including meter modification (cancels battery operation)			
BHO-04	Hard Carrying Case			

PT-9610 Hand-held Laser Qualification Meter

- Hand-held Single Channel Laser Qualification Meter for
  - Laser Power Measurement
    - Wavelength Range 350 to 1100 nm
    - Measurement Range up to 90 mW
  - Effective and Peak Noise Value Analysis
    - \* Effective Values with Wide Band, Low and High Frequency Selection
    - \* Peak Values with Positive, Negative and Peak to Peak Selection
- © Service and Production Use
- Handheld Portable Meter C
- © Battery or AC Operation

#### Laser Qualification

In most applications knowing the radiant power of a laser is the only qualifying parameter. That's why laser power meters are one of the most common instruments found in the lab and field service. But for specific applications, other parameters of the laser are also of interest.

#### Laser Noise

In laser use where measurement resolution is limited by the noise level of the laser radiation, the qualification of the noise level and noise function become important.

One example of this involves laser imaging scanners. The extremely high measurement bandwidth of these systems does not allow limiting the bandwidth of the detection system. Because of this not only laser power but to a greater extent the noise level and noise characteristic of the laser, used as a light source, influences the signal to noise ratio. So both laser power and noise must be qualified in incoming inspection, final testing and service

#### PT-9610 Laser Qualification Meter

Gigahertz-Optik developed the PT-9610 in close cooperation with the laser industry.

The idea was to develop a simple mobile meter for applications where laser power plus it's time structure in the form of modulation needs to be determined in the same measurement procedure. This information was of interest because any short and long term changes in intensity would effect the resolution of the measurement procedure.

#### **Functional Description**

The PT-9610 operates in two basic modes. CW power is always measured, i.e. the average power together with the component of the power with which the power oscillates about the mean value (modulation component).

Measurement mode of the modulation component can be selected for a more precise evaluation. The modulation component can be displayed as power ("absolute power, e.g. in W") or as a relative value related to the CW power.

A description of evaluation modes and display selections is summarized in the table shown on this page.

The device is also equipped with an analog output where the signal measured after the preamplifier is made available. The conversion factor between the detector signal and the output signal is between 103 V/A and 10<sup>5</sup> V/A, depending on the range of measurement. The output impedance is 10 k $\Omega$ .

### PD-1 Detector Head

The PD-1 is supplied as part of the PT-9610 system. It can handle a dynamic range of laser power from 1  $\mu$ W up to 90 mW (647 nm). This means that noise analysis using the maximum bandwidth of 1 MHz in the "RMS" or "Peak" modes has a resolution of 0.1% in the power range >1mW. The detector head can be used for lasers in the wavelength range from 350 nm up to 1100 nm and offers a 5 mm diameter measurement aperture.

#### **Traceable Calibration**

Calibration of spectral sensitivity is traceable to the ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities. The calibration is done in 10 nm steps within the wavelength

range from 350 to 1100 nm. A plot of the spectral sensitivity is part of the calibration certificate.

measurement value

83

9610

Selector

## **Evaluation Modes**

RMS WB

Peak +

- positive

signal

Peak -

- peak value

- peak value

CW value



measurement value



CW value

RMS LF

signal

- r.m.s. value

- low frequency





time



Peak pp









## PT-9610 Specifications & Ordering Information

PT-9610 Specifications					
ADC resolution "CW + RMS":	0.025 % of the full scale range value				
ADC resolution "Peak":	0.07 % of the full scale value (R1/WB)				
	0.01 % of the full scale value (R1/LF)				
	0.01 % of the full scale value (R2/WB)				
	0.005 % of the full scale value (R2/WB)				
Lower cut-off frequency for CW measurement:	10 Hz				
Cut-off frequency in (-3 dB) mode:	500 kHz (R1), 1 MHz (R2 + R3)				
Low pass filter in LF mode:	830 Hz (-3 dB) 480 Hz (-1.5 dB)				
High pass filter in HF mode:	280 Hz (-3 dB) 480 Hz (-1.5 dB)				
Calibration data storage:	External EEPROM in detector plug				
Measuring ranges:	R1, R2 and R3 with manual or automatic range switching (menu function)				
Operating panel:	Membrane keypad				
Display:	LCD with switch able background illumination				
Signal input:	9-pin SUB-D connector				
Analog output:	BNC socket				
Power supply:	Rechargeable battery or AC operation using external power supply unit (7.3 V/350 mA)				
Dimensions:	Approx. 20 cm x 10 cm x 4.5 cm (8 in x 4 in x 1.8 in) (L x W x H)				
Weight:	Approx. 500 g (1.1 lb) with batteries				
PT-9610 with PD1 Specifications	11 3 (	/			
Limits of Measurement					
	R1	R2	R3		
RMS WB	0.5 μW	1.5 μW	0.01 <i>µ</i> W		
HF	0.5 μW	1.5 <i>µ</i> W	0.01 µW		
LF	0.05 μW	0.3 µW	0.004 µW		
Peak-Peak WB	2.5 μW	4 μW	0.02 µW		
Max. Limits (637nm)					
CW	900 μW	9 mW	90 mW		
Decel disc		- A/	10.14/		

## PD-1 Spectral Sensitivity

Resolution



0.1 *µ*W

Dimensions

1 μW



10 µW

Ordering Information				
PT-9610-PD1	Laser power and laser noise analyzer including PD1 detector , handbook, calibration certificate and plug-in power supply			
PT-9610-RC-PD1	Laser power and laser noise analyzer with RS232 Interface. Including PD1, handbook, calibration certificate and power supply			
PD1	Laser power detector for use with PT-9610. Calibration data stored in calibration data connector. Calibration certificate.			
BHO-01	Carrying case for PT-9610 with PD1 detector and accessories.			

## **Optometers & Instruments - Page 35**

## HCT-99 Hand-held Luminous Color Meter

- © Compact Luminous Color Meter for
  - Correlated Color Temperature
  - x,y and u',v' Chromaticity Coordinates
  - Illuminance
  - Optional Luminance, Luminous Flux and Luminous Intensity
- © Tristimulus Detector with Real X<sub>short</sub>, X<sub>long</sub>, Y and Z Spectral Functions
- © Field Service and Laboratory Use
- © USB Interface for Remote Control Operation
- © Economical Price
- © OEM Labeling
- © Battery Operation

#### Luminous color

Color is defined as the attribute of visual perception consisting of any combination of chromatic and achromatic content. This attribute can be described by chromatic color names such as yellow, orange, brown, red, pink, green, blue, purple, etc., or by achromatic color names such as white, gray, black, etc., and qualified by bright, dim, light, dark or by combinations of such names.

Perceived color depends on the spectral distribution of the color stimulus, on the size, shape, structure and surroundings of the stimulus area, on the state of adaptation of the observer's visual system, and on the person's experience of prevailing and similar situations of observation.

#### Illuminance and Color

It has been known for many years and prescribed that high illumination levels will have positive effects on spiritual and physical performance. In comparison, low illumination levels can cause depression and even physical illness.

The classical photometric evalu-



is not the only factor for a healthy physical-biological home or work environment. Well balanced illumination <u>and</u> light-colors are necessary and conducive to a long term healthy life. A life surrounded by optical radiation. So new generation light meters should also measure color since it is a significant part of the total visual sensation

### Luminous Flux and Color

Light source manufacturers and other users need to know the luminous flux and color temperat u r e they are work-



ing with. Typically integrating spheres are used to measure these quantites.



#### Luminance and Color

Besides illuminance, luminance is one of the most important light measurement quantities used to specify the contrast situation on work stations and monitors.

**Luminous Intensity and Color** Spot lamps, like LED's for example, are very often qualified by their directional light intensity.



#### HCT-99 Color Meter

The HCT-99 is a compact portable light-meter for general lighting applications which also measures chromaticity coordinates x,y and u',v' as well as correlated color temperature. The ergonomically designed meter is simple to use for the benefit of inexperienced users.

### CT-4501 Detector Head

A compact design, 20 mm flat tristimulus detector is designed to measure broad-band light sources. Precisely corrected four cell design including the X<sub>short</sub> function ensure precise luminous color measurement independent from the light source emission

spectrum.

780

Optional Components To extend the unit's light measurement application range beyond luminous color, add:

• Integrating Spheres: luminous flux (calibration in lm)  Front lens: luminance (calibration in cd/m<sup>2</sup>)

II mall

Steradian front tube: luminous intensity (calibration in cd)

### Traceable Calibration

Calibration is traceable to the ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities and NIST standards. Calibration of detector sensitivity as well as an individually measured plot of spectral sensitivity is included as part of the calibration certificate.

#### **Custom Labeling:**

The HCT-99 is ready made for custom design and labeling. Customization may include the meter front panel, function/mode set-up, detector heads, manuals and calibration certificates. Contact the factory for details and application assistance.

#### Operation

The HCT-99 is simple to operate To measure, connect the detector and switch on the meter.

#### **CW Measurement**

CW mode is used to measure continuous DC or AC signals. Color temperature, x/y or u'/v' and illuminance are displayed all at once.

#### Stop/Run Function

Current reading can be 'frozen' on display by pressing 'stop' button.

#### **Calibration Selection**

To re-set the measurement application add the attachment to the CT-4501 and select the calibration in the menu mode.

## HCT-99 Specifications & Ordering Information

## Specifications: HCT-99 Meter

f<sub>2</sub> Cosine Error

 $\leq$  3 % (for illuminance measurements)

-			-99 Meter						
Signal Inpu	ıt								
Detector Inp	out	ing v	oltage to voltage		cade stepp	ed gain ranges	with ma	ax. gain	oltage converter amplifier with follow signal values from 20.0 $\mu$ A to 200. s.
Signal Processing A/D converter with 1 m Selectable from 1 ms to			le integratio	on time through	averagin	g of mu	ltiple measurements.		
Measureme	nt Time	4 tim	es the selected ir						
Frequency F	quency Range Signal conversion from 0.166 Hz to >300 MH			Ηz.					
Detector Co	nnector	or 9 pin MDSM9 socket, 4 measurement inputs							
Range Spec	cificatio	ns							
Range	Max.		Slew-Rate	Error	(with offse	t compensatio	n)		Permitted Detector
(A/V)	Va	ue	(10 - 90%)	1 year, 23°C ±	5°C ±(%	of reading + %	of range	e),	Capacitance
1x10-5	20,0		3 ms		0.2 % +				2 nF
1x10-6	2,00		3 ms		0.2 % +				2 nF
1x10-7	200		3 ms		0.2 % +				10 nF
1x10-8	20,0		3 ms		0.2 % +				10 nF
1x10-9 1x10-10	2,00		30 ms 30 ms		0.2 % +				10 nF 10 nF
	200,	Ј ра	30 1115		0.2 % +	0.03 %			TOTIF
Functions	ottingo	Do	tantian of the los			2 function butto			
Parameter S Measureme	-			t settings in continuous				liad wit	th calibration correction factor to dis
Measurenne	ni Quan			measurement quantiti		ce. Current sign	nai mulup	med wi	
General		- pie							
Display		10	CD graphic displa	$(07 \times 32 \text{ pixel})$ Text	A rows ear	ch 14 character	e IED ba	ekarou	nd illumination (switchable)
Operating T	omporat			104° F) (75 % rel. H, no				-	
Dimensions				/ 150 g (5.7 x 2.5 x 1.2			emperatu	16. 0 10	30 0 (32 10 122 1).
Power	weigin						(diaplay)	lluminoi	tion). USB: bus powered
		27	C Dallery Size AA	(2.2 - 3.2V). Current co	Insumption	. 6111A + 30111A	(uispiay i	liumina	lion). USB. bus powered
Interface									
			ID device)		1				
Specification				ead (typical Values)	Dimens	ions			
Illuminance			199999 lx with 0.0						<b>I</b>
Luminance			$1^{\circ}$ Lens / $\approx 2.5$ to $\approx 5 \times 10^{8}$ cd/m <sup>2</sup>			63 mm			50 mm
		5° Lens / $\approx$ 0.1 to $\approx$ 2 x 10 <sup>7</sup> cd/m <sup>2</sup> 10° Lens / $\approx$ 0.02 to $\approx$ 3 x 10 <sup>6</sup> cd/m <sup>2</sup>							50
Mine III une in a						ICT-99			
Min. Illuminance for Color Meas.		(	CIE standard illur CIE standard illur	,		Color-Meter			
		(	h CIE standard ill	/	- <u>G</u>	gahertz-Optik			E
Color unceri									45 mm
			< 1 % with BG 34, nom. x0.3914/y0.3925 < 1 % with BG 7, nom. x0.2646/y0.4057						
illuminant				m. x0.5417/y 0.4538	▏▕▌ <mark>┣</mark> ┻			E	
<ul> <li>nominal</li> </ul>	-		with VG 3, nom.		men	u run light		145 mm	
x 0.4476,	-		with RG 6, nom.					4	Ð
y 0.4074	=			om. x0.1450/y0.0426					CT-4501
	-			m. x0.4299/y0.5376					
				m. x0.5457/y0.4511					
X <sub>short</sub> f <sub>1</sub> Error		< 2 % ≤ 8.5 %			-				
X <sub>long</sub> f <sub>1</sub> Error		≤ 0.5 <i>//</i> ≤ 7 %			-				
Y f <sub>1</sub> Error			also photopic vis	ion detector )					
Z f <sub>1</sub> Error		<u></u> <u>~</u> % ( ≤ 3 %							
f Coolpo Er		/ /	(f '))		1				

Cal. Uncertainty Size & Weight	5 1.1 % ((V(λ)) 5 mm dia. x 20 mm; 2 m cable with -4			
Ordering Informa	tion			
HCT-99	HCT-99 Luminous color meter with CT-4501-4, hard carrying case, batteries, USB cable, USB DLL and manual			
Luminance Option	See section light detectors: SRT front lenses for 45-type model CT-4501			
Luminous Flux Option See section integrating spheres				
OS-X1	OS-X1 Software for remote control operation of the X11			

ł

30 mm

•
# **Optometers & Instruments - Page 37**

X-2000 Personal Dosimeter

- © Personal Dosimeter for Phototherapy and UV/Light Hazard Applications
- © Data-logger to Document Irradiation as Variable of Measurement Time
- © Free Programming, High-speed and Long-term Measurement Modes
- © Large Data Storage Capacity of 129,000 samples
- © ACGIH/ICNIRP, Erythema, UV-A, UV-B, UV-C Detectors and other Combinations
- © Cosine Corrected Field-of-View
- $\ensuremath{\mathbb{C}}$  Compact and Lightweight (60 g / 0.13 lb)
- © Low Power Consumption Electronics for Long Battery Life Time
- © RS232 Interface for Initialization and Data Read Out
- © Windows XP Compatible Software

#### Incoherent Optical Radiation

In simple terms incoherent optical radiation refers to radiation, other than that emitted by lasers, in the wavelength range between 100 nm and 1 mm.

# Health Risks from Incoherent Optical Radiation

Shallow penetration depth restricts the health risk primarily to the eye and skin.

- Acute effects to skin
   ©Erythema
   ©Burning
- Chronic effects to skin
   ©Skin cancer
   ©Skin ageing
- Acute effects to eye
   CPhotochemical and thermal retinal damage
   CPhotokeratitis
- Chronic effects to eye
- ©Cataract development ©Degeneration of the retina

#### Light Protection

The cumulative effects of incoherent optical radiation on the skin and eye are under ever increasing scrutiny. Longer exposures to higher levels of solar radiation plus artificial UV sources account for this. Dose levels are on the rise due to:

- reduced atmospheric UV shielding
- longer leisure time
- Ionger lifetime
- growing occupational use of high powered UV sources

As a result professional associations, institutes of health, radiation protection bureaus, dermatological institutes, responsible lighting manufacturers, insurance companies and others are interested in understanding the risks posed by natural and any artificial light sources used in industry and limit additional exposure dose during the work period.

#### Light Dose

When evaluating potential occupational harm from incoherent optical radiation, it is the effective radiance (or the time integral of the radiance) that is a concern for the retina, whereas for the skin, cornea and lens of the eye the critical quantity is effective irradiance (or the exposure or dose).

#### **Light Dose Measurement**

Photobiological sensors are available which allow detection of the exposure dose. Response time issues and missing information about peak exposure and exposure interruptions are a concern with these sensors.

Personal data-logging radiometers that can be worn by the subject enable recording and documenting of measured irradiation as it varies of the measurement time to allow a more precise evaluation of the exposure profile.

#### X-2000 Personal Dosimeter

The X-2000 meter series was developed as a personal UV monitoring dosimeter, which enables a point-by-point measurement of individual exposure tracked chronologically over a specific time period. A complete continuous profile of the measured signals is logged.

To fulfill the need of a personal dosimeter the X-2000 series

offers several outstanding features:

- small size and low weight for better subject acceptability
- long battery life due to low power consumption electronics with flash buffer
- large data sample memory
- free programming, fast and long-term sampling rates

#### Spectral Sensitivity

Various spectral functions are offered to fulfill different health hazard assessment requirements (see following page).

#### Cosine Corrected F.O.V.

Each detector is supplied with a cosine corrected field-of-view for precise, effective irradiance measurements.

#### Software

Initialization and data read-out via the RS232 interface is made easy with optional windows compatible OSDL software. Data storage in CSV file type allows

#### export to programs like Excel. Traceable Calibration

Calibration is traceable to the ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities and NIST standards. Calibration of the detector(s) irradiance sensitivity plus an individually measured plot of its spectral sensitivity is part of the calibration certificate.





The X-2000 series can be used in different health hazard applications because it can be configured with various detectors with different spectral sensitivity characteristics. This page describes those detectors.

Our Light Measurements Gui-

in particular should be protected

from strong UV radiation as the

damage is cumulative. The dose

received in the first years of life can be an important factor in the

development of skin problems in

By definition Erythema is meas-

ured in effective irradiance and

later vears

dose

#### Erythema

The typical symptom of erythema (sunburn) is acute skin inflammation caused primarily by over exposure to the UV-B component of solar radiation. Present opinion is that UV-A also plays a part in causing erythema because there is so much of it present in sunlight. Photobiological investigations have shown that intensive exposure to UV during leisure time and at work increases the risk of skin cancer. Children

### ACGIH/ICNIRP

The spectral weighting function for the acutely harmful effects of UV radiation, was developed by the American Conference of Governmental Industrial Hygienists (ACGIH) and the International Commission on Non-Ionising Radiation Protection (ICNIRP). Upon examination of the spectral curve describing this function, it is important to note that the spectral effectiveness in the UV-C and UV-B ranges is very high as compared to the UV-A range. ACGIH-ICNIRP Threshold Limit Values for the maximum permissible exposure of the skin are defined over the wavelengths from 200 to 400 nm. The limits of maximum permissible exposure for the eye in the range 200 (180) to 400 nm and 315 to 400 nm (UV-A) are defined separately. ACGIH-ICNIRP TLVs are specified in effective irradiance and dose.

guideline. The built-in eye pro-

tection devices mounted on

stationary testers enable EM6 to

state a possible risk to the skin

only. Stray light risk to the eye is

low because of the radiation's diffuse character. Because of

the UV-A rich spectral source

characteristic a two cell (AC-GIH-UV-B 250 to 325 nm and

ACGIH-UV-Askin 325 to 400 nm)

design is needed to completely

isolate UV-A from UV-B&UV-C

radiation.

#### ACGIH/ICNIRPSkin for UV-A Rich Sources

Measurement of UV radiation for the purpose of UV hazard assessment is the subject of the new **DGZfP-Merkblatt EM6** regulation. EM6 specifies that all UV sources used in fluorescent penetration test applications must be classified and regularly tested. Protective measures must be taken for the operators depending on the safety class.

The classification criteria is the  $E_{\mbox{\scriptsize eff}}$  UV hazard effective irradiation based on the ACGIH/ICNIRP

#### UV-A & UV-B

UV is widely used by dermatologists in the treatment of certain skin diseases like Psoriasis and Vitiligo. Whole body exposure booths and hand and foot units employing light sources which emit broadband UV-A, UV-B and combinations of UV-A and UV-B are used to irradiate the patient.

In PUVA photo therapy, also called photo chemotherapy, UV-A is applied in combination with a photosensitizing agent which is taken in pill form or applied topically to the skin. This medication called psoralen, giving rise to the acronym PUVA, makes the skin more sensitive and responsive to the UV-A (315-400 nm) wavelengths.

Due to the risks of premature skin ageing and skin cancer from prolonged exposures, also with consideration to skin type, PUVA is only recommended for moderate to severe cases of Psoriasis. UV-B broadband treatment is normally administered without a photosensitizing agent. It is considered safer than UV-A for wavelengths between approx. 290 to 315 nm, since it does not penetrate as deeply into the skin and is more energetic allowing shorter overall exposure times. However, it is generally accepted

**de** shown in our catalog and website offers additional tutorial and application notes concerning UV / light hazard measurements. Please contact the factory to discuss custom design X-2000 series instruments.



that wavelengths below 290 nm tic produce more erythema which len can actually inhibit the therapeu-

tic effects of the longer wavelengths.

🕞 Gigahertz-Optik



# Optometers & Instruments - Page 39

X-2000 Operation & Functions

The wireless X-2000 personal dosimeter is a self contained device. A computer is needed to initialize the measurement mode

#### **Measurement Mode Initialization**

Before the measurement is started, the user has to initialize the measurement mode and the

#### **Irradiance and Temperature Measurement**

In a two detector configuration sampling by one or two detectors can be selected. All X-2000 versions are supplied with an internal temperature sensor

High-speed Data-logger Mode

This mode is selected if light flashes or light sources with fast intensity changes are to be measured. The sampling rate can be selected between 5 ms and 1,984 s. The integrating time must be set to a shorter time than the sampling rate. The gain

#### Variable Integrating Time

As with most Gigahertz-Optik meters, all X-2000 versions offer selectable integrating times. This is achieved by the averaging of multiple measurements with the shortest integrating time at 1 ms. This function allows an adjustable selection of long integrating

#### Manual and Auto-ranging

The X-2000 offers six gain ranges that can be selected manually or automatically. In fast measurement applications the gain switching time must be considered. This depends on the inte-

#### Long Term Data-logger Mode

This mode is selected if data over a long measurement period must be sampled. The sampling rate can be set between 1 s and 127 min. To optimize battery life

#### **Calculating Maximum Measurement time**

To calculate the max. measurement time, first the memory requirement for one sample must be calculated (see specs.). Then the max data storage capacitance of 518,656 Bytes must be

#### Programmable logger Start time

The data-logger can be activated by unplugging the RS232 connector from the meter, by a signal higher than the trigger level

#### **RS232 Interface**

Because of the large amount of power consumed by the RS232 interface, remote control operation of the X-2000 is not recomexpected for the different operation modes (see specs.). or by a start date and time. On

divided by the calculated memory requirements. The battery

capacity should be checked

against the current consumption

consumption to only 5  $\mu$ A.

disconnection from the computer a LED flashes and confirms the set-up is active.

mended. RS232 connection should only be made for initialization or data read-out and disconnected when not in use.

tions are based on the current version of the X-2000 and optionally supplied Gigahertz-Optik software. A complete description of the interface and command list is supplied with the meter which allows skilled operators to write their own software as well.







dependent slew rate of the signal amplifier must be considered as

 $+85^{\circ}$ 

to 30 ms

ina time!

well as the gain switching time. If a maximum sampling rate is required, manual range setting and using one detector only is recommended.

and the start/stop time of the

measurement and also the data

read-out transfer via the RS232

interface. The following descrip-

start and stop time. Initialization

which allows sampling of the

operating temperature condition

in field service applications. The

measurement range is -30 to

is done via the RS232 interface.

**Gigahertz-Optik** 

85 mm

# X-2000 Specifications & Ordering Information

# Specifications:

Measureme	ent Ranges (typ. \	/alues)					
UV-A Irradia	ance	50 nW/cm <sup>2</sup> to 180 mW/cm <sup>2</sup> with max. 1 nW/cm <sup>2</sup> resolution					
UV-B Irrad	iance	165 nW/cm <sup>2</sup>	165 nW/cm <sup>2</sup> to 670 mW/cm <sup>2</sup> with max. 3.3 nW/cm <sup>2</sup> resolution				
ACGIH Irra	diance	500 nW/cm <sup>2</sup>	500 nW/cm <sup>2</sup> to 2000 mW/cm <sup>2</sup> with max. 10 nW/cm <sup>2</sup> resolution				
Erythema Ir	radiance	165 nW/cm <sup>2</sup> to 670 mW/cm <sup>2</sup> with max. 3.3 nW/cm <sup>2</sup> resolution					
ACGIHskin	Irradiance	UV-A : $25 \mu$ W/cm <sup>2</sup> eff. to 0,1 mW/cm <sup>2</sup> eff. with max. 0,5 $\mu$ W/cm <sup>2</sup> eff. resolution					
			UV-B/C: 50 µW/cm <sup>2</sup> eff. to 0,2 W/cm <sup>2</sup> eff. with max. 1nW/cm <sup>2</sup> eff. resolution				
Internal Ter	•	-30°C to +85	5°C, ( -22 to 185°F ), max	x. resolution 1/10°C			
Data-Logg							
	rage Capacity	1.042.944By	tes (1 Mb)				
,	equirements for	Status		1 Byte			
Logger Dat	.a.	One detector		3 Byte			
		Two detector	ſS	6 Byte			
		Internal temp	perature	2 Byte			
		Voltage inpu	t*	2 Byte			
Logger Dat	a Sample Rate	sleep mode	off	5 ms to 1.984 s			
		sleep mode	on	1 s to 127 min			
Power Con	sumption	In Operation	tion 5 mA (at 1.3 V)				
		Flash Writing	h Writing 200 mA for 20 ms				
		Sleep Mode		5 µA			
		RS232 Conn	ected	16 mA			
General To	echnical Data:						
Max. Numb	per of Detectors	2					
Measureme	ent Ranges	6 (max. values 200 pA – 20 μA)					
Integration	Time	1ms - 2s (current signal only, see slew-rate in gain range specification)					
Calibration	Data	Max. 255 data sets for each current input					
Voltage Me	easurement	1 input (default gain setting: 100). Not activated in standard models.					
Interface		RS232, 8D, 1S, N; Baud rate: 57600 or 9600					
Operating \	Voltage	1.0 to 1.6 V (optional input 1.8 to 3.2 V, not activated in standard version)					
Operation 7	Temperature	5 to 45°C (41 to 113°F) recommended, -20 to 70°C (-4 to 158°F) with reduced battery life time and accuracy					
Size / Weig	ht	85 mm x 46 mm x 23 mm / 60 g (3.4 x 1.8 x 0.8 in / 0.13 lb)					
Battery		type N (model "Lady")					
Software Fi	unctions		/ NT4.0 / XP; programm (e.g. by Excel).	able data-logger, programmable	start time; logger data in "CSV" format for		
Range Sp	ecifications				Dimensions:		
Range* (A/V)	Max. Input Value* max.	Slew-Rate* (10 - 90%)		offset compensation) ±( % of reading + % of range),	46 mm		
1x10-5	20.00 µA	3 ms	0.2	2 % + 0.05 %			
1x10-6	2.000 µA	3 ms	0.2 % + 0.05 %				

(A/V)	value" max.	(10 - 90%)	Tyear, $23 \cup \pm 5 \cup \pm (\% \text{ or reading } + \% \text{ or range}),$	
1x10-5	20.00 µA	3 ms	0.2 % + 0.05 %	
1x10-6	2.000 µA	3 ms	0.2 % + 0.05 %	Gi: ahertz-Optik X20004
1x10-7	200.0 nA	3 ms	0.2 % + 0.05 %	UV-Monitoring Dosimeter
1x10-8	20.00 nA	3 ms	0.2% + 0.05 %	
1x10-9	2.000 nA	30 ms	0.2 % + 0.05 %	Erythem UV-A
1x10-10	200.0 pA	30 ms	0.2 % + 0.05 %	$\mathbf{O}$
*electronic	specifications			

<b>Ordering Inform</b>	Ordering Information				
OS-X2000	Software for initialization and data read-out of the X-2000 via RS232.				
X-2000-1	UV-Erythema instrument including BHO-06 hard case, battery, RS232 interface cable and handbook				
X-2000-2	ACGIH and UV-A instrument including BHO-06 hard case, battery, RS232 interface cable and handbook				
X-2000-3	UV-A instrument including BHO-06 hard case, battery, RS232 interface cable and handbook				
X-2000-4	UV-Erythema and UV-A instrument including BHO-06 hard case, battery, RS232 interface cable and handbook				
X-2000-5	UV-A and UV-B instrument including BHO-06 hard case, battery, RS232 interface cable and handbook				
X-2000-6	UV-C (254 nm) instrument including BHO-06 hand case, battery, RS232 interface cable and handbook				
X-2000-7	ACGIH <sub>Skin</sub> (250 to 325 nm & 325 to 400 nm cell) instrument with hard-case, battery, RS232 interface cable and handbook				

# 🕒 Gigahertz-Optik

# Optometers & Instruments - Page 41

# P-2000 2-Channel Bench-top Optometer

- © Two Channel Bench-top Optometer for Laboratory, Quality Control and Production
- © Universal Use in Any Light & Optical Radiation Measurement Application
- © Calibration Data Connector for faultless Detector Exchange
- © Measurement of DC, AC and Flash Signals
- © Signal Range from 0.1 pA to 2 mA
- © Adjustable Integration Time, 100 µs to 6 s
- © CW, Flash Energy, Dose, Data-Logger, RS232, IEEE488 Operation Mode
- © Analog Output
- © Optional Window Software

#### Associated Parts / Service:

Chapter Detector Heads Chapter Integrating Spheres Chapter Calibration

The P-2000 Optometer is an efficient dual-channel instrument designed for multipurpose use in any photometric, radiometric, transmittance, reflectance, absorbance application.

It offers many high-level technical features combined with a brilliant display and several different measurement modes.

These functions and the possibility of remote control operation by two different interfaces enable the P-2000 for the universal laboratory use as well as for process control integration.

#### Calibration data connector:



An unique feature of the P-2000 is its detector head calibration data connector. All data pertaining to a de-

tector including the model and serial number are stored in the coupler. When connected to the meter, this data is automatically transmitted and the system is ready to go. This guarantees faultless handling of the instrument when used with any number of different detector heads as it is usual in laboratory use.

#### Large dynamic range:



The P-2000's wide signal range of 0.1 pA to 2 mA covers the dynamic range of most current semiconductor photodiodes for nearly unrestricted use in any light measurement application.

#### 2 Signal Channel

The two signal channels do allow the connection and parallel operation of two detectors. This allows the use of the P-2000 in application with extended wavelength laser power measurements, dual wavelength-band measurements, attenuation measurements with variable reference e.g.



#### Variable measurement time:

Each channel of the P-2000 offers a fast signal input with 2 to 10 ms slew-rate (gain depending). The fast sample rate of  $100\mu$ s allows the use of the P-2000 as a fast single channel data logger. The integration time is adjustable by average calculation of up to 6 sec. This is an other key feature for individual application set-up's.

#### Precise measurements:

The P-2000 offers a high linear 12bit ADC input with 8 manually or automatically selected gain ranges. The max. error within this large dynamic range 0.2 %.

#### Remote control:

P-2000

Gigahertz-Optik

Optometer

A bi-directional RS232 serial interface and the IEEE488 interface allow external remote control operation. Optional Windows based software is available for a quick turn-key solution via the RS232 interface. The complete command set supplied in the meters manual allows the user to develop his own program.

#### Process integrating:

In combination with the optional available relay switch board the P-2000 is the right tool for process control with low-ok-high indication. The menu controlled set-up of the limiting values is simple.



#### Multiple applications:

The P-2000 can be combined with most of GO's detector heads for photometric and radiometric measurement quantities.

#### Many functional modes:

The unit's many functional modes of operation includes CW, dose, pulse-energy, datalogger measurements and many more. If the sixteen different operation modes should not include the one of your need we do offer custom design modifications.

#### **Re-Calibration**

For re-calibration by calibration labs or within industrial processes the factory programmed calibration factors can be changed with the OS CAL software via the RS232 interface. The IEEE488 interface allows external remote control.

	end eGO
nisi number: 1020	0x check 100x
CONNECTED	
sturement   data logger   Setup	
auto mesourement	
stari stop	measure
Channel 1 🕫 enabled	Channel 2 🕫 ended
maximum 2 54460e 05 W/m2 Cear	maximum 1.10600e-13A Clear
	resinum 1.10600e-13A Clear minimum 1.10600e-13A Clear
store minimum 2 54480p 05 W/m2 Dear	l'store
store minimum 2 5480e 05 W/m2 Cess	tore neimm 110600e12A Clear
store minimum 2 54480p 05 W/m2 Dear	rinimum 1.10600e 13 A Clear



# P-2000 Applications

Because of it's multiple functional modes and high-level specifications, the bench-top meter P-2000 is the right instrument for laboratory and process applica-

#### **Universal Light Meter**

Even in the computer dominated world instruments with large size, brilliant display needs to exist. The reasons are all the applications where the operator needs the direct feedback to his operation and

all the stand-alone set-ups. But it's not only the brilliant blue back-lighted display. It's the combination of high-grade specifications with safe and universal handling which had made the P-2000's to the right choice for many laboratories and production facilities. The calibration data connector for

#### **Photostability Testing**

The current ICH (International Conference for Harmonization) guidelines specify that drug and drug products must be photo-tested to ensure that exposure to light does not cause photochemical degradation of the product or packaging. The product under test must receive a measured dose of both UV-A (200 watt-hours per square meter) and Visible (1.2 million lux-hours) optical radiation exposure. This requires both radiometric and photometric measurements in terms of illuminance in lux and UV-A (315 to 400 nm) irradiance in W/m<sup>2</sup> multiplied by exposure time in hours

tions. GO's wide range of detector heads enables the P-2000 to be used in many different photometric and radiometric applications. It's two signal channels ex-

#### Optometer P-2000

#### +88.91× LUX\_ +0.11uW/cm2

3717

example ensures that you will never forget the up-date of the meter, if you change to an other detector head. You can also use the meter while one of the detector heads is out for re-calibration. New detector heads, purchased years later than the meter are just plugged in and work. Multiple operation function modes ensure highest flexibility in the use of the P-2000. And last not least



With UV-3717-2 and VL-3701-2 Gigahertz-Optik offers a UV-A irradiance and photometric illuminance detector head which fulfills the requirements for the evaluation of the UV-A and photometric exposure in photostability testing application. The P-2000 is the effective meter to operate both detectors in parallel

#### Luminous flux Meter for Light-guides, Endoscopes & LED's

Spot sources are light sources, which emit directional in one axis. Typically the light beam has a convergent or focused shape. The measurement of the luminous flux in Im of such light sou-

> rces requires a detector head which collects all light independent of beam shape, beam diameter and spot inten

sity. Integrating sphere based photometric detectors are a practical choice for this application. Different sphere diameter offer flexible selection of the measurement port diameter and max. power level. The spheres integrating function makes the measurement independent from the beam shape. Combined with a photometric corrected detector head, such as model VL-3701 and the P-2000 optometer a precise instrument for luminous

intensity measurement is given. Calibration standard lamps and software is offered for recalibration by the enduser in the case of frequent use of the instrument. tend the application range by attenuation, transmission and reflectance measurements. The following page offers typical P-2000 application's. Our **Guide to**  Light Measurement's available in our catalogue and website offers additional tutorial and application notes.



the RS232 or IEEE488 interfaces enables the use of the P- 2000 optometer in remote control operation.

#### Extended Wavelength Range Laser Power Meter

Semiconductor photodiodes offer low noise and high sensitivity, but are limited in the spectral sensitivity range and in high power detection.

Two photodiode, such as a silicon and InGaAs one, can be combined with an integrating sphere and the P-2000 to avoid this limitation.

The integrating sphere does extend the measurement range to high average powers level of up to few-hundred Watt and peak powers up to the kWatt range. The sphere's integration function does allow the parallel use of two diodes in the same beam which will extend the wavelength range from 350 to 1750 nm without the need to replace the detector.

Both can be parallel operated with the P-2000.





Detector Heads for use with P-2000 >> Chapter Detector Heads

## P-2000 Operation Function Modes & Specification

#### **Operation Functional Modes**

Because of it's unique electronic design and it's powerful microprocessor the P-2000 optometer is more than just a simple instrument for light intensity readings.

#### CW Measurement (Ch1 or Ch2 or Ch1&2)

CW mode is used to measure continuous DC or AC signals with the selected integration time from 100  $\mu$ s to 6s. Beside the measurement value and meas-

#### CW Offset (Ch1 or Ch2 or Ch1&2)

A constant offset value, such as given by ambient light, can be urement value.

#### CW Minimum or CW Maximum (Ch1 or Ch2 or Ch1&2)

Together with the measurement value the min. or max. value reached during the measurement period is displayed. during a measurement period (erased

the gain dependent slew-rate

(see tabular below) can be

function 'set-up/pulse measure-

ment time'. The time constant C

for daylight (0.1 s) and night time

observation (0.2 s) can be se-

lected in the menu function 'set-

up/IF time constant.

Sixteen different operation func-

tion modes in combination with a

variable measurement parameter

set-up function makes the P-

2000 to on of the most flexible

urement quantity the connected

detector/selected wavelength is

shown in the lower line of the

display. Manual and auto-rang-

#### Peak Minimum or Maximum, Peak to Peak (Ch1 or Ch2)

This modes allow to analyse the signal stability within the selected integration interval e.g. flicker of light sources. The min., max. or p-p values are displayed to-

#### I-Effective (Ch1 or Ch2)

Evaluation of the effective luminous intensity of a single light flash according to the Schmidt-Clausen method. The measurement is manually started with the 'run' botton. The integration time can be selected in the menu

#### Pulse Energy (Ch1 or Ch2)

Measurement of the energy of single pulses or a pulse chain within the selected measurement time. The measurement time is selected in the menu function 'set-up/pulse measurement

Pulse Offset (Ch1 or Ch2)

A offset value, such as given by ambient light, can be subtracted from the I-Effective and Pulse Energy measurement value. 'Static Offset' does subtract a

#### **Default Initiation**

Resets all parameters to the default condition.

#### Specification:

range operation 'UL/ OL" (under/ over-load) is displayed if a gain change is necessary.

Offset' does subtract the actual measured value before the pulse measurement is started. Selection in menu 'pulse offset'.

meter available. Because of that it's in manual and remote control use in process control, long-time stability search, service, teaching and R&D application. This page

will show the available function at the dead-line of this catalog. If you do not find your function mode pls. ask for up-dates and custom modification.

# Ratio relative (%), log. (dB), factor (Ref. Ch1 or Ch2)

Measurement of the ratio betplayed as relative ration (%) or ween a reference value and the logarithm ratio/attenuation (dB or actual measurement value. DisdBm) or ratio factor. Reference (Ch1 or Ch2) The reference value is used for be stored as reference value. A manual entered value can be ratio measurements. The ref. value can be set to 1 used as reference. with the selected quantity such The reference value '1.000 mW' us 1 W, 1 A. can be used to measure the A CW measurement value can attenuation in dBm. Hold (Ch1 & Ch2) Beside the actual measurement 'frozen' by pressing 'reset' butvalue a current reading can be ton. CW Level Check (Ch1 or Ch2 or Ch1&2) Compares the measured CW vathe RS232. The relay board Plue with stored pre-set lower and 9710Z-02 can be remote conupper limit values. The actual trolled to indicate the status by measurement value and it's staexternal lamps or integrate the tus is displayed. The limit values meter in process control applica-

tion

#### Dose (Integrated Energy) (Ch1 or Ch2 or Ch1&2)

Measurement values are accumulated with a logger rate of 1 s and displayed a dose. The measurement can be manually started and stopped or be auto-

can be entered manually or via

matically stopped at a max. dose measurement time (1 s to 1,000 h) or a max. dose value. The actual measurement status ca be displayed

RS232 or for the IEEE488 inter-

#### Automatic Data Logger (Ch1 or Ch2 or Ch1&2)

Up to 12,288 measurement valpling rate of 0.1 to 6000 s. ues can be stored with a sam-

#### Manually Data Logger (Ch1 or Ch2 or Ch1&2)

Up to 150 individual data records be stored by pressing the run (meas. values & parameters) can button.

face.

#### **Manual Calibration Data**

Instrument set-up for remote

Individual calibration correction data can be manually entered.

#### control operation either for the

**Remote Control** 

#### IEEE488 address

Sets the address for the IEEE488 communication.

Range and U	Range and Uncertainty Specification						
Range (A/V)	Range max. signal	Slew-Rate (10-90%)	Error (with offset compensation) 1 year 23°C +/-5°C +/-(% of reading + % of range)	Gain (A/V) Analog Output			
1 x 10 <sup>-3</sup>	2.000 mA	2 ms	0.2 % + 0.05 %	1 x 10 <sup>-3</sup>			
1 x 10 <sup>-4</sup>	200.0 µA	2 ms	0.2 % + 0.05 %	1 x 10 <sup>-3</sup>			
1 x 10 <sup>-5</sup>	20.00 µA	3 ms	0.2 % + 0.05 %	1 x 10 <sup>-5</sup>			
1 x 10⁻ <sup>6</sup>	2.000 µA	3 ms	0.2 % + 0.05 %	1 x 10 <sup>-5</sup>			
1 x 10 <sup>-7</sup>	200.0 nA	4 ms	0.2 % + 0.05 %	1 x 10 <sup>-7</sup>			
1 x 10 <sup>-8</sup>	20.00 nA	4 ms	0.2 % + 0.05 %	1 x 10 <sup>-7</sup>			
1 x 10 <sup>-9</sup>	2.000 nA	10 ms	0.2 % + 0.05 %	1 x 10 <sup>-9</sup>			
1 x 10 <sup>-10</sup>	200.0 pA	10 ms	0.2 % + 0.05 %	1 x 10 <sup>-9</sup>			

# constant value. 'Continuous

time'. The measurement is started with the 'run' botton. In auto-

by pressing 'reset' button). gether with the CW average value. Only signals longer that

subtracted from the CW meas-

ing operation.

measured.



# P-2000 Specification & Ordering Information

### Specification:

Signal Input						
		Two photosympatts voltage converter emplifier	with following voltage to voltage amplifier (v10). O decode standed go			
ranges w			with following voltage to voltage amplifier (x10). 8 decade stepped gain 0 mA to 200.0 pA . Manual or automatic range switching. One 12 bit s.			
Signal Processin	g	A/D converter with 100 $\mu$ s time interval. Longer integration (100 $\mu$ s to 6s) through averaging of multiple measurements.				
Frequency Range	Э	Signal conversion from 0.166 Hz (6s integration	time setting) to >300 MHz.			
Zero Setting		Gain independent offset subtraction of unwanted	d ambient light signal.			
Detector Connec	tor	9 pin DSUB-socket . Detector heads with calibra	tion data connector (type –2).			
Function		·				
Parameter Setting	gs	Menu controlled parameter set-up. Retention of	the last settings in continuous memory. 10 function buttons.			
Measurement Qu	lantity	Ampere calibrated with DKD calibrated current source. Current signal multiplied with calibration correction factor to display absolute photometric or radiometric quantities. Calibration data stored in calibration data connector of the detector heads manually entered into the meter storage.				
Dose Measureme	ent	Integration of the measurement signal with 1 s sampling rate. Adjustable max. measurement time from 1 s to 1000 h. Adjustable maximum dose limit value. Current status display function.				
Data Logger		Storage of up to 12,288 readings. Adjustable sampling rate from 0.1 to 6000 seconds. Manual recording mode. Display of readings stored in the flash Eproms on the display or on computer using the RS232 interface and software.				
Analog Output		Two, gain dependent: 0 - 200 mV or 0 - 2 V (10 k $\Omega$ internal resistance). BNC type sockets				
General		·				
Display		LCD module, LED backlight illuminated, 4 rows x 20 character				
Operating Tempe	erature	5 to 40 °C (41 to 104 ° F) (75 % rel. H, non-condensing). Storage Temperature: 0 to 50°C (32 to 122 °F).				
Dimensions/Wei	ght	230 mm x 215 mm 115 mm / 800 g (9.1 x 8.5 x 4.5 in /1.8 lb).				
Serial Port Setting	gs	RS232 (9600 baud, 8 data bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector				
Power supply		Battery or AC operation. Built-in rechargeable lead battery, 6V,0.5 Ah. Approx 6 h with display illumination. Batter charge under 8 % is displayed. Operation from AC plug-in power supply 230V/50 Hz (other values on request) wit specific U/I recharge characteristic.				
Interface						
RS232		9600 Baud, 8 data bit, 1 stop bit, no parity. TRIAD01 / 5 pin connector with integrated analogue output.				
IEEE488		AH1, SH1, L4, T4				
Detector Head /	Measu	rement Output	Dimension			
Detector Heads	data d	ailable detector heads with -2 type calibration connector. See chapter 'detector heads' to select stector head for your application.	220 mm			
Data Connector         Storage of sensor data such as detector model num ber, serial number, calibration data . Calibration dat of integral sensitivity or spectral sensitivity with or without accessory. Selection of the calibration data of the wavelength in the menu function of the P-9710 Automatic data transfer if detector head is connected		erial number, calibration data . Calibration data egral sensitivity or spectral sensitivity with or ut accessory. Selection of the calibration data or avelength in the menu function of the P-9710.	Cigeners Optite Optometer			



## **Ordering Information**

to the meter.

Optometer with gain dependent slew-rate, rechargeable battery with plug-in power supply and manual
All Gigahertz-Optik detector heads with -2 type calibration data connector (example VL-3701-2)
RS232 Interface Cable to connect P-9710 to a PC or P-2000Z-02 Relay Motherboard.
Relay Motherboard (power supply and housing not supplied)
Adapter cable to connect detector with BNC-type connectors to P-2000
Adapter cable to connect detector with calibration data connector (-2) to meters with BNC-type socket input
Software for remote control of the P-2000-1, including OS-CAL.
Software to enter calibration data via the P-2000 meter into -2 type data connector
Hard -shell Case to carry and store the P-2000 with accessories
Hard -shell Case to carry and store the P-2000 with accessories

# Gigahertz-Optik

# Optometers & Instruments - Page 45

# P-9801 8-Channel Synchronous Optometer

- © 8-channel Bench-top Meter for Laboratory Use and Application Integration
- © Universal Use in any Light & Color Measurement Application
- © Synchronized Operation of up to 8 Detectors or two CT-37 Color Detectors
- © Measurement of DC and AC Signals
- © Wide Detector Signal Dynamic Range from 0.1 pA to 2 mA
- © 100 µs Fast Sampling Rate
- C Adjustable Integrating Time from 1 ms to 10 s
   C CW, Dose, Data-Logger, Color, ext. Trigger
- RS232, IEEE488 Operation Mode © Optional Windows Software

#### Associated Parts / Service:

Chapter Detector Heads Chapter Integrating Spheres Chapter Calibration

There are many applications for *multiple detector head arrangements* in light measurement. Examples include luminous color measurements of light sources



3701, profiling or monitoring of irradiance dose for process control at various locations in UV curing or for multi-wavelength radiometry for UV-A, UV-B, VIS and NIR irradiance measurements.



**Desirable features of multichannel light meters** used for these jobs would include:

- simultaneous measurement of all detector channels
- wide detector signal dynamic range
- short and variable measurement time
- •fast, multi-channel datalogging

remote control operation

**The P-9801** offers all of these features. It is a highly efficient eight-channel optometer designed for multipurpose use in any photometric, radiometric and colorimetric application.

#### Eight Identical A/D Channels Eight identically built photocur-

rent-to-voltage amplifiers and eight 12 bit highly linear analogto-digital converters (ADC) enable signal digitization of the 8



signal amplifiers at exactly the same time.

#### Wide Dynamic Range:

Each channel's wide 0.1 pA to 2 mA signal range covers the dynamic range of most current semiconductor photodiodes for nearly unrestricted use in any light measurement application.

#### Fast Measurements:

Each channel offers a slew rate of 2 to 10 ms (gain dependent) allowing fast signal detection of events like the switch-on characteristic of light sources or the pulse energy in UV polymerization processes. A quick 100  $\mu$ s sample rate enables the P-9801 to work as a fast eight channel data logger with >5k sample storage capacity for each channel. In low light level applications the measurement process time can be increased up to 6 s

through multi-sampling and calculated averaging of signal.

#### Precise Measurements:

1666

The 8 manually or automatically selected amplifier gain ranges are calibrated using a traceable current source for a maximum linearity error of 0.2 %. The 12 bit ADC (resolution increases to 14 bit for longer measurement times) offers optimum linearity.

#### Remote Control:

A bi-directional RS232 serial and IEEE488 interface allows external remote control.

Optional Windows based soft-



ware is available for a quick turnkey solution or user generated programming is possible using the complete command set supplied. Adjustment of the factory programmed calibration factors can be accomplished using OS-CAL software (optional).

#### System Integration:

The P-9801 is suitable for integration into other equipment with features like 19" rack mounts.

#### Metal-shielded Housing

A high quality metal housing offers best EMV shielding for applications in sensitive ambient environments.

#### **Multiple Applications:**

The P-9801 is compatible with most of GO's detectors covering any photometric, radiometric and colorimetric measurement quantity.

#### **Numerous Functions:**

The unit's many modes of operation include CW, dose, data-log and external trigger.



# Page 46 - Optometers & Instruments

measurement and sampling time

makes the P-9801 the right tool

for any photometric, radiometric

and colorimetric application. All

single and multi-cell Gigahertz-

Optik detectors can be used with the P-9801. Plus RS232 and

color

sory

cannot

quantities such as current or

temperature. The comparative

instrument used is the human

eye. In 1931 the Commission

Internationale de l' Eclairage

(CIE) recommended, for the

unambiguous determination of

colorimetric measures, the use of

3 spectral evaluation functions x

luminous flux & radiant power

mon radiometric application

involves checking the blocking

efficiency of UV and IR (heat)

Multi-wavelength range measurements are easily performed using multiple and/or different kinds of detector heads connected to the P-9801. Using the 4-cell design CT-3701 color

detector head as the base unit,

other input components can be

attached to it to fulfill the measurement geometries for different

measured at several points to

tensity

blocking filters.

nal figures and that

these dimensional fi-

gures can be meas-

ured. In this context.

color measurement is

a comparison of one

since colors, as sen-

be

back to other physical

with another,

impressions,

traced

# P-9801 Applications

Featuring simultaneous operation of up to eight detectors, the P-9801 is one of the most powerful optometers available today. Additional high end specifications such us large and linear signal dynamic ranging, fast

#### **Luminous Color Measurements**



Color sensations are human sensory impressions and color measurement technology must express them in descriptive and comprehensible quantities.

Colorimetry is the study of the dimensional relations between colors. It assumes that colors can be described by dimensio-

#### Luminous Color Measurements Combined with Photometric & Radiometric Quantities

Along with measuring the luminous color and color temperature of light sources, photometric & radiometric information may be required such as:

- illuminance & irradiance
- luminance & radiance



#### High-speed Eight-channel Irradiance Data-logger



If the design of a radiation source ensures a uniform irradiation of a surface area, the irradiance only needs to be measured at one point to control intensity. If source uniformity is not the known, the irradiance must be

ensure uniform irradiance over the surface area. Also, if the irradiation exposure is very short and if the distance from the surface area to the light source is not constant multi-point irradiation is needed. In three-dimensional UV curing applications the irradiance dose depends on the sample to UV source distance and the irradiation time. To measure the irradiance dose uniformity in these applications a multichannel simultaneous sampling of signal with data-logging capa-

• standard diffuser (illuminance) · luminous intensity & radiant in-• front lens (luminance) The wavelength range of interest • integrating sphere (luminous for typical radiometric quantities flux) spans the UV to the NIR. A com-

applications :

 steradian tube (luminous intensity)

IEEE488 interfaces enable inte-

gration of the P-9801 in process

control applications. This page

describes a few typical P-9801

Our Light Measurement Guide

available in our catalog and

 $(\lambda)$ ,  $y(\lambda)$  and  $z(\lambda)$ , derived from

the measurements made by

Guild and Wright for a 2° field of

view in humans with normal color

vision. For many color measure-

ment tasks it is important to

determine the color temperature

of luminous objects. According

to DIN 5031-P.5, the color tem-

perature t<sub>c</sub> of a radiator requiring

characterization is the tempera-

ture of a Planck's radiator at

which it emits radiation of the

same color type as that of the

radiator being characterized. The

P-9801 in use with one or two

CT-3701 luminous color detector

heads allows the measurement

of color (x/y and u'/v' values) and

color temperature of self emitting

applications.

Integrating sphere based measurement systems can be built for both directional (spot) and non-



website offers additional tutorial and application notes for the Measurement of Light and Measurement with Light.

light sources. The CT-3701's four cell detector head design accurately measures high color temperatures or predominantly blue light sources. A small diameter cosine corrected measurement aperture avoids errors caused by non uniform illumination. Simultaneous operation of the four cells allows fast, remote controlled color measurements in production processes or fast sampling rate data-logging to measure the switch-on characteristic of and

lamps other events.

directional (flood) lamps. Several P-9801s, each with (2) CT-3701 plus steradian front tubes can be operated in parallel via the IEEE488 bus to control the luminous color and luminous intensity distribution of light sources.



Commonly used radiometric detectors are the UV-3717 (UV-A) & RW-3704 (800-1100 nm).

bility is needed to document the irradiationtime profile. The P-9801 can operate

up to eight RCH-type detectors to measure the irradiance of high-power UV-sources used in UV curing processes. This model detector offers a low profile for close to the sample surface measurements. The P-9801's

built-in data-logger allows stand alone use or it can be used with P-9801-RP software the



(optional) for remote control operation.

Accessories for P-9801 >> Chapters: Light Detector, Integrating Spheres





# P-9801 Operation Modes & OS-P9801 Software

#### **Operation Modes**

Because of it's fast and precise eight-channel amplifier electronics and 16 bit microprocessor the P-9801 optometer is one of the most powerful optometers available. Several useful func-

#### **CW Measurement**

CW mode is used to measure continuous DC or AC signals at a user selected integration time from 1 ms to 10 s. Readings and

#### CW Offset

A constant offset value, such as an ambient light level, can be

#### Ratio Relative (%), Relative log. (dB), Relative factor

Measurement of the ratio between a reference value and the actual measurement value. Dis-

#### Reference

The reference value is used for ratio measurements and can be set to 1 with the selected unit such us 1 W, 1 A for example. A CW measurement value can

be stored as reference value.

#### **Dose (Integrated Energy)**

Measurement values are accumulated and displayed as dose. The measurement can be manually started and stopped or be automatically stopped at a max.

#### Data Logger

Up to 5,957 measurement values per channel can be stored at a

#### Fast Data Logger

Up to 5,957 measurement values per channel can be stored at a

#### **Default Initialization**

OO Doood O the

Allows re-set of meter to the standard parameter and mode

tions and user adjustable meas-
urement parameter set-up
makes the P-9801 one of the
most flexible as well.
Multiple functions, features plus

and RS232 interfaces IFFF

measurement units of all eight channels are displayed. User selectable manual or auto-ranging operation.

measured and subtracted from

the CW measurement value.

played as relative ratio (%) or logarithm ratio/attenuation (dB or dBm) or ratio factor.

A manually entered value can be used as reference.

The measurement value of an other channel can be used as reference (dynamic reference).

dose measurement time or a max. dose value. The actual measurement status can be displayed

sampling rate of 0.1 to 6000 s.

sampling rate of 2 to 100 ms in manual range mode.

set-up as supplied by the factory.

make the P-9801 ideal for remote control operation in process control, high-speed multichannel data-logging, R&D and many more applications. This page describes the various functions of the unit. Contact the factory to discuss customized units with other user specified operational modes or complete custom application solutions.

ble. The trigger input of the P-9801 can be used to check the

operating temperature of one or

two CT-3701 detector heads.

The display flashes if temp.

If only one color detector is used,

the other four channels are avail-

able for other detectors. These

four readings are displayed to-

fast measurements or to monitor

readings at some constant level.

gether with the color values.

drops out of operating range.

#### **Color Measurement**

Up to two color detector heads can be simultaneously operated with the P-9801 (channel 1 to 4 and 5 to 8). Color temperature, chromaticity values x/y or u'/v" and photometric quantity (illuminance, luminance, luminous intensity or luminous flux) are displayed at one time.

Adjustment of factory calibration factors by the end-user is possi-

#### Manual & Auto ranging

Manual or auto ranging operation can be user selected. Manual ranging is recommended for

#### Self Calibration

Calibration data for a user detector can be adjusted against a known calibration or in-house standard. The measured values

#### Analog Output

The P-9801 offers one analog output. One of the 8 channels

#### **Display Digits**

With longer integrating times the ADC resolution will increase up to 14 bits. In this case the dis-

#### **Remote Control**

Instrument can be set-up for remote control operation using

#### IEEE488 Address

Sets the address for the IEEE488 communication.

of the standard are used to calculate new calibration data.

can be switched to the analog output.

played measurement value resolution can be increased to maximum of 5 digits.

either RS232 or IEEE488 interface

801 Software Ver. 1.1		×	La 9801 Software Ver. 1.1	
Measurement Mode ingle kogen Rogen High speed Codee PC-kogger PC-kogger	☐ Trigger Input enabled	High Speed Log Cycle C 2 ma S ma C 10 m S 50 m C 100 m C 100 m No of Logger cycles 1	Measurement Mode indige kogen kogen <u>BC-Sogen</u> <u>PC-Sogen</u> <u>PC-Sogen</u> <u>I 0</u> indigene (HH MM-SS) <u>I 2598 56</u> indigene (HH MM-SS) <u>I 2598 56</u> indigene (HH MM-SS) <u>I 2598 56</u> indigene (HH MM-SS) <u>I 10</u> indigene (HH MM-SS) <u>I 10</u> indig	
1	open save file		open save file	
	enable measurement			
				1

# P 9801 Specifications & Ordering Information

# Specifications:

-	d Uncertainty	Specifications		
Range (A/		x. Slew-Rate (10 - 90%)	Error (with offset compensation) 1 year, 23°C ±5°C ±(% of reading + % of range),	Gain (A/V) Analog Output
1x10 <sup>-3</sup>	2.000 mA	2 ms	0.2% + 0.05%	1x10 <sup>-3</sup>
1x10 <sup>-4</sup>	250.0 μA	2 ms	0.2% + 0.05%	1x10 <sup>-4</sup>
1x10⁻⁵	25.00 μA	3 ms	0.2% + 0.05%	1x10 <sup>-5</sup>
1x10 <sup>-6</sup>	2.500 µA		0.2% + 0.05%	1x10 <sup>-6</sup>
1x10 <sup>-7</sup>	, 250.0 nA		0.2% + 0.05%	1x10 <sup>-7</sup>
1x10 <sup>-8</sup> 25.00 nA			0.2% + 0.05%	1x10 <sup>-8</sup>
1x10 <sup>-9</sup>	2.500 nA		0.2% + 0.05%	1x10 <sup>-9</sup>
1x10 <sup>-10</sup>	250.0 pA		0.2% + 0.05%	1x10 <sup>-10</sup>
Signal Inp		101113	0.270 + 0.0070	1710
Detector In	put	gain ranges with max. gai bit ADC with up to 14 bits a		c range switching. Eight
Signal Proc Frequency	,		time interval. Longer integration (1 ms to 10 s) through averaging 66 Hz (6s integration time setting) to >300 MHz	or multiple measurements
Zero Setting	g	Gain independent offset su	ubtraction of unwanted ambient light signal.	
Detector Co	0	•	heads with BNC connector (type –1).	
Functions				
Parameter	Settings	Menu controllad parameter	r set-up. Retention of the last settings in continuous memory. 10 fi	
	ent Quantity	Amperes calibrated with E display absolute photomet tector heads manually enter Setting of the max. integra	DKD calibrated current source. Current signal multiplied by cali ric or radiometric quantities. Calibration data stored in calibration ered into the meter memory. Ition time for all channels, or the max. dose that will end the dos	bration correction factor n data connector of the d
<u></u>		•	est of the current status of the dose measurement	
Data Logg Color Meas		Signal inputs 1-4 and 5-8 flux phi and the color temp	0.0 s or fast sampling in steps between 2 ms to 100 ms; max. 595 for detectors A and B. Calculation of the color values x/y or u'/v' perature $T_c$ . "lamp selection" for adaptation to different types of la ine for automatic compensation of the stored and measured cal ing via trigger input	, illuminance E or luminou amps, up to 8 of which ca
Trigger Inp	ut		gered (started) by external event using Trigger Input	
Analog Ou			from the assigned input amplifier	
General	iput	Dite sector, output signal		
General			und illumination (switchable), 160x80 pixels	
Display	<b>F</b>	1.3.		
Display Operating <sup>-</sup>	Temperature	+5 to +40 °C (+41 to +10	4°F)	
Display Operating <sup>-</sup> Dimension	s/Weight	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mm	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb)	
Display Operating <sup>-</sup> Dimension Serial Port :	<b>s/Weight</b> Settings	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mm RS232 (9600 baud, 8 data	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector	
Display Operating <sup>-</sup> Dimension Serial Port s Power supp Electromag	<b>s/Weight</b> Settings	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mr RS232 (9600 baud, 8 data 6.5 - 7.5 VDC / 1A; cavity p 5.5/2.5 mm, inner conductor	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector lug 5.5/2.5 mm, Plug-in AC power supply unit 230 V/50 Hz; 7.5 VI or positive. lity is assessed in accordance with EN 61326-1 Class B (noise en	
Display Operating <sup>-</sup> <b>Dimension</b> Serial Port s Power supp Electromag patibility	s/Weight Settings oly	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mr RS232 (9600 baud, 8 data 6.5 - 7.5 VDC / 1A; cavity p 5.5/2.5 mm, inner conductor Electromagnetic compatibil	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector lug 5.5/2.5 mm, Plug-in AC power supply unit 230 V/50 Hz; 7.5 VI or positive. lity is assessed in accordance with EN 61326-1 Class B (noise en	
Display Operating <sup>-</sup> Dimension Serial Port s Power supp Electromag patibility Interface	s/Weight Settings oly netic Com-	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mr RS232 (9600 baud, 8 data 6.5 - 7.5 VDC / 1A; cavity p 5.5/2.5 mm, inner conductor Electromagnetic compatibil noise immunity for "continu	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector olug 5.5/2.5 mm, Plug-in AC power supply unit 230 V/50 Hz; 7.5 VL or positive. lity is assessed in accordance with EN 61326-1 Class B (noise en jous supervised operation"	
Display Operating <sup>-</sup> Dimension Serial Port S Power supp	s/Weight Settings oly netic Com- RS232, adjust IEEE488 with sum calculation mands (Hexa	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mr RS232 (9600 baud, 8 data 6.5 - 7.5 VDC / 1A; cavity p 5.5/2.5 mm, inner conducto Electromagnetic compatibi noise immunity for "continu able baudrate 600 - 57600. settable device address; pn; for debugging purposes decimal/ASCII) or measurer	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector olug 5.5/2.5 mm, Plug-in AC power supply unit 230 V/50 Hz; 7.5 VI for positive. liity is assessed in accordance with EN 61326-1 Class B (noise en uous supervised operation" Dimensions optional check- s, received com- nent results can on	nission for "living areas",
Display Operating <sup>–</sup> Dimension Serial Port S Power supp Electromac patibility Interface RS232 IEEE488	s/Weight Settings oly netic Com- RS232, adjust IEEE488 with sum calculation mands (Hexa	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mr RS232 (9600 baud, 8 data 6.5 - 7.5 VDC / 1A; cavity p 5.5/2.5 mm, inner conduct Electromagnetic compatibi noise immunity for "continu able baudrate 600 - 57600. settable device address; on; for debugging purposes decimal/ASCII) or measurer in parallel to remote operati	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector olug 5.5/2.5 mm, Plug-in AC power supply unit 230 V/50 Hz; 7.5 VI or positive. lility is assessed in accordance with EN 61326-1 Class B (noise en Jous supervised operation" Dimensions optional check- s, received com- ment results can	nission for "living areas",
Display Operating <sup>-</sup> Dimension Serial Port S Power supp Electromag patibility Interface RS232 IEEE488 Detector H	s/Weight Settings oly gnetic Com- RS232, adjust IEEE488 with sum calculation mands (Hexa be displayed Iead / Measur eads All det See cl	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mr RS232 (9600 baud, 8 data 6.5 - 7.5 VDC / 1A; cavity p 5.5/2.5 mm, inner conduct Electromagnetic compatibi noise immunity for "continu able baudrate 600 - 57600. settable device address; on; for debugging purposes decimal/ASCII) or measurer in parallel to remote operati	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector olug 5.5/2.5 mm, Plug-in AC power supply unit 230 V/50 Hz; 7.5 VI or positive. lility is assessed in accordance with EN 61326-1 Class B (noise en Jous supervised operation" Dimensions optional check- s, received com- ment results can on BNC connectors.	nission for "living areas",
Display Operating <sup>-</sup> Dimension Serial Port 9 Power supp Electromac patibility Interface RS232 IEEE488 Detector He Detector He	s/Weight Settings oly gnetic Com- RS232, adjust IEEE488 with sum calculation mands (Hexa be displayed Iead / Measur eads All det See cl	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mr RS232 (9600 baud, 8 data 6.5 - 7.5 VDC / 1A; cavity p 5.5/2.5 mm, inner conducto Electromagnetic compatibi noise immunity for "continu able baudrate 600 - 57600. settable device address; on; for debugging purposes decimal/ASCII) or measurer in parallel to remote operati ement Output ector heads with -1 type E hapter 'detector heads' to s	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector olug 5.5/2.5 mm, Plug-in AC power supply unit 230 V/50 Hz; 7.5 VI or positive. lility is assessed in accordance with EN 61326-1 Class B (noise en Jous supervised operation" Dimensions optional check- s, received com- ment results can on BNC connectors.	nission for "living areas", 
Display Operating <sup>-</sup> Dimension Serial Port S Power supp Electromac patibility Interface RS232 IEEE488 Detector H Detector H Detector H	s/Weight Settings oly netic Com- RS232, adjust IEEE488 with sum calculatio mands (Hexa be displayed Head / Measur eads All det See cl tor hea nformation	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mr RS232 (9600 baud, 8 data 6.5 - 7.5 VDC / 1A; cavity p 5.5/2.5 mm, inner conducte Electromagnetic compatibil noise immunity for "continu able baudrate 600 - 57600. settable device address; on; for debugging purposes decimal/ASCII) or measurer in parallel to remote operati <b>ement Output</b> ector heads with –1 type E hapter 'detector heads' to s id for your application.	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector plug 5.5/2.5 mm, Plug-in AC power supply unit 230 V/50 Hz; 7.5 VI or positive. lility is assessed in accordance with EN 61326-1 Class B (noise en jous supervised operation" Dimensions optional check- s, received com- ment results can on BNC connectors. select the detec-	nission for "living areas", 
Display Operating <sup>–</sup> Dimension Serial Port S Power supp Electromac patibility Interface RS232 IEEE488 Detector H Detector H Detector H Detector H	s/Weight Settings oly netic Com- RS232, adjust IEEE488 with sum calculati mands (Hexa be displayed lead / Measur eads All det See cl tor hea nformation Opto	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mr RS232 (9600 baud, 8 data 6.5 - 7.5 VDC / 1A; cavity p 5.5/2.5 mm, inner conducte Electromagnetic compatibin noise immunity for "continu able baudrate 600 - 57600. settable device address; on; for debugging purposes decimal/ASCII) or measurer in parallel to remote operati ement Output ector heads with -1 type E hapter 'detector heads' to sid for your application.	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector plug 5.5/2.5 mm, Plug-in AC power supply unit 230 V/50 Hz; 7.5 VI or positive. lility is assessed in accordance with EN 61326-1 Class B (noise en jous supervised operation" Dimensions optional check- s, received com- ment results can on BNC connectors. select the detec- ug-in power supply	nission for "living areas", 
Display Operating <sup>-</sup> Dimension Serial Port 9 Power supp Electromac patibility Interface RS232 IEEE488 Detector H Detector H Detector H Drdering In D-9801 Detectors	s/Weight Settings oly netic Com- RS232, adjust IEEE488 with sum calculati mands (Hexa be displayed Head / Measur eads All det See cl tor hea nformation Opto All Gi	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mr RS232 (9600 baud, 8 data 6.5 - 7.5 VDC / 1A; cavity p 5.5/2.5 mm, inner conducte Electromagnetic compatibi noise immunity for "continu able baudrate 600 - 57600. settable device address; on; for debugging purposes decimal/ASCII) or measurer in parallel to remote operati ement Output ector heads with –1 type E hapter 'detector heads' to s id for your application.	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector olug 5.5/2.5 mm, Plug-in AC power supply unit 230 V/50 Hz; 7.5 VL or positive. lility is assessed in accordance with EN 61326-1 Class B (noise en jour supervised operation" Dimensions optional check- s, received com- ment results can on BNC connectors. select the detec- ug-in power supply Is with BNC-type (-1) connector	nission for "living areas",
Display Operating <sup>–</sup> Dimension Serial Port S Power Supp Electromac patibility Interface RS232 IEEE488 Detector H Detector H Detector H P-9801 Detectors DS-P9801-F	s/Weight Settings Dy Inetic Com- RS232, adjust IEEE488 with sum calculation mands (Hexa be displayed Iead / Measur eads All det See cl tor hea nformation All Gi RP Softw	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mr RS232 (9600 baud, 8 data 6.5 - 7.5 VDC / 1A; cavity p 5.5/2.5 mm, inner conducte Electromagnetic compatibi noise immunity for "continu able baudrate 600 - 57600. settable device address; on; for debugging purposes decimal/ASCII) or measurer in parallel to remote operati ement Output ector heads with -1 type E hapter 'detector heads' to s id for your application.	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector olug 5.5/2.5 mm, Plug-in AC power supply unit 230 V/50 Hz; 7.5 VI or positive. lility is assessed in accordance with EN 61326-1 Class B (noise en Jous supervised operation" Dimensions optional check- s, received com- ment results can on BNC connectors. select the detec- ug-in power supply ds with BNC-type (-1) connector application	nission for "living areas",
Display Operating Dimension Serial Port S Power supp Electromac patibility Interface RS232 IEEE488 Detector H Detector H	s/Weight Settings oly netic Com- RS232, adjust IEEE488 with sum calculation mands (Hexa be displayed Head / Measur eads All det See cl tor heat nformation All Gi RP Softw RPC Softw	+5 to +40 °C (+41 to +10 280 mm x 250 mm x 70 mr RS232 (9600 baud, 8 data 6.5 - 7.5 VDC / 1A; cavity p 5.5/2.5 mm, inner conducte Electromagnetic compatibi noise immunity for "continu able baudrate 600 - 57600. settable device address; on; for debugging purposes decimal/ASCII) or measurer in parallel to remote operati ement Output ector heads with -1 type E hapter 'detector heads' to s id for your application.	4°F) n; 1 kg (11 in x 9.8 in x 2.8 in; 2.2 lb) bits, 1 stop bit, no parity) 5 pin cylindrical TRIAD01 connector olug 5.5/2.5 mm, Plug-in AC power supply unit 230 V/50 Hz; 7.5 VI or positive. lility is assessed in accordance with EN 61326-1 Class B (noise en Jous supervised operation" Dimensions optional check- s, received com- ment results can on BNC connectors. select the detec- ug-in power supply ds with BNC-type (-1) connector application	nission for "living areas", 

# 🕃 Gigahertz-Optik

P-9802 Multi-channel Meter

- © Multi-channel Bench-top Optometer for Process Integration
- © Variable set-up of 2 to 36 Measurement Channels
- © Measurement of DC and AC Signals
- © Signal Range from 0.1pA to 200 ∝A
- © 20 ms to 4 s Adjustable Integration Time
- © CW and Dose Operation Mode
- © RS232 Remote Control

Associated Parts / Service: Chapter Detector Heads Chapter Integrating Spheres Chapter Calibration

Arrangements of multiple detector heads are used for many light measurement tasks associated with quality assurance or process control. Typical examples include:

- luminous intensity distribution measurement of directional spot lamps and flood lamps (see the graph on this page)
- determination of the ANSI lumen value of projection equipment using nine or more illuminance detector heads
- matrixes of detectors for 1 : 1 room lighting simulations
- monitoring systems for assessment of effective irradiance for plant physiology in green-houses and climatic chambers
- multi-channel test cabinets used for investigating the aging behavior of lamps, LEDs and other light sources.

Due to the large amounts of data generated, evaluation of these measurement signals is usually carried out under PC supervision or by PLCs.

The P-9802 is designed as a multi-channel instrument exclu-



sively for use under remote control over an RS232 interface. Its electronics design is based on a master board with an external RS232 interface and an internal I<sup>2</sup>C bus. Up to 18 amplifier modules can be controlled by this internal bus through the master board.

**The number of modules** is application dependent and allows a very flexible set-up of the P-9802 to individual needs. The basic version of the P-9802 has one amplifier module with two signal inputs. Additional amplifier modules allow the optometer to be expanded up to a maximum of 18 amplifier modules, i.e. 36 signal inputs.

**Each module** implements a signal amplifier with two switchable signal inputs. A microprocessor controls the operating modes, the input channel switching and the calibration data. The calibration data of each module is stored in eeprom.

The detector heads are connected via BNC sockets located on the front and back panels of the instrument.

#### Precise Measurements:

The P-9802 offers a highly linear 12 bit ADC input with 7 manually or automatically selected gain ranges. The max. error within this wide dynamic range is 0.2 %.

#### Multi-application Capability:

The flexibility to combine the P-9802 with most Gigahertz-Optik detector heads enables it's use in a wide application range of radiometric and photometric measurements.

#### Traceable Calibration

Calibration is traceable to the ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities. Calibration of detector sensitivity as well as an individually measured plot of spectral sensitivity is part of the calibration certificate.

#### Operation

The P-9802 offers simple operation via RS232 interface.

#### **CW Measurement**

CW mode is used to measure continuous DC or AC signals .

#### **Dose Measurement**

Measurement values are accumulated at a logger rate of 1 s and displayed as dose.

#### Auto/Manual Gain Ranging

When test signal levels remain in the same range, the gain range can be manually selected to avoid any auto-ranging time delays.





# P-9802 Specifications & Ordering Information

### **Specifications:**

Signal Inpu	t of (one	amplifier board)						
Detector Inp			pe converter amplifier with following voltage to voltage amplifier (x values from 200.0 $\mu A$ to 200.0 pA . Automatic range switching. 12					
Signal Proce								
Frequency F	ange	Signal conversion fror	gnal conversion from 0.166 Hz to >300 MHz.					
Detector Co	nnector	BNC socket.	C socket.					
Signal Chan		2 up to max. 18 iden measurements from a	tical measuring amplifiers boards, each with 2 switchable signal II A or B channels	inputs; simultaneous acquisition of				
Range Spec	ification	6						
Range (A/V)	Max. In Valu		Error (with offset compensation) 1 year, $23^{\circ}C \pm 5^{\circ}C \pm (\% \text{ of reading } +\% \text{ of range})$ ,	Max. Detector Capacitance				
1x10-4	200.0	uA 30 ms	0.2 % + 0.05 %	2 nF				
1x10-5	20,00	uA 30 ms	0.2 % + 0.05 %	2 nF				
1x10-6	2,000	uA 30 ms	0.2 % + 0.05 %	2 nF				
1x10-7	200,0	A 30 ms	0.2 % + 0.05 %	10 nF				
1x10-8	20,00	nA 30 ms	0.2 % + 0.05 %	10 nF				
1x10-9	2,000	nA 30 ms	0.2 % + 0.05 %	10 nF				
1x10-10	200,0	pA 30 ms	0.2 % + 0.05 %	10 nF				
Function								
Parameter S	ettings	Remote controlled	ia the RS232 interface. Retention of the last settings in continuous	s memory.				
Operating M	odes	CW; Peak, Dose, R	elative (%), Channel 1/Channel 2 (%)					
Dose Measu	rement	Integration of the n time (1 to 65535 s).	Integration of the measured values at 1 sample / 100 ms intervals; Automatic stop when reaching the max. measuring					
Measuremer	nt Quantit		Amperes calibrated with DKD calibrated current source. Current signal multiplied with calibration correction factor to se-					
Calibration E	)ata	max. 255 calibration	max. 255 calibration entries per measuring amplifier calibration via the RS232 interface.					
General								
Operating Te	mperatu	re 5 to 40 °C (41 to 10	04 ° F) (75 % rel. H, non-condensing). Storage Temperature: 0 to 5	0°C (32 to 122 °F).				
Dimensions	Weight	280 mm x 250 mm	x 70 mm; approx. 1 kg (11 in x 9.8 in x 2.8 in; ~2 lb)					
Power	-		supply unit 230 V/50 Hz. 6 VDC/200 mA. Cavity plug 5.5/2.5 mm, ir	ner conductor positive				
Interface								
RS232 96	00 B, 8D,	1S, N, DSUB 9 pin plu	g					

#### Dimensions



Ordering Inf	Ordering Information			
P-9802	Optometer with 2 measurement channels. Handbook and plug-in power supply			
P-9802Z-1	Additional amplifier board (2-channels). Max. up to total 18 boards.			
OS-P9802	Software for data readout and Excel transfer			
Detectors	All Gigahertz-Optik detector heads with BNC-type (-1) connector			
P98Z-01	Rack-Mount Option			

TR-9600 High-speed Data Logger & Pulse-form Analyzer

- Single Channel Bench-top Instrument
- © Single Light Flash & Pulse Train Measurement
- © Measurement in Absolute Radiometric & Photometric Quantities
- © 100 ns Slew Rate Signal Amplifier
- © Data-logger with 10 Mega Sample / sec Rate
- © Transient Recorder with 512 000 Sample Capacity
- © **Remote Control Gain Selection**
- C **Remote Control Trigger Mode Selection**
- C IEEE488&RS232 Remote Control
- © Windows Based Software

#### **Fast Light Signals**

Some light sources such as xenon lamps and LEDs are used to generate short light flashes only a few microseconds in pulse length. Because of the short pulse length with long pulse repetition rate, the peak power generated by these light sources can be much higher than in DC mode while not increasing the average power.

Typical applications for pulsed xenon lamps or LEDs in the visible spectral range include anti-collision lights, warning flashers, fairway strobes, stroboscopes and photo flashers. In the UV range xenon sources are used in polymerization of chemicals and photobiological studies. Pulsed infrared LED's are used for IR remote control, telemetry and in conveyor control switches.

#### **Pulse-form Analysis**

Most Gigahertz-Optik optometers are able to measure the average power of high frequency modulated AC light sources. But in some applications - see application notes on following page more data is required like:

- peak power
- pulse width
- pulse shape



#### single pulse energy • pulse repetition rate

The key information is the pulse shape, measured in absolute quantities.

#### **Pulse-shape Measurement**

The measurement of the pulse shape is accomplished through data logging at a sample rate (measurement and storage) much faster than the pulse length. Since both, signal and measurement time are stored, a signal to time dependent database of the signal shape is recorded.

#### **Fast Rise Time Amplifier**

For very fast pulses, a signal amplifier with a rise and fall time shorter than the pulse rise and fall time is required. Flashes only a few microseconds long require amplifiers with a slew-rate of equal to or less than 1  $\mu$ s.

#### High-speed Data-logger

Besides the fast amplifier a highspeed storage medium is needed that allows retention of the measurement signal and measurement time with a highspeed sampling rate.

A transient recorder allows sampling rates of up to 10 Mega samples per second or one sample every 100 ns.

When the transient recorder is activated, the measurement data are continuously stored by run round overwriting of the recorded data. A trigger incident will stop the run around storage mode. All samples after triggering will be stored up to maximum storage capacity except for a specified number of samples, which represent the signal before the trigger incident.

#### TR-9600 Data-logger

6-

The TR-9600 combines a fast slew-rate amplifier with a highspeed transient recorder for pulse-shape measurement applications.

Because of the large volume of data handled the TR-9600 is designed for remote control operation via its RS232 or IEEE488 interface.

Two versions of the TR-9600 are available:

- TR-9600-1 offers a slew-rate of 1  $\mu$ s with 10 remote controlled gain ranges from 30 nA/V to 1 mA/V

- TR-9600-2 offers a slew-rate of 100 ns with 4 remote controlled gain ranges from 10  $\mu$ A/V to 300 μA/V.

Both meters feature a remote controlled sampling rate from 1 ksample/s to 10 Msample/s sampling rate with a data storage capacity of 512 ksamples that can be increased up to 2 Msamples (option).

supplied with the TR-9600 provides all necessary functions to do remote control pulse-shape measurements and analysis via the RS232 or IEEE488 interface. A versatile triggering facility controls the recording.

Optometer TR 9600

/ER 0

The measured signal is stored as a database which allows the display of a time-intensity graph with an axis segment function and calculation of peak value, pulse integral and pulse length of one or more pulses.

#### **Detector Heads**

Several photometric and radiometric detector heads with short rise and fall times are available for use with the TR-9600 to allow measurements in absolute quantities such as illuminance, luminous intensity and radiant power.

#### **Traceable Calibration**

Calibration of the detector heads is traceable to the ISO EN 17025 accredited part of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities.





# Page 52 - Optometers & Instruments

## **TR-9600** Applications

Because of it's unique features the TR-9600 is the right tool to measure the pulse-shape of high frequency modulated light or short light flashes. Due to the

fast rise & fall times needed in this application the number of detector heads available is limited to those listed in this data sheet. However, custom design

#### Illuminance, Luminous Intensity and Luminance Measurement of Light Flashes Msample/s complete details are

The same detector can be used

to measure luminous intensity

when the detector is placed at a

Luminance in cd/m<sup>2</sup> can be

given distance from the source.

available, such as:

• pulse length in us

• rise time in  $\mu$ s

• peak illuminance in lx

Quantity of light in lx s



The evaluation of a single light flash or a chain of light flashes in absolute photometric quantities is one domain of the TR-9600. In combination with the VL-3704-

1 with its rise time of less than 1  $\mu$ s and a sample rate of up to 10

#### Pulse-shape, Peak-power and IR Remote Control Unit Coding



Infrared Light Emitting Diodes (LEDs) are used in remote control units in the audio and automotive industries as well as in data link systems. The light beam of the remote control unit includes coded information for

measured using the LDM-9901-1 detector head Both detectors offer a precise the receiver. The information is in bar code like form but transmitted as a chain of pulse signals. Besides the information about peak intensity and pulse length, needed to ensure a minimum signal to noise ratio at a given distance, the key code of the remote control unit needs to be measured. With a 100 ns rise

applications are open to discussion. This page offers some typical TR-9600 applications. Our Light Measurement Guide

liaht

trol.

detector heads as well as new

in our catalog and website offers additional tutorial and application notes in the field of Measurement of Light & Measurement with Light.





#### Radiant Intensity Measurement of Pulsed IR LEDs used in Optical Conveyor Control Switches

time and a sampling rate of 10

Msample/s the TR-9600-2 com-

bined with a high-speed photo-

diode make it ideally suited to

measure & evaluate IR remote

Infrared LEDs used in conveyor control sensors are operated with short pulses of high peak intensity. The high peak power enables these sensors to be used in long distance applications or with low reflectance objects.

Another strategy for operating LEDs at very short pulse lengths is used for battery operated devices where high peak power and short pulse length ensures low pulse energy which equals long battery life.

Real pulse shape data in absolute measurement quantities is needed to optimize the electronics that control LEDs in order to select LEDs with the shortest rise times and to do qualification measurements in production to ensure critical parameters. The quantity used for LED meas-

urement in this application is radiant intensity. The measure-

#### Laser Classification EN 60825 (Peak Power, Half-Bandwidth, Pulse-Energy)

Laser are useful tools in measurement and production applications. Beside it's useful function such as high power, monochromatic and directional beam radiation, laser radiation takes also a risk for the human eye.

Because of it's high power, even laser stray-light may be a risk for the human eye. The EN 60825 standard describes the risk and measurements for risk classification. The common tool to measure laser stray-light are detector heads with a 7 mm dia. free aperture which represent the

open pupil. Such a detector head combined with a TR-9600-1 is the right meter for risk classifi-

cation of lasers with pulse length of larger that 10  $\mu$ s. The software supplied with the

TR-9600 does offer the pulseshape characteristic as well as the information about the peak intensity, pulse length and pulse energy.

The detector head which is calibrated in 10 nm steps does allow the measurement at the laser wavelength. The calibration is traceable to the ISO-EN 17025

standard. The TR-9600-1 datalogger combined with PD-9304-1 and 100 mm length front tube can measure the class B radiant intensity of pulsed LED's with pulse length of equal or more than 10µs in reference to CIE 127 -

ment of LED radiant

intensity is described

in CIE 127 -1997

1997 standard

accredited part of Gigahertz-Optik's calibration laboratory.

		Pu	ilse Data I	Display		
B					[	OK
	Start [ms]	Length [ms]	Peak [µA]	Integral [nC]	FWHM calc. [ms]	
12	3.3 3.4	0.0102	75.2 75.1	0.7375	0.009807	÷.
3	3.4	0.0102	75.2	0.7375 0.7375	0.00982 0.009807	
4	3.6	0.0103	75.1	0.7406	0.009861	
5 6 7	3.7 3.8	0.0102 0.0102	75.2 75.1	0.7375	0.009807 0.00982	
	3.9	0.0102	75.2	0.7375	0.009807	
8 9	4	0.0102	75.2	0.7375	0.009807	
9	4.1	0.0102	75.1	0.7375	0.00982	100





Because of it's unique electronic design with a short rise time amplifier, high-speed datalogger and powerful microprocessor the TR-9600 is a highly

#### Set-up

There are three TR-9600 set-up windows labeled Input, Time Base and Trigger. Respectively

#### Input

The Input window allows setup of the gain range and rise time (TR-9600-1 only).

The detector in-use calibration data can be selected as wel as the wavelength of laser power detectors. In addition the user may specify a bias voltage for the detector, i required.

#### **Time Base**

The Time Base window allows the user to select the sampling rate of the datalogger. A high sampling rate means high time resolution and short measurement time. The Single Page-Mode offers the complete 512 kilo sample data capacity for one measurement. The Multi Page Mode separates the memory into 16 pages to enable storage of up to 16 individually triggered measurements. This function allows the measurement of a chain of flashes with long repetition rates or sporadic flash

#### Trigger

High speed applications require variable trigger setting facilities. The TR-9600 software features this capability. Besides defining the trigger source, which can be externally connected to the special input of the TR-9600 device, AC or DC coupling and level or edge triggering can be selected separately. In addition the user can indi-

vidually set the trigger level and

#### **Detector Calibration Data**

The TR-9600 can be operated with several different detector heads. Serial number, calibration factor, wavelength range, wavelength dependent calibration data and comments (handling instructions. accessories. etc.) can be stored. The calibration data can be selected in the Input window or displayed in the Detector Information window as shown above

useful tool to measure single light flashes and light pulse trains. Several modes of operation and functions allow the user to set-up the instrument to his

they allow individual pre-set of the important parameters for the measurement task ..

t- e n	(watch overload o	detector for trans sterise time to av or for correct cal age (observe ma	simum ratings!).
er	A	Rise (ine	Detector
n	O 2m O 6.1µ	( 1µs	ID Anperes 🛓
s	○ 610µ ○ 2µ ④ 200µ ○ 610n	C 10µs C 100µs	λ 500.0 📄 m
- 1	O 51µ O 200n	C 1ms	Riss C.C. El vi
if	O 20µ O 51n		Bias 0.0
	1		

Selec mode Push	t 'Run' trigger mo for single shots. 'Reset' to start a	te to meet your obser ode for continuus mea new measurement, nulate a scan and 'St	
Rate/s	Page Mode	Trigger egable	Trigger control
@ 10M	C Single	C Run	<b>500</b>
C 1M	@ Multi	Single	Stimulate
C 100k			
C 10k			<u>.</u>
O 1k		Start	Stop scan

events with high time resolution. Trigger enable specifies the start mode of a measurement. Trigger control is used to manually start and stop a measurement.



define a trigger delay or history.



specific measurement application. Because of it's fully remote controllable operation, the software supplied with the meter is an essential part of the system.

This page lists all functions available at the time of printing. If you do not see a desired function ask for spec. updates or custom modification.

the CW Client and Pulse Client

**TR-9600 Operation Modes** 

#### **Measurement Mode**

The TR-9600 basic software offers two measurement modes,

#### **CW Client**

The CW Client window with numeric data in the units of measurement based on detector calibration and a bar chart is continuously displayed. As shown in the screen shot to the right, radio buttons located at the top of the display allow manual or automatic ranging.



#### **Pulse Client**

Measurement of the pulse shape of single pulses or a pulse chain after a trigger incident or manually started. The trigger is defined in the Trigger window.

The sample rate, which also defines the measurement time (512 ksample / 100 ns sample rate = 51.2 ms measurement time) is selected in the Time Base window

Two different data storages modes can be selected in the Time Base window. In application with a long repetition rate between very short flashes the Multi Page mode should be selected. In this case each single flash is stored on a single page.



single page mode



#### **Pulse Analysis**

At the end of a measurement the pulse data of a single flash or a chain of flashes is shown on the Pulse Data Display.



#### **Data Transfer**

Data-logger measurements result in large numbers of data, e.g. 512 x 1024 = 542,288. For screen graphic display this number can be reduced to shorten the data transfer time. For external data analysis, Single Point resolution must be selected in the Export data resolution window which takes much



longer for the data transfer.



# **TR-9600 Specification & Ordering Information**

#### Specification:

•						
Sensor Input	BNC-socket, max. +/-2 mA, +/-5 V					
Detector Bias Voltage	Adjustable from -12 V to +12 V					
Display LED's	POWER: device switched on. CONNECTED: remote command received. ERROR: error					
Ext. Trigger Input	TTL/CMOS, positive edge or level triggered					
Trigger Output	CMOS, positive level if triggered					
ADC	12 Bit, sampling rate from 10 Msample to 1 ksample					
Memory Capacity	512 kilo samples (optional 2 Msamples)					
Measurement Ranges	1 $\mu$ s version: 10 gain ranges from 1 mA/V to 30 nA/V					
	100 ns version: 4 gain ranges 300 mA/V to 10 mA/V					
Slew Rate	Switchable (only for 1 $\mu$ s-version): 1 $\mu$ s, 10 $\mu$ s, 100 $\mu$ s, 1 ms					
Analog Output	BNC socket (-2 V to +2 V; $Ri = 100 \Omega$ )					
Interfaces	RS232 (75-57600 Baud, 8 D, 1 S, N); IEEE488-1978 (AH1, SH1, L4, T4)					
Power Supply	7.0 VDC / 1.2 A. Cavity plug 5.5/2.5 mm. Inner conductor positive. Built-in battery with approx. 3 hrs. operating time					
Operation Temperature	+5 to +40 °C (+41 to +104°F)					
Dim. / Weight	h=7 cm (2.8 in), b=25.5 cm (10 in), t=26.5 cm (10.4 in); 2.75 kg (6 lb) with battery, 2 kg (4.4 lb) without battery					
Accessories	Plug-in AC power supply unit 230 V/50 Hz; 7.0 VDC/1.4 A; cavity plug 5.5/2.5 mm, inner conductor positive					

#### Range Specification TR-9600-1 (1 µs-Version) Error 1 year, 23°C ±5°C Noise(p-p) Range Max. Input Slew-Rate (10 - 90%) A/V Value ± (% of reading + % of range), 1 % + 0.1 % 1x10-3 2 mV ±2 mA 1*μ*s 1 % + 0.1 % 3x10-4 ±600 μA 1 μs 3 mV 1x10-4 ±200 μA 1*μ*s 2 mV 1 % + 0.1 % 3 mV 1 % + 0.1 % 3x10-5 ±60 μA 1*μ*s 1x10-5 ±20 μA 1*μ*s 2 mV 1 % + 0.1 % 4 mV 1 % + 0.1 % 3x10-6 ±6 μΑ 1*μ*s 1x10-6 ±2 μΑ

### Dimension:





# Range Specification TR-9600-2 (100 ns-Version) Range Max. Input Slew-Rate Noise(p-p)

A/Ň	Value	(10 - 90%)	,	$\pm$ (% of reading + % of range),
3x10-4	±600 μA	100 ns	2 mV	1 % + 0.1 %
1x10-4	±200 µA	100 ns	4 mV	1 % + 0.1 %
3x10-5	±60 µA	100 ns	4 mV	1 % + 0.1 %
1x10-5	±20 µA	100 ns	8 mV	1 % + 0.1 %

#### **TR-9600 Specifications with Detector**

In principle the TR-9600 can be combined with all Gigahertz-Optik detector heads. But because of it's high-speed characteristic the TR-9600 should only be used with detector heads with

±600 nA

±200 nA

±60 nA

3x10-7

1x10-7

3x10-8

a short rise time. Those detector heads recommended for use with the TR-9600 are listed in the ordering information table below. Further to this, because of the unique nature of pulsed optical radiation measurement applications, the TR-9600 is very often set-up with detector heads specially suited for a specific measurement requirement. For this reason only a few example detectors designed for high speed pulse-form analysis are shown. Please contact our sales engineers to discuss your specific application requirements.

Ordering Informati	ion
TR-9600-1	1 $\mu$ s slew rate . Including manual and power supply
TR-9600-2	100 ns slew rate. Including manual and power supply
TR-9600Z	Memory expansion to 2 Msample
BHO-02	Hard case
VL-37 series	Photometric detector head, select / -1, BNC - type connector
PD-37 series	Modular detector head with 37 - type housing, select / -1, BNC - type connector
UV-37 series	UV - Irradiance detector head, select / -1, BNC - type connector
PD-11 series	Modular detector head with 11 - type housing, select / -1, BNC - type connector
LP-01 series	Laser power or irradiance detectors with integrating spheres, select / -1, BNC - type connector
LDM-9901-1	Luminance detector head with -1 type connector

Error 1 year, 23°C ±5°C

# 🕞 Gigahertz-Optik

# Optometers & Instruments - Page 55

10-5

10<sup>-4</sup> 10<sup>-3</sup> REM

P-9202 Current to Voltage Amplifier

- © Single Channel Amplifiers for Laboratory Use or System Integration
- © Current to Voltage Converter
- $\ensuremath{\mathbb{C}}$  Low Offset Voltage for Photovoltaic Mode Operation
- © High Gain and High Speed Optimized Models
- © Eight Manually or Remote Controlled Gain Ranges
- © Simple Operation
- © Metal Shielded Package
- © Remote Control Interface with Opto-Coupler
- © AC operation

#### Associated Parts / Service:

Chapter Detector Heads Chapter Integrating Spheres Chapter Calibration

**Photodiodes** (Si, InGaAs, Ge) generate current signals with an intensity that correlates to a wide dynamic range linear to the incident optical radiation.

This linear function is only achieved if the photodiodes are operated in the photovoltaic mode, which means almost in a short circuit condition.

In an open circuit configuration the photodiode would offer a voltage signal with a nearly logarithm characteristic.

**The practical use of photodiodes** requires amplifiers which offer the following features:

- current-to-voltage conversion
- lowest offset voltage for 'ideal' short circuit condition
- large dynamic range
- high gain for high sensitivity
- short slew rate for fast measurements.

Gigahertz-Optik's **P-9202 Amplifiers** offer optimum performance when used with state-ofthe-art photodiodes. These amplifiers feature careful design of the input stage using high quality photocurrent amplifiers, the use of reed relays for switching between the high impedance amplification ranges and a remote control interface isolated by opto-couplers.

Due to its superior electronic and mechanical stability, the P-9202 series, originally designed for laboratory use, have found their way into industrial OEM applications.

Three standard versions are offered, differing in maximum sensitivity and bandwidth:

P-9202-4 Fast



**Amplifier** offers an 8-step switch-able sensitivity range from 300 nA/V to 1  $\mu$ A/V and a nearly constant slew-rate of 1  $\mu$ s in all gain ranges. Photodiodes can be operated in photovoltaic or photodiode mode (-5 V bias voltage). Useful in applications with need for high bandwidth up to 330 kHz or short, 1  $\mu$ s rise time.

#### P-9202-5 Universal

PHOTOCURRENT/VOLTAGE AMPLIFIER P-9202-5

BIAC

Amplifier offers an 8-step switchable sensitivity range from 100 pA/V to 1 mA/V and variable, gain dependent slew-rate. Photodiodes can be operated in photovoltaic or photodiode mode (0.5 V bias voltage). This model is suitable for use as a pre-amplifier for lock-in amplifier to extend their measurement range.



#### P-9202-6 High-sensitive

10

ANGE A/V



Amplifier with an 8-step switchable sensitivity range from 10 pA/V! to 100  $\mu$ A/V and variable, gain dependent slew-rates. This model is suited to applications involving very low signals from the photodiodes starting in the 10 femto ampere (0.01 pA) range.

Each amplifier is AC operated with an external power unit supplied.



# P-9202 Specifications & Ordering Instruction

#### Specifications

#### Limits:

max. input voltage: max. signal input current: max. output current: max. output voltage: Supply voltage: Remote input voltage: Operating temperature:

#### Technical data:

Housing: Dimensions:

Weight: Signal input: Signal output: Power supply: +/-12 V +/-5 mA +/-5 mA +/-9 V min. 12 V, max. 24 V (80 mA) +5 V (25 mA) +5 °C to +40 °C (+41 °F to +104 °F)

Aluminum 105 mm x 80 mm x 45 mm (4.1 in x 3.2 in x 1.8 in) approx. 400 g (0.9 lb) BNC socket BNC socket 24 V/80 mA, 2 pin FRIWO connector

Range Sp	Range Specifications									
Model	Gain Stage	Sensitivity	Slew Rate	Error ± of Reading	Noise Voltage					
P-9202-4	1	1 mA/V	1 µs	0.2 % +/-2 mV	1 mV p-p					
	2	300 µA/V	1 µs	0.2 % +/-5 mV	1 mV p-p					
	3	100 µA/V	1 µs	0.2 % +/-2 mV	1 mV p-p					
	4	30 µA/V	1 µs	0.2 % +/-5 mV	1 mV p-p					
	5	10 µA/V	1 µs	0.2 % +/-2 mV	1 mV p-p					
	6	3 µA/V	1 µs	0.2 % +/-5 mV	3 mV p-p					
	7	1 μA/V	3 µs	0.2 % +/-2 mV	3 mV p-p					
	8	300 nA/V	3 µs	0.2 % +/-5 mV	10 mV p-p					
P-9202-5	1	1 mA/V	5 µs	0.2 % +/-1 mV	1 mV p-p					
	2	100 µA/V	5 µs	0.2 % +/-1 mV	1 mV p-p					
	3	10 μA/V	30 µs	0.2 % +/-1 mV	1 mV p-p					
	4	1 μA/V	30 µs	0.2 % +/-1 mV	1 mV p-p					
	5	100 nA/V	500 µs	0.2 % +/-1 mV	1 mV p-p					
	6	10 nA/V	500 µs	0.2 % +/-1 mV	2 mV p-p					
	7	1 nA/V	20 ms	0.7 % +/-1 mV	1 mV p-p					
	8	100 pA/V	20 ms	0.7 % +/-1 mV	4 mV p-p					
P-9202-6	1	100 µA/V	25 ms	0.2 % +/-1 mV	0.5 mV eff					
	2	10 µA/V	25 ms	0.2 % +/-1 mV	0.5 mV eff					
	3	1 μA/V	250 ms	0.2 % +/-1 mV	0.5 mV eff					
	4	100 nA/V	250 ms	0.2 % +/-1 mV	0.5 mV eff					
	5	10 nA/V	250 ms	0.5 % +/-1 mV	0.5 mV eff					
	6	1 nA/V	250 ms	0.5 % +/-1 mV	0.5 mV eff					
	7	100 pA/V	2.5 s	1 % +/-1 mV	0.5 mV eff					
	8	10 pA/V	2.5 s	1 % +/-1 mV	0.5 mV eff					

#### Model Max. Bias Bias Voltage Offset Input Current Voltage Drift Impedance P-9202-4 5 pA 0 V or –5 V $^{1)}$ 1 μV/°C Virtual short P-9202-5 2 pA 0 V or -5 V 1) 1 μV/°C circuit P-9202-6 0.2 pA 5 μV/°C 1) on the outer contact of the BNC signal input socket

#### Dimensions

Amplifier Input Specifications





# Calculation of the Input Noise Voltage

Noise volta

$$- N_{eff}(\sqrt{Hz}) = \frac{N_{p-p} * \sqrt{t_{(10-90)} * 1.5} * sensitivity (A/V)}{6} \left( A/\sqrt{Hz} \right)$$

Ordering Infor	Ordering Information							
P-9202-4	Amplifier, 300 nA/V to 1 mA/V. Including external power supply							
P-9202-5	Amplifier, 100 pA/V to 1 mA/V. Including external power supply							
P-9202-6	Amplifier, 10 pA/V to 100 $\mu$ A/V. Including external power supply							

🕞 Gigahertz-Optik

Remote interface:

**Parts Supplied:** 

D-SUB 9-pin (socket terminal strip) **Remote interface pin-out:** PIN 1: remote central point PIN 2: Ranges 7/8 PIN 3: Ranges 5/6 PIN 4: Ranges 3/4 PIN 5: Ranges 1/2 PIN 6: Ground PIN 7: Signal output ( $R_{out}$ =1 k $\Omega$ ) PIN 8: Remote COMMON PIN 9: Not connected

amplifier, plug-in AC power supply unit (220 V/50 Hz, 24 VDC/80 mA)



# Optometers & Instruments - Page 57

# **Optometers, Instruments Accessories**

#### **BHO Carrying Cases for Optometers, Detectors & Accessories**

Optical radiation measurements instruments are built with precision optical, electro optical and high tolerance electronic components for low level current measurements. As such, they should be protected, carried and stored carefully.

Gigahertz-Optik offers specially designed carrying cases for its

BHO-01



Hard case for the P-9710 optometer with 37-type standard detector heads and accessories such as plug-in power supply.

BHO-04

**BHO-05** 

**BHO-08** 



Hard case for the X11 or X9 Type optometer with one 37 type and LDM-99 type detector heads and additional accessories.

Hard case for the X11 or X92 optometer with up to two RCH-0 or RCH-1 detector heads. Additional space for up to three RCH- instruments. Besides the standard models shown on this page, custom design carrying cases for private label instruments in different sizes, colors,

inserts and company logo are available.

#### **BHO-02**

Hard case for the P-9710 optometer with LDM-98 detector head or the P-9801 optometer



with CT-3701 color detector head. Additional space for plugin power supply.



#### BHO-06

Hard case for one X-2000 with RS232 interface cable and spare battery or one HCT-99 color me-



ter or X11 optometer with CT-4501 ordetector head and spare batteries.



## **BHO-09**



Aluminum hard case with universal partitionable foam rubber to store meter, detector-heads and accessories which do not fit into the fix partitioned BHO series hard cases.



#### sal partitionable foam rubber to store meter, detector heads and accessories which do not fit into the fixed partitioned BHO series hard cases.

Aluminum hard case with univer-

Z light guide adapters.

Dimensions &	Weight:					
Model	Outside (mm)	Outside (inch)	Inside (mm)	Inside (inch)	Weight (kg)	Weight (lb.)
BHO-01	400 x 350 x 90	16 x 14 x 4	380 x 280 x 50	15 x 11 x 2	1.10	2.42
BHO-02	540 x 430 x 130	21 x 17 x 5	530 x 360 x 55	21 x 14 x 2	2.50	5.50
BHO-04	330 x 280 x 70	13 x 11 x 2.7	320 x 230 x 35	13 x 9 x 1.4	0.65	1.43
BHO-05	330 x 280 x 70	13 x 11 x 2.7	320 x 230 x 35	13 x 9 x 1.4	0.65	1.43
BHO-06	240 x 210 x 55	9.5 x 8 x 2	230 x 170 x 30	9 x 7 x 1.2	0.30	0.66
BHO-08	370 x 310 x 145	15 x 12 x 6	350 x 265 x 90	14 x 11 x 3.5	1.75	3.85
BHO-09	460 x 360 x 170	18 x 14 x 7	440 x 320 x 100	17 x 13 x 4	2.30	5.06
Ordering Infor	mation					
BHO-01	Hard Carrying Ca	se.				
BHO-02	Hard Carrying Ca	se				
BHO-04	Hard Carrying Ca	se				
BHO-05	Hard Carrying Ca	se				
BHO-06	Hard Carrying Ca	se				
BHO-08	Hard Carrying Ca	se				
BHO-09	Hard Carrying Ca	se				

Page 58

# **Table of Contents**

#### **General Information**

Gigahertz-Optik manufactures light detectors for use in combination with Gigahertz-Optik optometers and accessories to form complete radiometric and photometric measurement systems. Detectors can also be used with integrating spheres to form the basis of uniform light sources and reflectance/ transmittance instruments. A typical sensor head may consist of a photodiode, optical bandpass filter, diffuser, lens assembly or other optical elements. A complete range of detector head housings and configurations designed around the specific application demands of dynamic range, spectral range, physical size and measurement environment are available. All optical radiation detectors are calibrated and certified by Gigahertz-Optik's calibration laboratory with both absolute sensitivity data and spectral responsivity plot provided.

Table of Cont	ents								
Light Detecto	r Connector Types for D	ifferent G.O. Op	otometers						Page 62
Calculation of	f the Maximum Measura	ble Intensity an	d Maximum	Attainable I	Resolution				Page 63
Model	Spectral Function	Wavelength Range	Diffuser Diameter	Aperture (mm)	Sphere Diameter	Unit	Pac	kage	Specifi- cations
		nm	mm	F.O.V.	mm		Туре	Page	Page
		Com	npact Size II	luminance [	Detectors				
VL-1101	Photopic; f₁≤5%	380-780	-	1,1 mm Ø	-	lx, fc	11	90	63
		Photopi	ic & Scotop	ic Illuminan	ce Detectors				
VL-3701	Photopic; f₁≤3%	380-780	7	Cosine	-	lx, fc	37/20	90	64
VL-3702	Photopic; f₁≤5%	380-780	7	Cosine	-	lx, fc	37/20	90	64
VL-3704	Photopic; f₁≤5%	380-780	7	Cosine	-	lx, fc	37/20	90	64
VL-3705	Scotopic; f₁≤5%	380-780	7	Cosine	-	lx, fc	37/20	90	64
PD-9310	Photopic; f₁≤3 or 6%	380-780	30	Cosine	-	lx, fc	PD93	91	64
		Temperat	ture Control	lled Illumina	nce Detector	rs			
TD-11VL01	Photopic; f₁≤3%	380-780	-	-	-	lx, fc	TD-11	90	65
		Compact	Size Broad	band Irradia	nce Detecto	rs			
RW-1103	Radiometric VISIBLE	400-800	-	1.1 x 1.1	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	11	90	66
RW-1104	Radiometric NIR	800-1000	-	1.1 x 1.1	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	11	90	66
RW-1105	Radiometric VISNIR	400-1000	-	1.1 x 1.1	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	11	90	66
		Temperature C	Controlled B	roadband Ir	radiance De	tectors			
TD-11RW03	Radiometric VISIBLE	400-800	-	2.8 x 2.8	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	TD-11	90	66
TD-11RW04	Radiometric NIR	800-1000	-	2.8 x 2.8	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	TD-11	90	66
TD-11RW05	Radiometric VISNIR	400-1000	-	2.8 x 2.8	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	TD-11	90	66
		High Sens	sitive Broad	band Irradia	ance Detecto	rs			
RW-3701	Radiometric BLUE	400-500	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	67
RW-3702	Radiometric RED	700-800	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	67
RW-3703	Radiometric VISIBLE	400-800	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	67
RW-3704	Radiometric NIR	800-1000	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	67
RW-3705	Radiometric VISNIR	400-1000	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	67
	- <b>-</b>	Compact S	ize Broadba	and UV Irrad	iance Detect	ors			
UV-1101	Radiometric UV-A	315-400	-	2.5 x 2.5	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	11	90	68
UV-1102	Radiometric UV-B	280-315	-	1.1 x 1.1	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	11	90	68
	Т	emperature Co	ntrolled Bro	adband UV	Irradiance D	etectors			
TD-11UV01	Radiometric UV-A	315-400	-	2.5 x 2.5	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	TD-11	90	68
TD-11UV02	Radiometric UV-B	280-315	-	1.1 x 1.1	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	TD-11	90	68
		High Sensiti	ivity Broadb	and UV Irra	diance Detec	tors			
UV-3701	Radiometric UV-A	315-400	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	69
UV-3702	Radiometric UV-B	280-315	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/50	90	69
UV-3703	Radiometric UV-C	250-280	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	69

# Page 60 - Light Detectors



# Table of Contents

Model	Spectral Function	Wavelength Range	Diffuser Diameter	Aperture (mm)	Sphere diameter	Unit	Pack	age	Specifi- cations
		nm	mm	F.O.V.	mm		Туре	Page	Page
		High Sensitivit	y Broadban	d UV Irradia	ance Detect	ors			
UV-3710	Radiometric UV-A	320-400	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	69
UV-3711	Radiometric UV-B	280-320	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/50	90	69
UV-3716	Radiometric UV-A	305-400	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	69
UV-3717	UV-A Visible Blind	325-400	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	69
UV-3718	Narrowband UV-C	254	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	69
UV-3719	Broadband UV	250-400	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	69
		Photobiolo	gical Actini	c Irradiance	Detectors		1		1
UV-3704	UV-Erythema	250-400	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	69/70
UV-3706	Bilirubin	420-530	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	69/70
UV-3708	ACGIH/ICNIRP	250-400	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/50	90	69/70
UV-3709	Blue-Light Hazard	400-520	11	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/32	90	69/70
	<u> </u>	Plant Pl	hysiology Ir	radiance De	etectors				
PS-3701	PAR	400-700	11	Cosine	-	μMol/m²/s	37/32	90	71
PS-3702	Photon Effective	320-500	11	Cosine	-	μMol/m²/s	37/32	90	71
PS-3703	Photon Effective	590-900	11	Cosine	-	μMol/m²/s	37/32	90	71
	High Int	ensity/Temperat	ure Irradian	ce Detecto	rs / UV-Curi	1	,		1
RCH-006	Broadband UV	250-400	9	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/8/F	91	72/73
RCH-008	Narrowband UVA	365 peak	9	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/8/F	91	72/73
RCH-009	Narrowband BLUE	430 peak	9	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/8/F	91	72/73
RCH-106	Broadband UV	250-400	9	Cosine	_	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/8/R	91	72/73
RCH-108	Narrowband UVA	365 peak	9	Cosine	_	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/8/R	91	72/73
RCH-109	Narrowband BLUE	430 peak	9	Cosine	_	W/m <sup>2</sup> ; W/cm <sup>2</sup>	37/8/R	91	72/73
RCH-506	Broadband UV	250-400	6	Cosine	_	W/m <sup>2</sup> ; W/cm <sup>2</sup>	15	91	72/73
RCH-508	Narrowband UVA	365 peak	6	Cosine	_	W/m <sup>2</sup> ; W/cm <sup>2</sup>	15	91	72/73
RCH-509	Narrowband BLUE	430 peak	6	Cosine		W/m <sup>2</sup> ; W/cm <sup>2</sup>	15	91	72/73
	Nanowband BECE	360 Degree Fie			ance Detect		10	51	12,10
ROD-360	Narrowband UV-C	254	ROD	360 Deg		W/m <sup>2</sup> : W/cm <sup>2</sup>	ROD	92	73
NOD-360	Narrowband 0V-C	Multi-Channe		0	- Dotocto	, , , ,	nob	92	73
XD-9501	UV-A 315-400 & UV		8	Cosine		[	XD95	91	74/75
XD-9501 XD-9502	UVA 315-400 & 0V		8	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup> W/m <sup>2</sup> ; W/cm <sup>2</sup> & lx	XD95	91	74/75 74/75
XD-9502 XD-9503		•			-		XD95		
XD-9503 XD-9504	UV-A/B 240-340 & U Radiometric VISIE		8	Cosine Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup> W/m <sup>2</sup> ; W/cm <sup>2</sup>	XD95	91 91	74/75 74/75
XD-9505	UV Broadband	250-400		Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	XD95	91	74/75
XD-9505 XD-9506			8		-				
XD-9506 XD-9509	ACGIH 250-314/315-400		8	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup> W/m <sup>2</sup> ; W/cm <sup>2</sup>	XD95	91	74/75
	Erythema I250-32		8	Cosine	-		XD95	91	74/75
XD-9510	ACGIH 250-314/315-400		8	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	XD95	91	74/75
XD-9511	UV-A visible blind	315-400	8	Cosine	-	W/m <sup>2</sup> ; W/cm <sup>2</sup>	XD95	91	74/75
TP-4501	Triple PAR & Pl	•	8	Cosine	-	µMol/m²/s & lx	45	91	74/75
			s Color & III	1	Jetectors		0===		
CT-3701	x,y,z, 2 Degrees	380-780	10	Cosine	-	x,y; u,v; K, lx	37/TC	92	76
CT-4501	x,y,z, 2 Degrees	380-780	10	Cosine	-	x,y; u,v; K, lx	45	90	76
			nance & Rad						
LDM-9810	Interchangeable PD- Spectral function PD-			° and 6° Sel		PD-16 dependent	LDM98	92	77/78
LDM-9811			1.7, 11 ar	nd 100 mrad	Selectable	PD-16 dependent	LDM98	92	77/78
PD-16-BLH	Blue Light Hazard	400-520	-	5.8 x 5.8	-	W/m <sup>2</sup> sr	PD16	92	77/78

# Light Detectors - Page 61

Table of Contents

LSM-9901         Photopic,           PRW-0505         Radiometric           Integrating         Spheres from           Spheres         Spheres from           LP-9901         Si Photoco           LP-0101         InGaAs Pho           LP-0102         Si & InGaAs Pho           LP-0103         Si Photoco           LP-9910         Si Photoco           LP-9920         InGaAs Pho           LP-9930         Si & InGaAs Pho           LP-9930         Si & InGaAs Pho           LP-9930         Si & InGaAs Pho           PD-1101         Si Photoco           PD-1102         InGaAs Pho           PD-1103         Si LP Photo           PD-1104         InGaAs Pho           PD-1105         Si C Photo           PD-1106         Si LP Photo           PD-1107         Si LP Photo           PD-1108         Si LP Photo           PD-1109         GaP Photo           PD-1109         GaP Photo           PD-1101         Si Photoco           PD-1102         InGaAs Pho           PD-1103         Si LP Photoco           PD-1104         InGaAs Pho           PD-1105         Si LP Photoco	I Function	Wavelength Range	Diffuser Diameter	Aperture (mm)	Sphere Diameter	Unit	Pack	age	Specifi- cation
PD-16-RTHARTH IFPD-16-RW05RadiometricPD-16-VL01Photopic,LDM-98Z-NL-LDM-98Z-FC-LDM-9901Photopic,SRT-M37A Range ofUSM-9901Photopic,RW-0505RadiometricIntegrating SpheresSpheres from RWLP-9901Si Photopic,LP-9901Si Photopic,PRW-0505RadiometricIntegrating SpheresSpheres from RWLP-9901Si Photopic,LP-9901Si Photopic,LP-0102Si & InGaAs Pho Si LP Photopic,LP-0103Si Photopic,LP-0104InGaAs Pho Si LP Photopic,LP-9930Si & InGaAs Pho Si LP Photopic,PD-1101Si Photopic,PD-1102InGaAs Pho Photopic,PD-1103InGaAs Pho Si LP Photopic,PD-1104InGaAs Pho Si LP Photopic,PD-1105Si LP Photopic,PD-1106Si LP Photopic,PD-1107Si LP Photopic,PD-1108Si LP Photopic,PD-1109GaP Photopic,PD-1109GaP Photopic,PD-1101Si Photopic,PD-1103InGaAs Pho Si LP Photopic,PD-1104InGaAs Pho Si LP Photopic,PD-1105Si LP Photopic,PD-1106Si LP Photopic,PD-1107Si LP Photopic,PD-1108Si LP Photopic,PD-1109GaAs Pho Si LP Photopic,PD-1101Si Photopic,PD-1103InGaAs P		nm	mm	F.O.V.	mm		Туре	Page	Page
PD-16-RTHARTH IFPD-16-RW05RadiometricPD-16-VL01Photopic,LDM-98Z-NL-LDM-98Z-FC-LDM-9901Photopic,SRT-M37A Range ofUSM-9901Photopic,RW-0505RadiometricIntegrating SpheresSpheres from RWLP-9901Si Photopic,LP-9901Si Photopic,PRW-0505RadiometricIntegrating SpheresSpheres from RWLP-9901Si Photopic,LP-9901Si Photopic,LP-0102Si & InGaAs Pho Si PhotocLP-0103Si PhotocLP-9910Si LP PhotoLP-9920InGaAs Pho Si LP PhotoLP-9930Si & InGaAs Pho Photopic,PD-1101Si PhotocPD-1102InGaAs Pho Photopic,PD-1103InGaAs Pho Si LP PhotocPD-1104InGaAs Pho Si LP PhotocPD-1105Si LP Photoc Si LP PhotocPD-1106Si LP Photoc Si LP PhotocPD-1107Si LP Photoc Si LP PhotocPD-1108Si LP Photoc Si LP PhotocPD-1109GaAs Pho Si LP PhotocPD-1109Spheres from SpheresTD-1101Si Photoc Si PhotocTD-1102InGaAs Pho Spheres from SpheresTD-1103InGaAs Pho Spheres from SpheresTD-1103Si Photoc Spheres from Spheres from Spheres from		Lur	ninance & R	adiance Dete	ectors		1		
PD-16-RW05RadiometricPD-16-VL01Photopic, ?LDM-98Z-FC-LDM-9901Photopic, ?SRT-M37A Range ofUN-9901Photopic, ?SRT-M37A Range ofUN-9901Photopic, ?RW-0505RadiometricIntegrating SpheresSpheres from RWUP-0101InGaAs PhotopicLP-0101Si & InGaAs PhotopicLP-0102Si & InGaAs PhotopicLP-0103Si PhotocicLP-0103Si PhotocicLP-9920InGaAs PhotopicLP-9930Si & InGaAs PhotopicLP-9910Si LP PhotopicPD-1101Si LP PhotopicPD-1102InGaAs PhotopicPD-1103Si LP PhotopicPD-1104InGaAs PhotopicPD-1105Si LP PhotopicPD-1106Si LP PhotopicPD-1107Si LP PhotopicPD-1108Si LP PhotopicPD-1109GaP PhotopicPD-1109Si LP PhotopicPD-1101Si LP PhotopicPD-1103Si LP PhotopicPD-1104Si LP PhotopicPD-1105Si LP PhotopicPD-1106Si LP PhotopicPD-1107Si LP PhotopicPD-1108Si LP PhotopicPD-1109GaAsPhopicPD-1103InGaAsPhopicPD-1104Si LP PhotopicPD-1105Si LP PhotopicPD-1105Si LP PhotopicPD-1105Si LP PhotopicPD-1105Si LP PhotopicPD-1105 <t< td=""><td>ermal Hazard</td><td>500-1200</td><td>-</td><td>5.8 x 5.8</td><td>-</td><td>W/m²sr</td><td>PD16</td><td>92</td><td>77/78</td></t<>	ermal Hazard	500-1200	-	5.8 x 5.8	-	W/m²sr	PD16	92	77/78
PD-16-VL01Photopic, iLDM-98Z-NL-LDM-98Z-FCPhotopic, iSRT-M37A Range ofLSM-9901Photopic, iPRW-0505RadiometricIntegrating SpheresSpheres from RWLP-9901Si PhotooicLP-0102Si & InGaAs Photopic, iLP-0103Si PhotooicLP-0103Si PhotooicLP-9901Si A InGaAs Photopic, iLP-0103Si PhotooicLP-9910Si PhotooicLP-9920InGaAs Photopic, iLP-9930Si & InGaAs Photopic, iLP-9930Si & InGaAs Photopic, iLP-9930Si & InGaAs Photopic, iLP-9910Si LP Photopic, iPD-1103InGaAs Photopic, iPD-1104InGaAs Photopic, iPD-1105Si LP Photopic, iPD-1106Si LP Photopic, iPD-1107Si LP Photopic, iPD-1108Si LP Photopic, iPD-1109GaP Photopic, iPD-1109GaAs Photopic, iPD-1101Si Photopic, iPD-1102InGaAs Photopic, iPD-1103Si LP Photopic, iPD-1104Si LP Photopic, iPD-1105Si LP Photopic, iPD-1106Si LP Photopic, iPD-1107Si LP Photopic, iPD-1108Si LP Photopic, iPD-1109GaAs Photopic, iPD-1101Si Photopic, iPD-1102InGaAs Photopic, iPD-1103Si Photopic, iPD-1104Si LP Photopic, iPD-1105	H IR-A	800-1200	-	5.8 x 5.8	-	W/m <sup>2</sup> sr	PD16	92	77/78
LDM-98Z-NL-LDM-98Z-FC-LDM-9901Photopic,SRT-M37A Range ofLSM-9901Photopic,PRW-0505RadiometricIntegrating SpheresSpheres from RWLP-9901Si Photopic,LP-9901Si Photopic,LP-0102Si A InGaAs Pho LP-0103LP-0103Si PhotocLP-9901Si LP Photo Si LP PhotoLP-9901Si LP Photo Si LP PhotoLP-9910Si A InGaAs Pho LP-9920LP-9920InGaAs Pho Si LP PhotoLP-9930Si & InGaAs Pho D-1102PD-1101Si Photoc Si LP PhotoPD-1102InGaAs Pho PhotopPD-1103InGaAs Pho PhotopPD-1104InGaAs Pho PhotopPD-1105SiC Photop Si LP PhotopPD-1106Si LP Photop Si LP PhotopPD-1107Si LP Photop Si LP PhotopPD-1108Si LP Photop Si LP PhotopPD-1109GaAs Pho Si LP PhotopPD-1109Si LP Photop Si LP PhotopPD-1109Si LP Photop Si LP PhotopPD-1109Si LP Photop Si LP PhotopPD-1109Si LP Photop Si LP PhotopPD-1101Si LP Photop Si LP PhotopPD-1103InGaAs Pho Si LP PhotopPD-1104Si LP Photop Si LP PhotopPD-1105Si LP Photop Si LP PhotopPD-1105Si LP Photop Si LP PhotopPD-1105Si LP Photop Si LP PhotopPD-1105Si LP Photop Si LP Photop </td <td>etric VIS-NIR</td> <td>400-1000</td> <td>-</td> <td>5.8 x 5.8</td> <td>-</td> <td>W/m²sr</td> <td>PD16</td> <td>92</td> <td>77/78</td>	etric VIS-NIR	400-1000	-	5.8 x 5.8	-	W/m²sr	PD16	92	77/78
LDM-98Z-FC-LDM-9901Photopic, "SRT-M37A Range ofUSM-9901Photopic, "PRW-0505RadiometricIntegrating SpheresSpheres from RWLP-9901Si PhotooLP-0102Si & InGaAs Photopic, "LP-0103Si PhotooLP-0201Si & InGaAs Photopic, "LP-9920InGaAs Photopic, "LP-9930Si & InGaAs Photopic, "LP-9910Si LP Photopic, "LP-9920InGaAs Photopic, "LP-9930Si & InGaAs Photopic, "LP-9930Si & InGaAs Photopic, "LP-1101Si LP Photopic, "PD-1102InGaAs Photopic, "PD-1103InGaAs Photopic, "PD-1104Si LP Photopic, "PD-1105SiC Photopic, "PD-1106Si LP Photopic, "PD-1107Si LP Photopic, "PD-1108Si LP Photopic, "PD-1109GaP Photopic, "PD-1109Si LP Photopic, "PD-1101Si Photopic, "PD-1102InGaAs Photopic, "PD-1103Si LP Photopic, "PD-1104Si LP Photopic, "PD-1105Si LP Photopic, "PD-1106Si LP Photopic, "PD-1107Si LP Photopic, "PD-1108Si LP Photopic, "PD-1109GaAsP Photopic, "PD-1101Si Photopic, "PD-1102InGaAsP Photopic, "PD-1103Si Photopic, "PD-1104Si Photopic, "PD-1105Si LP Photopic, "PD	oic, f1≤3%	380-780	-	5.8 x 5.8	-	cd/m <sup>2</sup>	PD16	92	77/78
LDM-9901Photopic,SRT-M37A Range ofLSM-9901Photopic,PRW-0505RadiometricIntegrating SpheresSpheres from RWLP-9901Si PhotoolLP-0102Si & InGaAs Photopic,LP-0103Si PhotoolLP-0103Si & InGaAs Photopic,LP-9910Si PhotoolLP-9920InGaAs Photopic,LP-9920InGaAs Photopic,LP-9930Si & InGaAs Photopic,LP-9920InGaAs Photopic,LP-9920InGaAs Photopic,LP-9930Si & InGaAs Photopic,LP-9910Si LP Photopic,LP-9920InGaAs Photopic,LP-9930Si & InGaAs Photopic,PD-1101Si LP Photopic,PD-1102InGaAs Photopic,PD-1103InGaAs Photopic,PD-1104InGaAs Photopic,PD-1105Si LP Photopic,PD-1106Si LP Photopic,PD-1107Si LP Photopic,PD-1108Si LP Photopic,PD-1109GaP Photopic,PD-1109GaP Photopic,PD-1101Si Photopic,PD-1102InGaAs Photopic,PD-1103Si LP Photopic,PD-1104Si LP Photopic,PD-1105Si LP Photopic,PD-1106Si LP Photopic,PD-1107Si LP Photopic,PD-1108Si LP Photopic,PD-1109GaP Photopic,PD-1101Si Photopic,PD-1102InGaAs Photopic,PD-1103Si Photopic,PD-1104 </td <td>-</td> <td>380 - 1000</td> <td>-</td> <td>50</td> <td>-</td> <td>-</td> <td>LDM98</td> <td>92</td> <td>77/78</td>	-	380 - 1000	-	50	-	-	LDM98	92	77/78
SRT-M37A Range ofLSM-9901Photopic, iPRW-0505RadiometricIntegrating SpheresSpheres from RWLP-9901Si PhotocicLP-9901Si PhotocicLP-0102Si & InGaAs PhoLP-0103Si PhotocicLP-0103Si PhotocicLP-9901Si & InGaAs PhoLP-9910Si PhotocicLP-9920InGaAs PhoLP-9930Si & InGaAs PhoLP-9930Si & InGaAs PhoLP-9930Si & InGaAs PhoPD-1101Si PhotocicPD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105SiC PhotocicPD-1106Si LP PhotocicPD-1107Si LP PhotocicPD-1108Si LP PhotocicPD-1109GaP PhotocicPD-1109GaP PhotocicPD-1109Spheres fromSpheresSpheres fromSpheresSpheres fromSpheresSpheres fromSpheresSpheres fromSpheresSpheres fromSpheresSpheres fromSpheresSpheres fromSpheresSpheres from	-	Fiber Coupler f	or flexible ligh	nt guide bundl	es			92	77/78
LSM-9901 Photopic, PRW-0505 Radiometric Integrating Spheres from Spheres Si Photoco LP-0101 Si Photoco LP-0102 Si & InGaAs Pho LP-0103 Si Photoco LP-0201 Si LP Photoco LP-9910 Si Photoco LP-9920 InGaAs Pho LP-9920 Si & InGaAs Pho LP-9930 Si & InGaAs Pho LP-9930 Si & InGaAs Pho PD-1101 Si LP Photoco PD-1102 InGaAs Pho PD-1102 InGaAs Pho PD-1103 InGaAs Pho PD-1104 InGaAs Pho PD-1105 SiC Photoco PD-1105 Si LP Photoco PD-1106 Si LP Photoco PD-1107 Si LP Photoco PD-1108 Si LP Photoco PD-1109 GaP Photoco PD-1109 GaP Photoco PD-1109 GaP Photoco PD-1109 Spheres from Spheres from Spheres from TD-1103 InGaAs Pho	oic, f1≤5%	380-780	-	1°	-	cd/m <sup>2</sup>	LDM99	92	79
PRW-0505RadiometricIntegrating SpheresSpheres from RWLP-9901Si PhotocLP-9901Si PhotocLP-0102Si & InGaAs Pho Si & InGaAs Pho LP-0103Si PhotocLP-0103Si PhotocLP-0103Si PhotocLP-9910Si PhotocLP-9920InGaAs Pho Si & InGaAs Pho LP-9930LP-9930Si & InGaAs Pho PhotocPD-1101Si PhotocPD-1102InGaAs Pho PhotocPD-1103InGaAs Pho PhotocPD-1104InGaAs Pho PhotocPD-1105SiC Photoc PhotocPD-1106Si LP Photoc PhotocPD-1107Si LP Photoc Si C PhotocPD-1108Si LP Photoc PhotocPD-1109GaAs Pho SpheresTD-1101Si Photoc Spheres from SpheresTD-1102InGaAs Pho Spheres from Spheres from Spheres from	e of Front Lens	ses is Offered fo	r the VL, RW	and UV Detect	tors for Lumir	nance & Radiance S	et-ups	89	80
PRW-0505RadiometricIntegrating SpheresSpheres from RWLP-9901Si PhotocLP-9901Si PhotocLP-0102Si & InGaAs Pho LP-0103LP-0103Si PhotocLP-0103Si PhotocLP-9910Si LP PhotocLP-9920InGaAs Pho LP-9930LP-9930Si & InGaAs Pho LP-9930LP-9930Si & InGaAs Pho PD-1101PD-1101Si PhotocPD-1102InGaAs Pho PD-1103PD-1103InGaAs Pho PD-1104PD-1104InGaAs Pho PD-1105PD-1105Si LP Photoc PD-1107PD-1108Si LP Photoc PD-1108PD-1109GaP Photoc PD-1109PD-1101Si Photoc PD-1105PD-1103InGaAs Pho Photoc PD-1109PD-1104Si LP Photoc Photoc PD-1105PD-1105Si LP Photoc Photoc PD-1109PD-1108Si LP Photoc Photoc PD-1109PD-1109GaAsP Photoc Photoc PD-1101Integrating TD-1102Spheres from SpheresIntegratingSpheres from Spheres fromIntegratingSpheres from Spheres from		Lumino	us Flux & Ra	adiant Power	Detectors				
Integrating SpheresSpheres from RWLP-9901Si PhotodLP-0101InGaAs PhoLP-0102Si & InGaAs PhoLP-0103Si PhotodLP-0103Si PhotodLP-9910Si PhotodLP-9920InGaAs PhoLP-9930Si & InGaAs PhoLP-9910Si LP PhotodLP-9920InGaAs PhoLP-9930Si & InGaAs PhoPD-1101Si PhotodPD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105SiC PhotodPD-1106Si LP PhotodPD-1107Si LP PhotodPD-1108Si LP PhotodPD-1109GaP PhotodPD-1109GaP PhotodPD-1109Spheres fromSpheresSpheres fromTD-1101Si PhotodTD-1103InGaAs PhoTD-1103Spheres from	 bic, f1≤5%	380-780	-	12.5 Ø	50	lm	11/50	91	81
Spheres         RW           LP-9901         Si Photos           LP-0101         InGaAs Pho           LP-0102         Si & InGaAs Pho           LP-0103         Si Photos           LP-0103         Si Photos           LP-0103         Si Photos           LP-0201         Si LP Photos           LP-9910         Si Photos           LP-9920         InGaAs Pho           LP-9930         Si & InGaAs Pho           LP-9930         Si & InGaAs Pho           PD-1101         Si Photos           PD-1102         InGaAs Pho           PD-1103         InGaAs Pho           PD-1104         InGaAs Pho           PD-1105         Si LP Photos           PD-1106         Si LP Photos           PD-1107         Si LP Photos           PD-1108         Si LP Photos           PD-1109         GaP Photos           PD-1109         GaP Photos           PD-1109         GaP Photos           PD-1109         GaP Photos           PD-1101         Si Photos           PD-1102         InGaAs Pho           Integrating         Spheres from           Spheres         InGaAs Pho	etric VIS-NIR	400-1000	-	12.5 Ø	50	W	11/50	91	81
LP-9901         Si Photoco           LP-0101         InGaAs Pho           LP-0102         Si & InGaAs Pho           LP-0103         Si Photoco           LP-0201         Si LP Photoco           LP-9910         Si Photoco           LP-9920         InGaAs Pho           LP-9930         Si & InGaAs Pho           LP-9930         Si & InGaAs Pho           LP-9930         Si & InGaAs Pho           PD-1101         Si LP Photoco           PD-1102         InGaAs Pho           PD-1103         InGaAs Pho           PD-1104         InGaAs Pho           PD-1105         Si LP Photoco           PD-1106         Si LP Photoco           PD-1107         Si LP Photoco           PD-1108         Si LP Photoco           PD-1109         GaP Photoco           PD-1108         Si LP Photoco           PD-1109         GaP Photoco           PD-1109         GaP Photoco           PD-1109         GaP Photoco           PD-1101         Si Photoco           PD-1102         InGaAs Pho           PD-1103         Si Photoco           PD-1104         GaAs Pho           Integrating         Spheres	from 100 mm	(4 inch) to 500 n	nm (20 inch)	Diameter are (	Dffered which	can be Combined	with VL,	See Ir	ntegrating
LP-0101InGaAs PhoLP-0102Si & InGaAs PhoLP-0103Si PhotocLP-0103Si PhotocLP-0201Si LP PhotoLP-9910Si PhotocLP-9920InGaAs PhoLP-9930Si & InGaAs PhoLP-9930Si & InGaAs PhoLP-9910Si LP PhotoLP-9920InGaAs PhoPD-1101Si LP PhotoPD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105SiC PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109GaAsP PhoIntegrating SpheresSpheres fromTD-1103InGaAs PhoInGaAs PhoInGaAs PhoSpheresSpheres from						surement Set-ups		Sp	oheres
LP-0101InGaAs PhoLP-0102Si & InGaAs PhoLP-0103Si PhotocLP-0103Si PhotocLP-0201Si LP PhotoLP-9910Si PhotocLP-9920InGaAs PhoLP-9930Si & InGaAs PhoLP-9930Si & InGaAs PhoLP-9910Si LP PhotoLP-9920InGaAs PhoPD-1101Si LP PhotoPD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105SiC PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109GaAsP PhoIntegrating SpheresSpheres fromTD-1103InGaAs PhoInGaAs PhoInGaAs PhoSpheresSpheres from		Laser St	ray-light and	d Laser Powe	r Detectors				
LP-0102Si & InGaAs PLP-0103Si PhotocLP-0201Si LP PhotoLP-9910Si PhotocLP-9920InGaAs PhoLP-9930Si & InGaAs PLP-9930Si & InGaAs PhoLP-9930Si & InGaAs PhoPD-1101Si PhotocPD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105Si LP PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109Spheres fromSpheresSpheres fromTD-1102InGaAs PhoTD-1103InGaAs Pho	otodiode	350-1100	-	7 Ø	-	W/m² nm / W nm	37/8.5	91	82
LP-0102Si & InGaAs PLP-0103Si PhotocLP-0201Si LP PhotoLP-9910Si PhotocLP-9920InGaAs PhoLP-9930Si & InGaAs PLP-9930Si & InGaAs PhoLP-9930Si & InGaAs PhoPD-1101Si PhotocPD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105Si C PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109Spheres fromSpheresSpheres fromTD-1102InGaAs PhoTD-1103InGaAs PhoTD-1103Spheres from		Laser Pow	er Detectors	s with Integra	ting Sphere	s			
LP-0103Si PhotoLP-0201Si LP PhotoLP-9910Si PhotoLP-9920InGaAs PhoLP-9930Si & InGaAs PhoLP-9930Si & InGaAs PhoLP-9930Si & InGaAs PhoPD-1101Si LP PhotoPD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105SiC PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109Spheres fromSpheresSpheres fromTD-1103InGaAs PhoTD-1103InGaAs PhoTD-1103Spheres from	Photodiode	800-1800	-	5 Ø	30	W nm	11/30	91	82/83
LP-0201Si LP PhotoLP-9910Si PhotocoLP-9920InGaAs PhoLP-9930Si & InGaAs PhoLPPA-9901Si LP PhotoPD-1101Si PhotocoPD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105Si LP PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109Spheres fromSpheresInGaAs PhoTD-1101Si PhotocoTD-1102InGaAs PhoTD-1103Spheres fromIntegratingSpheres fromSpheresSpheres from	s Photodiode	350-1800	-	5 Ø	30	W nm	11/30	91	82/83
LP-9910Si PhotocLP-9920InGaAs PhoLP-9930Si & InGaAs PhoLP9930Si & InGaAs PhoD-1101Si LP PhotoPD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105Si C PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109Spheres fromSpheresSpheres fromTD-1102InGaAs PhoTD-1103Spheres from	otodiode	350-1100	-	5 Ø	30	W nm	11/30	91	82/83
LP-9920         InGaAs Pho           LP-9930         Si & InGaAs Pho           LPPA-9901         Si & InGaAs Pho           PD-1101         Si LP Photo           PD-1102         InGaAs Pho           PD-1103         InGaAs Pho           PD-1104         InGaAs Pho           PD-1105         SiC Photo           PD-1106         Si LP Photo           PD-1107         Si LP Photo           PD-1108         Si LP Photo           PD-1109         GaP Photo           PD-1109         Spheres from           Spheres         Si Photoc           TD-1101         Si Photoc           TD-1102         InGaAs Pho           Integrating         Spheres from           TD-1103         InGaAs Pho           TD-1103         InGaAs Pho	hotodiode	400-1100	-	2 Ø	8	W nm	11/8	91	82/83
LP-9930Si & InGaAs PLPPA-9901Si LP PhotoPD-1101Si LP PhotoPD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105Si C PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109Spheres fromSpheresSpheres fromTD-1101Si PhotoTD-1103InGaAs PhoIntegratingSpheres fromSpheresSpheres from	otodiode	400-1100	-	12.5 Ø	50	W nm	11/50	91	83
LPPA-9901 Si LP Photo PD-1101 Si Photo PD-1102 InGaAs Pho PD-1103 InGaAs Pho PD-1103 Si C Photo PD-1105 Si C Photo PD-1106 Si LP Photo PD-1106 Si LP Photo PD-1107 Si LP Photo PD-1108 Si LP Photo PD-1109 GaAs Pho Integrating Spheres Since Strom Spheres Since Strom TD-1101 Si Photoco TD-1102 InGaAs Pho InGaAs Pho InGaAs Pho	Photodiode	800-1800	-	12.5 Ø	50	W nm	11/50	91	83
PD-1101Si PhotocPD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105SiC PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109GaAsP PhoIntegrating SpheresSpheres fromTD-1101Si PhotocTD-1102InGaAs PhoIntegrating Spheres from	s Photodiode	400-1800	-	12.5 Ø	50	W nm	11/50	91	83
PD-1101Si PhotocPD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105SiC PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109GaAsP PhoIntegrating SpheresSpheres fromTD-1101Si PhotocTD-1102InGaAs PhoIntegrating Spheres from		Laser Pu	ulse Shape I	Radiant Powe	er Detector	<u> </u>			
PD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105SiC PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109GaAsP PhoIntegrating SpheresSpheres fromTD-1101Si PhotoTD-1102InGaAs PhoIntegrating SpheresSpheres from	hotodiode	400-1060	-	12.5 Ø	50	V / W nm	LPPA	91	84
PD-1102InGaAs PhoPD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105SiC PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109GaAsP PhoIntegrating SpheresSpheres fromTD-1101Si PhotoTD-1102InGaAs PhoIntegrating SpheresSpheres from		Co	mpact Size	Modular Dete	ectors		1		
PD-1103InGaAs PhoPD-1104InGaAs PhoPD-1105SiC PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109GaAsP PhotoPD-1110GaAsP PhotoIntegrating SpheresSpheres fromTD-1101Si PhotocoTD-1102InGaAs PhoIntegrating SpheresSpheres from	otodiode	200-1100	-	3.6 x 3.6	-	With Accessory	11	90	85
PD-1104InGaAs PhoPD-1105SiC PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109GaAsP PhoIntegrating SpheresSpheres fromTD-1101Si PhotoTD-1102InGaAs PhoIntegrating SpheresSpheres from	Photodiode	800-1800	-	0.3 Ø	_	With Accessory	11	90	85
PD-1104InGaAs PhoPD-1105SiC PhotoPD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1109GaAsP PhoIntegrating SpheresSpheres fromTD-1101Si PhotoTD-1102InGaAs PhoIntegrating SpheresSpheres from	Photodiode	800-1800	-	1Ø	_	With Accessory	11	90	85
PD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1110GaAsP PhoIntegrating SpheresSpheres fromTD-1101Si PhotocTD-1102InGaAs PhoIntegrating SpheresSpheres from	Photodiode	800-1800	_	3Ø	_	With Accessory	11	90	85
PD-1106Si LP PhotoPD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1110GaAsP PhoIntegrating SpheresSpheres fromTD-1101Si PhotocTD-1102InGaAs PhoIntegrating SpheresSpheres from	notodiode	200-400	_	1.1 x 1.1	_	With Accessory	11	90	85
PD-1107Si LP PhotoPD-1108Si LP PhotoPD-1109GaP PhotoPD-1110GaAsP PhoIntegrating SpheresSpheres fromTD-1101Si PhotocoTD-1102InGaAs PhoTD-1103InGaAs PhoIntegrating SpheresSpheres from		400-1050	_	0.5 x 0.5	_	With Accessory	11	90	85
PD-1108Si LP PhotoPD-1109GaP PhotoPD-1110GaAsP PhotoIntegrating SpheresSpheres fromTD-1101Si PhotocoTD-1102InGaAs PhotocoTD-1103InGaAs PhotocoIntegrating Spheres from		400-1050	_	1.9 x 1.9	_	With Accessory	11	90	85
PD-1109 GaP Photo PD-1110 GaAsP Photo Integrating Spheres from Spheres TD-1101 Si Photoco TD-1102 InGaAs Pho TD-1103 InGaAs Pho Integrating Spheres from		400-1050	-	3.4 x 3.4	_	With Accessory	11	90	85
PD-1110 GaAsP Pho Integrating Spheres Spheres from TD-1101 Si Photoc TD-1102 InGaAs Pho TD-1103 InGaAs Pho Integrating Spheres from		250-550	-	1.1 x 1.1	_	With Accessory	11	90	85
Integrating SpheresSpheres fromTD-1101Si PhotocoTD-1102InGaAs PhoTD-1103InGaAs PhoIntegratingSpheres from		200-760	_	2.3 x 2.3				+	
TD-1102InGaAs PhoTD-1103InGaAs PhoIntegratingSpheres from		1 inch) to 500 mr				an be Combined w	ith PD-11		ntegrating oheres
TD-1102InGaAs PhoTD-1103InGaAs PhoIntegratingSpheres from		Tempera	ature Contro	olled Modular	Detectors			· · · ·	
TD-1102InGaAs PhoTD-1103InGaAs PhoIntegratingSpheres from	otodiode	200-1100	-	3.6 x 3.6	-	With Accessory	TD11	90	86
TD-1103 InGaAs Pho Integrating Spheres from		800-1800	-	0.3 Ø	-	With Accessory	TD11	90	86
Integrating Spheres from		800-1800	-	1Ø	-	With Accessory	TD11	90	86
			ם (20 inch) ח		l fered which a	can be Combined w			ntegrating
•			or Radiant Po	wer Measurer					oheres
MD-37-GP6 GaP Photo	notodiode	250-550	-	2.5 x 2.5	-	With Accessory	MD37	90	86

# Page 62 - Light Detectors



# Table of Contents

Model	Spectral Function Wavelen Range		Diffuser Diameter	Aperture (mm)	Sphere Diameter	Unit	Pack	age	Specifi- cation	
		nm	mm	F.O.V.	mm		Туре	Page	Page	
			Modula	r Detectors	4					
MD-37-GAP	GaAsP Photodiode	200-790	-	2.3 x 2.3	-	With Accessory	MD37	90	86	
MD-37-IGA1	InGaAs Photodiode	800-1800	-	1Ø	-	With Accessory	MD37	90	86	
MD-37-IGA3	InGaAs Photodiode	800-1800	-	3 Ø	-	With Accessory	MD37	90	86	
MD-37-SC1	SiC Photodiode	200-400	-	1 x 1	-	With Accessory	MD37	32	86	
MD-37-SU13	Si Photodiode	200-1100	-	3.6 x 3.6	-	With Accessory	MD37	32	86	
MD-37-SU33	Si Photodiode	200-1100	-	5.8 x 5.8	-	With Accessory	MD37	32	86	
MD-37-SU100	Si Photodiode	200-1100	-	10 x 10	-	With Accessory	MD37	32	86	
MD-37Z-C11	Front Ca	ap Adapter		11 Ø	-	-	MD37	32	86	
MD-37Z-DR11	RADIN Diffuser Cap	200-2500	-	11 Ø	-	-	MD37	32	86	
MD-37Z-H7	Filter Adapter for 0.5 or 1	inch Diameter F	ilter				MD37	32	86	
MD-37Z-H7xx	Filter Adapter with Custor	m Specified Ban	d-pass or We	edge Filter			MD37	32	86	
Integrating Spheres	Spheres from 100 mm (4 inch) to 500 mm (20 inch) Diameter are Offered which can be Combined with MD-37         See Ir           Detectors for Radiant Power Measurement Set-ups         Spheres from 100 mm (4 inch)         Spheres from 100 mm (4 inch)									
		1 cm <sup>2</sup>	Circular Are	ea Modular D	etectors					
PD-9304	Si Photodiode	350-1100	-	11.28 Ø	-	W nm	PD93	91	87/88	
PD-9306	UV-Si Photodiode	250-1100	-	11.28 Ø	-	W nm	PD93	91	87/88	
PD-9302-VL	Photopic Front Filter	380-780	-	15.5 Ø	-	-	PD93	91	87/88	
PD-9302-RW	Radiometric Front Filter	400-1100	-	11.28 Ø	-	-	PD93	91	87/88	
PD-9303-COS	Diffuser Front Cap	380-1100	20	Cosine	-	-	PD93	91	87/88	
		Avera	ged LED Int	ensity Front	Adapter			1		
PD-9311	0.01 Steradian Solid Ang	e Front Tube for	PD-9304; CI	E 127 Conditi	on B	cd or W/sr	PD93	91	87/88	
PD-9312	0.001 Steradian Solid Ang	gle Front Tube fo	or PD-9304; (	CIE 127 Condi	tion A	cd or W/sr	PD93	91	87/88	
			Weather	Proof Option						
WPD-01	Weather Proof Detector H	lousing to be Ec	quip with Pho	tometric or Ra	diometric Det	ector	WPD	92	88	
			Light Detect	or Accessor	es					
ИМВ	Integrating Spheres from	100 mm / 4 in to	o 500 mm / 20	) in Diameter	with Accessor	ry for System Set-up	S	Int.	Spheres	
UP	Precise Machined Integrating Spheres from 8 mm / 0.3 in to 10 in Dia. with Accessory for System set-ups Int. S								Spheres	
SRT-M37	Front Lenses, Barrels & Adapters for 37-type Detectors 37 89								89	
/WQ	Waterproofing Option for 37-type Detectors     92								90	
/LC	Cable Length Extension									
			Ca	rrying Cases					90	

### **Optometer Model Depending Plug Types:**

Gigahertz-Optik light detectors come equipped with a plug type compatible with the particular optometer it will used with (see table).

The -2 calibration data plug contains an Eeprom that stores the detectors serial number, model, units and calibration data or data table for automatic information transfer to the meter when connected.

Both standard BNC (-1) and ITT-9PIN (-4) connectors are straight forward plugs without internal Eeprom.



- 1 BNC Connector

- 2 Calibration Data Connector

- 4 ITT Type Connector

Plug Type		Meter
BNC	-1	P-9202, P9801, P-9802, TR-9600
Calibration Data	-2	P-9710, P-2000
ITT (MSDM9)	-4	X9, X1, HCT-99

# Measurement Range Calculation; Illuminance & Irradiance

#### Calculation of the Maximum Measurable Intensity and Resolution:

Typical sensitivity factors for each light detector in its calibrated units are included in the specifications listed on the following pages. The maximum measurable intensity and attainable resolution with the different models of optometer offered can be calculated as follows

is

#### **Maximum Resolution**

= Meter Current Signal Resolution / Detector Sensitivity e.g. 0.1 pA / 3 nA / ( mW / cm<sup>2</sup> ) = 0.33 nW / cm<sup>2</sup> Maximum Signal = Max Meter Signal Current / Detector Sensitivity e.g.  $20 \,\mu\text{A} / 3 \,\text{nA} / (\,\text{mW} / \text{cm}^2\,) = 6.66 \,\text{W} / \text{cm}^2$ 

tor heads".

 $lx = lm / m^2$ 

 $fc = Im / ft^2$ 

Illuminance E

vertically in the units of lux (lx) or Illuminance refers to the luminous footcandles (fc). When the inciflux per unit area impinging on a particular surface from one or dent light is not parallel, which in more sources of light. Illuminance practice is normal, a cosine diffuser must be used as the measmeasured horizontally and

#### Irradiance E

Irradiance refers to the radiant power impinging on a particular surface from one or more sources of optical radiation. Irradiance is measured horizontally and verti-

Each optical radiation quantity

calls for its own measurement

geometry for the proper reception

of the radiation. Illuminance and

irradiance measurement systems require a cosine corrected field of cally in the units of watts per square meter (W/m<sup>2</sup>). When the incident optical radiation is not parallel, which in practice is normal, a cosine diffuser

**Cosine Corrected Field of View** 

view. Only then can the laws for

the incidence of diffuse radiation

from one or more sources be sat-

If the incident radiation is not par-

allel, the accuracy of the cosine

must be used to correct the measurement geometry for irradiance detector heads.

function is critically important to

the result of the measurement.

urement geometry for "lux detec-

VL-1101 with UPB-50-L

	$\Phi^*\cos \alpha$



isfied

Photopic Spectral Response

Ordering Inf	Ordering Information & typical Specifications										
Model	λresp	f <sub>1</sub>	Typical Sensitivity	Imax	Sensing Area	cable	Temp.	plug	package		
	InGaAs	$\leq$ %	nA/lx	mA	photodiode	m	°C		page		
VL-1101	$V(\lambda)$	5	0.3	1	1.1 mm Ø	2	5 - 40	1,2,4	90		
K-VL1101-I	Calibratio	on of t	he illuminance sensitivi	ty in Ix	or fc. Including	K-SR in	order with	new de	etector		
KDW-S	Calibratio	on of t	he spectral sensitivity ir	n comb	pination with acc	essory					
KDW-P	Calibratio	Calibration of the integral photometric sensitivity in combination with accessory									

#### VL-1101: Compact Size Illuminance Detector



of discrete linear arrays (11 mm grid size) to measure the luminous intensity distribution of spot lamps.

The detector can be combined with integrating spheres with 11type adapter for luminous flux measurements.

Calibration is offered with or without accessory.

#### VL-3701, VL-3702, VL-3704 & VL-3705: Photopic & Scotopic Illuminance Detectors

Illuminance is one of the most important measurements in the field of commercial or industrial lighting. It enables us to see things properly and comfortably. Illuminance detector's spectral responsiveness must be equal the photopic vision characteristic  $V(\lambda)$ , as defined by the CIE. The very best matching of the detector spectral response to the photopic vision function is necessary especially if the measurements involve different kinds of light sources such as daylight, tungsten, fluorescent lamps, LED's etc

Illuminance detectors require a cosine field-of-view characteristic. This spatial response properly 'weights' the effects of the illumination reaching the detector from different angles of incidence. The accuracy of the cosine correction is as equally important as the photometric responsivity for illuminance detectors

The height of the detector is an other important factor, since the illuminance should be measured close to the subject surface. To measure the ANSI Lumen rating of projectors a max. height of 20 mm is specified.



#### VL-3701: Photopic with DIN Class A Parameters

The VL-3701 is a high quality detector for the measurement of illuminance. Its specifications satisfy the requirements for lux detector heads according to DIN 5032 Part 7.

The VL-3701's spectral adaptation to the  $V(\lambda)$  function for daylight vision is better than 3%. The precise adaptation of its spectral sensitivity to the ideal V( $\lambda$ ) function makes this detector head appropriate where sharply different spectra need to be measured (arc lamps, color monitors, LEDs, etc.). The deviation from the cosine function is < 1.5 %. The low detector profile of 20 mm allows its use in applications where the height of the detectors surface over the illuminated surface is restricted.

Calibration of the illuminance, in lux or fc is performed at Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities, and is supported by a factory certificate.

#### VL-3702: Photopic with DIN Class B Parameters

The VL-3702 detector is constructed the same as the VL-3701 model, but has a lower precision of photometric adaptation, at 6 %, sufficient for DIN quality class B, and a maximum deviation of 3 % from the cosine function. Available versions and calibration are the same as model VL-3701.

#### VL-3704: Photopic with DIN Class B Parameters

The VL-3704 detector specifications are equal to that of the VL-3702 detector except that it is less sensitive. This allows the VL-3704 detector to be used with optometers like the X11, X91 and P-9802 with amplifiers having a limited signal range.

#### VL-3705: Scotopic

The spectral response of the human eye changes with light intensity. In daylight conditions >0.1 lx the photopic action spectrum applies. In low brightness applications 0.01 to 0.0001 lx the spectral eye response changes to the scotopic (dark adapted) action spectrum. Light intensities below 0.0001 k can not be detected by the human eye.

The VL-3705 detector offers a precise scotopic spectral match





Scotopic Spectral Response

with an  $f_1 = < 5\%$ . This is within DIN class B specifications qualifying the VL-3705 for use in most low light level application.

Ordering In	Ordering Information & typical Specifications											
Model	λresp	f <sub>1</sub>	Typical S	Sensitivity	Imax	Sensing Area	cable	Operation	plug	package		
		$\leq$ %	nA/lx	nA/fc	mA	Diffuser	m	Temp.		page		
VL-3701	$V(\lambda)$	3	0.5	5	1	7 mm Ø	2	5 - 40	1,2,4	90		
VL-3702	$V(\lambda)$	5	0.5	5	1	7 mm Ø	2	5 - 40	1,2,4	90		
VL-3704	$V(\lambda)$	5	20 pA/lx	200 pA/fc	1	7 mm Ø	2	5 - 40	4	90		
VL-3705	V'(λ)	5	0.5	5	1	7 mm Ø	2	5 - 40	1,2,4	90		
K-VL37xx-I	Calibratior xx = mode			ensitivity in ly	or fc.	Including K-SR	with ne	w detector	order.			
KDW-S	Calibratior	n of sp	ectral sensi	tivity with ac	cesso	y components						
KDW-P	Calibratior	n of int	egral photo	metric sens	itivity i	n combination w	ith acce	essory				
K-FOV	Calibratior	n of co	sine field o	f view functi	on. Inc	luded with new	detecto	or order				
V/L 07:04 III.					-000	Negel imite (8/	•					

VL-37xx Illuminance Detectors compa	VL-37xx Illuminance Detectors comparison DIN 5032 Class Limits (%)											
Characteristic	Symbol	DIN 5032 Class A	DIN 5032 Class B	VL-3701	VL-3702	VL-3704						
Calibration Uncertainty	$U_{kal}$	1.5	3	1.1	1.1	1.1						
V(λ) Match Characteristic	f <sub>1</sub>	3	6	3	5	5						
UV Response Characteristic	u	1	2	0.01	0.01	0.01						
IR Response Characteristic	r	1	2	0.01	0.01	0.01						
Directional Response (Cosine)	f <sub>2</sub>	1.5	3	1.5	3	3						
Linearity Characteristic	f <sub>3</sub>	1	2	0.2	0.2	0.2						
Fatigue Characteristic (at 1 klx)	f <sub>5</sub>	0.5	1	0.1	0.1	0.1						
Temperature Dependence Characterist.	f <sub>6</sub>	2	10	1	1	1						

#### **Accessories:**

Mating SRT-M37 front lens adapters allow VL-37 detectors to be adapted for luminance measurements. See page 89 for specifications.



VL-37 detectors can be combined with integrating spheres for luminous flux measurements. See integrating sphere chapter.





# Light Detectors - Page 65 Illuminance / Irradiance

### PD-9310: High Sensitivity Photopic Illuminance Detector



**Ordering Information & typical Specifications** 

 $f_1$ 

≤%

3

6

λresp

V(λ)

V(λ)

Typical Sensitivity

nA/lx

2.8

2.8

Calibration of the spectral sensitivity in combination with accessory

Imax

mΑ

1

1

Calibration of the integral photometric sensitivity in combination with accessory

Calibration of the photometric sensitivity in Ix or fc. Including K-SR in order with new detector

Sensing Area

Diffuser

30 mm Ø

30 mm Ø

cable

m

2

2

Operation

Temp

5-40 °C

5-40 °C

Model

PD-9310A

PD-9310B

K-PD9310-I

KDW-S

KDW-P



large 30 mm diameter diffuser window combined with a large 100 mm<sup>2</sup> area photodiode. It's high sensitivity makes this detector ideal for all applications in which very low light levels needs to be measured.

The detector can be combined with the PD-93 modular detector accessories and with integrating spheres with 37-type adapters. Calibrations are offered with or without accessory.



### TD-11VL01: Temperature Controlled Illuminance Detector

plug package

1,2,4

1,2,4

page

91

91



The TD-11VL01 detector offers a unique temperature control for filter and photodiode by precise heating to a higher operation temperature than the ambient temperature. The control electronic is supplied in an external housing with plug-in power supply. The detector can be combined with integrating spheres with 11-type adapter for luminous flux measurements.

Calibrations are offered with or without accessory.

Ordering Infor	Ordering Information & typical Specifications													
Model	λresp	f <sub>1</sub>	Typical Sensitivity	Imax	Sensing Area	cable	Opera-	plug	package					
		≤%	nA/lx	mA	photodiode	m	tion Temp.		page					
TD-11VL01	V(λ)	5	tbc with sphere	1	2.77 mm x 2.77 mm	2	55°C	1,2,4	90					
K-TD11VL01-I	Calibra	tion of	the photometric sen	sitivity	in lx or fc. Including k	K-SR in	order with	new o	detector					
KDW-S	Calibra	tion of	the spectral sensitiv	ity in c	ombination with acce	ssory								
KDW-P	Calibra	Calibration of the integral photometric sensitivity in combination with accessory												

VISIBLE-NIR Polychromatic Radiometric Light Detectors

Polychromatic radiometric detectors are primarily used for integral intensity measurements in a defined range of wavelengths. Correction filters are used to shape the bare detector re-



RW-01 BLUE 400-500 nm Spectral Response

sponse to the desired bandpass function, and ensure a radiometric responsiveness function. The plots below and on the following page summarizes the standard measurement heads

offered with correction filters and spectral responses. Customerspecific solutions with respect to spectral range, measurement geometry and other design fea-

tures are available along with full

assistance from our sales engineers.



sensitivity 0.5 ē 0 350 450 550 650 750 850 wavelength (nm)



# Irradiance

#### VISIBLE-NIR Polychromatic Radiometric Light Detectors



### RW-11: Compact Size VISIBLE-NIR Polychromatic Radiometric Detectors



**The RW-11** detectors offer a compact package with flange mount which allows arrangement of discrete linear arrays with a grid of 11 mm to measure the radiant intensity distribution of light sources. The detector can be combined with integrating spheres with 11type adapter for radiant power measurements. Calibrations are offered with or without accessory.

RW-11 assembled to UM series sphere



🖲 Gigahertz-Optik

ordering in	ormation & typical S	pecification	5							
Model	λresp	Response	Typical Sensitivity nA/W/m <sup>2</sup> nA/W		Imax	Sensing Area	cable	Operation	plug	package
	polychromatic	Page			mA	photodiode	m	Temp.		page
RW-1103	VISIBLE400-800 nm	65			1	1.1 x 1.1 mm	2	5-40 °C	1,2,4	90
RW-1104	NIR <sub>800-1000 nm</sub>	66	tbc with	sphere	1	1.1 x 1.1 mm	2	5-40 °C	1,2,4	90
RW-1105	VISNIR400-1000 nm	66			1	1.1 x 1.1 mm	2	5-40 °C	1,2,4	90
K-RW11xx-I	Calibration of the irrad	iance sensiti	vity in A/W/m² a	and A/W/cm <sup>2</sup> .	Including	g K-SR in order wit	h new de	etector. xx = de	etector m	nodel
KDW-S2	Calibration of the spec	ctral irradianc	e sensitivity at	one or a chai	n of wave	length without or i	n combi	nation with acc	essory	
KDW-R	Calibration of the integ	Calibration of the integral radiometric sensitivity in combination with accessory								

## TD-11RW: Temperature Controlled VISIBLE-NIR Polychromatic Radiometric Light Detectors



**The TD-11RW** detectors offers a unique temperature control for filter and photodiode by precise heating to a higher operation temperature than the ambient temperature. The control electronic is supplied in an external housing with plugin power supply. The detector can be combined with integrating spheres with 11type adapter for radiant power measurements. Three different kinds of spectral responses e.g. TD-11RW03, TD-11RW04 and TD-11RW05 are offered which fulfill the need of most radiometric applications for integral detectors. Calibrations are offered with or without accessory.

Ordering Information	Ordering Information & typical Specifications											
Model	λresp	Response	51 5		Imax	Sensing Area	cable	Operation	plug	package		
	polychromatic	Page			mA	photodiode	m	Temp.		page		
TD-11RW03	VISIBLE400-800 nm	65			1	2.8 x 2.8 mm	2	55°C	1,2,4	90		
TD-11RW04	NIR <sub>800-1000 nm</sub>	66	tbc with sphere		1	2.8 x 2.8 mm	2	55°C	1,2,4	90		
TD-11RW05	VISNIR400-1000 nm	66			1	2.8 x 2.8 mm	2	55°C	1,2,4	90		
K-TD-11RWxx-I	Calibration of the irrad	iance sensiti	vity in A/W/m <sup>2</sup> a	and A/W/cm <sup>2</sup> .	Includ	ling K-SR in order	with nev	v detector				
KDW-S	Calibration of the spec	Calibration of the spectral sensitivity in combination with accessory										
KDW-R	Calibration of the integ	alibration of the integral radiometric sensitivity in combination with accessory										

Irradiance

## RW-37: High Sensitivity VISIBLE-NIR Broadband Irradiance Detectors



The RW-37 irradiance detectors are for use in radiometric applications requiring high sensitivity. The diffuser window offers a cosine corrected field-of-view. The compact 37-type package fits

into tight spaces in end-on viewing set-up. A side M6 tapped hole allows post mounting or fixturing into the application.

The detector can mounted to integrating spheres using 37type adapters and calibrated for radiant power measurements. See Integrating Spheres chapter. For simple radiometric radiance measurements the RW-37 detectors can be combined and calibrated with SRT-M37 front lenses. Calibrations are offered with or without components attached.



Ordering Info	rmation & typical Spe	cifications									
Model	λresp	Response	Typical Sensitivity In		Imax	Sensing Area	cable	Temp.	plug	package	
	Broadband	Page	nA/W/m <sup>2</sup>	mA/W/cm <sup>2</sup>	mA	Diffuser	m	°C		page	
RW-3701	BLUE <sub>400-500 nm</sub>	65	70	0.7	1	11 mm Ø	2	5-40	1,2,4	90	
RW-3702	RED <sub>700-800 nm</sub>	65	70	0.7	1	11 mm Ø	2	5-40	1,2,4	90	
RW-3703	VISIBLE400-800 nm	65	1.7	0.017	1	11 mm Ø	2	5-40	1,2,4	90	
RW-3704	NIR <sub>800-1000 nm</sub>	66	200	2	1	11 mm Ø	2	5-40	1,2,4	90	
RW-3705	VISNIR400-1000 nm	66	400	4	1	11 mm Ø	2	5-40	1,2,4	90	
K-RW37xx-I	Calibration of radiome	tric sensitivity	in A/W/m² an	d A/W/cm <sup>2</sup> . In	cludes K	-SR in new detect	or order	. xx = detect	or model		
KDW-S	Calibration of spectral	sensitivity at	one or multiple	wavelengths	without	or in combination	with acc	cessory com	oonents		
KDW-R	Calibration of integral I	alibration of integral radiometric sensitivity in combination with accessory components.									

ULTRAVIOLET broadband radiometric detectors are primarily used for integral intensity measurements in defined UV band pass ranges of wavelengths.



lowing page summarize the standard measurement heads offered with correction filters and spectral responses. Customerspecific solutions with respect to

sensitivity 60

<u>e</u>

**ULTRAVIOLET** Polychromatic Irradiance Light Detectors

spectral range, measurement geometry and other design features are available along with full assistance from our sales engineers.



UV-01 Spectral Response: UV-A 315-400 nm



UV-10 Spectral Response: UV-A 320-400 nm



sensitivity 2'0 Ð C 260 275 290 305 320 elength ( nm )

UV-11 Spectral Response: UV-B 280-320 nm



UV-03 Spectral Response: UV-C 200/250-280 nm



UV-16 Spectral Response: UV-A 305-400 nm

# Irradiance

#### **ULTRAVIOLET Broadband Irradiance Detectors**



### UV-11: Compact Size UV Broadband Irradiance Detectors



**UV-A/UV-B** are the most frequently used wavelength ranges in the qualification procedure of light sources used in photobiological and industrial application. Besides standard narrow band detectors, Gigahertz-Optik offers real broadband detectors. **The UV-11** detectors offer a compact package with flange mount to arrange detector arrays with only a grid size of 11 mm. Or they can be combined with integrating spheres using 11type adapters for radiant power measurements. Calibrations are offered with or without accessory components.

Ordering Info	Ordering Information & typical Specifications											
Model	λresp	Response	Typical Sensitivity		Imax	Sensing Area	cable	Temp.	plug	package		
	Broadband	Page	nA/W/m <sup>2</sup>	nA/W	mA	photodiode	m	°C		page		
UV-1101	UV-A 315-400 nm	67	tbc	tbc with	0.2	2.5 x 2.5 mm	2	5-40	1,2 or 4	90		
UV-1102	UV-B <sub>280-315 nm</sub>	67	tbc	sphere	0.05	1.1 x 1.1 mm	2	5-40	1,2 or 4	90		
K-UV11xx-I	Calibration of radion	netric sensitiv	vity in A/W/m <sup>2</sup> a	and A/W/cm <sup>2</sup> .	Includes	K-SR in with new	detector	order. xx =	detector ma	odel		
KDW-S	Calibration of spectr	Calibration of spectral sensitivity at one or a chain of wavelength without or in combination with accessory components.										
KDW-R	Calibration of integra	al radiometric	sensitivity with	accessory c	omponen	ts						

#### **TD-11UV: Temperature Controlled UV Broadband Radiometric Detectors**

**The TD-11UV** detectors offer a unique temperature control feature where the filter and photodiode are heated to a higher operating temperature than the ambient temperature.

The control electronics are supplied in an external housing with a plug-in power supply. The detector can be combined with integrating spheres with 11-type adapter for radiant power measurements. Two different kinds of spectral responses, UV-A<sub>315-400 nm</sub> and UV-B<sub>280-315 nm</sub> are offered which fulfill the need of most radiometric applications for integral detec-

tors. Calibrations are offered with or without accessory components.



Ordering Inform	Ordering Information & typical Specifications										
Model	λresp	Response	Typical Sensitivity		Imax	Sensing Area	cable	Operation	plug	package	
	Broadband	Page	nA/W/m <sup>2</sup>	nA/W	mA	photodiode	m	Temp.		page	
TD-11UV01	UV-A 315-400 nm	67	tbc	tbc with	0.2	2.5 x 2.5 mm	2	55°C	1,2,4	90	
TD-11UV02	UV-B <sub>280-315 nm</sub>	67	tbc	sphere	0.05	1.1 x 1.1 mm	2	55°C	1,2,4	90	
K-TD11UVxx-I	Calibration of radiom	etric sensitivi	ty in A/W/m² ar	nd A/W/cm². I	ncludes	K-SR in new deteo	ctor ord	ler. xx = dete	ector		
KDW-S	Calibration of spectra	alibration of spectral sensitivity at one or multiple wavelengths without or in combination with accessory components									
KDW-R	Calibration of integra	alibration of integral radiometric sensitivity with accessory components									

UV-37

## UV-37: High Sensitivity Broadband UV Irradiance Detectors

### UV-3701, UV-3702, UV-3703

These detectors represents the classic DIN and CIE ultraviolet radiation wavelength bands UV-A\_{315-400 nm}, UV-B\_{280-315 nm} and UV-C\_{100-280 nm}. Deep UV in the range of 100 to 250 nm is very rarely

observed in radiometry. So the UV-3703 offers a practical UV-C solution with a sensitivity range from 250 to 280 nm.

#### UV-3710, UV-3711

Some non-biological disciplines specify the wavelength ranges 320 to 400 and 280 to 320 nm for the evaluation of UV-A and UV-B

eye operation).

tion >400 nm..

#### UV-3716

The sharply increasing shortwave spectral component of modern lamps creates a potential risk of exposure of the eyes to excessive UV-A radiation. The limit values for  $E_{\rm 305-400\ nm}$  irradi

In applications where the UV-A irradiance must measured amidst intense blue & visible light, the UV-3701 and UV-3710 may not offer sufficient visible wavelength range signal rejection. This will produce an inaccu-

UV-3717 JV-A rately high UV-A reading. A good example of this is fluorescent lamps which generate significant mercury lines at 405, 436, 546 and 577 nm. The UV-3717 is visi-

ble blind for best stray light rejec-

ance were established to limit

the intensity this radiation on the

retina as when optical fibers are

used in eye operations (aphakic



#### UV-3718

The model UV-3718 is designed for narrow band UV-light sources with distinct 254 nm peak emission spectrum. The RADIN type diffuser offers high UV stability under UV-C irradiation. The detector is calibrated with a narrow band light source at 254 nm.

#### UV-3719

The model UV-3719 offers a broadband spectral sensitivity from 250 to 390 nm. This detector is typically used in applications where the lamp emission spectrum is known allowing an a (z) calibration correction.

The UV-37 detectors are high sensitivity irradiance detectors for radiometric applications involging polychromatic optical radiation. The diffuser window provides a cosine corrected field-of-view for diffuse light signals. The compact 37-type package fits into tight spaces with a vertical end-on view. An M6 tapped hole allows post mounting or fixturing in the application. The detectors can be combined and calibrated with integrating spheres or SRT-M37 quartz front lenses.

Ordering Information & typical Specifications										
Model	λresp	Response	Typical Sensitivity I		Imax	Sensing Area	cable	Temp.	plug	package
	Broadband	Page	nA/W/m <sup>2</sup>	µA/W/cm <sup>2</sup>	mA	Diffuser	m	°C		page
UV-3701	UV-A 315-400 nm	67	4	40	0.1	11 mm Ø	2	5-40	1,2 or 4	90
UV-3702	UV-B <sub>280-315 nm</sub>	67	1.7	17	0.05	11 mm Ø	2	5-40	1,2 or 4	90
UV-3703	UV-C 200/250-280 nm	67	2	20	0.05	11 mm Ø	2	5-40	1,2 or 4	90
UV-3710	UV-A 320-400 nm	67	7	70	0.1	11 mm Ø	2	5-40	1,2 or 4	90
UV-3711	UV-B 280-320 nm	67	3	30	0.05	11 mm Ø	2	5-40	1,2 or 4	90
UV-3716	UV-A 305-400 nm	67	10	100	0.1	11 mm Ø	2	5-40	1,2 or 4	90
UV-3717	UV-A 325-400 nm	68	1	10	0.1	11 mm Ø	2	5-40	1,2 or 4	90
UV-3718	UV-C 254 nm	68	2	20	0.05	11 mm Ø	2	5-40	1,2 or 4	90
UV-3719	UV-A 250-400 nm	68	3	30	0.1	11 mm Ø	2	5-40	1,2 or 4	90
K-UV37xx-I	Calibration of radiometric sensitivity in A/W/m <sup>2</sup> and A/W/cm <sup>2</sup> . Includes K-SR in new detector order. xx = detector model									
KDW-S2	Calibration of spectral irradiance sensitivity at one or multiple wavelengths without or in combination with accessory components									
KDW-R	Calibration of radiometric sensitivity with accessory components									

#### UV-37: High Sensitivity Photobiologically Actinic UV Irradiance Detectors

Photobiology is concerned with the interaction of optical radiation and living organisms. Photobiological radiometric measurement systems are essential tools used for the evaluation of sources of optical radiation in cosmetics, medical and therapeutic, health and safety and other areas. The photodetectors used in these various application areas require spectral sensitivities corresponding directly to a particular photobiological response function. This enables direct measurement of the photobiological dose of a radiation source.

The spectral response function of the sensor is generated by optical correction filters used to tailor the bare detector response. Since the ideal target function cannot be perfectly duplicated, it is necessary to find the best possible compromise through extensive computer simulation taking a great variety of lamp spectra into account to minimize error. The associated series of measurements, which are an essential part of this engineering process, are carried out at Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities. On the following page, irradiance light detectors available from Gigahertz-Optik that are primarily intended for applications in the fields of radiation protection and of radiation therapy are presented. For a specific response function not shown, or if you should require more detailed information, please contact our technical sales department directly.

## Actinic Irradiance

#### UV-3704: UV-Erythemal Actinic Irradiance Detector

The typical symptom of UV erythema is acute skin inflammation caused by UV radiation (sunburn) which has been linked to skin cancer over prolonged exposure times.

The UV-3704 detector permits direct measurement of the UV Erythema effective irradiance by means of it's spectral sensitivity adaptation to the nominal CIE Erythemal spectral function.

#### UV-3706: Bilirubin Actinic Irradiance Detector

Newborn jaundice or neonatal hyperbilirubinaemia, a yellowish appearance of the skin and whites of the eyes, is present to some degree in almost all newborn infants. This is caused by an elevated level of bilirubin molecule in the blood which results from immaturity of the liver function combined with the destruction of red blood cells present. When these levels are very high, one method of clearing the jaundice is by exposing the newborn to light in the blue spectral region between 400 to 550 nm. The UV-3706 detector allows the direct measurement of phototherapeutically effective irradiance employed for lowering the bilirubin level in newborn infants.

The UV-3708 detector permits direct measurement of effective

irradiance according to ACGIH/

Measurement uncertainty can be

evaluated and reduced using

Gigahertz-Optik's a(z) method

when the lamp emission spectra

is known with dataset provided.

ICNIRP guidelines.

Measurement uncertainty can be

evaluated and reduced using

Gigahertz-Optik's a(z) method

when the lamp emission spectra

is known with dataset provided.

#### UV-3708: ACGIH/ICNIRP Actinic Irradiance Detector

range.

The spectral weighting function for the acutely harmful effects of UV radiation, was developed by the American Conference of Governmental Industrial Hygienists (ACGIH) and the International Commission on Non-Ionising Radiation Protection (ICNIRP).

The spectral effectiveness in the UV-C and UV-B ranges is very high as compared to the UV-A

# UV-3709: Blue-Light Hazard Actinic Irradiance Detector

If optical radiation in the wavelength range between 380 and 550 nm of sufficient intensity reaches the retina it can cause photochemical injury. Radiation in the "blue" part of the spectrum triggers photochemical reactions, if the photon energy in the radiation is high enough, converting chemically unstable molecules into one or more other molecule types. BLH irradiance

is relevant exclusively in connection with ophthalmic instruments (microscopes, observation devices used in optician's practices). Otherwise the measurement of radiance applies. The UV-3709 detector head is designed for direct measurement of the effective irradiance for blue light hazard, responsible for retinal damage.









Ordering Int	formation & Specific	ations								
Model	λresp	Wavelength	Typical Sensitivity		Imax	Sensing Area	cable	Temp.	plug	package
	Biological Effective	Range	nA/W/m <sup>2</sup>	µA/W/cm <sup>2</sup>	mΑ	Diffuser	m	°C		page
UV-3704	Erythema	250-400 nm	3	30	0.05	11 mm Ø	2	5-40	1, 2, 4	90
UV-3706	Billirubin	400-550 nm	200	2000	1	11 mm Ø	2	5-40	1, 2, 4	90
UV-3708	ACGIH/ICNIRP	250-400 nm	1,5	15	0.05	11 mm Ø	2	5-40	1, 2, 4	90
UV-3709	Blue-light Hazard	400-520 nm	150	15000	1	11 mm Ø	2	5-40	1, 2, 4	90
K-UV37xx-I	Calibration of actinic irradiance sensitivity in A/W/m <sup>2</sup> and A/W/cm <sup>2</sup> . Includes K-SR in new detector order. xx = detector									
KDW-S	Calibration of spectral sensitivity with accessory components									
KDW-R	Calibration of radiometric sensitivity with accessory components									



# Plant Physiology

#### PS-37: Plant Physiology Actinic Irradiance Detectors

The radiation conditions used in determining the rate of photosynthesis and the photosynthetic potential of various plant or algae types are not the same in all research institutions. Results obtained under very different radiation conditions, using detector heads with non-uniform rectangular (radiometric) characteristics, and then relating them to one another, may lead to false conclusions. This is because the varying spectra of the radiation sources in use are ignored in obtaining the measurement.

The solution is to evaluate the irradiance with a sensor with an appropriate spectral response function. It is presently assumed that the number of light quanta absorbed is responsible for plant growth, which implies that it is quantum magnitudes effective in plant biology that need to be measured. The most important

magnitude is the photosynthetic photon irradiance E  $_{\rm p,sy.}$ 

The wavelength limits of integration band pass need to be specified. If, for example, the photosynthetic photon irradiance is to be measured in the range of wavelengths between 400 nm and 700 nm, 320 nm and 500 nm and 590 nm to 900 nm, the integration is carried out in the corresponding spectral segments.

sensitivity

ē

0.5

0

380

430

480

530

580

wavelength (nm)

630

680

This numerical integration can be performed implicitly by means of a cosine corrected integral detector such as the PS-37 series.



Waterproof version of the PS-37 type detector head with dome cover

#### **PS-3701: PAR Irradiance Detector**

Photosynthesis is one of the most important biochemical processes on the planet. In the process of photosynthesis green plants absorb carbon dioxide from the atmosphere and water from the soil, combining them with the aid of radiation energy to build sugar, releasing oxygen and water into the atmosphere. In general plant physiology, the term **P**hotosynthetically **Active**  **R**adiation (**PAR**) refers to the radiation in the range of wavelengths between 400 nm and 720 nm.

The PS-3701 detector is designed for direct evaluation of **P**hotosynthetically **Active R**adiation in the 400 to 700 nm wavelength range. This detector can also be supplied with an optional water proof dome cover.

#### PS-3702: BLUE<sub>320-500 nm</sub> Plant Physiology Irradiance Detector

**Phototropism** describes the effect of optical radiation on the direction of plant growth. The regions of maximum effect lie in the blue range between 380 nm and 520 nm. Radiation can have the effect of causing parts of plants to move.

The PS-3702 detector is designed for direct evaluation of the **phototropism** effective irradiation over the spectral range from 320 to 500 nm for UV-A to green/visible assessment. This detector can also be supplied with an optional water proof dome cover.



#### PS-3703: RED<sub>560-900 nm</sub> Plant Physiology Irradiance Detector

Photomorphogenesis describes the way in which plants are formed under the influence of optical radiation. Radiation in the red region of the spectrum encourages linear growth, while blue radiation yields small, strong plants. To be more precise, the ratio of the radiation intensities in the range of wavelengths from 690 nm to 780 nm (long wavelength red) to the range of wavelengths from 560 nm to 680 nm (short wavelength red) is of great importance for the plant's biological processes. The PS-3703 detector evaluates photomorphogenesis effective radiation in the wavelength range from 590 to 900 nm. This detector can also be supplied with an optional water proof dome cover.



Ordering In	formation & typical \$	Specifications							
Model	λresp	Wavelength	Typical Sensitivity	Imax	Sensing Area	cable	Operation	plug	package
	Plant Physiology	Range	nA / µMol*m <sup>-2</sup> *s <sup>-1</sup>	mA	mA Diffuser r		Temp.		page
PS-3701	PAR	400-700 nm	100	1	11 mm Ø	2	5-40°C	1, 2, 4	90
PS-3702	BLUE	320-500 nm	2	1	11 mm Ø	2	5-40°C	1, 2, 4	90
PS-3703	RED	590-900 nm	100	1	11 mm Ø	2	5-40°C	1, 2, 4	90
K-PS37xx-I	Calibration of PAR sensitivity in A/ $\mu$ Mol*m <sup>-2</sup> *s <sup>-1</sup> . Includes K-SR in new detector order. xx = detector model								
KDW-S	Calibration of spectral sensitivity at one or multiple wavelengths without or in combination with accessory components								
KDW-R	Calibration of integral radiometric sensitivity in combination with accessory components								

# High Intensity Irradiance / UV-Curing

**Three Different Package Designs** 

### High Intensity Irradiance Detectors for UV-Curing Applications

Gigahertz-Optik offers irradiance detectors specially designed for hostile ambient conditions involving high intensity irradiation and high temperature.

The detectors consist of two

main components, the passive

RADIN element and the detector

The RCH type detectors are of-

that are connected by a flexible or rigid light guide.

The light guide protects the detector and corrective band pass filter from heat damage and also reduces measurement errors due to the temperature coefficient (drift) of the photodiode.

for use in the most common UV

RADIN itself is high UV irradiation and temperature stable up to 100°C with short peak measurements to 200°C. The low profile (9 mm) RADIN sensor element permits irradiance measurement close to the sample surface of the probe and offers a cosine

adapted field-of-view. Irradiances of up to 40 W/cm<sup>2</sup> can be measured.

For spot curing applications, adapters are available for simple positioning of different size light guide nozzles in front of the RADIN sensor.

#### **Three Different Spectral Sensitivities**

Detector spectral responses are

365 nm peak UVA as well as UV broadband and BLUE ranges.

> 410 430

450 470

i san il

06: UV Broadband Sensitivity






High Intensity & UV-Curing Actinic Irradiance / 360 Deg. F.O.V. Irradiance

### RCH-1xx, RCH-1xx & RCH-5xx: High Intensity Irradiance Detectors

Ordering Inf	ormation & typic	cal Spe	cifications	\$									
Model	λresp	Resp.	Max. E	E & T	Typ. Sensitivity	Imax	Sensing Area	Light Guide	cable	Front ad	dapter	plug	package
	Broadband	Page	W/cm <sup>2</sup>	°C	nA/mW/cm <sup>2</sup>	mA	Diffuser	cm / inch	m	Dia.	Page		page
RCH-006	UV Broadband	14	40	100	0.3	0.1	9 mm Ø	50 / 20	0.5	5,7,10	91	1,2,4	91
RCH-008	UVA Peak 365 nm	14	40	100	0.3	0.1	9 mm Ø	50 / 20	0.5	5,7,10	91	1,2,4	91
RCH-009	BLUE Peak 430 nm	14	40	100	0.2	0.1	9 mm Ø	50 / 20	0.5	5,7,10	91	1,2,4	91
RCH-106	UV Broadband	14	40	100	0.3	0.1	9 mm Ø	22 / 8.7	0.5	5,7,10	91	1,2,4	91
RCH-108	UVA Peak 365 nm	14	40	100	0.3	0.1	9 mm Ø	22 / 8.7	0.5	5,7,10	91	1,2,4	91
RCH-109	BLUE Peak 430 nm	14	40	100	0.2	0.1	9 mm Ø	22 / 8.7	0.5	5,7,10	91	1,2,4	91
RCH-506	UV Broadband	14	40	100	0.065	0.05	6 mm Ø	-	2	-	-	1,2,4	91
RCH-508	UVA Peak 365 nm	14	40	100	0.096	0.1	6 mm Ø	-	2	-	-	1,2,4	91
RCH-509	BLUE Peak 430 nm	14	40	100	0.065	0.1	6 mm Ø	-	2	-	-	1,2,4	91
K-RCHxxx-I	Calibration of irra	diance	sensitivity i	n A/W/a	m². Includes K-S	R in n	ew detector ord	er. xxx = dete	ector m	nodel			
KDW-S2	Calibration of spe	ectral irra	adiance se	nsitivity	at one or multiple	e wave	elengths without	or in combin	ation w	vith acces	sory c	ompor	nents
KDW-R2	Calibration of inte	egral irra	idiance ser	nsitivity	with accessory co	ompor	ients.						

### ROD-360-UV18: 360 Degree F.O.V. UV-C<sub>254nm</sub> Irradiance Detectors

The ROD-360 is an unique irradiance detector which offers a 360 degree field-of-view. A quartz-rod is used to collect all

light irradiating it's diffuse detec-

(



tion window independent of the horizontal incident angle within the round angle. The vertical axis exhibits a diffuse viewing characteristic.

> With it's narrow band UV-C response the ROD-360 is suitable for measurement of the effective UVGI in air and water germicidal applications employing low and medium pressure mercury lamps.

Calibration is done using a 254 nm low pressure mercury light source.

The ROD-360 features a waterproof housing which allows measurements in humid or underwater applications. The 10 mm diameter clear quartz tube not only seals the detector rod but along with it's stainless steel housing the probe and active

ROD-360 fixed in vertical mound adapter with tripod threaded hole at the bottom

window can be easily cleaned. This makes the ROD-360 usable in gray water or other dirty measurement environments and also in medical applications.

A protective cap and mounting adapter is supplied to fixture the probe for vertical or horizontal use on a standard tripod or for integration into the application.

Ordering Information & typical Specifications													
Model	λresp	Wavelength	Typical Sensitivity In		Imax	Sensing Area	cable	Operation	plug	package			
	Narrow Band	Range	nA/W/m <sup>2</sup>	µA/W/cm <sup>2</sup>	mA	Rod	m	Temp.		page			
ROD-360-UV18	UV-C	220-280 nm	0.8	8	0.1	5 Ø x 6.5 mm	2	0-40°C	1,2,4	92			
K-ROD360-UV18-S	Calibration of th	e irradiance sensi	tivity in A/W/m <sup>2</sup>	<sup>2</sup> and. A/W/cm	<sup>2</sup> Inclu	iding K-SR in orc	ler with i	new detector.					
KDW-S2	Calibration of spectral irradiance sensitivity at one or multiple wavelengths												

# Multi-Channel Illuminance & Irradiance

### XD-95: Single & Dual Channel Illuminance & Irradiance Detector

The XD-95 detectors are designed for use with Gigahertz-Optik's multi-channel X1 and X9 hand-held optometers. The ability to measure two wavelength ranges without having to change and replace the detector head greatly simplifies the measurement procedure. Several detectors are offered covering common applications. A short overview describing the various models is shown here. More information is available in the X9 and X11 optometer data descriptions.

The XD-95 detectors are supplied in a compact lightweight

### XD-9501: UV-A & UV-B Irradiance

Ultraviolet radiation is used in the treatment of certain skin diseases like Psoriasis and for photobiological studies like SPF testing. The phototherapist needs to monitor the source irradiance or energy for accurate dosimetry. Typical wavelength ranges of interest are UV-A<sub>320</sub>.

400nm, UV-B<sub>280-320nm</sub> and UV-B<sub>311nm</sub>. The XD-9501 detector offers a real polychromatic radiometric spectral match to the UV-A and UV-B spectral ranges and a precise cosine corrected field of view.

### XD-9502: UV-A Irradiance & V(λ) Illuminance

Liquid Penetrant Testing of surface defects using the dye penetration process (DIN EN 1956, ASTM and MIL Standards) and Photostability testing of drug and drug products as stated in ICH guidelines (International Conference for Harmonization) requires the intensity or dose control of the light sources used for test sample irradiation. The XD-9506 detector offers a real broadband radiometric UV-A\_{315-400nm} detector and a illuminance detector (f1'  $\leq$ 6%), both with cosine diffuser for precise readings in both applications.

### XD-9503: UV-B<sub>240-340nm</sub> & UV-A<sub>315-400nm</sub> Irradiance

TL01 and TL12 light sources are widely used in phototherapy applications. The phototherapeutic effective radiation of the TL01 and TL12 source falls within the 240 to 340 nm bandpass with peak at 313 nm.

tic effective UV-B and UV-A irradiance of TL01 and TL12 light sources. The detectors spectral sensitivity functions and calibration using TL1 and TL12 light sources ensure precise readings.

The XD-9503 is specially designed to measure the therapeu-

### XD-9504: VISIBLE<sub>400-800nm</sub> & NIR<sub>800-1200nm</sub> Irradiance

Light has therapeutic effects in many different wavelength ranges. However broadband light sources will emit light at wavelengths outside the phototherapeutic wavelength range. This 'stray light' can interfere with the treatment or even cause harm in terms of heat for example, so must be measured in order to be kept to minimal levels.

The XD-9504 is designed to measure irradiance in the 'signal' wavelength range (400-800 nm) and 'noise' range (800-1200 nm). Both detectors offer a 'flat' broadband spectral response

### XD-9505: UV-Broadband<sub>240-400nm</sub> Irradiance

In some applications the total UV irradiance of broadband light sources needs to be measured. But because of the unavailability of ultraviolet detectors with radiometrically 'flat' spectral sensitivities across the entire UV range, relative measurements are normal. The XD-9505 can be

used for relative broadband UV assessment and can provide more precise UV measurement through calibration correction when the emission spectrum of the light source is known.

The single detector offers a cosine diffuser for precise readings in diffuse irradiation zones. and low profile plastic housing with a 2 m long cable with -4

type plug for use with the X9 and X1 meters.





wavelength ( nm )











# 🕞 Gigahertz-Optik

# Light Detectors - Page 75





# **Multi-Channel Illuminance & Irradiance**

### XD-9506: EM6 & EN14255 ACGIH Irradiance

Several guidelines and standards concerning UV hazard risk assessment exist today. Most often the ACGIH/ICNIRP spectral weighting function for the acutely harmful effects is recommended as reference for irradiance measurements (American Conference of Governmental Industrial Hygienists (ACGIH) and the International Commission on Non-Ionising Radiation Protection (ICNIRP). The XD-9506 ACGIH detector is designed to meet EM 6, DIN-EN 14255 and BGV B9 regulations. It's two cell design offers best possible isolation between UV-A and UV-B.

As part of these requirements an additional UV-A irradiance detector like the XD-9502, XD-9511 or UV-3717 is needed.

### XD-9509: 2-Channel Erythema Effective Irradiance

The typical symptom of UV erythema is acute skin inflammation caused by UV radiation (sunburn) which may be linked to skin cancer over prolonged exposure times. The XD-9509 detector permits direct measurement of the UV Erythemal effective irradiance by means of it's spectral sensitivity adaptation to the nominal CIE Erythemal spectral function. It's two cell design offers best possible isolation between the UV-A and UV-B range.

### XD-9510: DIN EN 12198 ACGIH Irradiance

The XD-9510 detector is a modified version of the XD-9506 ACGIH irradiance detector. The difference is the spectral response of the UV-A cell which simulates the *flat UV-A response* specification for DIN EN 12198. Both detectors offer a cosine diffuser.

### XD-9511: UV-A & EN 14255 UV-A<sub>315-400nm</sub> Irradiance

The XD-9511 offers a single detector with UV-A spectral response from 315 to 400 nm. Because of it's good blocking of the visible spectrum above 400 nm, this detector can also be used in combination with the XD-9506 for measurement of UV-A irradiance following DIN EN

#### 14255 and BGV B9.

The detector offers a cosine diffuser for precise measurements in diffuse light incident conditions.

Ordering In	formation & typ	oical Specificati	ons								
Model	Ch1 λresp	Ch2 λresp	Typical Se	ensitivity	Sensing Area	cable	Operation	Optor	neter	plug	package
			nA/	nA/	Diffuser	m	Temp.	X9 type			page
XD-9501	UVA <sub>320-400nm</sub>	UVB <sub>280-320nm</sub>	17 W/m <sup>2</sup>	2.5 W/m <sup>2</sup>	8 mm Ø	2	5-40°C	X96	X11	4	91
XD-9502	UVA <sub>315-400nm</sub>	$V(\lambda)$	10 W/m <sup>2</sup>	0.05 lx	8 mm Ø	2	5-40°C	X98	X11	4	91
XD-9503	UVA 315-400nm	UV <sub>Peak 311nm</sub>	4 W/m <sup>2</sup>	2 W/m <sup>2</sup>	8 mm Ø	2	5-40°C	-	X11	4	91
XD-9504	VIS <sub>400-800nm</sub>	NIR <sub>800-1200nm</sub>	0.7 W/m <sup>2</sup>	130 W/m <sup>2</sup>	8 mm Ø	2	5-40°C	-	X11	4	91
XD-9505	UV <sub>Broadband</sub>	-	13 W/m <sup>2</sup>	-	8 mm Ø	2	5-40°C	X97	X11	4	91
XD-9506	UVA <sub>ACGIH</sub>	UVB <sub>ACGIH</sub>	4000 W/m <sup>2</sup>	1.5 W/m <sup>2</sup>	8 mm Ø	2	5-40°C	-	X11	4	91
XD-9509	UVA <sub>Erythema</sub>	UVB <sub>Erythema</sub>	tbc W/m <sup>2</sup>	tbc W/m <sup>2</sup>	8 mm Ø	2	5-40°C	-	X11	4	91
XD-9510	UVA <sub>ACGIH</sub>	UVB <sub>ACGIH</sub>	4000 W/m <sup>2</sup>	1.5 W/m <sup>2</sup>	8 mm Ø	2	5-40°C	-	X11	4	91
XD-9511	UVA <sub>315-400nm</sub>	-	4 W/m <sup>2</sup>	-	8 mm Ø	2	5-40°C	X97	X11	4	91
K-XD95xx-l	Calibration of int	tegral illuminance	e/irradiance sen	sitivity in A/Ix	or A/W/cm <sup>2</sup> . Inc	ludes ł	<-SR in new	detector o	rder. xx =	detecto	r model
KDW-S2	Calibration of sp	oectral irradiance	sensitivity at or	e or multiple	wavelengths						

# Multi-Channel Illuminance, Irradiance & Luminous Color

### **TP-4501: Triple PAR Irradiance Detectors**



The TP-4501 is a unique detector head designed for use with the X11 hand-held optometer to measure on-site lighting conditions in greenhouses, plant growth studies, soil and seed science.

The compact detector houses

four different detectors:

PAR: Measures the photonsynthetically effective radiation in the 400 to 700 nm wavelength range actinic for green growth. BLUE: Measures the phototropism effective radiation within the 320 to 500 nm wavelength range actinic for directional plant growth.

RED: Measures the photomorphogensis effective radiation within the 560 to 900 nm wavelength range actinic for plant growth formation.  $V(\lambda)$ : Measures the **photomet-**

ric illuminance which specifies the ambient lighting condition. The low profile detector housing



is only 20 mm high with a central 10 mm diameter diffuser which ensures the cosine corrected field of view required in illuminance & irradiance applications.

Ordering In	formation &	Specification	ns											
Model	λresp	λresp	λresp	λresp	Т	ypical S	Sensitivi	ty	0	cable	Operation			package
	Ch1	Ch2	Ch3	Ch4	CH1	CH2	CH3	CH4	Area	m	Temp. ℃	Туре		page
	photometric	Plant I	Physiology Eff	ective	pA/lx	pA/μ	Mol*m	<sup>-2*</sup> S <sup>-2</sup>	Diffuser		C			
TP-4501	$V(\lambda)$	PAR <sub>400-700 nm</sub>	BLUE <sub>320-500 nm</sub>	RED <sub>560-900 nm</sub>	40	0.1	2	70	10 mm Ø	2	5-45	X11	4	90
K-TP4501-I	Calibration o	f photometric	& plant physic	logy effective	e sensit	ivity in	A/Ix & A	õMol*	m <sup>-2*</sup> s <sup>-2</sup> . Inc	ludes l	≺-SR in new	detect	or ord	er.
KDW-S2	Calibration o	ation of spectral irradiance sensitivity at one or multiple wavelengths without or in combination with accessory components.												

### CT-3701 & CT-4501: Luminous Color and Illuminance Detectors



### CT-3701

The CT-3701 and CT-4501 luminous color detectors are designed with precise x,y,z tristimulus matching functions to measure the illuminance, x,y chromaticity values and color temperature of broad band emitting light sources. Four detectors mounted in one compact housing are used to form the  $x_{\mbox{\tiny short}},\,x_{\mbox{\tiny long}},\,y$  and z spectral tristimulus values for the 2 degree viewer.

CT-4501-4 Both probes feature two separate  $x_{short}$  and  $x_{long}$  functions to provide more accurate readings in the blue region over detectors

with only the  $\boldsymbol{x}_{\text{long}}$  function and a simulated  $x_{short}$  using the z values. Sandwich filtering technology allows a very compact housing

design with a only 10 mm diameter diffuser window. This ensures a uniform illumination of the dif-



fuser as required for the measurement of illuminance.

A special feature of the CT-3701 detector is temperature control of it's photodiodes and filters for ambient temperature independent operation. This allows the

CT-3701 to be integrated into industrial qualification process control applications where long term stability is essential. CT-3701 and CT-4501 can be combined with other components like luminance steradian tubes.

Ordering In	formation &	Specificatio	ns											
Model	λresp	λresp	λresp	λresp	Т	ypical S	Sensitivi	ty	Sensing	cable	Opera-	Meter	plug	package
	Ch1	Ch2	Ch3	Ch4	CH1	CH2	CH3	CH4	Area	m	tion Temp.	Туре		page
	380-500 nm	500-730 nm	380-780 nm	380-580 nm		nA/lx at	2856 K	Ś	Diffuser		remp.			
CT-3701	x short	x long	у	Z	0.07	0.03	0.08	0.02	10 mm Ø	2	+40°C	P-9801	1	92
CT-4501	x short	x long	у	Z	0.07	0.03	0.04	0.01	10 mm Ø	2	5-40°C	X11	4	90
K-CT3701	Calibration c	f illuminance :	sensitivity A/lx,	x,y chromatio	city valı	ues and	color te	empera	ture. Incluc	les K-S	R in new o	detector (	order.	
K-CT4501	Calibration o	on of illuminance sensitivity A/Ix, x,y chromaticity values and color temperature. Includes K-SR in new detector order.												
KDW-S	Calibration o	f spectral sen	sitivity at one o	or multiple wa	avelenç	gths with	nout or i	in comb	pination wit	h acces	ssory com	ponents		

# Luminance & Radiance

Luminance & Radiance

Radiance L is described as the intensity of optical radiation from an irradiated or irradiating surface in a particular direction measured with a specified solid angle.

The units of radiance are W/ (m2\*sr). Light detectors with a defined angle of view are used to measure radiance



**Photometric and Radiometric** 

detectors from the PD-16 series

combine with the LDM-9810 and

LDM-9811 viewing module to set

up a luminance or radiance

The PD-16VL01 photometric

detector has been adapted with

great care to the ideal V( $\lambda$ ) func-

tion, and in combination with the

I DM-98 meets the DIN class A specification for the adaptation

error of  $f_1$  ' less than or equal to

3%. Typical applications of the

luminance detector LDM-98/PD-

16VL01 include photometric

• Luminous surfaces such as

monitor screens, alphanumeric

displays, information signs,

emergency lighting and illumi-

• Reflecting surfaces such as

walls and workplace equip-

ment, projection screens, traf-

fic and information signs, road-

• Light emission in accordance

• Fluorescent pigments with

• In lighting design stage of

workplace and office design

with Federal Emissions Stat-

brightness measurement of:

nated control panels

ways and roller tracks

long afterglow decay

Luminance Measurement:

measurement device.

view.

Luminance L is described as the measurable photometric brightness of an illuminated or illuminating surface. In many cases luminance describes the quality of illumination much better than illuminance. The units of luminance are candela per unit area (cd/m<sup>2</sup>) or nit and footlamberts (fL). Detector heads

with a defined angle of view are used to measure luminance so that a small area within a larger uniform field is sampled.

> $cd/m^2 = nit = Im/(m^2 * sr)$  $fL = Im/(ft^2 * sr)$  $1 \text{ cd/m}^2 = 2.919 \text{x} 10^{-1} \text{ fl}$

### LDM-9810 & LDM-9811: Luminance & Radiance Detectors

### **Radiance Measurement:**

The PD-16RW05 radiometric detectors with spectral sensitivity within the wavelength range from 400 to 1000 nm are the right choice for radiance measurement in the visible and near infrared wavelength region.

### **Light Hazard Protection:**

The quantity used for determination of blue light hazard and retinal thermal hazard to the human eye is radiance, measured in the radiometric unit of W/m<sup>2\*</sup>sr. Three different spectral response functions are typically used for light hazard protection radiance measurements:

- Blue-light Hazard (400-520 nm)
- Retinal Thermal Hazard (520-1400 nm)
- Retinal Thermal Hazard IR-A (780-1400 nm)

Gigahertz-Optik offers three different PD-16 detectors to be combined with the LDM-9811 viewer module for this application.

• PD-16BLH:

Blue light hazard detector

- PD-16RTH: Retinal thermal hazard detector
- PD-16RTHA: Retinal thermal hazard IR-A detector

### **Optional Accessories:**

The LDM-98NL narrow lens provides a variable 1:1 to 2:1 near field magnification for measurement of spot diameters down to 0.1 mm.

The LDM-98FC enables coupling a flexible fibre bundle instead of a PD-16 detector to the LDM-98 to allow connection and use with spectral radiometers. The BHO-01 hard carrying case holds the LDM-98/PD16 with P-



9710 optometer for mobile applications.

### Calibration in Light Measurement Units:

Calibration of the detector is carried out by Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities, traceable to international standards.

Calibration in the units related to the selected PD-16 detector is supplied for each viewing angle with and without optional narrow lens.

For best handling of the multiple calibration factors the P-9710 and P-2000 optometers are recommended for use with the LDM-98/PD16 luminance and radiance detector heads outfitted with (-2) programmable data connectors



PD-16 Light Detector

LDM-9810 and LDM-9811 are modularly designed viewer modules that are combined with PD-16 detectors to form luminance and radiance measurement heads offering flexible spot size diameter selection. Both units are built with stable aluminium housings to ensure precise measurement in laboratory or field use.

The unit's wide aperture focussing objective is achromatically corrected, and satisfies the tightest requirements for the suppression of stray light and image formation.

Both viewer modules offer three selectable fields of view:

- LDM-9810: 20', 1° and 6°
- LDM-9811 .

1.7, 11 and 100 mrad

A f.o.v. selector knob is located on the rear of the device. The resultant size measurement spot is visible through the ocular viewfinder. In combination with the cross-hair targeting aid alignment of the LDM-98 to the zone of interest is simple.

Focussing is achieved by adjusting the sharpness of the image on the viewfinder screen.

The useable measurement distance of the LDM-98 spans from 0.3m to ∞. The area of the measured surface depends on the distance to the target and on the angle chosen for the field of

> Eve Eyepiece Surrounding Field Cross LDM-98 Hairs Detector Aperture Lens

utes

sample Beam Splitter Focusing Adjustment Measurement Spot

# LDM-9810 & LDM-9811: Luminance & Radiance Detectors









PD-16RW05

PD-16RTHA



PD-16VL01

F.O.V.		LDM-9810				
Distance	<b>6</b> °	1°	20'	100 mrad	LDM-9811 11 mrad	1.7 mrad
0.3 m	21	3.5	1.2	19.9	2.2	0.4
0.5 m	41.9	7	2.3	39.8	4.4	0.8
1 m	94.3	15.8	5.2	89.6	9.9	1.8
2 m	199	33.2	11	189.2	20.9	3.8
10 m	1037	173	57	986	109	19.8
th LDM-98NL Nar	row Lens (Optional)			L		
100 mm / f=∞	10.5	1.8	0.6	10	1.1	0.2
75 mm / f=0.3m	5.2	0.9	0.3	5	0.6	0.1

### **Ordering Information & typical Specifications**

Model	λresp	Wavelength	f1	Тур	oical Sensitivi	ty	Imax	Sensing Area	cable		plug	packag
		Range	$\leq \%$	*) nA/cd*	*m² or **) nA	/W/m²sr	mA	Lens	m	Temp.		page
LDM-9810				20'	1°	6°		50 mm Ø		5-40°C		92
PD-16VL01	V(λ)	380-400	3	0.0035 *)	0.033 *)	0.9 *)	1	5.8 x 5.8	2	5-40°C	1,2,4	92
LDM-9811				1.7 mrad	11 mrad	100 mrad		50 mm Ø		5-40°C		92
PD-16BLH	BLH	400-520	-	0.2 **)	5.7 **)	380 **)	1	5.8 x 5.8	2	5-40°C	1,2,4	92
PD-16RTH	RTH	500-1200	-	0.3 **)	11 **)	780 **)	1	5.8 x 5.8	2	5-40°C	1,2,4	92
PD-16RTHA	RTHA	800-1200	-	0.2 **)	5 **)	360 **)	1	5.8 x 5.8	2	5-40°C	1,2,4	92
PD-16RW05	RW05	400-1000	-	0.38 **)	12 **)	840 **)	1	5.8 x 5.8	2	5-40°C	1,2,4	92
PD-16VL01	V(λ)	380-400	3	0.00004 *)	0.00015 *)	1.1 *)	1	5.8 x 5.8	2	5-40°C	1,2,4	92
LDM-98Z-NL	Narrow Lens	s for use with L	DM-9	810 and LDN	Л-9811							
LDM-98Z-FC	Fiber Couple	er to adapt flex	ible liq	ght guide bu	ndles to the L	DM-9810 a	and LD	M-9811				
K-LDM98BLH	Calibration o	of effective BLH	l radia	ance sensitiv	ity with <b>or</b> wit	hout LDM-9	98NL ir	n A/W/m²*sr (at	3 f.o.v.	angles). 1)		
K-LDM98RTH	Calibration of	of effective RTH	l radia	ance sensitiv	ity with <b>or</b> wit	hout LDM-	98NL ir	n A/W/m²*sr (at	3 viewir	ng angles). 1	)	
K-LDM98RTHA	Calibration of	of effective RT	HA ra	diance sensi	tivity with <b>or</b> w	without LDN	Л-98NL	_ in A/W/m²*sr (a	at 3 viev	ving angles).	. 1)	
K-LDM98RW05	Calibration of	of 400-1000 nm	n radia	ance sensitiv	ity with <b>or</b> wit	hout LDM-9	98NL ir	n A/W/m²*sr (at	3 viewir	ng angles). 1	)	
K-LDM98VL01	Calibration of	of luminance se	ensitiv	ity with <b>or</b> wi	thout LDM-98	BNL in A/cd	l/m² (a	t 3 viewing angle	es). 1)			
K-LDM98NL	Additional ca	alibration of lur	ninan	ce or radiand	ce sensitivity f	for LDM-98	with L	DM-98NL narro	w lens			
KDW-S	Calibration of	of spectral sens	sitivity	at one or mi	ultiple wavele	engths with	out or	in combination v	vith acc	essory comp	oonents	3
1) Includes K-SR	with new dete	ector order										

1) Includes K-SR with new detector order

Luminance

### LDM-9901: Luminance Detector

Luminance detectors that are characterized as quality class A or B, in accordance with DIN 5032 Part 7, need to be constructed from carefully selected elements. These include optics with achromatic correction and low stray light, and a photopic detector with a response curve that has been carefully adapted to the ideal V( $\lambda$ ) function. Add an expensive telescopic finder and a focusing optical system for locating the target area and these luminance detector heads become too costly for many applications. The widely used auxiliary lenses that can be attached to illuminance detector heads for luminance measurement are not a good alternative, since they typically do not satisfy the requirements of DIN 5032 Part 7.

An economical alternative which does satisfy the requirements of IEC 61223-2-5 and DIN 5032 Part 7 is the LDM-9901. It is a high quality photometric detector for determining luminance in cd/ m<sup>2</sup>. Its properties satisfy the requirements for Quality Class B of DIN 5032 Part 7.

Distance t	to Spot Comparison
distance	spot diameter
0.5 m	~ 31 mm
0.7 m	~ 35 mm
1 m	~41 mm
5 m	~ 120 mm
10 m	~ 220 mm
50 m	~ 1000 mm
100 m	~ 2000 mm

# The LDM-9901 detector key components are:

- ©achromatically corrected low stray light lens to collect light with a 1° field of view
- Chigh-quality photodiode with accurate V( $\lambda$ ) correction filter
- ©sight for locating the target measuring area

The low-stray-light achromatic corrected objective is designed so that in its useable measurement range of 40 cm to infinity it is not necessary to make focusing adjustments to the lens. The 1° field of view means that the diameter of the measurement spot differs depending on the measuring distance.

The adaptation for photopic vision offers a f<sub>1</sub>'of  $\leq$  5 %. This means that the LDM-9901 detector can be used to measure the output of monitors, LED displays and other sources without suffering from an unacceptable increase in measurement uncertainty due to the quasimonochromatic type radiation of these sources.



троа	Adapter	(Optioi

LDM-9901 Comparison to DIN 5032 Cla	ass B Limi	ts (%)	
Characteristics	Symbol	LDM-9901	DIN
Calibration Uncertainty	U <sub>kal</sub>	1.5	4
$V(\lambda)$ Match Characteristic	f <sub>1</sub>	5	6
UV Response Characteristic	u	0.01	2
IR Response Characteristic	r	0.01	2
Linearity Characteristic	f <sub>3</sub>	0.2	2
Fatigue Characteristic (at 1 klx)	f <sub>5</sub>	0.1	1
Temperature Dependence Characteristic	f <sub>6</sub>	1	10



The LDM-9901 detector has an externally mounted targeting These back and front sights are adjusted for measuring distances of 70 cm, 140 cm and  $\infty$ as shown below. In order to locate the object to be measured, the detector head is held in front of the eye at such a distance (about 25 cm) that the back and front sights appear sharp. Depending on the observer's age, other distances may be appropriate. The two sights are then aligned with the desired part of the object being measured. The sights consists of a black

70 cm

slotted V-notch and a white ball. The following figure shows the different alignments for various measuring distances.

In many applications a luminance detector is used with a tripod. An adapter plate to attach the detector and tripod are offered as options.

The detector is connected to the optometer via a 1 m flexible connecting cable .

Calibration of luminance sensitivity in A/(m<sup>2</sup>cd<sup>-1</sup>) is carried out at Gigahertz-Optik's Calibration Laboratory and is confirmed by a factory certificate.

Infinity



140 cm

Notch and Bead Sight at difference Distances

Ordering Info	Ordering Information & typical Specifications												
Model	λresp	Wavelength	f1	Typical Sensitivity	Imax	Sensing Area	cable	Operation	plug	package			
	Photometric	Range	≤%	pA/cd*m <sup>2</sup>	mA	Lens	m	Temp.		page			
LDM-9901	$V(\lambda)$	380-780 nm	5	25	1	22 mm Ø	2	0-40°C	1, 2, 4	92			
LDM-99Z-02	Ambient light	t shade made b	y elastic	rubber to place the LDM-99 d	lirect on	the monitor surfa	ce						
K-LDM9901	Calibration o	f integral lumina	ince sen	sitivity in A/cd/m². Including K	SR in n	new detector orde	r.						
KDW-S	Calibration o	f spectral sensit	ivity at or	ne or multiples wavelengths									

Ordering Information & typical Specification

### Luminance & Radiance / Luminous Flux & Radiant Power

### SRT-M37: Front Lenses for 37-Type and 45-Type Illuminance & Irradiance Detectors



In some applications simple front lenses are required to limit the field of view of irradiance and luminance light detectors. The SRT-M37L series front lenses can be combined with the 37-type and 45-type irradiance,

illuminance and luminous color detectors for this purpose. The detector itself is mounted into the SRT-M45/37 base mount that has a M37x1 front thread where the SRT-M37L front lens can be attached.

The base mount offers a side M6 and camera type (1/4"-20 BSW) threaded hole for standard tripod or bench post or to fixture the device into an application. Beside the four front lenses offered custom solutions with quartz lenses, other lens diameters are available on special request.

Contact an applications engineer to discuss your requirements.

Ordering Information &	·· ·	1			1			1	
Model	λresp	Wavelength	Typica	al Sensitivity	Sensing Area	cable	Operation	plug	package
		Range			Lens	m	Temp.		page
SRT-M37L-1/VL-3701	$V(\lambda)$	380-780	1.2	pA/cd*m <sup>2</sup>		2	5-40°C	1, 2 or 4	89
SRT-M37L-2/VL-3701	V(λ)	380-780	2.3	pA/cd*m <sup>2</sup>		2	5-40°C	1, 2 or 4	89
SRT-M37L-5/VL-3701	$V(\lambda)$	380-780	12	pA/cd*m <sup>2</sup>		2	5-40°C	1, 2 or 4	89
SRT-M37L-1/CT-4501	V(λ)	380-780	0.05	pA/cd*m <sup>2</sup>		2	5-40°C	1, 2 or 4	89
SRT-M37L-2/CT-4501	V(λ)	380-780	0.4	pA/cd*m <sup>2</sup>	22.4 mm Ø	2	5-40°C	1, 2 or 4	89
SRT-M37L-5/CT-4501	V(λ)	380-780	2	pA/cd*m <sup>2</sup>	-	2	5-40°C	1, 2 or 4	89
SRT-M37L-10/CT-4501	V(λ)	380-780	9	pA/cd*m <sup>2</sup>	-	2	5-40°C	1, 2 or 4	89
SRT-M37L-1/RW-3703	Radiometric	400-800	5	nA/W/m²sr	-	2	5-40°C	1, 2 or 4	89
SRT-M37L-2/RW-3703	Radiometric	400-800	9	nA/W/m²sr	-	2	5-40°C	1, 2 or 4	89
SRT-M37L-5/RW-3703	Radiometric	400-800	48	nA/W/m²sr	-	2	5-40°C	1, 2 or 4	89
Specifications for other De	etector/Front Lens	Combinations	not shown	are available or	request. Quartz	lenses for	UV applicatio	ns are ava	ilable.
KDW-P3	Calibration of int	egral luminance	e sensitivity	of an illuminand	ce detector with f	ront lens ir	n A/cd/m²		
KDW-R3	Calibration of int	egral radiance s	sensitivity o	of an irradiance (	detector with fror	t lens in A/	W/m²*sr		
KDW-S3	Calibration of sp	ectral radiance	sensitivity	of an irradiance	detector with fro	nt lens in A	/W/m²*sr nm		
SRT-M45/37B	Basic holder to r	nount 37-type a	nd 45-type	e detectors to SF	RT-M37 type com	ponents			
SRT-M37L-1	Front lens with 1	° field of view. N	leeds SRT	-M45/37B to cou	ple with detecto	r. 1 mm dia	ameter output	aperture.	
SRT-M37L-2	Front lens with 2	° field of view. N	leeds SRT	-M45/37B to cou	ple with detecto	r. 2 mm dia	ameter output	aperture.	
SRT-M37L-5	Front lens with 5	° field of view. N	leeds SRT	-M45/37B to cou	uple with detecto	r. 4.8 mm o	diameter outp	ut aperture	Э.
SRT-M37L-10	Front lens with 1	0° field of view.	Needs SR	T-M45/37B to co	ouple with detect	or. 10 mm	diameter outp	out apertur	e.
SRT-M37Z01	Ambient light sha	ade made by el	astic rubbe	er to be used wit	h the SRT-M37-L	lenses or	the SRT-M37-	-5 tube.	

### **Luminous Flux & Radiant Power**



Luminous flux ♦ is the light power of any light source and is measured in lumens (Im). Since light is not typically emitted as a more or less parallel light beam, luminous flux must be measured with a measurement geometry that acquires the luminous flux independent of its spatial distribution. Light collecting integrating spheres or goniophotometers which can sum the angular light output over 360° are often used.

The luminous flux of a 100 W incandescent bulb is about 1380 Im, while that of a 20 W compact fluorescent lamp is about 1200 Im.

**Radiant power**  $\phi$  is the total power of optical radiation emit-

ted by a source measured in watts (W). The same measurement geometry as in luminous flux measurement applies only the detection system is not photopically corrected.

The most common method **to measure luminous flux and radiant power** from all directional emitting divergent beam sources employs an integrating sphere light detection system. Omnidirectional emitting light sources are placed in the center of the sphere, whereas the light from spot lamps enters the sphere through a port in the



Diffuse multiple reflections at the inner sphere wall suppresses disturbance effects created by the angle of inci-

dence, formation of shadows, reflections, modes etc.

#### sphere wall.

In the "Integrating Spheres" chapter several spheres from 8 mm up to 500 mm diameter are described which can be combined with Gigahertz-Optik light detectors and optometers to form complete luminous flux and radiant power light measurement systems.

# Luminous Flux & Radiant Power

### LSM-9901: Luminous Flux Detector

tor is positioned close to the entrance port in accordance with DIN guidelines and allows for an acceptance angle of up to 90°. The detector is shielded from exposure to direct radiation by a baffle

The specifications of the photodiode correspond to DIN quality class B, permitting use with cold light sources, lamps with a high color temperature, or quasi-monochromatic radiation such as that from light emitting diodes.

The 50 mm diameter integrating sphere is coated with BaSO<sub>4</sub>, guaranteeing diffuse reflectivity and a spectrally neutral reflection characteristic. Optometer connections are made by means of a 2 m coaxial cable with appropriate plug type. Calibration of

luminous flux in lumens (Im) is carried out at Gigahertz-Optik's Calibration Laboratory for Optical Radiation Measurement, and is confirmed by a factory certificate.

Ordering Info	rmation & ty	Ordering Information & typical Specifications											
Model	λresp	Wavelength	f1	Typical Sensitivity	Imax	Sp	here	cable	1	plug	package		
	Photometric	Range	$\leq$ %	nA/Im	mA	Port	Diameter	m	Temp.		page		
LSM-9901	V(λ)	380-780 nm	5	40	1	12.5 mm Ø	50 mm	2	5-40°C	1, 2, 4	91		
K-LSM9901	Calibration of integral luminous flux sensitivity in A/Im. Includes K-SR in with new detector order.												
KDW-S	Calibration of spectral sensitivity at one or multiple wavelengths without or in combination with accessory components.												



Integrating spheres are commonly used in radiant power measurement systems. Functioning as an optical integrator, the integrating sphere is able to measure radiation entering it's port independent of angle. The PRW-0505 radiometric detector for radiant power measurement in the visible and near infrared (NIR) is fitted with an integrating sphere. The sphere, with an internal diameter of 50 mm, is coated with Barium Sulfate offering a diffuse and spectrally flat reflectance characteristic within a specified wavelength range. BaSO4 offers a high re-

# PRW-0505: Polychromatic Radiant Power Detector

flectance of  $\sim$  97 % ensuring good sensitivity and also good long term stability.

The detector is positioned close to the sphere's entrance port to allow highly divergent radiation beams of up to 90 degrees to be accurately measured. The input port has a diameter of 12.7 mm. The radiometric detector is shielded from exposure to direct radiation from the measurement port by a baffle.

Its radiometric sensitivity covers wavelengths between 400-1000 nm allowing the radiant power of broadband and of quasi-monochromatic lamps (such as light emitting diodes) to be measured irregardless of their emission spectra. Gigahertz-Optik optometers are connected with a 2 m coaxial cable with an appropriate plug type. Calibration of sensitivity to radiant power



in W 400-1000 nm is carried out at Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities, and is supported by a factory certificate.

Ordering Inf	Ordering Information & typical Specifications										
Model	λresp	Wavelength	Typical Sensitivity	фтах	Sph	ere	cable	Operation	plug	package	
	Radiometric	Range	μA/W	mW	Port	Diameter	m	Temp.		page	
PRW-0505	Polychromatic	400-1000 nm	90	500	12.5 mm Ø	50 mm	2	5-40°C	1, 2, 4	91	
K-LSM9901	Calibration of integral radiant power sensitivity in A/W. Includes K-SR in new detector order.										
KDW-S1	Calibration of spectral radiant power sensitivity at one or multiple wavelengths without or in combination with accessory components.										



**The LSM-9901** detector is used to measure the luminous flux, in lumens, of directional light beams with varying divergences. The measurement aperture size of its 50 mm diameter integrating sphere is 12.7 mm in diameter, which is sufficient for applications with endoscopes, light emitting diodes, optical fiber bundles and other beam emitters. The photometric light detec-

### LP-9901: Laser Power and Laser Stray Light Detector



W/m<sup>2</sup>

The LP-9901 Detector is designed to measure both laser power in W (the laser beam under fills the detector active area) and laser irradiance in mW/m<sup>2</sup> (the laser beam overfills the detector active area).

The measurement aperture has a diameter of 7 mm which correlates to the maximum size of the eve's pupil.

The LP-9901 offers a dynamic range from 0.1 µW to 100 mW (at 662.8 nm) for power measurement, and 0.0026  $\mu$ W/cm<sup>2</sup> to



260 mW/cm<sup>2</sup>, for the determination of maximum permissible exposure. The low profile detector can be securely held in the laser beam with a rigid 100 mm long detector handle built around the cable and connects to the optometer by a 2 m long cable

with appropriate plug type. Calibration of spectral sensitivity from 400 to 1100 nm is performed in 10 nm increments. Calibration is carried out at Gigahertz-Optik's Calibration Lab and is confirmed by a works certificate

Ordering In	formation & typ	ical Specificati	ons								
Model	λresp	Wavelength	Typical Se	ensitivity	<b>¢</b> ma	ах	cable	lmax.	Operation	plug	package
	Photodiode	Range	633 nm	900 nm	633 nm	900 nm	m	mA	Temp.		page
LP-9901	Si & ND Filter	400-1100 nm	1.3 mA/W	20 mA/W	100 mW	50 mW	2	1	0-40°C	1,2,4	91
K-LP9901	Calibration of spectral radiant power sensitivity in A/W nm and calculated spectral irradiance sensitivity A/W/m <sup>2</sup>										
KDW-S1	Calibration of spectral radiant power sensitivity at one or multiple wavelengths in combination with accessory components										

### LP-01 & LP-02: Radiant Power Detectors with OP.DI.MA. Integrating Sphere





LP-01 detectors are designed for laser power and general optical power measurements in telecommunication testing systems. Using an integrating sphere



Typical spectral sensitivity LP-0101

size, high shunt resistance photodiodes providing high sensitivity and fast rise time to be used. As a result of multiple diffuse

reflectance, integrating spheres can reduce polarization effects, beam misalignment risk, signal bounce-back and PTD saturation. The machined OP.DI.MA. (optically diffuse material) spheres offer the highest reflectance (low attenuation) and longest term stability currently available. The LP-0101, LP-0102 and LP-0103 are built around a 30 mm diameter sphere with a 5 mm measurement aperture. A unique Gigahertz-Optik baffle design offers a large light acceptance angle with no risk of direct detector irradiation.

The LP-0201 employs an 8 mm diameter ODM integrating sphere with a 2 mm measurement port diameter for lowest attenuation. A low profile fast Si

ē

photodiode is used enabling a very short rise time.

Common features include:

Diode array spectrometer can be coupled to an additional detector port with SMA-type fiber connector

Open port configuration is standard for direct measurement of laser diodes, LEDs or lasers.

Fiber connector adapters for FC, SC, ST and SMA connectors are available for the 30 mm sphere measurement port.

Calibration of spectral radiant power sensitivity in A/W nm is offered within the sensitivity range of each detector.



Typical spectral sensitivity LP-0103





**Laser Radiant Power** 

### LP-01 Series: Radiant Power Detectors with OP.DI.MA. Integrating Sphere

Ordering Info	rmation & typi	cal Specificatio	ns										
Model	λresp	Wavelength	Typical Se	ensitivity	Spl	here	cable	Imax.	φmax	Operation	plug	package	
	Photodiode	Range	633 nm	1300 nm	Port	Diameter	m	mA	mW	Temp.		page	
LP-0101	InGaAs	800-1800 nm	-	0.4 mA/W	5 mm Ø	UPK-30-L	2	1	500	5-40°C	1,2,4	91	
LP-0102	Si & InGaAs	350-1800 nm	0.6 A/W	0.4 mA/W	5 mm Ø	UPK-30-L	2	1	500	5-40°C	1,2,4	91	
LP-0103	Si	350-1100 nm	0.6 mA/W	-	5 mm Ø	UPK-30-L	2	1	500	5-40°C	1,2,4	91	
LP-0201	Si LP	400-1100 nm 30 mA/W - 2 mm Ø UPK-8-L 2 1 100 5-40°C 1,2,4 91											
LP-01Z-01	Additional dete	litional detector port for UPK-30-L integrating sphere of LP-01 for PD-11 type detectors or UFC-11/SMA socket											
UFC-11/FC	FC-type fiber s	ocket adapter fo	r the measure	ement port o	f LP-01 dete	ectors with L	JPK-30-	L integr	ating sph	nere			
UFC-11/SC	SC-type fiber s	ocket adapter fo	r the measure	ement port c	f LP-01 det	ectors with L	JPK-30	-L integr	ating spl	nere			
UFC-11/ST	ST-type fiber so	ocket adapter fo	r the measure	ment port o	f LP-01 dete	ectors with U	IPK-30-	L integr	ating sph	nere			
UFC-11/SMA	SMA-type fiber	SMA-type fiber socket adapter for the measurement port of LP-01 detectors with UPK-30-L integrating sphere											
K-LP01xx	Calibration of spectral radiant power sensitivity in A/W nm. $xx =$ detector model number												
K-LP0201	Calibration of spectral radiant power sensitivity in A/W nm												
KDW-S1	Calibration of s	pectral radiant p	ower sensitivi	ity at one or	a chain of v	wavelength i	n comb	ination	with acce	essory			

### LP-99 Series: Radiant Power Detectors with Barium Sulfate Integrating Sphere

**The LP-99** detectors are designed for general radiant power measurements of laser diodes and lasers in the wavelength range from 400 to 1700 nm.

The use of a 50 mm diameter integrating sphere as light collector offers a large 12.7 diameter measurement port and negates the need for using large diameter photodiodes. Small size photodiodes offer lower cost, higher shunt resistance and low capacitance. Also through its multiple reflectance characteristic, integrating spheres can reduce polarization effects, the risk of beam misalignment, signal bounce-back and PTD satura-

> sensitivity 2'0

> > 0

350 450 550 650 750 850 950

ē



tion. Barium sulfate is a cost effective white diffuse coating for larger diameter integrating spheres. It's 97 % reflectance in the visible spectral range exhibits low attenuation making high sensitivity sphere based detectors

1050 1150

1,00

0,50

0,00

sensitivity

æ

are built around a 50 mm diameter sphere with a 12.5 mm aperture. A unique Gigahertz-Optik baffle design offers a large light acceptance angle without direct detector irradiation.

800 900 1000 1100 1200 1300 1400 1500 1600 1700 1800

wavelength(nm)

LP-9920



The LP-9910 is supplied with a Si photodiode covering the 400 to 1100 nm wavelength range.

The LP-9920 is supplied with an InGaAs photodiode for the 800 to 1800 nm range.

The LP-9930 offers both a Si and InGaAs photodiode for broadband use from 400 to 1800 nm with a 2-channel optometer.

The open port configuration is standard for direct measurement of laser diodes, LEDs or lasers. **Calibration** of spectral radiant power sensitivity in A/W nm is provided.

LP-9910

wavelength(nm)

Ordering Information & typical Specifications												
Model	λresp	Wavelength	Typical Se	ensitivity	Sph	ere	cable	lmax.	φmax	Operation	plug	package
	Photodiode	Range	633 nm	1300 nm	Port	Diameter	m	mA	mW	Temp.		page
LP-9910	Si											
LP-9920	InGaAs	InGaAs 800-1800 nm - 0.3 mA/W 12.5 mm Ø UPB-50-L 2 1 500 5-40°C 1,2,4 91										
LP-9930	Si & InGaAs	400-1800 nm	2.5 mA/W	0.3 mA/W	12.5 mm Ø	UPB-50-L	2	1	500	5-40°C	1,2,4	91
LP-99Z-01	Additional dete	ector port for UF	B-50-L integr	rating spher	e of LP-99 for	PD-11 type	detecto	ors or UF	-C-11/SN	IA socket		
K-LP99xx	Calibration of spectral radiant power sensitivity in A/W nm. xx = detector model number											
KDW-S1	Calibration of spectral radiant power sensitivity at one or multiple wavelengths in combination with accessory components											

# Laser Power & Laser Pulse Shape

### LPPA-99: Laser Power and Pulse Shape Detector



photon absorption outside the

Photodiodes with small active

areas cannot be used to meas-

ure radiant power at a risk that

the laser beam would be larger

than the photodiodes area creat-

Conventional PIN photodiodes

require a large bias voltage for

full depletion for long wave-

The LPPA-99 series detectors

are designed around a 50 mm

diameter integrating sphere. The

ing measurement error.

lengths above 800 nm.

depletion zone.

Optoelectronic sensing systems such as laser range finders, profile scanners, distance sensors for example, make use of pulsed lasers generating high peak power and pulse lengths in the order of nanoseconds.

For general analysis or for reasons of safety the pulse shape of a single pulse or pulse train needs to be measured, a high speed detector with a rise time shorter than that of the laser pulse is required.

These photodiodes must be very low capacitance as well as offer

Tek Run: 2.00GS/s Average



large 12.7 mm diameter measurement port allows the measurement of large diameter laser beams and laser diodes with divergent beams. A low-profile type Si photodiode provides a fast rise time even at 1060 nm. A baffle protects the photodiode from direct radiation exposure from the entrance port.

These unique features make the LPPA-99 detectors the right choice for pulse analysis of short and high peak power laser pulses in the absolute units of watts (W).

The Low Profile photodiode is operated with 12 V reverse bias, and is placed in series with a load resistor to create a voltage signal that correlates to the radiant power. The detector connects to a fast sensitive oscilloscopes to display the pulse shape.

Digital storage oscilloscopes enable the user to store individual pulse shapes.

Three LPPA-99 models are available with different sensitivities and rise times.

The spectral sensitivity of the detectors in V/W nm is calibrated in 10 nm increments from 400 to 1060 nm.

Calibration is carried out at Gigahertz-Optik's Calibration Laboratory for Optical Radiation Quantities, and is confirmed by a factory certificate.



Output: SMC Socket for 50 Ohm Coaxial Cable

Ordering In	Ordering Information & typical Specifications												
Model	λresp	Wavelength	Typical S	Sensitivity	<b>φ</b> min	<b>φ</b> max	Rise	Sphere Din	nension	cable	Load	plug	package
	Photodiode         Range nm         633 nm         900 nm         @800 nm         Time ns         Port         Diameter         m         Ohm         page												
LPPA-9901													
LPPA-9902													
LPPA-9903	Si LP	400-1060	1 mV/W	1 mV/W	200 mW	5 kW 1)	≤2	12.5 mm Ø	50 mm	2	50	BNC	91
K-LPPA99 Calibration of spectral radiant power sensitivity in V/W nm.													
1) Pulse peak power only! Average power should not exceed 500 mW													

### **Modular Light Detectors**

Modular light detectors offer a mechanical interface which allows accessory components such as optical filters, integrating spheres, diffuser windows and other front-end optics to be easily attached and interchanged. A wide range of base detectors are stocked of different photodiode type and active area. This permits selection of the best fit photodiode spectral sensitivity, light responsivity, rise and fall time for the specific job.

The following spectral plots show the typical spectral sensitivities of the photodiodes available in the PD-11, TD-11 and MD-37 series modular detectors. Note that spectral sensitivity will

change when the detector is combined with an input optic component including integrating spheres. For this reason the actual measured spectral sensitivity of any detector accessory combination is provided in the detector calibration certificate. Calibrations are optional and ordered separately.



The **PD-11** series modular detectors are primarily designed to be used in combination with Gigahertz-Optik integrating spheres. A typical application example for sphere based detectors is the measurement of radiant power of lasers, laser diodes and other monochromatic light sources.

**The PD-11** detectors offer a compact package with flange mount to allow direct mounting to all spheres with 11-type port adapters. Arrangement of discrete linear arrays with a grid size

of 11 mm are also possible. Calibrations are offered with or without accessory.



Ordering I	nformation	n & typie	cal Specifica	ations									
Model			Photodiode	Э		Ту	o. Sensitivity	A/W	lmax.	Operating	plug	cable	package
	λresp	Resp.	$\lambda$ range nm	mm <sup>2</sup>	Size mm	@ 350 nm	@ 900 nm	@ 1350 nm	mA	Temp °C		m	page
PD-1101	Si	Page	200-1100	13	3.6 x 3.6	0.15	0,5	-	1	5 to 40	1,2,4	2	90
PD-1102	InGaAs	85	800-1800	0.07	0.3 Ø	-	0.14	0.9	1	5 to 40	1,2,4	2	90
PD-1103	InGaAs	85	800-1800	0.79	1 Ø	-	0.14	0.9	1	5 to 40	1,2,4	2	90
PD-1104	InGaAs	85	800-1800	7.1	3 Ø	-	0.14	0.9	1	5 to 40	1,2,4	2	90
PD-1105	SiC	85	200-400	1	1.1 x 1.1	0.02	-	-	0.05	5 to 40	1,2,4	2	90
PD-1106	Si LP	85	400-1050	0.25	0.5 x 0.5	0.06	0.4	-	1	5 to 40	1,2,4	2	90
PD-1107	Si LP	85	400-1050	3.6	1.9 x 1.9	0.06	0.4	-	1	5 to 40	1,2,4	2	90
PD-1108	Si LP	85	400-1050	11.9	3.4 x 3.4	0.06	0.4	-	1	5 to 40	1,2,4	2	90
PD-1109	GaP	85	250-550	1.0	1.1 x 1.1	0.07	-	-	0.1	5 to 40	1,2,4	2	90
PD-1110	GaAsP	85	200-760	5.2	2.3 x 2.3	0.04	-	-	0.1	5 to 40	1,2,4	2	90
K-PD11xx	Calibratior	n of relat	ive spectral s	ensitivity.	xx = detec	tor model nu	ımber						
KDW-S1	Calibration of spectral radiant power sensitivity at one or multiple wavelengths in combination with an integrating sphere												
KDW-S2	Calibration of spectral irradiance sensitivity at one or multiple wavelengths in combination with a diffuser												
KDW-S3	Calibratior	n of spec	ctral radiance	sensitivity	y at one or r	nultiple wav	elengths in co	ombination wi	th radia	nce front tul	ce/lens		
KDW-S4	Calibratior	n of spec	ctral radiant ir	ntensity se	ensitivity at c	one or multip	le wavelengt	hs					

# Modular

# TD-1101, TD-1102 and TD-1103: Temperature Controlled Modular Detectors



The **TD-11** family of detectors are designed with a unique temperature control feature. The photodiode is precisely heated and maintained at a higher operation temperature than the ambient temperature. This function ensures measure-

ment accuracy when these detectors are to be used in applications with widely varying ambient temperatures as in laser power measurements involving sphere based detectors for example. The control electronics are housed in an external box with a plug in power supply.

Both silicon and indium gallium arsenide photodiodes are offered for the wavelength range 200 to 1100 nm and 800 to 1800 nm respectively.

TD-11 detectors can be direct mounted to all spheres with 11-type port adapters.

Calibrations are offered for the detector with or without any accessory components.

Ordering I	nformation	n & Spe	cifications											
Model			Photodiode	Э		Тур	o. Sensitivity	A/W	lmax.	Operating	plug	cable	package	
	λresp	page	$\lambda$ range nm	mm <sup>2</sup>	Size mm	@ 350 nm	@ 900 nm	@ 1350 nm	mA	Temp °C		m	page	
TD-1101	Si	27	200-1100	13	3.6 x 3.6	0.15	0.5	-	1	55	1,2,4	2	90	
TD-1102	InGaAs													
TD-1103	InGaAs	GaAs 27 800-1800 0.79 1Ø - 0.14 0.9 1 55 1,2,4 2 90												
K-TD11xx	Calibratior	n of rela	tive spectra	sensitiv	ity. xx = de	etector moc	lel number							
KDW-S1	Calibratior	n of spe	ectral radiant	power s	ensitivity at	one or mu	ltiple wavele	engths in com	nbinatic	n with an int	egrating s	sphere		
KDW-S2	Calibration of spectral irradiance sensitivity at one or multiple wavelengths with a diffuser													
KDW-S3	Calibration of spectral radiance sensitivity at one or multiple wavelengths in combination with radiance front tube/lens													
KDW-S4	Calibration of spectral radiant intensity sensitivity at one or multiple wavelengths wavelengths													

### **MD-37: Modular Detector**



#### The modular light detectors of the MD-37 series feature a M30x1 threaded front interface for fast and simple screw-on assembly of mating accessory components.

For multi-purpose use modular detectors offer a wide range of base photodiode detector types and different active areas. This provides a great degree of freedom in selecting a spectral sensitivity, light responsivity, rise and fall time for a specific job. M30x1 is the standard thread size for all 37-type accessories which mate to the MD-37 detectors.

Some typical detector set-ups for the MD-37 series include:

 Broadband irradiance detectors (MD-37 with MD-37Z- DR11 diffuser front cap)

 Narrow band irradiance detectors (MD-37 with narrow band pass filter assembled in MD-37Z-H7 plus diffuser front cap MD-37Z-FR11)

Calibrations are offered with or without accessory components attached.

Ordering Inform	mation &	Specifie	cations										
Model			Photodiode	;		Тур	o. Sensitivity	A/W	Imax.	Operating	plug	cable	package
	λresp	Resp.	$\lambda$ range nm	mm <sup>2</sup>	Size mm	@ 350 nm	@ 900 nm	@ 1350 nm	mA	Temp °C		m	page
MD-37-GP6	GaP	27	250-550	6.25	2.5 x 2.5	0.07	-	-	0.1	5 to 40	1, 2, 4	2	90
MD-37-GAP5	GaAsP	27	200-760	5.29	2.3 x 2.3	0.04	-	-	0.1	5 to 40	1, 2, 4	2	90
MD-37-IGA1	InGaAs	27	800-1800	0.79	1 Ø	-	0.14	0.9	1	5 to 40	1, 2, 4	2	90
MD-37-IGA3	InGaAs	27	800-1800	7.1	3 Ø	-	0.14	0.9	1	5 to 40	1, 2, 4	2	90
MD-37-SC1	SiC	27	800-1800	1	1 sq	0.02	-	-	0.05	5 to 40	1, 2, 4	2	90
MD-37-SU13	Si	27	200-1100	12.96	3.6 x 3.6	0.15	0.5	-	1	5 to 40	1, 2, 4	2	90
MD-37-SU33	Si	27	200-1100	33,64	5.8 x 5.8	0.15	0.5	-	1	5 to 40	1, 2, 4	2	90
MD-37-SU100	Si	27	200-1100	100	10 x 10	0.15	0.5	-	1	5 to 40	1, 2, 4	2	90
MD-37Z-C11	Front cap	with 11	mm diamet	er apert	ure								
MD-37Z-DR11	Front cap	with 11	mm diamet	er RADI	N diffuser								
MD-37Z-H7	Front ada	apter an	d/or filter hol	der for C	.5 to 1 inch	n diameter fil	ters						
MD-37Z-H7xx	Front ada	apter wit	h custom sp	ecified b	and-pass	or edge filter	. xx = filter ty	rpe					
K-PD37xx	Calibratio	on of rela	ative spectra	l sensitiv	vity. xx = c	letector mod	el number						
KDW-S1	Calibration of spectral radiant power sensitivity at one or multiple wavelengths in combination with an integrating sphere												
KDW-S2	Calibratio	on of spe	ectral irradia	nce sens	sitivity at or	ne or multiple	wavelength	s in combinat	ion wit	h a diffuser			
KDW-S3	Calibratio	on of spe	ectral radian	ce sensi	tivity at one	e or multiple	wavelengths	in combinatio	on with	radiance fr	ont tube	/lens	
KDW-S4	Calibratio	on of spe	ectral radiant	intensit	y sensitivity	/ at one or m	ultiple wavel	engths					

🖲 Gigahertz-Optik

# Light Detectors - Page 87

Modular

### PD-93: 1 cm<sup>2</sup> Circular Area Modular Light Detectors

Modular light detectors using photodiodes with a one square centimetre circular active area have been offered by Gigahertz-Optik since 1986. The symmetry of a circular detection area combined with a large 11.28 mm diameter has made these detectors a standard for many applications.

The area around the light sensitive 1 cm<sup>2</sup> area is metal shielded and thus insensitive to light so that irradiance (W/cm<sup>2</sup>) can easily be calculated from a known radiant power (W) assuming the active area is to be evenly overfilled.

The photodiodes mounted into a housing that can be fastened into optical test arrangements using the threaded M6 and 1/4-20 side holes. The front of the housing is internally threaded into which accessories can be attached (common 1.3/16-24-UNS thread size). In addition to two different photodiodes, Giga-

sensitivity

ē

0.5

hertz-Optik offers accessories to form a wide variety of detector configurations The simple design of the mechanical parts also means that special custom fabrications can be prepared easily and economically for soapplications. Our sales engineers are ready to work with you and provide advice on standard and custom configurations.



PD-9304: 1 cm<sup>2</sup> Si-Photodiode



The **PD-9304** is a large, 1 cm<sup>2</sup> photodiode for general light measurement purposes and for use in combination with PD-93VL and PD-93RW photometric and radiometric correction filters for illuminance and integral irradiance measurements.

#### PD-93COS: Diffuser

The **PD-93COS** diffuser cap generates a field of view approximating a cosine-corrected function, enabling the measurement of illuminance or irradiance. The diffuser screws onto the PD-9302 or PD-9304.



**PD-93VL: Photometric Filter** 

The **PD-93VL** V( $\lambda$ ) correction filter screws directly onto the PD-9304 detector. It's built into the PD-9302 filter holder which is internally and externally threaded (1.3/16-24-UNS) for mating to PD detectors and to accept accessories. **PD-93RW: Radiometric Filter** 



Typical spectral sensitivity with PD-9304

The **PD-93RW** filter built into the PD-9302 filter holder, gives the PD-9304 a radiometric flat spectral sensitivity within the wavelength range from 400 and 1000 nm.

13mm

6mm

PD-9303

PD-9302: Modular Schematic

27.2mm

Photodiode

with BNC Connector



The **PD-9302** universal holder is 1.3/16-24-UNS internally and externally threaded suitable for attachment to the **PD-9301** detector housing. One inch diameter filters like neutral density, band pass and correction filters can be mounted into it.

### PD-9303: Front Cap

The PD-9303 cap can be used as an end piece on the PD-9301

One of the parameters most commonly used to specify LEDs is the directional output intensity. This radiometric or photometric intensity is derived from the flux incident on a detector by the LED at specified distance.

A detector with a circular entrance aperture having 100 mm<sup>2</sup> detector housing, or the PD-9302 universal holder.

# PD-9311 & PD-9312: Averaged LED Intensity Front Tubes

37mm

(11.3 mm diameter) is specified for the CIE standard A and B measurement conditions for average LED intensity. The distance between the front tip of the LED and the plane of the entrance aperture of the detector is stated at d = 316 mm for CIE standard condition A and d =



100 mm for standard condition B. This corresponds to solid angles of view of 0.001 sr for Condition A and 0.01 sr for Condition B. The PD-9311 and PD-9312 front tubes attach to the PD-9304 detector with either PD-93VL photometric or PD-93RW radiometric filter for CIE Condition A and B conformal

25mm

PD-9301

measurements. Calibration of the average LED Intensity sensitivity in cd and W/sr is offered by Gigahertz-Optics calibration laboratory.

PD-9302

# Cigahertz-Optik

# Modular, Weather Proof

### PD-9306: 1 cm<sup>2</sup> Circular Area Light Detector

The **PD-9306** is a large area 1 cm<sup>2</sup> UV-enhanced silicon photodiode for spectral radiant power and/or spectral irradiance measurements. It's large diameter active area offers higher signals for applications with low intensity monochromatic radiation.

The detector is supplied in the PD-9301 housing with internal 1.3/16-24-UNS front thread to accept other accessory compo-

nents. A 2 m long coaxial cable with BNC plugs can be coupled to the BNC connector at the end of the photodiode. Calibration of spectral radiant power sensitivity is supplied by the Gigahertz-Optik's calibration laboratory as required.



### **Ordering Information & Specifications**

Model	λresp	Wavelength	Typ	ical Sensitivity	Sensing Area	Imax	cable	Operating	plug	package
	Moop	Range	176	loar containing	Photodiode	mA	m	Temp °C	pidg	page
PD-9304	Si Photodiode	380-1100 nm	0.4	A/W @ 633 nm	1 cm <sup>2</sup>	1	2	5 to 40	1,2,4	91
PD-93VL&PD-9304	$V(\lambda)$	380-780 nm	28	nA/lx	1 cm <sup>2</sup>	1	2	5 to 40	1,2,4	91
PD-93COS&PD-93VL&PD9304	V(λ)	380-780 nm	2.8	nA/lx	1 cm <sup>2</sup>	1	2	5 to 40	1,2,4	91
PD-9311&PD93-VL&PD-9304	V(λ)	380-780 nm	2.6	μA/cd	1 cm <sup>2</sup>	1	2	5 to 40	1,2,4	91
PD-93RW&PD-9304	Radiometric	400-1100 nm	0.2	A/W @ 800 nm	1 cm <sup>2</sup>	1	2	5 to 40	1,2,4	91
PD-93COS&PD-93RW&PD-9304	Radiometric	400-1100 nm	16	mA/W/cm <sup>2</sup>	1 cm <sup>2</sup>	1	2	5 to 40	1,2,4	91
PD-9311&PD-93RW&PD-9304	Radiometric	400-1100 nm	1.8	mA/W/sr	1 cm <sup>2</sup>	1	2	5 to 40	1,2,4	91
PD-9306	UV Si	250-1100 nm	0.16	A/W @ 350 nm	1 cm <sup>2</sup>	0.2	2	5 to 40	1,2,4	91
K-PD9304	Calibration of s	pectral radiant	power s	ensitivity in A/W/nr	n from 350 to 1 <sup>-</sup>	100 n	m in 10	nm steps		
K-PD9306	Calibration of s	pectral radiant	power s	ensitivity in A/W/nr	n from 250 to 1 <sup>-</sup>	100 n	m in 10	) nm steps		
KDW-P2	Calibration of ill	luminance sens	sitivity in	lx of PD-9304/PD-	93VL with or wit	hout	PD-930	COS		
KDW-P4	Calibration of average LED Intensity sensitivity in cd of PD-9304&PD-93VL&PD-9311 or PD-9312									
KDW-R2	Calibration of ir	radiance sensi	tivity in V	V/m <sup>2</sup> of PD-9304/P	D-93RW with or	with	out PD-	93COS		
KDW-R4	Calibration of a	verage LED Int	ensity se	ensitivity in W/sr of	PD-9304&PD-9	3RW	&PD-93	311 or PD-9	312	
KDW-S	Calibration of spectral sensitivity at one or multiple wavelengths without or with accessory components									

### **WPD: Weather Proof Detector**



The **WPD** series weather proof detectors are designed for year round outdoor light measurements. To withstand all environmental conditions the light sensor is shielded in a rugged metal housing. The detector aperture is enclosed and sealed under a precision made quartz dome. Photodiode, filter and diffuser are

temperature stabilized to +25 deg C by a pettier cooler. Temperature is stabilized to +/-1 deg C for operation independent of the ambient conditions. The specified operating temperature range is -20 to +50 deg. C. The electronics of the **PTC-0101** pettier temperature controller are supplied in a separate compact

housing for bench-top or rackmount use with cable connections.

In principle the sensor elements of all Gigahertz-Optik light detectors can be integrated into the WPD housing. The most common applications to date are in the ultraviolet spectral range. For example WPD detectors can serve as reference detectors for high resolution spectral radiometers monitoring global solar UV radiation The WPD water proof light detectors are normally connected with a Gigahertz-Optik signal amplifier or optometer for direct measurement of current or irradiance as well as data logging.

Due of the custom nature of this detector and supporting electronics interested customers should contact the factory to discuss his specific requirements.





**Light Detector Accessories** 

### SRT-M37: Front Tubes and Front Lenses

**SRT-M45/37B:** Base holder for coupling 45-type and 37-type standard light detector and 37-type solid angle tubes and SRT-37L front lenses.

M30x1 front thread. M6 and camera tripod (1/2"-20BSW) side mounting holes.

### Front Tubes:

**SRT-M37-50:** 37 mm outside diameter tube, 50 mm length internally threaded over its complete length and externally threaded front end (both M30 x 1). Can be machined to any length down to 12.5 mm.

SRT-37-AB Apertures can be glued into the tube at either end. SRT-37/25: Reducer to couple

SRT-M37-50 to SRT-M25-25 to decrease the outside diameter of solid angle tubes.

**SRT-25-25:** 25 mm outside diameter tube, 25 mm length internally threaded over its complete length and externally threaded front end (both M20 x1). Can be machined to any length down to 12.5 mm.

**SRT-37-AB:** Aperture plate insert for SRT-M37 tubes. 2 mm diameter centering hole for drilling the aperture opening to the desired diameter.

### Front Lenses:

The SRT-M37L Front Lenses are used with the 37-type (eg. VL-3701, RW-3701) or 45-type (eg. HCT-99) Gigahertz-Optik detectors to form economical luminance and radiance measurement set-ups. The detector plus front lens can be used for relative measurement or can be calibrated for direct readout in cd/m<sup>2</sup> or W/m<sup>2</sup>/sr with a Gigahertz-Optik optometer.

The SRT-M37L set-up consists of the SRT-



M45/37B base holder which mounts onto the detector by means of its M30x1 threaded front and one of the SRT-M37L lenses mounted into it. Lenses are available with different fieldof-views. The 25 mm diameter BK7 lens provides a "flat" wave-

length range from 380 nm to 1500 nm. Quartz lenses are available on request



<b>Ordering Inform</b>	nation & Specifications		
Model	Description	Min. Required Detector Aperture	Specifications with Detectors on Page
SRT-M45/37B	Base holder to couple 45 and 37 type light detectors to SRT-M37 accessory	-	-
SRT-M37-50	37 mm diameter front tube, 50 mm length and M30x1 thread	-	-
SRT-M37/M20	Adapter to mount 37 and 25 tubes together	-	-
SRT-M20-25	25 mm diameter front tube, 25 mm length and M20x1 thread	-	-
SRT-M37-AP	Aperture plate to glue into SRT-M37-50 front tube. 2 mm center hole	-	-
SRT-M37L-1	Luminance & radiance front lens for SRT-M45/37B with 1° field-of-view	0.7 mm Ø	80
SRT-M37L-2	Luminance & radiance front lens for SRT-M45/37B with 2° field-of-view	1.4 mm Ø	80
SRT-M37L-5	Luminance & radiance front lens for SRT-M45/37B with 4.8° field-of-view	3.4 mm Ø	80
SRT-M37L10	Luminance & radiance front lens for SRT-M45/37B with 10° field-of-view	7 mm Ø	80



# Light Detector Accessories / Dimensions

/WG

/WQ

### /WQ: Waterproof Detector Option

	ing: © Oceanog © Limnolog © Aquacultu © Solar Biod	y	and other user specific require- ments are available through Gi- gahertz-Optik's custom design services. A transparent dome, made from glass or UV transmitting quartz covers the cosine diffuser. The detector housing is sealed and	filled with a drying agent (desiccant). This option cannot be retrofit as an after sales modi- fication! Please contact our application engineering department to dis- cuss your underwater light meas- urement project.	
/WQ Waterproof Option ef-	Ordering Information & Specifications				
ively seals any type-37 series	Model	Description			

nal modifications. Ordering P/N example: PS-3703-2/WG.

modifications. Ordering P/N example: PS-3702-2/WQ.

The /WQ Waterproof Option effectively seals any type-37 series detector housing. This modification enables full submersion of the detector in water and other liquids. UV/Vis/NIR underwater detectors can be custom tailored

### /LC: Cable Extension

For long distance applications requiring the standard 2 m cable between optometer and light

detector be extended. This option is offered for single channel detectors with BNC type (-1) and

calibration type (-2) detectors only. For a VL-3701 detector requiring a total cable length of 5

Waterproof modification of 37 type detectors. Glass dome cap for VISIBLE to NIR , and inter-

Waterproof modification of 37 type detectors. Quartz dome cap for UV to NIR, and internal

m three 3 m /LC should be ordered since 2 m is already included in the detector price.

### **Ordering Information & Specifications**

ModelDescription/LCCable extension in

Cable extension in 1 m steps for light detectors with BNC type (-1) or calibration data type (-2) connectors

### BHO: Carrying Cases

Carrying cases are offered for destorage and transporting light Ple

detectors and optometers. Please see Optometer chapter for information on available models.



**11 Type Housing Dimensions** 

### **37 Type Housing Dimensions**



TD-11 Type Housing Dimensions



### **45 Type Housing Dimensions**



### MD-37 Type Housing Dimensions





### RCH-0, RCH-1 and RCH-5 Housing Dimensions



LP-99, LSM-99 and PRW-05 Housing Dimensions



**LP-02 Housing Dimensions** 



Ø 15 mm Ø 15 mm Ø 15 mm Ø 15 mm Ø 63 mm Ø 6 mm

### **LP-01 Series Housing Dimensions**



### LPPA-9901 Housing Dimensions



# Page 92 - Light Detectors

# Light Detector Dimensions



### **Integrating Spheres**

Integrating spheres are unique tools used in many laser & photonics applications. Gigahertz-Optik offers a wide range of integrating spheres for both detection purposes and for uniform light sources. To meet the many varied application demands, spheres with different diameters are offered as well as different coatings and measurement geometries. Besides the modular UM series for light measurements and uniform light source set-ups Gigahertz-Optik offers the UP series with precisely aligned port geometries for reflectance and transmittance measurements. Complete systems can be assembled using accessory components and an instrument from Gigahertz-Optik's photometer, radiometer and colorimeter program. To satisfy specific application demands, custom design and private labeling solutions are offered.

Table of Contents						Page
UM Series	Descriptio	on and exam	ples for inc	dividual UM series	integrating sphere set-ups	95-99
Model		Sphere		Accessory	Description	Specifi-
	Туре	Diameter mm / in	Coating	Туре		cations
UMBB-100	Spun Al	100 / 4	BaSO4		Basic integrating spheres for detection & light source set-ups.	100
UMBB-150	Spun Al	150 / 6	BaSO4		First, port frames, baffles and stands are added to the spun	
UMBB-210	Spun Al	210/8.3	BaSO4		aluminum sphere to set-up the sphere for a basic application. Then light sources, variable apertures, detectors, sample hold-	
UMBB-300	Spun Al	300 / 12	BaSO4		ers, auxiliary lamps and other components can be assembled	
UMBB-500	Spun Al	500 / 20	BaSO4		to the port frames per end-user specifications. Finally, periph-	
UMBB-1000	Spun Al	1000 / 40	BaSO4		eral instruments like optometers and lamp power supplies com- plete the configuration.	
UMBB-1700	Spun Al	1700 / 67	BaSO4		Three different coatings are supplied: barium sulfate (UMBB	
UMBG-100	Spun Al	100 / 4	Gold		models) can be used for all sizes and most accessories, gold	
UMBG-150	Spun Al	150 / 6	Gold		(UMBG models) for infrared applications and OP.DI.MA. (UMBK models) for UV-VISIBLE-IR broadband applications with limited	
UMBG-300	Spun Al	300 / 12	Gold		availability sphere sizes and accessories.	
UMBK-190	Spun Al	190 / 7.5	OPDIMA		Please contact the factory or your local Gigahertz-Optik repre-	
UMBK-250	Spun Al	250 / 10	OPDIMA		sentative for configuration assistance.	
UMBK-460	Spun Al	460 / 18	OPDIMA			
UMSS-SM14/M6				Sphere Mount	Post mount socket for small diameter spheres	101
UMSS-SMT				Sphere Mount	Flange mounted adapter for UMSS-BT use	101
UMSS-SMV				Sphere Mount	Flange mounted adapter for post mount use	101
UMSS-BT150				Sphere Stand	Bench top stand for UMBB-150 & UMBG-150	101
UMSS-BT210				Sphere Stand	Bench top stand for UMBK-190 & UMBB-210	101
UMSS-BT300				Sphere Stand	Bench top stand for UMBB-300, UMBG-300, UMBK-250	101
UMSS-BT500				Sphere Stand	Bench top stand for UMBK-460 & UMBB-500	101
UMSS-BT1000				Sphere Stand	Bench top stand for UMBB-1000	101
UMSS-BT1700				Sphere Stand	Bench top stand for UMBB-1700	101
UMSS-HF300				Sphere Stand	Hinge frame bench top stand for UMBB-300	102
UMSS-HF500				Sphere Stand	Hinge frame bench top stand for UMBB-500	102
UMSS-HF1000				Sphere Stand	Hinge frame stand for UMBB-1000	102
UMSS-HF1700				Sphere Stand	Hinge frame stand for UMBB-1700	102
UMPF-xx				Port Frames	From 0.5 to 5.0 inch dia Fix mounted to UMB	101
UMPP-xx				Port Plugs	From 0.5 to 5.0 inch to plug in UMPF-0.5 to 5.0	103
UMPR-xx				Port Reducer	From 0.5 to 5.0 inch	103
UMPD-37				Detector Port	For 37 mm dia. light detectors. Fix mounted to UMBB	104
UMPD-45				Detector Port	For 45 mm dia. light detectors. Fix mounted to UMBB	104
UMPF-LSOK30				Port Frame	For LS-OK30 light source assembling	104
UMPF-LSOK45				Port Frame	For LS-OK45 light source assembling	104
UMPB-SM				Port Baffle	For light baffling between ports. Sphere wall mounted	104
UMPB-PM				Port Baffle	For light baffling to sphere center. Post mounted	104
UMPB-IL				Port Baffle	For light baffling of in-line ports. Spider mounted	104
UMPA-0.5/11				Port Adapter	To assemble 11-type detectors to UMPF-0.5	105-106
UMPA-0.5/11RD				Diffuser	RADIN diffuser to be assembled in UMPA-0.5/11	105-106
UMPA-0.5/F				Port Adapter	Universal machineable. Fits to UMPF-0.5	105-106
UMPA-1.0/F				Port Adapter	Universal machineable. Fits to UMPF-1.0	105-106

# Page 94 - Integrating Spheres



# Table of Contents

UM Series						Page
Model		Sphere		Accessory	Description	Specifi
	Туре	Diameter mm / in	Coating	Туре		cations
UMPA-1.5/LGA13				Port Adapter	Light guide adapter for Spectrometer. Fits UMPF-1.5 (1.5")	105-106
UMPA-2.0/AXL				Port Adapter	For auxiliary lamp set-up with LS-IS1.5. Fits UMPF-2.0 (2.0")	105-106
UMPA-2.0/LED5				Port Adapter	For LED-5xx LED test sockets. Fits UMPF-2.0 (2.0")	105-106
UMPA-4.0/QD1.9				Port Adapter	48 mm dia. diffuse quartz window. Fits UMPF-4.0 (4.0")	105-106
UMPA-4.0/QD3.0				Port Adapter	75 mm dia. diffuse quartz window. Fits UMPF-4.0 (4.0")	105-106
UMPA-5.0/LED5				Port Adapter	For LED-5xx LED test sockets. Fits UMPF-5.0 (5.0")	105-106
UMPA-5.0/SH				Port Adapter	Sample base holder with 4" open aperture. Fits UMPF-5.0 (5.0")	105-106
UMPA-5.0/SH-P				Port Adapter	Port plug for UMPA-5.0/SH	105-106
UMPA-5.0/SH-CM				Port Adapter	Port plug for UMPA-5.0/SH with universal sample mount	105-106
UMLA-1.5B				Lamp Adapter	Base for center position lamp adapter	100 100
UMLA-300				Lamp Adapter	For center lamp/sample position inside UMBB-300	106
UMLA-500				Lamp Adapter	For center lamp/sample position inside UMBB-500	100
UP Series				Lamp Adapter		107
UPB-50-L	CNC AI	50/2	BaSO4	1	Precision machined single port sphere	108
UPB-100-F	CNC AI	100/4	BaSO4 BaSO4		Precision machined single port sphere Precision machined multi-port flexible design sphere with plugs	108
UPB-150-F	CNC AI	150 / 6	BaSO4 BaSO4		Precision machined multi-port flexible design sphere with plugs	108
UPB-250-F						
	Spin Al	250 / 10	BaSO4		Precision machined multi-port flexible design sphere with plugs	109
UPB-500-F	Spin Al	500 / 20	BaSO4		Precision machined multi-port flexible design sphere with plugs	110
UPK-30-L	CNC AI	30 / 1.2	OPDIMA		Precision machined single port sphere	111
UPK-50-F	CNC AI	50/2	OPDIMA		Precision machined multi-port flexible design sphere with plugs	111-112
UPK-50-L	CNC AI	50/2	OPDIMA		Precision machined single port sphere	111-112
UPK-50-ULS	CNC AI	50/2	OPDIMA		Precision machined (8) LED port sphere. Uniform light source.	111-112
UPK-100-F	CNC AI	100 / 4	OPDIMA		Precision machined multi-port flexible design sphere with plugs	112
UPK-100-L	CNC AI	100 / 4	OPDIMA		Precision machined single port sphere	112
UPK-150-F	CNC AI	150 / 6	OPDIMA		Precision machined multi-port flexible design sphere with plugs	113
UPK-190	CNC AI	190 / 7.5	OPDIMA		Precision machined sphere. Custom design configuration.	113
UPK-250	CNC AI	250/10	OPDIMA		Precision machined sphere. Custom design configuration.	114
UPG-75-G	CNC AI	75/3	Gold		Precision machined multi-port flexible design sphere with plugs	114
UPG-100-F	CNC AI	100 / 4	Gold		Precision machined multi-port flexible design sphere with plugs	115
Accessories		1				
ULT-18				Light Trap	For assembly to 11-type ports	115
UFC				Fiber Socket	FC, SC, SMA and ST fiber coupler adapter for 11-type ports	116
Light Sources & Lig	ght Source	e Accesso	ries			
LS-IS1.5				Internal Source	Lamp housing for 5 to 100 W QH-lamps. Fits UMPF-1.5 (1.5")	117
LS-OK30				External Source	Lamp housing for 5 to 100 W QH-lamps. Fits UMPF-LSOK30	118
LS-OK30-FH				Filter Holder	For use with LS-OK30	118
LS-OK30-FHI				Filter Holder	Insert for 2 inch diameter filter for use with LS-OK30-FH	118
LS-OK30-MIR				Variable Aperture	High resolution Iris diagraph for use with LS-OK30	118
LS-OK30-VA				Variable Aperture	for use with LS-OK30	118
LS-OK45				External Source	Lamp housing for 250 W QH-lamps.	119
LS-OK45-LG				Light Guide	Adapter. Color temperature control operation with CT-3701	119
VAM-45				Variable Aperture	Stepper motor operated variable aperture. Needs SMC-01.	119
FWM-12/2				Filter Wheel	Stepper motor controlled filter wheel. Needs SMC-01.	119
LS-CB				Beam Source	Collimated light source for reflectance & transmittance meas.	119
LPS-250				Power Supply	Precision lamp power supply (up to 250 W lamps)	120
LCRT-2000				Power Supply	Lamp power supply (up to 10 W lamps)	120
				Motor Controller	4-channel stepper motor controller with interface.	121
SMC-01						

# Integrating Spheres - Page 95

# **Gigahertz-Optik**

# UM Series

Years of experience in manufacturing integrating spheres has taught us that a line of standard spheres will not fulfill all possible customer needs. Most often either the end-user accepts a standard sphere as a compromise solution or must have the stock item custom modified adding extra cost and lead time. The new **UM** integrating sphere series allows individual integrating sphere set-up in the specific configuration required with only

those components needed. An added benefit to this design freedom is that you don't pay for something you don't need. With standardized stock components and an innovative assembly process the UM series offers economical prices and short delivery times for integrating spheres that others can only claim as custom products. Port frames with free apertures in different diameters as well as detector and light source ports can be added and positioned on the basic spheres according to end-user design. **UMB Basic Spheres** are available in different diameters and with different coatings.

Sphere Accessory Components such as port plugs, reducers, adapters, baffles, sphere mounts and stands are available. Application Accessory Components & Instruments like fiber optic adapters, light sources & detectors, photometers, radi-

### **Individual Sphere Design**

ometers, colorimeters & calibration standards allow complete systems to be assembled.

The following pages describe typical application set-ups as well as individual component specifications. Light measurement instrumentation and calibration equipment technical specifications and descriptions are shown in other chapters of this catalog.

Sphere Components

### Light Detector



**UM Sphere Configuration** 



### **Assembly Orientation**

**UMB Basic Spheres** are assembled using two hollow hemispheres made from aluminum sheet stock.

The **Orbit Flange** located on open side of each hemisphere is used to mechanically mate the sphere halves. The standard position for the orbit flange is vertical as shown in the above drawing. But its actual position can be specified at any angle from vertical. Note that port frames, sphere stands or other accessory may limit the choice of angle. 5 deg. angle steps with a tolerance of +/- 5 deg. are recommended.

To specify position coordinates for **Accessory Components**, the same 5 deg. +/-5 deg. resolution is recommended. Position can be mapped using the sideview 'SV' and top-view "TV' angle charts as shown above.

The sphere Al sheet forming process only allows a typical position tolerance of +/- 5 degrees.

For more precise alignment **UP** series spheres are recommended.

# Page 96 - Integrating Spheres



# UM Series "Set-up Examples"

### Luminous Flux & Radiant Power Measurement of Spot Sources

The integrating sphere is the preferred tool for the measurement of radiant power or luminous flux of spot sources with a diverging light beam. Typical examples of spot sources are LEDs, LED panels, laser diodes, fiber bundle light sources, reflector spot lamps, flat panel displays, endoscopes and others.

The reason why the integrating sphere is preferable to a planar detector is that typical photodiode detectors are limited in active area, size and acceptance angle. Integrating spheres offer large area measurement apertures and large acceptance angles in observance to the rule that the 'measurement aperture area should not exceed 5% of the total sphere area'. Temperature is another reason for using integrating spheres in applications involving high power tungsten or xenon spot lamps. Large diameter spheres are required to maintain temperature within operating limits, prohibit heat damage and for stability/ accuracy of the measurement.

In this set-up a measurement port and a detector port is needed. Photometric, radiometric or colorimetric detectors can be mounted onto the integrating sphere with an accompanying read-out instrument. In applications where wide variations in sphere housing temperature may occur, detectors with temperature stabilization are recommended to avoid drift of the measured signal. A spectrometer can also be used with or as an alternative to the integral light detector. Baffles are placed between the lamp and detector to prohibit direct illumination of the detector by the incoming signal.

The complete sphere system can be calibrated in absolute quantities such as luminous flux

1

**Directional LED Measurement** 

5

3



(Im), radiant power (W) or spectral radiant power (W/nm). Lamp standards are normally used for calibrations in illuminance (Ix) or spectral irradiance (W/(m<sup>2</sup> nm)). See *Calibration Standards* sec-



Spot Lamp Measurement



150 mm (6 in) dia sphere with photometric detector for luminous flux measurements.

- 1. UMBB-150: 150 mm (6") dia integrating sphere
- 2. UMSS-SM14: sphere socket
- 3. UMPF-1.0: 1.0" dia port frame
- 4. UMPB-SM: port baffle
- 5. UMPF-0.5: 0.5" dia port frame
- UMPA-0.5/11: port adapter for 11-type light detector
- 7. UMPA-0.5/RADIN: diffuser for UMPA-0.5/11 port adapter
- 8. VL-1101-2: photometric detector with calibration data connector for P-9710-1
- 9. P-9710-1: single channel optometer with RS232 Inter-

face 10.KDW: Calibration of luminous flux sensitivity

#### Options:

2

- TD-11VL01-2: temp. stabilized photometric detector
- P-2000: two channel optometer with RS232 and IEEE488 interface.
- UMPF-2.0: 2.0" dia port frame
- UMPR-2.0/xx: port reducer plug, xx = aperture dia
- PM-B + PM-P: post stand
- UMSS-BT150: bench-top stand alternative to UMSS-

500 mm (20 in) dia sphere with colorimetric detector for luminous flux and color temperature measurements.

- 1. UMBB-500: 500 mm (20") dia integrating sphere
- 2. UMŠS-SMT
- 3. UMSS-BT500: bench-top stand
- 4. UMPF-4.0: 4.0" dia port frame
- 5. UMPR-4.0/xx: 1 or more port reducer, xx = aperture dia
- 6. UMPB-SM: port baffle
- 7. UMDP-37: detector port for 37type detectors
- 8. CT-3701: luminous flux, color temperature and xy chromaticity value detector. Tempera-

ture stabilized

- 9. P-9801: 8-channel optometer with RS232 and IEEE488 interface
- 10.OS-P9801: remote control software
- 11.KDW: calibration of luminous flux sensitivity and color temperature
- Options:
- UMSS-HF500: hinge Frame bench top stand for full opening of the front hemisphere
- Additional radiometric detectors

# Integrating Spheres - Page 97

# UM Series "Set-up Examples"

# Luminous Flux & Radiant Power Lamp Measurement

the detector by the incoming signal.

The complete integrating sphere light detection system can be calibrated in absolute optical

measurement quantities such us luminous flux (Im), radiant power (W) or spectral radiant power (W/ nm). Please refer to the *Calibration Standards* section for further



Large-size Lamp Measurement

(88)

5

Measuring total radiant power or luminous flux emitted by lamps is one of the most common applications for integrating spheres. Other than spot sources, lamps emit light in all directions. The integrating sphere collects all of the emitted light entering it and supplies an integrated signal to its mounted light detector.

Lamps come in many different form, size and output power today. Examples include tungsten filament lamps, fluorescent tube & bulb shape lamps, high power xenon sources and many more. Selecting the size of the integrating sphere is typically based on the maximum dimension of the lamp to be measured. The sphere diameter should be at least ten times the maximum dimension of the lamp. For tube lamps it should be twice the largest dimension of the source. For flux measurements a multidirectional lamp is placed in the center of the sphere. Different forms and sizes of sockets and individual lamp holders are required for each different lamp type. For smaller size lamps a top-load port can be used for insertion and removal. For large size lamps integrating spheres with a hinged frame allowing one half of the sphere to fully open are recommended.

Photometric, radiometric or colorimetric detectors can be mounted onto the integrating sphere with an accompanying read-out instrument. In applications where wide variations in sphere housing temperature may occur, detectors with temperature stabilization are recommended to avoid drift of the measured signal. A spectrometer can also be used with or as an alternative to the integral light detector. Baffles are placed between the lamp and detector to prohibit direct illumination of

# Miniature Lamp Measurement



150 mm (6") dia top-load sphere with photometric detector for luminous flux measurement:

- 1. UMBB-150: 150 mm (6") dia Sphere
- 2. UMSS-SMT: sphere mount
- 3. UMSS-BT150: bench-top stand
- 4. UMPF-1.5: 1.5" dia port frame5. UMLA-1.5/B: lamp adapter
- base 6 UMLA 150: Jamp holder With
- 6. UMLA-150: lamp holder. Without socket
- UMPF-0.5: 0.5" dia port frame
   UMPA-0.5/11: port adapter for
- 11 type detector head

- 9. UMPA-0.5/RADIN: RADIN Diffuser for UMPA-0.5/11 port adapter
- 10. UMPB-PM: port baffle
- 11. TD-11VL01-2: temp. stabilized photometric detector
- 12. P-9710: single channel optometer with RS232 Interface
- 13. BN-0104: luminous flux transfer standard with UMLA-150 lamp holder
- 14. LPS-250: lamp power supply <u>Option:</u>
- P-2000: two channel benchtop optometer with RS232 and IEEE488 interface.

500 mm (20") dia sphere with photometric and UV-A detector for luminous flux and UV-A radiant power measurements.

- 1. UMBB-500: 500 mm (20") dia sphere
- 2. UMSS-HF500: hinge frame bench-top stand
- 3. UMPF-1.5: 1.5" dia port frame
- 4. UMLA-1.5/B: lamp adapter
- base 5. UMLA-500: lamp holder. Without socket
- 6. 2 x UMPF-0.5/11: 0.5" port frame
- 7. 2 x UMPA-0.5/11: port adapter for MD-11 detector head
- 8. 2 x UMPA-0.5/RADIN: diffuser

for UMPA-0.5/11 port adapter 9. UMPB-PM: port baffle

2

- 10. TD-11VL01-2: temp. stabilized photometric detector
- 11. TD-11UV01-2: temp. stabilized UV-A detector
- 12. P-2000: two channel benchtop optometer with RS232 and IEEE488 interface.
- 13. BN-0104: spectral radiant power transfer standard lamp 14. LPS-250: lamp power supply Options:
- UMLA-500: Additional lamp holder
- UMPA-2.0/AXL: Auxiliary lamp adapter



# **UM Series "Set-up Examples"**

### Uniform Light Source, Luminance and Spectral Radiance Standard

Uniform light sources are required to perform uniformity calibration of imaging systems and to calibrate luminance and spectral radiance measurement instruments.

Because of the integrating sphere's ability to produce multiple diffuse internal reflections and a uniform illumination of the inner sphere wall, it is the right tool to form the basis for uniform light sources.

Integrating spheres are available in different diameters offering the possibility for larger diameter emitting windows.

A number of optional accessory components can be added to the integrating sphere to expand its basic capabilities.

- Multiple lamps can be mounted onto one sphere offering high flexibility in intensity level.

If each lamps is operated with its own power supply, intensity can be varied in steps by simply switching light sources on and off.

- External spot lamps can be combined with variable attenuators to control the light output intensity in small steps. Attenuators with different resolutions are available

- External spot lamps can also be combined with manually exchangeable filters used for both neutral density attenuation and for forming the emission spectrum purposes.

- Remote control filter wheels and attenuators are another option to build a completely automated system.

- A large dynamic intensity range can be realized by combining neutral density filters with a variable attenuator

- Extra band pass filtering allows uniformity calibration across different wavelength ranges.

Large Aperture Uniform Light Source

- High speed shutters as fast as 40 ms enable calibration of the lamp's on/off characteristic.

- Luminance and spectral radi-

ance calibration is available through GO's calibration lab (ISO EN 17025 accredited for spectral irradiance & sensitivity).



Adjustable Uniform Light Source





Uniform light source 500 mm (20 in) dia sphere and (4) light sources for high uniformity and high luminance intensity. Color temperature controlled light sources

- 1. UMBB-500: 500 mm (20") dia. integrating sphere
- UMSS-SMT: sphere mount 3. UMSS-BT500: Bench top
- sphere stand
- UMPF-5.0: 5" dia port frame 5. UMPR-5.0/xx: port reducer. xx
- = 100 mm dia 6 4 x UMPB-SM: port baffle
- 4 x UMPF-1.5: 1.5" dia port 7
- frame

- 8. 4 x LS-IS1.5: light source with 50 W QH lamp
- 9. 4 x LPS-250: lamp power supply
- 10. 4 x BTH-19/2: 1/2 19" bench to housing for LPS-250
- 11. UMDP-37: detector port
- 12. UMPB-SM: port baffle
- 13. CT-3701: temperature stabi-
- lized color detector 14. P-9801: 8-channel meter
- 15. KLW: calibration of color temperature und luminance Options:

Software for remote control of intensity and color temperature control of each lamp

Adjustable uniform light source 300 mm (12 in) dia sphere and light source with manually controlled attenuator. Calibrated luminance detector for luminance intensity control

- 1. UMBB-300: 300 mm (12") dia integrating sphere
  - 2. UMSS-SMT: sphere mount
- 3. UMSS-300: bench top sphere stand
- 4. UMPF-2.0/3.5: port frame
- 5. UMPR-2.0/3.5/xx: port reducer, xx = 50 mm dia
- 6. UMPF-LSOK30: port frame 7. UMPB-PM: port baffle

- 8. LS-OK30-MIR: micrometer drive variable attenuator
- 9 LS-OK30-H100: spot lamp with 100 W QH lamp
- 10. LPS-250: lamp power supply 11. BTH-19/2: 1/2 19" bench top
- housing for LPS-250
- 12. UMPF-0.5: port frame
- 13. UMPA-0,5/11: port adapter
- 14. TD-11VL01-2: temperature stabilized photometric detector head
- 15. P-9710-1: optometer
- 16. KLW: calibration of luminance intensity

# Integrating Spheres - Page 99

# UM Series "Set-up Examples"

### Multi-port Configurations for Reflectance, Transmittance, Absorbance

Integrating spheres offer unique functions which makes them very useful in reflectance. transmittance and absorbance applications

The Lambertian emittance characteristic of uniform light sources incorporating integrating spheres provides a hemispherical diffuse and uniform illumination of test samples e.g. such as light panels used for backlighting of displays.

In this case the luminance contrast of the light panels can be measured using an additional luminance meter viewing through an additional port.

The large acceptance angle of integrating sphere based light detection systems is the main reason for using spheres in reflectance and transmittance applications

Any light that is reflected by a

diffuse material or passing through a diffuse material must be completely detected. This should be independent of the angle of reflected or transmitted light and also from any increase in spot size. Flat field detectors do not meet this requirement. The port frame will not interfere with the acceptance angle if it is designed with a knife-edge.

Besides acceptance angle, larger measurement apertures can be made, an other argument for the integrating sphere.

A precisely collimated light beam is a prerequisite for accurate reflectance and transmittance measurements. The collimated beam must not only precisely target the sample area but also not contain any diffraction rings which can produce an offset light level inside the sphere limiting

measurement resolution. Consider the UP series integrating spheres for reflection, transmission, absorbance and other applications where more precise port positioning is critical.



Transmittance of Diffuse Transmitting Samples

25



Combined reflectance transmittance system built with two 150 mm (6 in) dia. spheres and two detectors.

- Reflectance sphere:
- 1. UMBB-150: 150 mm (6") dia integrating sphere
- 2. UMSS-14/M6: post stand
- 3. UMPF-1.0: 1.0" dia port frame
- 4. UMPF-1.5: 1.5" dia port frame
- 5. UMPR-1.5/xx: 1.5" port redu-
- cer with xx = 25 mm dia and
- knife edge
- 6. UMPB-SM: port baffle
- 7. UMPF-0.5: 0.5" dia port frame 8. UMPA-0.5/11: port adapter
- 9. UMPA-0.5/RADIN: diffuser

- 10. PD-1101-2: detector head
- Transmittance sphere:
- 11. UMBB-150: 150 mm (6") dia integrating sphere
- 12. UMSS-14/M6: post stand
- 13.UMPF-1.5: 1.5" dia port frame 14. UMPR-1.5/xx: 1.5" port redu-
- cer with xx = 50 mm dia and knife edge
- 15. UMPB-SM: port baffle
- 16. UMPF-0.5: 0.5" port frame 17. UMPA-0.5/11: port adapter
- 18. UMPA-0.5/RADIN: diffuser
- 19. PD-1102-2: detector head
- Option:
- 20. P-2000: 2-channel optometer

Reflectance sphere 500 mm (20") dia, 25 deg illumination port and photometric detector. Without bench top stand.

3

- 1. UMBB-500: 500 mm (20") dia integrating sphere
- 2. UMSS-SMT: sphere mount 3. UMPF-2.5/3.5: 2.5/3.5" port
- frame
- 4. UMPR-2.5/3.5/xx: 2.5/3.5" port reducer with xx = 50 mm diaand knife edge
- 5. UMPB-SM: baffle

Δ

6. UMDP-37: 37mm dia detector port

7. VL-3701-2: photometric illuminance detector with 37type package

8

8. UMPF-2.0: 2.0" dia port frame

### Option:

- 9. P-9710: Optometer
- 10. LS-CB50: collimated light source set-up for 25 mm beam diameter
- 11. LPS-250: lamp power supply 12. BTH-19/2: 1/2 19" bench top housing

Hollow spheres with diameters from 100 mm (4 in.) to 1700 mm (68 in.) and three different coatings are offered to build integrating spheres to your need. Port frames, sphere stand and application accessory is assembled by your selection.

Please contact your local representation or the Gigahertz-Optik head office for personal assistance to discuss the set-up of the sphere and get your offer for the complete sphere set-up.



O.E.M. inquiries with different diameters, custom color painting of the sphere housing etc. are welcome.

UMB: Basic Spheres









**UM Basic Spheres** 

**Barium sulfate** is an economical coating offering a  $\sim$  97 % (555nm) diffuse reflectance characteristic within the wavelength range from 300 nm to 2400 nm. For photometric applications the reflectance can be reduce to  $\sim$  80 % to reduce substitution effects errors produced by high reflectance.

Besides the standard ODP97 coating with best reflectance characteristic a more durable coating is available with slightly less reflectance capability.

**OP.DI.MA.** is Gigahertz-Optik's own white plastic with an excellent diffuse reflectance characteristic and high durability. Its diffuse reflectance is close to

that of a perfect lambertian reflector ensuring a highly uniform light distribution across the inner walls of the integrating sphere. The spectral reflectance covers a wide spectral range from ultraviolet to IR, 250 nm to 2500 nm with > 95 % reflectance and a peak reflectance of > 98 % in the VIS/NIR spectral range.

Uncoated gold outperforms all other uncoated metallic reflectors at infrared wavelengths. Gold's high reflectivity in the red portion of the visible spectrum is apparent by it's yellow hue. With a reflectance of  $\sim$  95 % in the wavelength range from 800 nm to 20  $\mu$ m, gold is the best choice for surface coating of integrating spheres used in IR applications. A proprietary interior surface preparation creates the diffuse reflectivity required for uniform light distribution inside the sphere .

Ordering Information	Ordering Information & typical Specifications							
Model	Coating / Reflectance %	Hollow Sphere Diameter mm / in.	Sphere Frame Diameter mm / in.	Hollow Sphere Surface cm <sup>2</sup>	5% Area Port Size mm / in.			
UMBB-100	ODP97 / 97%	100/4	124 / 4.9	314	43 / 1.7			
UMBB-150	ODP97 / 97%	150/6	174/6.8	707	66 / 2.5			
UMBB-210	ODP97 / 97%	210/8.3	234 / 9.2	1385	93 / 3.6			
UMBB-300	ODP97 / 97%	300/12	324/12.7	2827	130/5.1			
UMBB-500	ODP97 / 97%	500/20	524/20.6	7584	220/8.6			
UMBB-1000	ODP97 / 97%	1000 / 39	tbc	31416	450 / 17.7			
UMBB-1700	ODP97 / 97%	1700 / 68	tbc	90792	760/29.9			
UMBK-190	ODM98 / 98%	190/~7.5	234 / 9.2	1134	84 / 3.3			
UMBK-250	ODM98 / 98%	250/10	324 / 12.7	1964	112/4.4			
UMBK-460	ODM98 / 98%	460/18	524/20.6	6648	205/8.0			
UMBG-100	ODG95 / 95%	100/4	124 / 4.9	314	43 / 1.7			
UMBG-150	ODG95 / 95%	150/6	174/6.8	707	66 / 2.5			
UMBG-300	ODG95 / 95%	300/12	324 / 12.7	2827	130/5.1			

# Integrating Spheres - Page 101

### **UM Series Components**

### UMSS-SM14, UMSS-SMT & UMSS-SMV Sphere Mount Adapters



The UMSS-SM14 sphere mount is the right choice for small diameter spheres up to 150 mm (6 in). The 14 mm diameter socket with M6 tapped hole allows the spheres to be mounted to commercial optical bench posts. The UMSS-SM14 is specified for upright use or for hanging.



**The UMSS-SMT** sphere mount is required to assemble UMB series spheres to the UMSS-BT bench-top stands using the M6 horizontal side holes provided. The SMT is fixed to the orbit flange. Additional M6 holes offer additional sphere mounting options into end-user applications.



**The UMSS-SMV** sphere mount enables spheres with a vertical orbit orientation to be assembled onto post mounts. The SMV is fixed to the orbit flange. Vertical M6 holes are provided for this purpose.



UMSS-SM14



 Ordering Information & typical Specifications

 Model
 Description
 Mounting Holes a

 UMSS-SM14
 Post mount socket fix mounted to sphere
 M6

 UMSS-SMT
 Pair of flange mounted triangular sockets fix mounted to sphere
 M6

 UMSS-SMV
 Pair of flange mounted sockets for fix mounted to sphere
 M6

Only available with UMB basic sphere order

### UMSS-SMT UMSS-BT Bench-top Sphere Stands



The UMSS-BT stands are available for UMB series spheres from 150 mm (6") to 1700 mm (68") diameters.

The stands are made out of aluminum for lightweight stability. A modular design allows freedom for custom design modification or complete application setups.

Ordering Information & typical Specifications							
Stand Model	Sphere Model	Optical Axis (mm)	Width (mm)	Length	Al profile		
UMSS-BT150	UMBB&UMBK-150	118	220	150	20 x 20		
UMSS-BT210	UMBB-210, UMBK-190	tbc	tbc	tbc	20 x 20		
UMSS-BT300	UMBB-300, UMBK-250, UMBG-300	203	370	300	20 x 20		
UMSS-BT500	UMBB-500, UMBK-460	315	593	500	30 x 30		
UMSS-BT1000	UMBB-1000	tbc	tbc	tbc	tbc		
UMSS-BT1700	UMBB-1700	tbc	tbc	tbc	tbc		
Only available with LIMB basic sphere order							

Only available with UMB basic sphere order

# Page 102 - Integrating Spheres

# **UM Series Components**

### **UMSS-HF Bench-top Hinged Frame Sphere Stands**





The UMSS-HF bench-top sphere stand is designed for those applications requiring open access to the center of the integrating sphere for insertion and removal

of the test lamp or sample. This is a common requirement in luminous flux or radiant power measurements of large multidirectional lamps, absorbance

and transmission measurements. The UMSS-HF stands are designed for rugged long-term use. Port frames and other components like detector ports, light guide adapters, auxiliary lamps & lamps holders can be assembled to both sphere halves.

Model	Sphere Model	Height of optical axis	Width	Length	Al profile
UMSS-HF300	UMBB-300	tbc	tbc	tbc	tbc
UMSS-HF500	UMBB-500	345	610	500	20 x 40
UMSS-HF1000	UMBB-1000	tbc	tbc	tbc	tbc
UMSS-HF1700	UMBB-1700	tbc	tbc	tbc	tbc

Only available with UMB basic sphere order

# **UMPF Port Frames**



Port frames are permanently mounted to the sphere at specified positions. Frames are available with free apertures from 0.5 to 5 inch diameter. A machined V-groove around the frame's



outer edge allows assembly of port plugs, reducers, adapters and other accessory components onto the port. Gold coated port frames are offered for use with UMBG series spheres.



Ordering Information & Specifications					
Model BaSO4	Model Gold	Free aperture diameter (a)	Outer diameter (b)	Frame Height (c)	
UMPF-0.5	UMPF-0.5-G	0.5 in. / 12.7 mm	0.75 in. / 18.8 mm	0.1 in. / 2.7 mm	
UMPF-1.0	UMPF-1.0-G	1.0 in. / 25.4 mm	1.25 in. / 31.5 mm	0.1 in. / 2.7 mm	
UMPF-1.5	UMPF-1.5-G	1.5 in. / 38.1 mm	1.75 in. / 44.2 mm	0.1 in. / 2.7 mm	
UMPF-2.0	UMPF-2.0-G	2.0 in. / 50.8 mm	2.25 in. / 56.9 mm	0.1 in. / 2.7 mm	
UMPF-2.0/3.5	UMPF-2.0/3.5-G	2.0 in. / 50.8 mm	3.5 in. / 88.9 mm	0.1 in. / 2.7 mm	
UMPF-2.5	UMPF-2.5-G	2.5 in. / 63.5 mm	2.75 in. / 69.6 mm	0.1 in. / 2.7 mm	
UMPF-3.0	UMPF-3.0-G	3.0 in. / 76.2 mm	tbc	0.1 in. / 2.7 mm	
UMPF-4.0	UMPF-4.0-G	4.0 in. / 101.6 mm	4.25 in. / 107.7 mm	0.1 in. / 2.7 mm	
UMPF-5.0	UMPF-5.0-G	5.0 in. / 127 mm	5.25 in. / 133.1 mm	0.1 in. / 2.7 mm	



Uniy available with UNIB basic sphere

### **UMPP Port Plugs**



Port plugs are used with UMPF port frames to close sphere port openings while maintaining it's uniformly coated interior surface. Plugs are fixed onto the side Vgroove of the port frame with three M2.5 screws. The surface facing the sphere interior is coated with barium sulfate or gold as applicable. Port plugs for UMBK spheres are available by special request.



Drdering Information & Specifications					
Model BaSO4	Model Gold 1)	Port Frame	Outer diameter a ( mm / inch )	Height b ( mm / inch )	
UMPP-0.5	UMPP-0.5-G	UMPF-0.5	27 / 1.06	5.3 / 0.2	
UMPP-1.0	UMPP-1.0-G	UMPF-1.0	39.9 / 1.57	5.3 / 0.2	
UMPP-1.5	UMPP-1.5-G	UMPF-1.5	52.6 / 2.07	5.3 / 0.2	
UMPP-2.0	UMPP-2.0-G	UMPF-2.0	65.3 / 2.57	5.3 / 0.2	
UMPP-2.0/3.5	UMPP-2.0/3.5-G	UMPF-2.0	97 / 3.81	5.3 / 0.2	
UMPP-2.5	UMPP-2.5-G	UMPF-2.5	78 / 3.07	5.3 / 0.2	
UMPP-3.0	UMPP-3.0-G	UMPF-3.0	tbc	5.85 / 0.23	
UMPP-4.0	UMPP-4.0-G	UMPF-4.0	116.1 / 4.57	5.85 / 0.23	
UMPP-5.0	UMPP-5.0-G	UMPF-5.0	141.5 / 5.57	5.85 / 0.23	

### **UMPR Port Reducer**



Port reducers for the UMPF series spheres enable the free aperture diameter of port frames to be variably decreased according to the application. The aperture diameter can be end-user specified up to the maximum aperture on order. The edge of the aperture is machined in a knife-edge design. Port reducers are fixed onto the V-groove of the port frame with three M2.5 screws. The surface facing the sphere interior is coated with barium sulfate or gold as applicable. Port plugs for UMBK



spheres are available by special request. Other optional forms of non-circular reducer such as slits can be custom ordered.

Ordering Information & Specifications							
Model BaSO4	Model Gold	Port Frame	Outer diameter a (mm / inch)	Height b ( mm / inch )	xx = 0 to max free aperture *)		
UMPR-0.5/xx	UMPR-0.5/xx-G	UMPF-0.5	27 / 1.06	5.3 / 0.2	12.5 / 0.5		
UMPR-1.0/xx	UMPR-1.0/xx-G	UMPF-1.0	39.9 / 1.57	5.3 / 0.2	25.4 / 1.0		
UMPR-1.5/xx	UMPR-1.5/xx-G	UMPF-1.5	52.6 / 2.07	5.3 / 0.2	38.1 / 1.5		
UMPR-2.0/xx	UMPR-2.0/xx-G	UMPF-2.0	65.3 / 2.57	5.3 / 0.2	50.8 / 2.0		
UMPR-2.0/3.5/xx	UMPR-2.0/3.5/xx-G	UMPF-2.0	97 / 3.81	5.3 / 0.2	50.8 / 2.0		
UMPR-2.5/xx	UMPR-2.5/xx-G	UMPF-2.5	78 / 3.07	5.3 / 0.2	63.5 / 2.5		
UMPR-3.0/xx	UMPR-3.0/xx-G	UMPF-3.0	tbc	5.85 / 0.23	76.2 / 3.0		
UMPR-4.0/xx	UMPR-4.0/xx-G	UMPF-4.0	116.1 / 4.57	5.85 / 0.23	101.6 / 4.0		
UMPR-5.0/xx	UMPR-5.0/xx-G	UMPF-5.0	141.5 / 5.57	5.85 / 0.23	127 / 5.0		

) free aperture diameter xx in mm / inch with or without knife wedge needs to be specified on of

### **UMDP Detector Ports**



Detector ports are required to mount 37 and 45 mm diameter photometric, radiometric and color detectors to UM series integrating spheres.

The plastic ring that holds the detector electrically and thermally isolates the detector from the sphere.

It's free aperture can be in-



These port frames are needed to mount LS-OK30 and LS-OK34 external light sources to the integrating sphere. Typically these light sources are used together with the LS-OK30-VA variable attenuator.

creased according to the detector diffuser size. The sphere surface side of the detector adapters are coated with barium sulfate.

Simple adapters that fit into the detector port allow detector heads with different outside diameters to be mounted.



S	Ordering Information & Specifications						
Э	Model	Detector dia.	Free aperture diameter *) a	Outside diameter b	Height c		
- า	UMDP-37	37 mm	10 to 38 mm	46 mm	13 mm		
	UMDP-45	42 & 45 mm	10 to 47 mm	56.9 mm	13 mm		

\*) machined on order. Only available in order with UMB basic sphere

# 0 С

# UMPF-LSOK Port Frames for Light Source LS-OK30 & LS-OK45

Ordering Information & Specifications					
Model	Aperture Dia. a	Dimension ( mm )			
UMPF-LSOK30	30 mm	60 x 60			
UMPF-LSOK45	45 mm	tbc			
Only available with LIMB basic sphere order					

Only available with UMB basic sphere order

### **UMPB** Port Baffles



Baffles are employed to shield ports from direct irradiation from an other port, a lamp, probe or from first reflection off the sphere surface.

UMDB-SM baffles are direct mounted to the sphere housing. They are typically used between two ports or between inside assembled lamps and ports.

UMDB-PM baffles are used in front of detector ports to prohibit direct irradiation of the detector from centrally mounted lamps. This baffles are typically post mounted.

UMDB-IL baffles are uses between to ports in-line assembled to the sphere. This arrangement

is typically used for uniform light source set-ups with an external lamp at one port and the light

output at the other port.

 $(\times$ 



UMPB-SM

UMPB-PM

UMPB-IL

**Ordering Information** Model BaSO4 Model Gold Description UMPB-SM UMPB-SM-G Sphere mount baffle UMPB-PM UMPB-PM-G Post mount baffle UMPB-IL UMPB-IL-G In-Line spider mount baffle Only available with UMB basic sphere order

# 🕒 Gigahertz-Optik



Port adapters are universal tools used to assemble detectors, light guides, accessories and samples to UMPF sphere series port frames. The port adapter

### UMPA -0.5/11

Port adapter specially designed to mount standard Gigahertz-Optik 11-type housing detectors or UFC fiber connectors with 11type adapter flanges to the UMPF-05 port frame.



can be fixed in place by three M2.5 screws to the port frame's standard V-groove. The port adapters can be replaced by port plugs to close the port as

### UMPA -0.5/F & -1.0/F

Port adapter for use on UMPF-0.5 and UMPF-1.0 port frames respectively. The standard 1 mm dia. hole can be easily modified to larger diameters up to 0.5 / 1 in. (12.5 / 25.4 mm) to mount light guides and other accesso-



UMPA-5.0/SH, SH-P & SH-CM

**Model UMPA-5.0/SH** is a universal sample holder system which fits onto the UMPF-5.0 port frame. A 101.6 mm (4 in.) diameter free aperture allows samples to be placed in front or inside the sphere. The **UMPA-5.0/SH-P** port plug can also be used for custom modifications. The **UMPA-5.0/SH-CM** adapter is used when samples should be placed in the sphere center.



UMPA-5.0/SH with CM

### UMPA-1.5/LGA13

Port adapter to mount light guides with 13.2 mm dia. type adapter to the UM series integrating spheres.



required by the application. The following list of port adapters represents only a small sample of available parts in Gigahertz-Optik's continuously expanding program. Please contact your local representative or the factory for detailed drawings and also to keep abreast of new product developments.

**UMPA Port Adapter** 

### UMPA-4.0/QD1.9 & UMPA-4.0/QD3.0

Port adapter designed for uniform light source set-ups requiring a diffuser window. The 48 mm / 1.9 in dia. (model 1.9/QD)



or 76.2 mm / 3.0 in dia. (model 3.0/QD) diffuse quartz windows offer a useful wavelength range from 250-2500 nm.



UMPA-4.0/QD1.9

UMPA-4.0/QD3.0

### UMPA-2.0/LED5 & UMPA-5.0/LED5

Port adapter which allows the precise positioning of LEDs mounted in the LED-5xx mount series of Instrument Systems /

Munich to the entrance port of Gigahertz-Optik's integrating spheres.







### UMPA-2.0/AXL

Port adapter to set-up an auxiliary lamp by using a LS-IS1.5-H10 external light source. The adapter includes a hemisphere

baffle to protect ports and other components for direct illumination. The LS source can be direct mounted.



UMPA-2.0/AXL

LS-IS1.5 optional

# Page 106 - Integrating Spheres

# **UM Series Components**

Ordering Information & Specifications						
Model	Port Frame	Mechanical Interface	Outside Diameter	Height		
UMPA-0.5/11	UMPF-0.5	11-type detectors & UFC fiber couplers	25.4 mm / 1.0 in.	8.5 mm / 0.34 in.		
UMPA-0.5/11-RD	-	RADIN diffuser to be glued into UMPA-0.5/11	12 mm / 0.47 in.	1 mm / 0.04 in.		
UMPA-0.5/F	UMPF-0.5	1 mm dia., machineable up to 12.5 mm	25.4 mm / 1.0 in.	15 mm / 0.59 in.		
UMPA-1.0/F	UMPF-1.0	1 mm dia., machineable up to 25.4 mm	38.1 mm / 1.5 in.	15 mm / 0.59 in.		
UMPA-1.5/LGA13	UMPF-1.5	Socket for 13.2 mm dia light guide adapter	52.6 mm / 2.1 in	10.4 mm / 0.41 in		
UMPA-2.0/AXL	UMPF-2.0	Auxiliary lamp adapter with baffle for LS-IS1.5-10	65.3 mm / 2.6 in	6.4 mm / 0.25 in		
UMPA-2.0/LED5	UMPF-2.0	Socket for Instrument Systems LED-5xx LED adapter	65.3 mm / 2.57 in	25.85 mm / 1.01 in		
UMPA-4.0/QD1.9	UMPF-4.0	48 mm / 1.9 in dia quartz diffuser	116.1 mm/ 4.57 in	3.7 mm / 0.15 in.		
UMPA-4.0/QQ3.0	UMPF-4.0	76.2 mm / 3.0 in. diameter quart diffuser	116.1 mm / 4.57 in	3.7 mm / 0.15 in		
UMPA-5.0/LED5	UMPF-5.0	Socket for Instrument Systems LED-5xx LED adapter	141.5 mm / 5.57 in	25,85 mm / 1.01 in		
UMPA-5.0/SH	UMPF-5.0	101.6 mm / 4.0 in free aperture sample holder base	141.5 mm / 5.57 in	4.25 mm / 0.17 in.		
UMPA-5.0/SH-P	UMPF-5.0	Universal sample holder plate	141.5 mm / 5.57 in	6 mm / 0.24 in.		
UMPA-5.0/SH-CM	UMPF-5.0	Universal center mount sample holder	141.5 mm / 5.57 in	6 mm / 0.24 in.		

### **UMLA Lamp Adapter for Center Mount**



**UMLA** lamp adapters are designed to mount lamps in the center of the integrating sphere for luminous flux or radiant power measurements.

The **UMLA-1.5/B** base offers four banana sockets for current and voltage connections to the lamp sample. It's rugged connector socket permits mounting and connection of the UMLA-xx lamp adapters. A UMPF-1.5 port frame is needed to mount the UMLA.1.5/B adapter onto the sphere.

The UMLA-xx lamp holders are

available in different lengths for compatibility with different size spheres. It's connector positioned at the top end of the UMLA-xx allows simple connection and mounting to the UMLA-1.5/B base socket. Lamp socket is supplied and assembled by the end-user.

The **UMLA-xx** includes a lamp socket specified by the end-user as a special order. Consult factory for assistance.



**Ordering Information & Specifications** Model Accessory Description UMLA-1.5/B UMPF-1.5 Base adapter for UMLA-xx lamp holder **UMLA-300** Lamp holder for 300 mm / 12" diameter spheres UMLA-1.5/B **UMLA-500** UMLA-1.5/B Lamp holder for 500 mm / 20" diameter spheres UMLA-xx UMLA-1.5/B Lamp holder with lamp socket. Contact factory with detailed specs. Lamp adapter and lamp holder for UMBB-1000 and UMBB-1600 available by request

30 mm

**Gigahertz-Optik** 

### **Precision Machined Integrating Spheres**



Precise port alignment is a requirement in all kinds of transmittance, reflectance and absorbance measurements. Exact port positions produce optimum sample illumination and more accurate measurement of directional reflection and transmission.

Three different coatings are offered for UP Series Spheres:

1. UPB Barium Sulfate

2. UPG Gold

#### 3. UPK OP.DI.MA.

Three different standard port arrangements are offered:

-L type spheres are designed for the measurement of directional emitting light sources. A knife-edge measurement port opening offers a large acceptance angle for diverging light sources. Special baffle designs prevent any direct or first reflection illumination of the detector.

-F type spheres are designed for flexible use in measurement of reflectance (8°/D), transmittance and power. The knife-edge design of the measurement port ensures that any diffuse reflected or transmitted light enters the sphere. The back side ports allow 8° sample illumination. To measure diffuse reflection, the 8° port can be opened so that directional glow radiation can pass out. Special light traps are offered. The back-side central port permits the separation of diffuse and directional transmitted light. An additional substitution port may help to reduce the substitution error during calibration and measurement. The back-side and substitution ports are supplied with coated port plugs (same coating as used in sphere).

-US type spheres for uniform light source set-up based on LEDs.

Besides catalog products, Gigahertz-Optik offers custom design modification, custom labeling and complete new product development service. Please contact the factory to



integrating sphere

Coatings for UP Series



### UPB: Spheres with Barium Sulfate Coating

-F set-up

**Barium sulfate** is an economical coating offering a  $\sim$  97 % (600 nm) diffuse reflectance characteristic within the wavelength range from 300 nm to 2400 nm. For photometric applications the reflectance can be reduce to  $\sim$  80 % to reduce substitution effects errors produced by high reflectance.



### UPK: Spheres with OP.DI.MA. Coating

**OP.DI.MA.** is Gigahertz-Optik's own white plastic with an excellent diffuse reflectance characteristic and high durability. Its diffuse reflectance is close to that of a perfect lambertian reflector ensuring a highly uniform light distribution across the inner walls of the integrating sphere. The spectral reflectance covers a wide spectral range from ultraviolet to IR, 250 nm to 2500 nm with > 95 % reflectance and a peak reflectance of > 98 % in the VIS/NIR spectral range.



### **UPG: Spheres with Gold Coating**

**Uncoated gold** outperforms all other uncoated metallic reflectors at infrared wavelengths. Gold's high reflectivity in the red portion of the visible spectrum is apparent by it's yellow hue. With a reflectance of ~ 95 % in the wavelength range from 800 nm to 20  $\mu$ m, gold is the best choice for surface coating of integrating spheres used in IR applications. A proprietary interior surface preparation creates

the diffuse reflectivity required for uniform light distribution inside the sphere.



# Page 108 - Integrating Spheres

**UP** Series

### Model UPB-50-L



**The UPB-50-L** is a compact size 50 mm (2 in.) diameter integrating sphere coated with barium sulfate.

11-type detectors or 11-type fiber connectors can be directly mounted to the detector port which is baffled to prevent direct illumination from the 12.5 mm (0.5 in.) measurement port.

A threaded M6 hole are provided to mount the sphere onto a bench post.

The UP-50-L can be supplied

### Model UPB-100-F

**The UPB-100-F** is a compact size 100 mm (4 in.) diameter integrating sphere coated with barium sulfate.

11-type detectors or 11-type fiber connectors can be directly mounted to the detector port which is baffled to prevent direct illumination from the 15 mm (0.6 in.) diameter measurement port. The back-side  $+8^{\circ}$ ,  $0^{\circ}$  and  $-8^{\circ}$  ports and substitution port are supplied with port plugs for universal use.

A threaded M6 hole allows post mounting of the sphere.



with two detector ports to accommodate either two 11-type detectors or one detector and



one UFC-11 series fiber optic adapter.



 Dimensions (mm):

 a
 60
 c
 53

 b
 20
 d
 M6

Ordering Information & Specifications					
	Sphere	Port			
Model	Dia.*)		Diameter*)	Plug	Coating**)
UPB-50-L	50 / 2	P1	12.5 / 0.5	No	BaSO4 / 97 / 300-2400
		Pd	11-type	No	
DP-11	-	Pd	11-type	No	Additional port for 11-type detectors & accessories
*) dimension in mm / in. **) type / reflectance in % / wavelength in nm					
Accessory Components: PD-11 & TD-11 detectors; UFC-11 fiber adapter					


## 🖲 Gigahertz-Optik

## Integrating Spheres - Page 109

## UP Series









The	UPB	-150·	-F	s a	com	ipact
size	150	mm	(6	in)	diar	neter
integ	rating	i sph	iere	COa	ated	with
bariu	m sul	fate.				
<b>T</b> 1 ·						

This large diameter sphere is made exclusively to order offering complete freedom for individual design.

Contact the factory to discuss your sphere requirement.

Ordering In	Ordering Information & Specifications						
	Sphere		Port			а	168
Model	Dia.*)		Diameter*)	Plug	Coating**)	b	160
UPB-150-F	150 / 6	P1	tbc	No	BaSO4 / 97 / 300-2400	C	149
	1	P2	tbc	Yes			
	1	P3	tbc	Yes			
	1	P4	tbc	Yes			
	1	P5	tbc	Yes			
	1	Pd	tbc	No			
DP-11	-	Pd	11-type	No	Additional port for 11-type detectors & accessories		
*) dimension	is in mm /	in. **) t	ype / reflectan	ce in % /	wavelength in nm		
Accessory (	Compone	nts MC	0-11 & MDT-1	1 detecto	ors; <b>UFC-11</b> fiber adapter; <b>ULT</b> : light trap.		



	O
1	

The UPB-250-F is a compact size 250 mm (10 in) diameter integrating sphere coated with barium sulfate.

37-type or 45-type detectors can be mounted to the detector port with optional adapters. The measurement port is baffled to prevent direct illumination from the 50 mm (2 in) measurement port.

The back-side  $+8^{\circ}$ ,  $0^{\circ}$  and  $-8^{\circ}$ ports and the three substitution ports are supplied with Barium Sulfate coated port plugs for universal use.

	Dimens	sions	
а	252	С	255
b	90	d	90

#### **Ordering Information & Specifications**

	Sphere		Port					
Model	Dia.*)		Diameter*)	Plug	Coating**)			
UPB-250-F	250 / 10	P1	50 / 2	No	BaSO4 / 97 / 300-2400			
		P2/6/7	50 / 2	Yes				
		P3/4/5	25 / 1	Yes				
		Pd	1	No				
*) dimensions	s in mm / in. '	**) type / re	eflectance in % /	wavelength i	n nm			
Accessory C	components	37 & 45-tv	ne detector hear	lsea VI -37	7 RW-37 TD-37 CT-4501 III T light tran			

ccessory Components 37 & 45-type detector heads e.g. VL-37, RW-37, ID-37,

UPB-250-F



## **UP Series**

#### UPB-500-F



The UPB-500-F is a 500 mm (20 in.) diameter sphere with barium sulfate coating. A wide range of accessory components are available for use on the UP-500-F making it one of the most flexible sphere designs available. CNC machined ports guarantee best possible port alignment, a requirement for precise reflectance and transmittance measurements.

Both a measurement port and a additional top port for use as a

#### **UPB-500-F Standard Accessories**

The UPB-500-F offers several standard accessories for flexible set-ups. Measurement and top port apertures are 150 mm (6 in.) in diameter and can be reduced to 50 mm (2 in.) or closed with port plugs. The detector port is supplied with a port plug and a baffle plug to shield the detector from direct illumination from the

measurement port. The  $+8^{\circ}$ ,  $0^{\circ}$ and  $-8^{\circ}$  ports are supplied with port plugs.

UPB-500-F Uniform Light Source Set-up

The **UPB-500-F-Z14** quartz thalogen lamp combined (1 weights) with the **UPB-500-F-Z04** diffuser allows the UPB-500- Diffusor F to be set-up as a uniform light source. A lamp holder baffle prohibits direct illumination of the diffuser window. The quartz diffuser window is 48 mm in diameter. Electrical connections are made with banana plugs mm



mounted on the base holder.

Ordering Information & Specifications:							
Model	Sphere		Port				
	Dia.*)		Diameter*)	Plug	Coating**)		
UPB-500-F	500 / 20	P1	150 / 6 & 50 / 2	No			
		P3	50 / 2	Yes	BaSO4		
		P4	25 / 1	Yes	97		
		P5	25 / 1	Yes	300-2400		
		P7	150 / 6 & 50 / 2	Yes			
		Pd	1	Yes			
*) dimension in m	nm / in. **)	type	/ reflectance in % ,	/ wave	ength in nm		
Accessory:							
UPB-500-F-Z01	37 mm de	etecto	r adapter				
UPB-500-F-Z04	Diffuser w	vindov	v adapter				
UPB-500-F-Z12	Detector	baffle	adapter				
UPB-500-F-Z13	Lampe holder base						
UPB-500-F-Z14	100 W QH lamp with baffle (requires UPF-500-F-Z04)						
UPB-500-F-Z15	Base plat	e with	goniometric rotati	ng sta	ge		

substitution or 'load' port for lamps and sample holders are provided. Both ports offer a free aperture of 150 mm (6 in.) diameter and are supplied with port reducers with 50 mm (2 in.) free aperture and knife edge design. This allows DIN 5036 and CIE 130 traceable transmission and reflection measurement of thin and thick diffuse samples! The back-side +8°, 0° and -8° ports are supplied with port plugs for universal use of the UPB-500-F.

## Available accessory parts allow set-ups for:

- 1. Reflectance measurements
- 2. Transmittance measurement
- 3. Luminous flux measurement
- 4. Radiant power measurement
- 5. Uniform light source

Please contact the factory for more detail information and pricing for your sphere set-up.



UPB-500-F Reflectance & Transmittance Set-up



DIN 5036 and CIE 130 recommend the use of an integrating sphere with different measurement port diameters for the measurement of reflectance and transmittance of diffuse and nondiffuse samples.

The **UPB-500-F** is available with two sizes of measurement port at

50 mm or alternatively 150 mm diameter free aperture. The knife edge design of the port frame guarantees the large acceptance angle required to ensure that light from all directions enters the sphere.

The **UPB-500-F-Z15** base plate is the right tool for a DIN 5036 and CIE 130 conformal set-up of a reflectance and transmittance measurement system. A rugged goniometric rotating stage holds the sphere and allows precise positioning of the entrance port or +8° port to the collimated light source (optionally available). The LS-CB-50 emits a precisely collimated beam to ensure low stray light levels in the sphere for best possible signal to noise ratio.

Along with spheres and collimated light sources Gigahertz-Optik offers power supplies, photometric and radiometric detector heads and optometers for complete measurement system set-ups.

## 🕃 Gigahertz-Optik

## Integrating Spheres - Page 111

## **UP Series**

**UPK-30-L** 





Dimensions (mm):						
а	55	С	37.5			
b	41	d	M6 & 1/4"			
-						

#### Ordering Information & Specifications:

	Sphere		Port				
Model	Dia.*)		diameter*)	Plug	Coating**)		
UPK-30-L	30 / 1.2	P1	5 / 0.2	No	ODM98 / 98 / 250-2500		
		Pd	1 x11-type	No			
DP-11 Pd 11-type No		No	Additional ports for 11type detectors & accessories				
*) dimension in mm / in. **) type / reflectance in % / wavelength in nm.							
Accessorv	•	PD-11	& TD-11 detect	ors: UFC	-11 fiber adapter		

#### UPK-50-F, UPK-50-L & UPK-50-ULS

#### UPK-50-F









Dimensions	(mm):		
а	70	С	61
b	50	d	M6



The UPK-50 is a very popular compact size integrating sphere for many radiometric and photometric applications requiring sphere mounted integral detectors or diode array spectrometers.

The OP.DI.MA. coating is highly reflective from 250 nm to 2500 nm. In combination with its small 50 mm (2 in) diameter a low attenuation factor results which makes the UPK-50 series ideal for sensitive measurement applications.

The nearly ideal lambertian reflectance characteristic of OP.DI.MA. offers best light distribution by the multiple reflections, which is very important for small diameter spheres.



The UPK-30-L is a compact 30 mm (1.2 in.) diameter integrating sphere with OP.DI.MA. coating. The small diameter and high reflectance of 98 % in the wavelength range from 400 to 1700 nm result in a low attenuation which allows to build high sensitive sphere detectors with small area and therefore low price Siand InGaAs photodiodes. The unique baffle design combined with the good diffuse reflectivity of ODM98 makes this sphere insensitive against different light incident angles and reduces effects by polarization and re-reflected light. One, alternative two 11-type detectors or UFC fiber connectors can be assembled.



The knife-edge and unique baffle designs plus good diffuse reflectivity enable a large measurement port acceptance angle.

Model UPK-50-L is designed to measure the intensity of directional light. One or more detectors, or alternatively fiber optics, can be adapted to the sphere to increase the wavelength range.

Model UPK-50-F is a more flexible version for reflectance and transmittance measurements. One or more detectors, or alternatively fibers, can be adapted to the sphere to increase its wavelength range.

Model UPK-50-ULS is designed for uniform light source set-ups using multiple standard I FDs

## Page 112 - Integrating Spheres



#### UPK-50-F,

#### UPK-50-ULS







## Ordering Information & Specifications:

Sphere	1	Port		
Dia.*)		diameter*)	Plug	Coating**)
50/2	P1	10 / 0.4	No	
	Pd	1 x 11-type	No	
50/2	P1	10 / 0.4	No	ODM98
	P2/3/5	10 / 0.4	Yes	98 / 250-2500
	Pd	1 x 11-type	No	
50/2	P1	10 / 0.4	No	
	Pled	8 x 5 mm	No	
& -F)	Pd	1 x 5 mm	No	Additional ports for 11type detectors & accessories
	50 / 2 50 / 2 50 / 2	50 / 2         P1           50 / 2         P1           50 / 2         P1           2         P1           92/3/5         Pd           50 / 2         P1           92/3/5         Pd           92/3/5         Pd           92/3/5         Pd           91         PLED	50/2         P1         10/0.4           Pd         1 x 11-type           50/2         P1         10/0.4           P2/3/5         10/0.4           Pd         1 x 11-type           50/2         P1         10/0.4           Pd         1 x 11-type           50/2         P1         10/0.4           Pd         1 x 11-type           50/2         P1         10/0.4           PLED         8 x 5 mm	50 / 2         P1         10 / 0.4         No           Pd         1 x 11-type         No           50 / 2         P1         10 / 0.4         No           50 / 2         P1         10 / 0.4         No           P2/3/5         10 / 0.4         Yes           Pd         1 x 11-type         No           50 / 2         P1         10 / 0.4         Yes           Pd         1 x 11-type         No           50 / 2         P1         10 / 0.4         No           PLED         8 x 5 mm         No

Dimensions (mm):				
а	89			
b	50			
С	72			

#### \*) dimensions in mm / in. \*\*) type/reflectance %/wavelength nm

Accessory (only -L & -F): PD-11 & TD-11 detectors; UFC-11 fiber adapter

#### UPK-100-F & UPK-100-L



The UPK-100 is a 100 mm (4 in) diameter sphere made from machined OP.DI.MA. Its compact size and high reflectance from 250 nm to 2500 nm results in low attenuation making it suitable for sensitive measurement applications. A knife-edge and unique baffle design plus good diffuse reflectivity enable a large acceptance angle measurement port **Model UPK-100-L** is designed to measure the intensity of directional light.

**Model UPK-100-F** is a more flexible version for intensity, reflectance and transmittance measurements. Optional detectors or fibers can be added to both sphere models.



## a 128 c 107 b 70 d M6

#### Ordering Information & Specifications

	Sphere		Port			
Model	Dia.*)		diameter*)	Plug	Coating**)	
UPK-100-L	<b>I-100-L</b> 100/4 P1 15/0.6 No					
***)		Pd	1 x 11-type	No		
UPK-100-F	100 / 4	P1	15 / 0.6	No	ODM98 / 98 / 250-2500	
		P2	15 / 0.6	Yes		
		P3/4/5	10/0.4	Yes		
		Pd	1 x 11-type	No		
<b>DP-11</b> Pd		1 x 11 type	No	Additional detector port		
*) dimensions	in mm / in. **	) type/refle	ctance %/waveler	ngth nm ***)	as UPK-100-F without P2,P3, P4, P5	
Accessory C	omponents F	PD-11 & TI	D-11 detectors; U	FC-11 fiber	adapter	



**UP** Series

UPK-150-F



Dimensions ( mm )				
а	176	С	160	
b	90			

#### **Ordering Information & Specifications:**

••••••••••••••••••••••••••••••••••••••					
	Sphere		Port		
Model	Dia.*)		diameter*)	Plug	Coating**)
UPK-150-F	150 / 6	P1	25 / 1	No	
		P2	25 / 1	Yes	ODM98 / 98 / 250-2500
		P3	15/ 0.6	Yes	- ODIVI98 / 98 / 230-2300
		P4/5	10/0.4	Yes	
		Pd	1 x 11-type	No	
*) dimension in I	mm / in. **) type / re	eflectanc	e in % / waveleng	ith in nm	
DP-11		Pd	1 x 11 type	No	Additional detector port
DP-37		Pd	1 x 37 type	No	Additional detector port
Accessory:		MD-11	& MDT-11 detect	tors; <b>37t</b>	ype detectors; UFC-11 fiber adapter



**The UPK-150** is a 150 mm / 6 in. diameter sphere with OP.DI.MA. coating. The high reflectance from 250 nm to 2500 nm offers a low attenuation for sensitive measurement application. The knife-edge design, the unique baffle design and good diffuse reflectivity offer a large acceptance angle of the measurement port.

Large diameter ODM98 spheres are only made on order which offers all freedom in the individual design such as show in the above picture which shows a custom design sphere for reflectance measurements based on the UPK-150-F. Pls. Contact the factory to discuss your need.

UPK-190





Drawing shows a weight reduced version

	Dimensions ( mm )						
а	238	С	200				
b	110	d	100				

Ordering Information & Specifications								
	Sphere	F	Port					
Model	Dia.*)	Туре	diameter*)	Coating**)				
UPK-190	190 / 7.5	P1 to Pn	custom	ODM98 / 98 / 250-2500				
		Pd	custom					
*) dimensions in	1 mm / in. **) type	/ reflectance in 9	% / wavelength in nr	n				
Customization t	o end-user specif	ications						



The UPK-190 is a 190 mm (7.5 in) diameter sphere made from OP.DI.MA. Low attenuation for sensitive measurement applications or high intensity uniform light sources is made possible by ODM98's high reflectance from 250 nm to 2500 nm. The ODM98 is directly formed as a hollow sphere to reduce material and machining cost. Large diameter ODM98 spheres

Large diameter ODM98 spheres are made exclusively to order offering complete freedom for individual design. Pictured is a custom designed high intensity uniform light source based around the UPK-190 sphere. Contact the factory to discuss your sphere requirements.

## Page 114 - Integrating Spheres



## **UP** Series

#### UPK-250

The UPK-250 is a 250 mm (10 in) diameter sphere made from OP.DI.MA. Low attenuation for sensitive measurement applications or high intensity uniform light sources is made possible byODM98's high reflectance from 250 nm to 2500 nm. The ODM98 is directly formed as a hollow sphere to reduce material and machining cost.

Large diameter ODM98 spheres are made exclusively to order offering complete freedom for individual design. Pictured is a custom designed sphere based around the UPK-250 sphere. Contact the factory to discuss

your sphere requirements.



Example of UPK-250 with custom specified port layout

Dimensions							
а	290	С	268				
b	122	d	170				

Ordering Information & Specifications								
Sphere Port								
Model	Dia.*)	Туре	diameter*)	Coating**)				
JPK-250	250 / 10	P1 to Pn	custom	ODM98 / 98 / 250-2500				
		Pd	custom					
*) dimensions in mm / in. **) type/reflectance %/wavelength nm								
Customization to e	nd-user enerifica	tions						

Customization to end-user specifications

#### UPG-75-F



The UPG-75-F is a 75 mm (3 in) diameter sphere with a gold coating. Its compact size and high reflectance from 1 to 20  $\mu m$  provides for a low attenuation factor for sensitive measurement applications. A diffuse surface preparation offers good uniform radiation distribution inside the sphere. The knife-edge design measurement port creates a large acceptance angle .

Besides intensity measurement of directional radiation and transmittance, the +8° and -8° ports allow reflectance measurement opportunities as well. Accessory port reducers, baffles and port plugs are available.



Ordering Information & Specifications	
b 52	
a 80 c 78 P3/5 plugs P2 baffle P2/P3	8/P5 port reducer P2 port plug

Sphere			Port		
Model	Dia.*)	type	diameter*)	Plug	Coating**)
<b>UPG-75-F</b> 75/3		P1	12 / 0.47	No	ODG95 / 95 / 1-20
		P2	11 / 0.43	Yes	
		P3/5	10 / 0.39	Yes	
UPG-75Z-01		-	-	-	Plug-in baffle port P2 to P1 or to P3/5
UPG-75Z-02		-	-	-	Port reducer set for P1, P2, P3 and P5
*) dimension	s in mm / in	. **) type/re	flectance %/wavel	ength $\mu$ m	
Accessory (	Component	ts ULT: ligh	t trap P5 port		

## Cigahertz-Optik

## Integrating Spheres - Page 115

**UP** Series

UPG-100-F



Accessory Components ULT: light trap for -8° port

#### **ULT Light Trap**



Ordering Information & Specifications									
Model	Model Aperture Diameter b Interface a c d								
ULT-11	11 mm	11-type	32 mm	24 mm	37 mm				



Light traps are designed for reflectance and transmittance measurements with integrating spheres. They are used to fully absorb the directionally reflected or transmitted part of the light signal. The ULT light trap's internal design with black coating offers high absorbance with minimal re-reflected light.

## Page 116 - Integrating Spheres

**UP** Series

## **Gigahertz-Optik**

#### UFC, Fiber Connector Adapter



Ordering Information:

Description

FC type adapter

SC type adapter

ST type adapter

SMA type adapter

Model

UFC-11/FC

UFC-11/SC

UFC-11/ST

UFC-11/SMA



Fiber adapters are used to couple fibers with standard fiber optic connectors to integrating spheres.

The UFC-11 adapter fits all integrating spheres with 11 type interface ports.

Four different models are of-fered.



For touch-up repairs or self applied coating jobs, Gigahertz-Optik offers barium sulfate coating. The solution is water based for less toxicity and safer application and transport.

Please see chapter *Diffuse Reflectors* for additional information about the coating and accessories..

Ordering Information & Specifications:			
Model Description			
ODP97-1.0	Barium Sulfate Paint . 1.0 I bottle.		

Coating with optional sprayer set

#### **Light Sources**

Light sources are needed in application where integrating spheres are used as uniform light sources or in reflectance transmittance measurements. Gigahertz-Optik offers three different kinds of light sources as well as lamp power supplies and stepping motor drives for accessories used with light sources.











Integrating spheres are the ideal tool to build uniform light sources. The most economic way to set-up a uniform light source is to place lamps inside of the hollow sphere and baffle them against the light output port.

One or more LS-IS1.5 can be mounted to the UM spheres to reach the expected luminance level at the output port. The lamp housing of the UMLS-IS is compact and easy to assemble to one of the UMPF-1.5 port frames. The lamp exchange is simple because of the remove able cap. Different quartzhalogen tungsten lamps with 10 W to 100 W radiant power are offered. The electrical connection is done by banana jacks.

The number of lamps and their total power is limited by the max. operation temperature of the sphere. Optional fans, direct mounted to the lamp housing are offered to increase the max. power.

Ordering Information	tion & Specificat	ion:					
Model	Power (W)	Wavelength Range (nm)	Luminous Flux Im	Color Temperature	Life Time h	Operation Voltage (V)	Operation Current (A)
LS-IS1.5	-	-	-	-	-	-	-
LH-5	5		60	3000	4000	12	?
LH-10	10		130	3000	4000	12	?
LH-35	35	380 - 2500	600	3000	4000	12	?
LH-75	75		1450	3000	4000		
LH-50	50		930	3000	4000	12	?
LH-90	90		1800	3000	4000	12	?
LH-10-UV	10		?	?	?	12	?
LH-50-UV	50	250-2500	1000	?	1100	12	?
LH-100-UV	100		2800	?	2000	12	?
Accessory: Powe	r Supplies Temp	erature stabilized dete	ctor heads				

Accessory: Power Supplies, Temperature stabilized detector heads

LS-OK30 Light Source Series



LS-OK30 assembled to UPK-190

In applications were the light output intensity of a uniform light source needs to be controlled or the light has to be spectrally filtered the light source needs to be placed outside of the sphere to allow to place a variable aperture and/or optical filter between lamp and hollow sphere.

**The LS-OK** offers an unique reflector design which increases the intensity and uniformity of their light output. This reflector does also work like a 'simple satellite sphere' which effects an increased uniformity.

Different lamps from 10 to 100 W radiant power are offered. The electrical connection is done by banana jacks.

Fan's, direct to the lamp housing reduces the operation temperature of the lamp socket.

LS-OK30-VA with 1:6 gear drive and LS-OK30-MIR with a micrometer drive work as variable attenuators if they are placed between lamp and sphere.

The **LS-OHK30-FH** filter holder fits between lamp and sphere and allows optical filters placed into the light beam of the LS-OK30. The **LS-OK30-FHI** changeable filter inserts carry 50



Dim.	mm / in.	Dim.	mm / in.
А	66 / 2.6	С	70 / 2.8
В	60/2.4	D	185 / 7.4

mm dia filters with up to 2 mm thickness. Filter holder and variable attenuator, which can be combined as

Accessories

well will give a fix attenuation to the effective flux of the lamp given by the distance.





DIMENSIONS MIM					
А	271	С	90		
В	141	D			

	Information	0 0	pecification:
Urgering	Information	~ 5	Decification.
er wering		~ ~	poontoution

oracing mon	ing mornation & Specification.								
Model	Power	Wavelength	Illuminance	Illuminance with	Illuminance with	Life Time	Operation	Operation	No. of
	(W)	Range (nm)	with 150 mm	300 mm dia	500 mm dia	h	Voltage	Current	Fan
			dia sphere	sphere	sphere		V	A	
LS-OK30	No		-	-	-	-	-	-	2
LH-5	5		8.2 klx	2 klx	0.7 klx	4000	12	Inominal	-
LH-10	10		11	2.9	1	4000	12	nominal	-
LH-35	35	380 - 2500	71	17	6.5	4000	12	nominal	-
LH-50	50	000 2000	116	28	10	4000	12	Inominal	-
LH-75	75		183	45	16	4000	12	Inominal	-
LH-90	90		237	58	21	4000	12	nominal	-
LH-10-UV	10		16	4.1	1.5	tbc	12	Inominal	-
LH-50-UV	50	250-2500	143	35	13	1100	12	Inominal	-
LH-100-UV	100		333	81	30	2000	12	Inominal	-
LS-OK30-VA	Variable aperture manual controlled								
LS-OK30-MIR	Variable aperture high resolution drive								
LS-OK30-FH	Filter hol	Filter holder with changeable filter inserts.							
LS-OK30FHI	Filter insert for LS-OK30-FH. Max. filter size 50 mm dia x 2 mm								





Ordering Information & Specification:				
Model	Description			
LS-OK45 *)	External light source for lamps up to 250 W			
LS-OK45-LG *)	Light guide adapter to couple P-9801/CT-3701 luminous color meter to LS-OK45 for color temperature controlled lamp operation for stable emission spectrum			
VAM-45 *)	Remote controlled variable aperture			
FWM-12/2 *)				
HSS-65 *)				
LPS-250	-250 Lamp power supply up to 24V / 250 W			
*) Availability for System set-ups only				

In application were the light output intensity of an uniform light source needs to be controlled or the light has to be spectrally filtered the light source needs to be placed outside of the sphere to allow to place a variable attenuator and/or optical filter between lamp and hollow sphere. The LPS-OK45 offers an unique reflector design which increases the intensity and uniformity of their light output.

Quartz halogen lamps up to 250 W can be used in the LS-OK45. Fans with an effective heat conduction effect a low temperature for long lamp operation time.

The lamp can be adapted direct to UM integrating spheres with the UMPF-LSOK45 port frame.

Additional accessories such as a remote controlled filter wheel, remote controlled variable aperture, remote controlled > 40 ms shutter and a filter holder allow the manipulation of the light intensity and lamp emission spectrum.

In combination with the remote



controlled lamp power supply LPS-250, stepping motor drive SMC-01, light– and color meters, supplied by Gigahertz-Optik, complete remote controlled uniform light sources and standard lamps can be build.

Because of the set-up complexity of high intensity large dynamic range light sources please contact the factory to discuss your need and offer the best possible system solution for your application.

LS-CB: Collimated Beam Light Source



LS-CB18 with UPK-150-F in a set-up for reflectance measurements

Collimated light sources are needed in transmission and reflectance measurements. The LS-CB18 and LS-CB50 are designed with different diameter lenses which allow light beam diameters for small or large di-

LS-CB50

ameter integrating spheres. The LS-CB18 offers a maximum 18 mm / 0,71 inch diameter beam which is useful for integrating spheres up to 200 mm / 8 inch diameter.

The LS-CB50 offers a maximum 50 mm / 2 inch diameter beam

which is useful for integrating spheres up to 500 mm / 20 inch diameter.

The beam diameter of both light sources can be reduced for individual system set-ups.

The precise aperture in combination with the achromatic corrected optics and several stray light baffles ensures a precise light beam without diffraction stray light.

A temperature stabilized reference detector, with beam splitter in the collimated beam offers the possibility of precise light intensity operation in combination with our lamp power supplies.

Please contact the factory or your local representative to discuss your need.

Ordering Info	Ordering Information & Specification:		
Model Description			
LS-CB18 Light source with 18 mm diameter beam for reflectance transmittance measurements			
LS-CB50	Light source with 50 mm diameter beam for reflectance transmittance measurements		
LPS-250 Lamp power supply up to 24V / 250 W. RS232 und RS485 interface			

## Page 120 - Integrating Spheres

#### Accessories



## 🕃 Gigahertz-Optik

LPS-250 Lamp Power Supply



The LPS-250 Lamp Power Supply is specially designed to operate lamps in the power range up to 250 W which are used in uniform light sources, collimated light sources and as calibration standard lamps.

The power supply can be operated in current controlled or light intensity controlled mode. In the light intensity controlled mode a reference detector is needed which can be connected to the signal input at the BNC-socket on the back side.

The LPS-250 offers a 16 bit D/A converter which allows a precise current set-up of 0.3 mA. The current set-up can be manually controlled at the front panel or alternative by the RS232 or

RS485 interface.

For long lamp life time the LPS-250 offers a adjustable ramp function in on and off mode.

All electrical connectors are offered on the back side which makes the LPS-250 useful for rack mount applications.

The stand alone 1/2 19" case of the LPS-250 can be build into the BTH-19/2 1/2 width 19" rackmount housing which accept one LPS-250 case.

The LPS-250 is designed for lamps up to 270 W at 160 to 240 VAC or up to 150 W at 85 to 160 VAC main voltage whereas the LPS-250-A offers 270 W from 100 to 240 VAV and 220 W from 85 to 100 VAC.

Specifications LPS-250 & LPS-250-A					
Output Power LPS-250	Main Voltage 160 VAC to 240 VAC: 270 W, 0 to 15 ADC, max. 26 VDC				
	Main Voltage 85 VAC: 150 W, 0 to 15 A, max. 26 V				
Output Power LPS-250-A	Main Voltage 100 VAC to 240 VAC: 270 W, 0 to 15 ADC, max. 26 VDC				
	Main Voltage 85 VAC: 220 W, 0 to 15 A, max. 26 V				
Resolution of Lamp Current	0.3 mA				
Temperature Stability	+/- 0.3 mA / °K				
Warm-up Stabil- ity	+/- 1 mA (30 minutes after switch on of output current, constant environmental) for 8 hours				
Display	LCD-Graphic Display 97 x 32 Pixel Display Size 14.3 x 35.8 mm LED Backlight (switch on/off) Text Display 4 lines each 14 characters				
Manual Use	3 buttons (enter, menu, up/down, Backlight on/off				
Interface RS232 or RS485: 19200 Bd, 8D, 1S, N					
Main Voltage	85 VAC to 240 VAC (main voltage depending output power!)				
Temperature Range	Operation: 10 to 35 °C Storage: 5 to 50 °C				
Size	3HE, 42TE, Depth 236.5 mm				
Weight 3 kg					
Specifications BT	H-nn				
Size					
Weigt	kg (without LPS-250)				
Color					

Ordering Info	Ordering Information		
LPS-250 Lamp power supply for manual and remote controlled operation.			
LPS-250-A	<b>_PS-250-A</b> Lamp power supply for manual and remote controlled operation.		
BTH-19/2 Bench top housing for one LPS-250 module			
LCRT-2000 Lamp Power Supply			



	Ordering Information		
1	ent temperature instability. One	The LCRT-2000 config	guration is individually set-up based on the application its ordered for!
external d avoid dri	avoid drift effects due to ambi-	Dimension	185 x 80 x 175 / 7.3 x 3.2 x 6.9 in (width x height x depth)
	external detectors at +40 °C to		Fan (12 V DC)
	ctor). The LCRT-2000 allows mperature stabilization of four	Output signals	4 x heating output for external detectors (ea. 2 W)
	mode (requires à relefence de-		hamp function (ca 40 sec.)

#### SMC-01 Stepping Motor Controller

Specification:				
Main Voltage	230 VAC +/- 10 %, 50 to 60 Hz			
	120 VAC +/- 10 %, 50 to 60 Hz			
Interface	RS 485 or RS 232			
Output Channels	4			
Max. Current	1500 mA per Channel			
Motor Type	2-Phase Stepping Motor (bi polar)			
Interface Type Motor	RJ45			
Size	3 HE,42 TE, Depth 236.5 mm			
Weight	3 kg			
Temperature	Operation: 10 to 35 °C			
	Storage: 5 to 50 °C			
Specifications BTH-19/2				
Size				
Weight				
Color				



The Stepping Motor Controller SMC-01 offers remote controlled operation of up to four 2-phase stepping motors. Its specially designed to operate the filter wheel FWM-12/2 and the variable aperture VAM-45. Together with the Lamp Power Supply LPS-250 and Optometer P-2000 or P-9801 the SMC-01 is the right tool to set up fully remote controlled uniform light sources.

Beside that application the SMC-01 can be used for custom setups with linear and rotary stages. Special features of the SMC-01 are:

- micro steping
- automatic ramp function with program able parameters
- user specified ramp parameter
- RS 485 or RS 232 interface

Because of the custom design status of such set-ups please contact the factory to discuss your need and offer the best possible system solution for your application.

Ordering Information		
SMC-01 Four channel stepping motor controller in 1/2 19".		
BTH-19/2 Bench top housing for one LPS-250 module		

## Page 122 - Integrating Spheres

## **Custom Design Sphere Systems**

Gigahertz-Optik offers full custom design for application setups based on integrating spheres.

This service includes:

- Integrating spheres in custom design configuration
- OEM design integrating spheres
- Uniform light source set-ups manually controlled
- Uniform light source set-ups remote controlled
- Luminous Flux measurement systems for lamps
- Radiant Power measurement systems for lamps
- Luminous Flux measurement systems for LEDs, back-light
   panels. displays
- Luminance Standards
- Spectral Radiant Standards
- CIE conform Light Transmission measurement systems
- CIE conform Light Reflec-



Custom Luminous Flux & UV-A Radiant Power Measurement System



Custom Integrating Sphere with OP.DI.MA. Coating





Custom Luminous Flux, UV-A Radiant Power & Luminance Measurement System



Custom Light Transmittance Measurement System for Large Size Windows



tance measurement systems Your request

## 🖲 Gigahertz-Optik

#### Essentials of Reflection & Table of Contents

#### **Essentials of Reflection**

Reflection describes the redirection of optical radiation when it reaches a boundary between two different media. A basic distinction is drawn between diffuse and specular reflection.

In diffuse reflection, the reflection of directional incoming radiation flux is scattered in many directions. This is caused by roughness at the boundary surface where the roughness is of the same order of magnitude as the wavelength. Lambert's cosine law applies, to a good approximation, to perfectly diffusing surfaces. This law states that the radiant intensity / at the emission angle e of a perfectly diffusing surface A of radiance L has a magnitude given by  $I = L A \cos \theta$ e. It follows that the radiance of a Lambert surface is the same in all directions. Such a completely matte, white material scatters evenly in all directions, reflecting (transmitting) the radiation independently of the angle, and has a reflection factor (transmission factor) with the value 1. Directed or specular reflection

results when the roughness of the boundary is small in comparison with the wavelength of the reflected radiation. According to the law of reflection which applies in this case, the angle of the incident and reflected rays form the same angle with the normal in reference to the reflecting surface at the point of incidence. The angle  $\alpha$  is known as the angle of incidence, and the angle  $\alpha'$  is known as the angle of reflection.

Reflectance describes the relationship of the reflected radiation power (luminous flux) to the incident radiation power (luminous flux). When the reflectance is the same for all wavelengths this is known as *nonselective reflectance*. If the reflectance of a boundary surface depends primarily on the wavelength, or if reflection only takes place at in a very narrow range of wavelengths, the reflectance is selective.

Diffuse Reflecting Surfaces are required in applications where light needs to be nearly



Ideal diffuse reflection (Lambertian surface)

perfectly diffusely reflected independent of its incident angle to the surface. Typical applications are:

- Integrating spheres used for luminous flux and radiant power measurements
- Integrating spheres used for uniform light sources
- Diffuse reflectance standards for uniformity calibration of imaging sensors
- Diffuse reflectance standards for reflectance measuring systems
- Calibration standards for light based remote control systems



Diffuse reflection with directional component

- Calibration standards for optical distance sensors
- Large area reflectors for uniform back lighting
- Projection screens

Standard forms and sizes are available as described in this chapter. Gigahertz-Optik also offers full custom service for machined parts and surface coatings.

Table of Contents						Page
Model	Туре	Wavelength	Reflectance	Si	ze	Specifica-
		Range	%	mm	inch	tion
ODM: Optical Diffu	se Material (OP.DI.MA	.)				
OP.DI.MA. Optical	Diffuse Material: Gen	eral Description a	nd Specifications			124-126
ODM98-B01				200 x 200 x 200	7.8 x 7.8 x 7.8	
ODM98-B02				120 x 120 x 250	4.7 x 4.7 x 9.8	
ODM98-B03				120 x 120 x 120	4.7 x 4.7 x 4.7	
ODM98-B04				65 x 65 x 500	2.5 x 2.5 x 19.6	126-127
ODM98-B05			98 @ 555 nm	65 x 65 x 245	2.5 x 2.5 x 9.6	
ODM98-B06		250-2500 nm		65 x 65 x 120	2.5 x 2.5 x 4.7	
ODM98-B07	Raw Block Material			170 dia x 190	6.6 dia x 7.4	
ODM98-B08				76 x 76 x 250	2.9 x 2.9 x 9.8	
ODM50-B11			50 @ 555 nm	65 x 65 x 150	2.5 x 2.5 x 5.9	
ODM03-B11			3 @ 555 nm	65 x 65 x 150	2.5 x 2.5 x 5.9	
ODM98-B13			98 @ 555 nm	52 dia x 250	2.0 dia x 9.8	
ODM98-P01				520 x 260 x 12	20.4 x 10.2 x 0.47	
ODM98-P02				310 x 310 x 12	12.2 x 12.2 x 0.47	
ODM98-P03	Raw Plate Material	250-2500 nm	98 @ 555 nm	260 x 260 x 12	10.2 x 10.2 x 0.47	1
ODM98-P04		200 2000 1111		135 x 135 x 12	5.3 x 5.3 x 0.47	-
ODM98-P05				55 x 55 x 12	2.1 x 2.1 x 0.47	
ODMxx-P01	Raw Plate Material	250-2500 nm	xx @ 555 nm	520 x 260 x 12	20.4 x 10.2 x 0.47	1
ODMxx-P02	gray scaled		Availability on request	310 x 310 x 12	12.2 x 12.2 x 0.47	]

## Page 124 - Diffuse Reflectors

Cigahertz-Optik

## Table of Contents / OP.DI.MA. Optical Diffuse Material

Table of Contents	3					Page			
Model	Туре	Wavelength	Reflectance	Si	ze	Specifi-			
		Range	%	mm	inch	cation			
ODM: Optical Diff	use Material (OP.DI.MA	.)							
ODMxx-P03			xx @ 555 nm	260 x 260 x 12	10.2 x 10.2 x 0.47				
ODMxx-P04	Raw Plate Material	050 0500 mm	Availability	135 x 135 x 12	5.3 x 5.3 x 0.47	126-127			
ODMxx-P05	gray scaled	250-2500 nm	on request	55 x 55 x 12	2.1 x 2.1 x 0.47				
ODM98-F01			95 @ 555 nm	1.5 x 300 x 1000	0.059 x 11.8 x 39				
ODM98-F02	Raw Foil Material	250-2500 nm	75 @ 555 nm	0.2 x 105 x 1000	0.007 x 4.1 x 39	127			
ODM98-F03	_		90 @ 555 nm	0.5 x 105 x 1000	0.02 x 4.1 x 39				
ODM98-MP01				50.8 x 50.8 x 10.5	2.0 x 2.0 x 0.41				
ODM98-MP02	_	250-2500 nm		100 x 100 x 10.5	3.9 x 3.9 x 0.41				
ODM98-MP03	Machined Plate		98 @ 555 nm	200 x 200 x 10.5	7.8 x 7.8 x 0.41	127-128			
ODM98-MP04	Machined Flate			300 x 300 x 10.5	11.8 x 11.8 x 041				
ODM98-MD01				31.7 dia x 10.5	1.25 x 0.41				
ODM98-MD02				50.8 dia x 10.5	2 x 0.41	1			
ODP97: Optical D	oiffuse Paint		1		1	1			
ODP97-1.0	White Diffuse Coating	300-2400 nm	97 @ 555 nm	11b	ottle				
ODP-LS		Hig	h viscosity sprayer for	ODP-97					
ODP-RSB		S	pare Part Bottle for OI	DP-LS		129-130			
ODP-RSP	Pressure Unit for ODP-LS								
ODG95: Optical D	)iffuse Gold								
ODG95	Gold Coating	1 µm to 20 µm	95	Coating	Service	130			

#### **General Description**

reflection.

A side effect of volume reflection is a variation in transit times of the reflected radiation within the material eliminating constant differences in phase and therefore the speckling effect associated with coherent radiation.

In pure form, 10 mm thick OP.DI.MA. exhibits a reflectance of up to 98.5% in the visible spectrum and a minimum reflectance of 93% within the wavelength range from 250 nm to 2.5  $\mu$ m. Additives allow a reduced graduation in reflectance from 98.5% to 2 %.

OP.DI.MA. include a maximum operating temperature of up to 280° C, insolubility in water and resistance to UV degradation. The surface of the material can be re-machined and cleaned prolonging its operational life. Careful selection of the base material and execution of the manufacturing process inhibit the occurrence of fluorescent effects.

Of course, these outstanding properties are accompanied by some limitations: the material can only be manufactured in block form. This generally necessitates performing cutting operations to shape the material to the desired form. As a volume reflector, the reflection factor depends on the material thickness. The material can not be applied as a coating so successful use of ODM requires correct implementation and processing strategy.

This chapter provides assistance for the proper application of ODM.

Please contact the factory for personalized service.

OP.DI.MA. is a plastic material which works as a volume reflector. This means that radiation

reflects from many boundaries within the material itself. This results in a nearly perfect diffuse

#### **OP.DI.MA. Optical Diffuse Material**

#### Specifications

**OP.DI.MA. Reflectance - 10 mm thick** 

ODM98 is OP.DI.MA. in its purest form offering the highest possible reflectance.

A reflectance of 98% +/- 1% is specified in the visible wavelength range from 400 to 800 nm, whereas a minimum reflectance of 93 % is specified within the entire useful wavelength range from 250 nm to  $2.5 \,\mu$ m. Level and quality of reflectance depends on material properties, surface conditions and thickness. Any mechanical abrasion of the surface may result in specular reflections. Also, penetration by volatile substances alters ODM98's reflective behavior. The adverse optical effects caused by surfaces soiled from grease (fingerprints) or oil are similar to those of other optical components. If the surface cannot be cleaned using distilled water (without pressure), material must be removed. After cleaning with water or if it is suspected that liquids have been absorbed into the material, the plastic must be baked.

ODMxx Gray Scale OP.DI.MA. (xx = reflectance value) is produced by using an appropriate additive in different quantities. Reflectance values down to a minimum of 2% are possible. Gigahertz-Optik offers gray-scale OP.DI.MA. from deep black

Light is partially reflected within the material itself. As a result, a minimum thickness of 10 mm is recommended to obtain the optimum reflectance as specified.

A 10 mm minimum thickness is also recommended for all types of reflectance standards. In some applications OP.DI.MA.

less than 10 mm thick is required. Examples are:

· Replacement of printed cardboard reflectance standards

1,15

1,10

1,05

1,00

0.95

250

variation in reflectance

- Knife-edge integrating sphere port design
- Large size reflectors
- Diffuser windows

a is a volume reflector, As OP.DI.MA. reflectance decreases with thickness.

But since about 70% of the reflectance in the visible spectrum is accomplished within the first few hundred micrometers of the material, the slight reduction acceptable for many is applications.

1

2

3 4

5



(ODM03) to brilliant white sizes supplied on request. (ODM98). Available shapes and



OP.DI.MA. spectral reflectance as a function of thickness

#### **Ageing Characteristics**

The anti-ageing characteristic of OP.DI.MA. is one deciding criteria for its selection above other materials in many applications. Its fundamental long term stability results from the basic material itself, in association with a careful manufacturing process employing ISO 9001 certified Quality Management, and has no real limitations. Quantitative data on UV resistance is only provisional, because of the many factors which actively influence practical applications. One test, as shown in the adjacent graph, shows an

ageing test on an OP.DI.MA. reflection standard with a 420 W halogen-metal vapor lamp operating in the 250 to 400 nm wavelength range. Field reports involving applications using highpowered pump chambers, excimer lasers and on-line fluorescence sensors confirm minimal ageing under exposure to UV. Other factors of a proprietary nature involving material handling are also responsible for the good ageing characteristics.

Typical changes in reflectance resulting from UV radiation with a 420 W halogen-metal vapour lamp ((ULTRATECH 400/OSRAM). (1) = Beginning of measurement, 2) = 15 min, 3) = 2 hrs. 4) = 5 hrs., 5) = 7 hrs.. After about 100 hours of ageing the characteristic output was approximately reached. This result agrees with the research results from the NPL (UK) for this kind of material.

400

The maximum permissible radiation flux density for OP.DI.MA. can, like many other parameters, only be described through particular examples.

300

In a series of tests an ODM reflection standard was exposed to pulsed laser radiation. The wavelength of the laser was 1064 nm, the focus diameter 200  $\mu$ m, the

350

Wellenlänge ( nm )

pulse length 200  $\mu$ s, the repetition rate 25 Hz and the mean power was 21 W. The peak power of 4.2 kW resulting from this, representing a radiation flux

density of 13.3 GW/m<sup>2</sup> did not yield any detectable alterations. Surface impurities were removed by the laser itself at the start of the test series

Maximum Permissible Radiation Flux Density

## **OP.DI.MA. Optical Diffuse Material**

#### **Temperature Behavior**



Typical change in spectral reflectance vs. temperature. The spectral reflection factor at 25° C is represented by the reference line.

#### **ODM - Optical Diffuse Material**

Machining OP.DI.MA. is not perience with processing plas- difficult for those with some ex- tics. All machining methods such milling, etc., are possible. Block is presented later in this chapter.	Cleaning		
	0	1 91	 1 0

OP.DI.MA. is chemically inert, and is stable against acids, bases and other organic solvents. A special manufacturing process also gives it high mechanical stability. These properties mean that dust, for instance, can be removed with paper tis-

sues (lint-free, no pressure). Other impurities can be removed with water/alcohol mixtures or with methylene chloride or hexane (hexane is appropriate for organic impurities). When cleaning with solvents, these penetrate into the micro-porous

(amorphous) structure of the plastic. After cleaning, which can, for instance, be carried out using solvent-soaked paper tissues, the plastic must be "baked" at a temperature near the solvent's boiling point. Scratches and "polished" areas

OP.DI.MA. is capable of operat-

ing in high temperatures up to

280° C. This allows the material

to be used in intense applica-

tions environments. Investiga-

tions of the reflection factor de-

pendency on the operating tem-

perature indicate that it is highly

The adjacent graph shows that

the reflection factor during tem-

perature cycles from room temperature up to +100° C remains

stable. In fact the measured

deviation was within the repeti-

tion accuracy of the experimental

set-up used. Using temperature

cycles up to +170° C the sec-

stable

which diminish the reflective properties can be removed by removing the top layer with finegrained abrasive paper. It is recommended that calibrated reflection standards be recalibrated after cleaning.

#### Specifications

ODM98	DM98					Reflectance				
Density	g/cm <sup>3</sup>	1.5	Material	Reflectance	400-800 nm	250-2500 nm				
Hardness	ness Shore D 30-40			% © 555 pm						
Max. Operating Temp.	°C	280	1	@ 555 nm						
Coefficient of Thermal Expansion		75-150 *10 <sup>-6</sup>	ODM98	98	98 % +/- 1 %	min. 93 %				
Thermal Conductivity	kcal/mh°C	0.2	ODM70	70	70 % +/- 5 %	-				
Resistivity (DIN 53482)	$\Omega$ cm	10 <sup>16</sup>	ODM50	50	50 % +/- 5 %	-				
Water Solubility*	32011	insoluble	ODM25	25	25 % +/- 5 %	-				
,			ODM03	3	3 % +/- 1.5 %	-				
Resistance to Chemicals		high**		_	- ,, ,-					

\*Material is porous, reflectance properties will change with absorption of liquids \*\*A list of materials which OP.DI.MA. is resistant to is available

#### ODM-B & ODM-P: Raw Block and Raw Plate Material



OP.DI.MA. is produced in raw blocks and raw plates.

Gigahertz-Optik or "do-it-yourself" customers can manufacture the desired end product by machining these blocks and plates. For fast lead times on small quantities. Gigahertz-Optik keeps various standard sizes in stock

Along with the ODM98 high reflectance grade material a smaller selection of ODM gray scale raw stock is available. Subject to a minimum batch

size, other block dimensions can be produced on custom order. This allows block dimensions to be more appropriately adapted to the dimensions of the end product, thus reducing waste.

Please contact our technical sales department to discuss your application requirements.

ond diagram shows a constant

change in the reflection factor of

about 1%. Thus it is recom-

mended for applications involv-

ing high operating temperatures

that the material be subjected to

an appropriate stabilization proc-

Of course, at very high tempera-

tures, the mechanical stability of

all plastics must be considered.

ess.

## Diffuse Reflectors - Page 127

#### **OP.DI.MA. Optical Diffuse Material**

Ordering Infor	mation & Specifications							
Raw	Block Material	Raw	Plate Material	Reflectance				
Model	min. Dimension (mm)	Model	Dimension (mm)	@ 555 nm	400-800 nm	250-2500 nm		
ODM98-B01	200 x 200 x 200	ODM98-P01	520 x 260 x 12					
ODM98-B02	120 x 120 x 250	ODM98-P02	310 x 310 x 12					
ODM98-B03	120 x 120 x 120	ODM98-P03	260 x 260 x 12					
ODM98-B04	65 x 65 x 500	ODM98-P04	135 x 135 x 12	98	98 +/- 1 %	min. 93 %		
ODM98-B05	65 x 65 x 245	ODM98-P05	55 x 55 x 12					
ODM98-B06	65 x 65 x 120							
ODM98-B07	170 dia. x 190							
ODM98-B08	76 x 76 x 250							
ODM98-B13	52 dia. X 250							
ODMxx-B11	65 x 65 x 150	ODMxx-P01	520 x 260 x 12		Typical Values	-		
		ODMxx-P02	310 x 310 x 12		70.0/ . / . 5.0/	-		
		ODMxx-P03	260 x 260 x 12	*)	70 % +/- 5 % 50 % +/- 5 %	-		
		ODMxx-P04	135 x 135 x 12	,	25 % +/- 5 %	-		
		ODMxx-P05	55 x 55 x 12		3 % +/- 1.5 %	-		

\*) available in different gray scale reflectance values. Please contact the factory for stock status

In addition to its high reflectance and its diffuse reflectance characteristic, a further advantage of OP.DI.MA. is the high level of uniformity of these parameters. This makes it an appropriate material for the construction of large-area diffuse reflectors. A few examples of the many applications of this type are white-comparison standards in opto-electronic scanner systems, projection screens in large viewing angle applications, and white standards for image processing systems. The differing reflecting ray transit times associated with a volumediffusing material reduces laser speckling effects.

Gigahertz-Optik offers OP.DI.MA. foil sheets with a material thickness of 1.5 mm which can be bonded to a substrate. The example application shown is a projection screen about 3 m x 4 m in size.

Another application for these sheets is coating the inner surfaces of large diameter integrating spheres (Ulbrichtsche Kugel).

To learn more about ODM, please contact our technical sales department who will be happy to personally advise you.



#### **Ordering Information and Specifications**

	· · · · · · · · · · · · · · · · · · ·										
Model	<b>Basic Material</b>		Dimensions		Reflectance						
		Thickness (mm)	Width (mm)	Length (m)	Wavelength	@ 555 nm					
ODM98-F01	ODM98	ca. 1.5 +/- 0.1	300			95 %					
ODM98-F02		ca. 0.2 +/- 0.05	105	In Rolls of min. 1 meter	250-2500 nm	75 %					
ODM98-F03		ca. 0.5 +/- 0.1	105			90 %					

OP.DI.MA. is used in many applications as a reflectance standard because of its diffuse, spectrally flat, reflective properties.

Gigahertz-Optik carries various sizes and shapes with one side in high quality optical finish as standard components

Besides standard sizes with fast lead time based on small quantities, custom sizes and thick nesses are available on request. All plates can be supplied with

10 mm thick reflectance plates and disks

an adhesive backing. Absolute spectral reflectance calibration

2 mm thick reflectance standards with adhesive backing for fast and easy surface mounting

#### **Machined Reflectance Plates**



#### **Raw Foil Material**

## **OP.DI.MA. Optical Diffuse Material**

١	Circhanta	Ontil
1	Gigahertz	-Oplik

#### **Ordering Information and Specifications** Model Dimension **Reflectance %** Size (mm) Thickness (mm) **Optical Finish** 400-800 nm 250-2500 nm **ODM98-MP01** 50 x 50 +/- 0.2 **ODM98-MP02** 100 x 100 +/- 0.2 10.5 + 0/-1 1 side 98+/-1 % min 93 % **ODM98-MP03** 200 x 200 +/- 0.2 ODM98-MP04 300 x 300 +/- 0.2 ODM98-MD01 31.7 dia. +0/-0.1 (back side faced 0.3/45 deg.) ODM98-MD02 50.8 dia. +0/-0.1 (back side faced 0.3/45 deg.)

#### **Custom Service**

Besides standard parts and machined components Gigahertz-Optik will custom design and machine OP.DI.MA. accord-

#### **Gigahertz-Optik Custom Services**

#### Formed ODM:

The OP.DI.MA. manufacturing process does not permit molding of complex parts, but larger size parts in simple shapes such as hemispheres can be formed saving extra material costs.

# and form.

Self-Adhesive: Gigahertz-Optik offers OP.DI.MA. reflectance plates with an adhesive backing for fast and simple mounting especially for thin plates.

ing to customer specifications

starting with the most suitable

and cost effective raw stock size

Machining processes include simple cutting of plates to size as well as full CNC machining in

ODM Foil Cutting Service:

effective sheet cutting service.

ODM Plate Shape Cutting:

chined plates.

Gigahertz-Optik offers a cost

Gigahertz-Optik offers precision

shape cutting services for ma-

single and O.E.M. quantities. Please contact the factory for help in the selection of the most cost effective process for your

#### **ODM Block Machining:**

In-house full custom machining service including drilling, milling and lathe work operations are available.

CNC processing to customer design drawings or CAD drawings made by Gigahertz-Optik to customer specifications is offered.





#### **OP.DI.MA. Integrating Spheres**

Gigahertz-Optik manufactures a wide range of OP.DI.MA. integrating spheres.

OP.DI.MA. offers substantial improvements over barium sulfate coatings:

- Improved diffuse multiple internal reflections for better uniformity
- Higher operating temperature for high power light measurements
- Higher reflectance for high intensity uniform light sources
- More rugged coating characteristic
- High UV reflectance

Please refer to catalog section 'Integrating Spheres' and 'Calibration Standards & Uniform Light Sources' for more details.



#### UMBK Series:

Cost effective integrating spheres using spun aluminum housings. Sphere diameters from 7.5 to 18 inch (190 to 460 mm). Contact our sales engineers to discuss custom sizes and design services.



#### UPK Series:

Precision CNC machined Al housing integrating spheres with high tolerance multiple port layouts. Sphere diameters from 0.3 to 10 inch (8 to 254 mm). Contact our sales engineers to discuss custom sizes and design services.



#### Application Service:

Gigahertz-Optik offers uniform light sources, luminance and spectral radiance standards as well as light intensity (laser power, radiant power, luminous flux) measurement systems based on the UMBK and UPK series integrating spheres. Contact us for personal assistance. **BN-Rxx-D Series:** 

2 inch (50.8 mm) diameter spec-

tral reflectance standards are

available with and without 8/D

hemispherical reflectance

calibration certificate

## **OP.DI.MA. Optical Diffuse Material / ODP Optical Diffuse Paint**

#### **OP.DI.MA. Reflectance Standards**

#### **Reflection Standards:**

Gigahertz-Optik offers reflectance standards made from machined OP.DI.MA. in different shapes and sizes.

Standards are supplied in housings with a removable cap for safe storage. NIST and NRC traceable calibration service for spectral reflectance from 250 to 2500 nm is available.

Refer to the 'Calibration Standards' section for more details.

#### **ODP97: Optical Diffuse Paint**

#### **General Description**

structions concerning surface preparation and coating procedure are included.

A ODP97 repair kit is available which includes a glass bottle and air pressure unit for coating of small surface areas and accessories.

Gigahertz-Optik offers a full custom coating service. Custom paint for rugged applications or gray scale additives for photometric applications are also available on request.

Please contact the factory to discuss your project.

**ODP97 Optical Diffuse Paint** 



**BN-Rxx-SQ Series:** 

Reflectance standards from 2 x 2

to 18 x 18 inch ( 50 x 50 to 457 x

457 mm) are available with and

without 8/D hemispherical reflec-

tance calibration certificate

ODP97 is a white diffuse reflecting mixture used for coating integrating spheres, sphere components, large size panels and irregular surfaces.

The coating is based on pure barium sulfate and supplied in a proprietary solution including a binder. The binder is needed for good adhesion of the coating to the applied surface. Binder concentration is kept low to avoid any optical effect.

The paint is ready for instant application as supplied. 4 to 8 coats are needed to get the best diffuse and high reflectance. In-

# Ordering Information & SpecificationsModelDescriptionReflectanceODP97-1.0ODP97 in 1000 ml bottle400-800 nm~ 97 %500 ml covers about 200 square inches / 1200 cm²

ODP97 exhibits a typical reflectance of 97 % in the visible spectral range with a useable range specified from 300 nm to 2400 nm. The mixture is supplied ready for instant and non-toxic application.

Gigahertz-Optik's proprietary barium sulfate solution can be shipped anywhere without special permits and comes in 1000 ml plastic bottles.



#### **ODP97-RS High Viscosity Laboratory Sprayer**

 Ordering Information & Specifications

 Model
 Description

 ODP97-LS
 High Viscosity Laboratory Sprayer. 1 pc. bottle and 1 pc. pressure unit

 ODP-RSB
 1 pc. 90 ml bottle

 ODP-RSP
 1 pc. pressure unit

The ODP97-RS laboratory spray bottle can be used for service purposes or for coating small components.

The complete unit includes one 90 ml bottle and one pressure unit for applying ODM97 coating or other high viscosity fluids.



## ODP Optical Diffuse Paint / ODG95 Optical Diffuse Gold

#### **Custom Coating Service**



Custom coating services for new components as well as recoating service of Gigahertz-Optik or other manufacturer's products is available. The service is offered for single units as well as for O.E.M. quantities.

Please contact the factory to discuss the most economic

set-ups. Accurate reflection and

transmittance measurement

applications require the higher tolerances of the precision

#### Integrating Spheres with Barium Sulfate Coating

Gigahertz-Optik manufactures a wide range of ODP97 barium sulfate coated integrating spheres.

Barium sulfate offers an economical coating solution, especially for larger diameter spheres.

The **UMBB** sphere line represents one of the most flexible and cost effective design concepts for individual sphere

#### ODG95: Optical Diffuse Gold

machined **UPB sphere line.** Please refer to sections 'Integrating Spheres' and 'Calibration Standards & Uniform Light Sources' for more information.

100

eflectance (%

coating service for your particular application requirements.







80 -60 -40 -20 -0 -250 1300 2350 3400 4450 6000 8100 10200 12750 18000 w avelength ( nm )

**ODG95** is an uncoated gold which outperforms all other uncoated metallic reflectors at infrared wavelengths. Gold's high reflectivity in the red portion of the visible spectrum is apparent by it's yellow hue.

With its ~ 95 % high reflectivity in the wavelength range from 1  $\mu$ m to 20  $\mu$ m, gold is the best choice for surface coating of integrating spheres and reflectance stan-

#### Integrating Spheres with Gold Coating

ODG95 gold coated integrating spheres are designed for applications in the infrared spectral range.

The **UMBG sphere line** represents one of the most flexible and cost effective design concepts for individual sphere setups. Accurate reflection and transmittance measurement application require the higher tolerances of the precision machined **UPG sphere line**. result of a proprietary precoating surface preparation. Gigahertz-Optik supplies both

dards in IR applications. Its

highly diffuse reflectivity is a

gold coated integrating spheres and reflectance standards. Please check sections 'Integrating Spheres' and 'Calibration Standards & Uniform Light Sources' for more information. Standard products and custom design components are offered.





#### Table of Contents

Calibration standards are employed in determining the correlation between an input and an output quantity for all types of

measurement instrumentation. By supplying a signal of known quantity, the difference between the output signal of the test device and the calibration standard can be evaluated. From these differences calibration correction factors can be calculated allowing adjustment of the test device for absolute readings. Transfer standards are used to transfer the values of the primary standard, often certified by a national calibration laboratory, to the secondary calibration facility. This fulfills the traceability requirement for an unbroken chain of transfer comparisons back to the national primary standard.

**Calibration uncertainty** depends on the calibration hierarchy of the standards employed

and the technically competency of the calibration laboratory (see Calibration Chapter).

Proper care and use of the calibration standards is critical to long term success in the calibration transfer method.

#### Photometric and radiometric light measurement applications involve many different measurement quantities such as:

Illuminance / Irradiance

- Luminance / Radiance
- Luminous Flux /Radiant Power
- Luminous Intensity / Radiant Intensity

Each quantity requires its own calibration standard.

For optical radiation calibration of light detectors calibration standards in the form of light detectors are used. Calibration is accomplished using the transfer method described previously. Absolute sensitivity is confirmed in a calibration certificate that includes other descriptive and procedural information.

A typical example of a detector based calibration is the spectral sensitivity calibration of photodiodes employing a tunable monochromatic light source with its output compared to the known spectral sensitivity of a standard detector.

For the calibration of light sources calibration standards in the form of light sources are used. Here reference standard light sources are used to calibrate the light measurement system which in turn is used to calibrate the unknown light source.

This method is used for the cali-

## General Information

bration of spectral radiometers with a spectral irradiance standard source for example.

In imaging applications the uniformity in sensitivity of the imaging detection system is very important. Light sources with a uniform light emitting area are needed as reference standards in this type of calibration to determine the non-uniformity of a lens system or imaging detection system. **Uniform light sources** built around integrating spheres are the best known solution for setting up uniform light sources.

Gigahertz-Optik offers a wide selection of calibration standards and uniform light sources.

For the measurement quantities of spectral sensitivity and spectral irradiance Gigahertz-Optik's calibration laboratory is ISO EN 17025 accredited.

#### **Table of Contents**

			Light So	ources		
Model	Transfer Unit	Unit	Spectral Range nm	Lamp Power Reflectance	Comments	Spec. Page
BN-LH250	Spectral Irradiance	W/m² nm	250-2500	250 W	QH Lamp, Horizontal Emitting Axis	132
BN-9101	Spectral Irradiance	W/m² nm	250-2500	1000 W	QH Lamp, Horizontal Emitting Axis	133
BN-0001	Spectral Irradiance	W/m² nm	250-2500	1000 W	QH Lamp, Vertical Emitting Axis	133
BN-0104	Spectral Radiant Power & Luminance	W/nm Im	350-1100 380-780	100 W	QH Lamp, Post Mounted for use in 500 mm Diameter Integrating Sphere	134
BN-0102	Spectral Radiance	W/(m²sr) nm	380-1100	10 W	50 mm OP.DI.MA. Sphere with 20 mm Port	135
BN-ULS-K190			300-2500	≤ 100 W	190 mm OP.DI.MA. Sphere with 75 mm Port	138
BN-ULS-M150		W/(m² sr) nm	350-2400	≤ 100 W	Integrating Sphere Based Uniform Light	136 - 137
BN-ULS-M300	<ul> <li>Spectral Radiance</li> <li>Luminance</li> </ul>	cd/m <sup>2</sup>	350-2400	≤ 300 W	Sources with BaSO₄ or OP.DI.MA. Coating. Different Sphere Diameters with Custom	136 - 137
BN-ULS-M500	Uniformity	%	350-2400	≤ 500 W	Specified Light Emitting Ports, Internal and	136 - 137
BN-ULS-M1000	Childhing		350-2400	≤ 1000 W	External Light Sources, Reference Light De- tectors, Variable Apertures & accys.	136 - 137
BN-ULS-M1700			350-2400	≤ 2000 W	lectors, valiable Apertures & accys.	136 - 137
		L	Light De	tectors		
BN-DSR-100	Spectral Radiant Power Sensitivity	A/W nm	200-1100	-	Large Size Si Photodiode	139
BN-DSI-33	Spectral Irradiance Sensitivity	A/(W/m²) nm	250-1100	-	Photodiode with 11 mm Diameter Diffuser Window	139
			Reflectance	e Plates		
BN-Rxx-D2	Spectral Reflectance	% @ nm	250-2500	3, 50 & 98 %	2 in Diameter. xx = Reflectance	140
BN-R98-SQ50	Spectral Reflectance	% @ nm	250-2500	98 %	50 mm Square. $xx =$ Reflectance	140
BN-R98-SQ100	Spectral Reflectance	% @ nm	250-2500	98 %	100 mm Square. xx = Reflectance	140
BN-R98-SQ200	Spectral Reflectance	% @ nm	250-2500	98 %	200 mm Square. xx = Reflectance	140
BN-R98-SQ300	Spectral Reflectance	% @ nm	250-2500	98 %	300 mm Square. xx = Reflectance	140
BN-Rxx-SQ5	Spectral Reflectance	% @ nm	250-2500	3, 50 & 98 %	5 in / 127 mm Square. xx = Reflectance	140
BN-Rxx-SQ12	Spectral Reflectance	% @ nm	250-2500	3, 50 & 98 %	12 in / 304 mm Square. xx = Reflectance	140
BN-Rxx-SQ18	Spectral Reflectance	% @ nm	250-2500	3, 50 & 98 %	18 in / 457 mm Square. xx = Reflectance	140

**Spectral Irradiance** 

#### BN-LH250: 250 W Spectral Irradiance Standard Lamp



The **BN-LH250** spectral irradiance standard lamp is a precise transfer standard for spectral irradiance in the wavelength range from 250 to 2500 nm.

The lamp standard consists of a carefully selected 250 W tungsten halogen lamp with a diffuse quartz envelope and stable filament mounted into a ceramic lamp base to help with temperature equalization. The lamp base allows free standing and post mounted operation. The two banana sockets provided to supply power to the lamp are mounted so that they are shielded from light and heat irradiation by the lamp.

The **BN-LH250-BC** is qualified as a reference transfer standard. The BC version of the BN-LH250 undergoes a burn-in procedure where the lamp current, operating voltage and irradiance are documented during burn-in. The Gigahertz-Optik calibration engi-

Transferral One as March and a small One leader to be former at

neers evaluate this data to decide if the lamp qualifies for use as a reference standard lamp. If the lamp qualifies a burn-in certificate that includes this data is issued.

Calibration of spectral irradiance is done using a doublemonochromator spectral radiometer at a distance of 50 cm to the reference plane of the standard lamp. Description and specifications for this KLW-S1 spectral irradiance calibration procedure is listed in the *Calibration Service* chapter.

A BHO-10 carrying case is a required component for all BN-LH250 standard lamp deliveries.

To power the BN-LH250 and BN-LH250-BC lamps Gigahertz-Optik recommends the LPS-250 lamp power supply which is specially designed for the operation of light emitting standards.



Typical Spectral Irradiance at 3100 K

#### LPS-250 Power Supply



LPS-250 in Bench-Top Housing BTH-19/2

The LPS-250 lamp power supply is specially designed for stable operation of lamps. It offers a maximum operating voltage of 26 V and a maximum lamp current of 15 A.

A high resolution 16 bit digital to analog converter provides a high level of lamp current control with a resolution of 0.3 mA at the nominal current of 15 A. The current stability is specified at  $0.1x10^4$  A at the nominal current within 8 hours. An on/off ramp function prevents lamp filament shock during the on/off procedure. The RS232 or RS488 interface enables full remote control operation. In the manual control mode an alphanumerical four line display shows the set-up parameters. Manual set-up is accomplished via menu selection.

The power supply is offered in a 1/2-19" housing which allows rack-mounting. For laboratory use an optional bench top housing is offered. Full specifications are listed in the *Integrating Spheres* section.

Model	cations and Ordering Information:				Spectral Irradiance at 50 cm in mW/(m <sup>2</sup> nm)										
Model	Туре	Power	Voltage	Current	250 nm	1100 nm	1800 nm	Distance							
			@ 3100 K												
BN-LH250	<b>250</b> Halogen Lamp 250 W ~ 24 V 10.5 A 1.19 E-07					5.93 E+1	2.35 E+01	50							
BN-LH250-BC	Halogen Lamp with Burn-in Certificate														
BHO-10	Hard case for up to 3 of BN-LH250. Req	uired part fo	or either BN	I-LH250 or	rder.										
BPC-2	Banana-plug cable with 2 m length. Avail	ilable in red	, blue and	olack colo	r										
LPS-250	Precise current controlled power supply.	Current rar	np functior	n. RS232 o	r RS488 interfa	ace. 230 V / 50	Hz								
LPS-250A	Precise current controlled power supply.	Current rar	np functior	n. RS232 o	r RS488 interfa	ace. 100 to 230	V / 50 to 60 Hz	Z							
BTH—19/2	1/2 19" width bench top housing for LPS	S-250 and L	PS-250A												
KLW-S1	Calibration of spectral Irradiance														

#### Spectral Irradiance

#### BN-9101 & BN-0001: 1000W Spectral Irradiance Standard Lamps

BN-9101 & BN-0001 spectral irradiance standard lamps are precise spectral irradiance transfer standards for use in the wavelength range from 250 to 2500 nm.

Both lamps feature a large diameter filament which is essential for a long operating life and stable irradiance. These 1000 W spectral irradiance standard lamps have been supplied and calibrated by the Gigahertz-Optik

calibration laboratory for optical measurement quantities since

1991 and are in world wide use

in industrial and metrological

BN-9101: 1000 W FEL or Sylva-

nia tungsten halogen lamp and precision lamp socket for hori-

BN-0001: 1000 W DXW tungsten

halogen lamp mounted in a

BN-0001

zontal light orientation..

applications.

BN-9101

precision lamp socket for vertical light orientation.

Common features include hardwiring of the leads to the lamp pins in order to reduce measurement error caused by voltage drops across the connections. Also lamp position is fixed in a temperature stable ceramic base

An optional transparent window target marks the position on the filament used for the irradiance



Typical Spectral Irradiance at 3100 K



calibration. This allows precision alignment in the application or for re-calibration.

Each lamp undergoes a burn-in procedure with burn-in certificate. Several lamp parameters are documented by a on-line data logger. By examination of the burn-in data, only those lamps which display the expected trends are qualified to be



used as reference standards. A burn-in certificate is supplied with each qualified lamp. The BN-9101 is available in two

versions: • FEL type with filament support offers more intensity in the blue

- and UV spectral range than the Sylvania type • Sylvania type is recommended
- for universal use due to its excellent long term stability.

LPS-1000



Calibration of spectral irradiance with DKD certificate or traceable factory certificate is available through Gigahertz-Optik's DIN EN ISO/IEC 17025 accredited calibration laboratory. Descriptions and specifications of the KLW-S1 and KLD-S1 spectral irradiance calibrations is available in the Calibration Service section.



DMM-01

Voltage

LPS-Z01

Set-up for Remote Control Operation

Model	Lamp with Burn	-in Certificat	e		Spectral Irradiance at 70 cm in W/cm <sup>2</sup> nm- <sup>1</sup>					
	Тур	Power	Voltage	Current	250 nm 1100 nm		2500 nm	Distance		
					@ 3100 K		cm			
BN-9101-1	Halogen Lamp FEL Type	1000 W	110 V DC	8.000 A	0.11 mW/m <sup>2</sup>	116 mW/m <sup>2</sup>	18 mW/m <sup>2</sup>	70		
BN-9101-2	Halogen Lamp Sylvania Type	1000 W	101 V DC	8.100 A	0.07 mW/m <sup>2</sup>	96 mW/m <sup>2</sup>	16 mW/m <sup>2</sup>	70		
BN-0001	Halogen Lamp DXW Type	1000 W	115 V DC	8.000 A	0.18 mW/m <sup>2</sup>	219 mW/m <sup>2</sup>	-	50		
BN-9101Z-01	and BN-0001Z-01	Transpare	Transparent cross-hair target for precise alignment onto the filament reference spot							
BHO-10	Hard case for up to (3) BN-9101 and	(2) BN-0001.	Required pa	rt for BN la	amp orders.					
BPC-2	Banana-plug cable, 2 m length. Availa	ble in red, blu	ue and black	color						
LPS-1000	Precise current controlled 1000 W pow	/er supply. Cu	urrent ramp	function. IE	EE488 interfac	e. 230 V / 50 H	Z			
LPS-Z01	High-power shunt resistor with DKD ce	ertificate for p	recise curre	nt measure	ements in comb	ination with DN	/IM-01			
DMM-01	High resolution digital multimeter with	IEEE488 inter	rface and inp	out port mu	ultiplexer					
OS-LPS1000	Software to control and document BN-	-9101 & BN-0	001 operatio	on with LPS	S-1000, LPS-Z0	1 and DMM-01				
KLD-S1 & KL	W-S1	Calibration of spectral Irradiance with DKD or traceable factory certificate								



**Spectral Radiant Power & Luminous Flux** 

#### **BN-0104: Spectral Radiant Power and Luminous Flux Standard Lamps**



**The BN-0104** standard lamp is a precise transfer standard for the quantities of spectral radiant power and luminous flux.

Carefully burned-in tungsten halogen lamps are mounted into a UMLA-300 or UMLA-500 lamp adapter for use in the UMBB-300 and UMBB-500 integrating spheres (see *Integrating Spheres* section). The holder and lamp socket mounting plates are coated with barium sulfate (ODP-97) with 97 % reflectance. The UMLA lamp holder's PG type



connector allows simple mounting and connection of the lamp to the UMLA-1.5B lamp adapter base.

The BN-0104 is available in three different power ranges.

Calibration of spectral radiant power in W/nm within the wavelength range from 400 nm to 1000 nm is supplied by Gigahertz-Optics calibration laboratory for optical radiation measurement quantities.

The standard lamps are supplied in a special carrying case which safely holds and protects the lamp and coated parts.

To power the BN series lamps Gigahertz-Optik recommends the LPS-250 lamp power supply which is specially designed for the operation of light emitting standards.



Typical Spectral Radiant Power at 2856 K

LPS-250 Lamp Power Supply



The LPS-250 lamp power supply is specially designed for stable operation of lamps. It offers a maximum operating voltage of 24 V and a maximum lamp current of 13 A.

A high resolution 16 bit digital to analog converter provides a high level of lamp current control with a resolution of 0.3 mA at the nominal current of 13 A. The current stability is specified at  $0.1x10^{-4}$  A at the nominal current within 8 hours. An on/off ramp function prevents lamp filament shock during the on/off procedure. The RS232 or RS488 interface enables full remote control operation. In the manual control mode an alphanumerical four line display shows the set-up parameters. Manual set-up is accomplished via menu selection.

The power supply is offered in a 1/2-19" housing which allows rack-mounting. For laboratory use an optional bench top housing is offered. Full specifications are listed in the *Integrating Spheres* section.

Typical Specification	ons and Ordering Information	on:			F			ſ				
Model		Lamp			Spectral F	Spectral Radiant Power (mW/nm)						
	Туре	Power	Voltage	Current	400 nm	800 nm	1000 nm	Flux (lm)				
			·		@ 285	56 K						
<b>BN-0104-LH90</b> 1)	37	-	1100									
<b>BN-0104-LH50</b> 1)	Halogen Lamp	50 W	12 V DC	4.16 A	1.11	20.55	-	550				
BN-0104-LH35 1 )	Halogen Lamp	35 W	12 V DC	2,91 A	0.78	14.38	-	370				
1) Lamp supplied in	special carrying case mounted	d on lamp hold	der UMLA-30	00 or UMLA	-500 for use ir	UMBB-300 or	UMBB-500					
BPC-2	Banana-plug cable, 2 m leng	gth. Available i	n red, blue a	and black c	olor							
LPS-250	Precise current controlled 25	i0 W power su	pply. Currer	nt ramp fun	ction. RS232 c	r RS488 interfa	.ce. 230 V / 50	Hz				
LPS-250A	Precise current controlled 25	i0 W power su	pply. Currer	nt ramp fun	ction. RS232 c	r RS488 interfa	ce. 100 to 230	V / 50 to 60 Hz				
BTH-19/2	19"/2 width bench top housi	19"/2 width bench top housing for LPS-250 and LPS-250A										
KLW-S2	Calibration of spectral radiar	t power with c	alculated lu	minous flux	<							



Typical Spectral Radiance

**The BN-0102** standard source is a precise spectral radiance transfer standard. Its compact size makes it ideal in applications with limited space.

The unit is built around a small diameter OP.DI.MA.\* integrating sphere with a symmetrical OP.DI.MA. baffle between lamp and light output port. This offers the best possible uniformity within the 20 mm diameter light emitting area.

The small diameter sphere in combination with the large diameter light port limits the use of the radiance standard to light detection systems having a narrow field-of-view.

OP.DI.MA. is a nearly perfect

white diffuse reflecting plastic material with excellent long term stability.

A carefully burned-in 5 W tungsten halogen lamp operated in constant current mode functions as the light source.

The compact LCRT-2000 power supply is specially designed to run the BN-0102 lamp at a constant current.

Spectral radiance calibration is supplied by Gigahertz-Optik's calibration laboratory for optical radiation measurement quantities and supported by a factory calibration certificate.

\*Gigahertz-Optik's Optically Diffuse Material



#### **BN-0102: Compact Spectral Radiance Standard Source**



**Dimensions** 





#### LCRT-2000: Lamp Power Supply



The LCRT-2000 Lamp Power Supply is designed to operate lamps up to 10 W power. It can be operated in current controlled mode or light intensity controlled mode (requires a reference detector). The LCRT-2000 allows temperature stabilization of four external detectors at +40 °C to avoid drift effects due to ambient temperature instability. One of these detectors may be a reference detector for the light intensity control mode of the LCRT-2000. An additional output voltage for a cooling fan at the external lamp is available.

<b>Typical Spec</b>	Typical Specifications and Ordering Information:											
Model	Model Integrating Sphere			Lamp				Spectral Radiance (mW/m <sup>2</sup> sr nm)				
	Sphere	Port	Туре	Power	Voltage	Current	350 nm	1100 nm	2500 nm	cd/m <sup>2</sup>		
	Diameter	( mm)		@ 2700 K								
BN-0102	40	20	Halogen Lamp	5 W	12 V DC	417 mA	6	750	-	16000		
LCRT-2000	Lamp power su	amp power supply										
KLD-S3	Calibration of sp	ibration of spectral Radiance with traceable factory certificate										

#### Spectral Radiance, Luminous and Uniformity

#### **BN-ULS-M Series: Spectral Radiance, Luminance and Uniformity Standards**



BN-ULS-500 with for internal lamps

The BN-ULS-M Series radiance, luminance and uniformity standards offer the utmost flexibility in constructing a system to individual customer requirements. The design concept is based on providing the highest possible level specifications

ports. How high a luminance output is required is the only selection criteria for small diameter spheres.

A wide range of **Sphere Accessory Components** support configuration of the basic

sphere. In-stock status of all items limits the delivery time of the spheres to the time of assembly.

Standard bench-top **Sphere Stands** are constructed using modular aluminum rails that can be easily customized to the individual application.

**Port Frames** with free aperture diameters from 0.5 in. (12.7 mm) up to 5 in. (127 mm) provide the foundation for all accessory components assembled to the sphere.

Two different kinds of light sources are available for assembly onto the port frames:

Internal Sources are positioned inside of the sphere. The advantage of this type of light source is that all of the luminous flux is emitted inside the sphere offering the highest possible light intensity. Baffles are required to block direct illumination of the light exit port by the internal lamp. The resulting losses in uniformity and acceptance angle can be reduced by the use of multiple internal lamps.

> Integrating Sphere

> > Lamp

LPS-2001

External Sources are directional lamps which transfer their luminous flux through a sphere port into the sphere. The advantage of this type of light source is the ability to place light manipulators like iris diaphragm attenuators, optical filters and fast shutters into the light beam. The restriction with this light source is the lower light intensity. Gigahertz-Optik's unique lamp design employing a diffuse reflector offers high luminous flux efficiency combined with a diffuse light input into the sphere. In combination with its diffusebaffle, light uniformities equal to that of satellite sphere light sources are achieved at higher light intensities.



All **available components** for the construction of standard light source systems are described and specified in the *Integrating Spheres* section.



BN-ULS-300 with external lamp and remote controlled filter wheel

without adding more than is needed. This modular approach gives the customer exactly what he requires without the added cost of unnecessary parts.

Integrating Spheres with different diameters from 4 in. (100 mm) up to 67 in. (1700 mm), form the base units for each setup. The main selection criteria for determining the sphere size is how big the light emitting port must be. A rule of thumb for the maximum acceptable port diameter is no more than 5 % of the total sphere surface area including detector and lamp



BN-ULS-300 with 4 external lamp

**Spectral Radiance, Luminance and Uniformity** 

#### **BN-USM Series: Unit Construction System**



Halogen Lamps are similar in construction to conventional gas filled tungsten filament lamps except that a small trace amount of halogen is added. The addition of this halogen results in a regenerative cycle of the evaporated tungsten. These lamps exhibit:

- long operation time
- broad band spectral radiation ranging from the UV through IR
- stable light emittance charac-
- teristic making them ideal for use as

calibration standard lamps.

Gigahertz-Optik supplies halogen lamps with and without UVblocking quartz envelopes. Note that lamps without UV blocking exhibit a substantially shorter life time.

The following table shows the lamp specifications in combination with different size Gigahertz-Optik integrating spheres and lamp housings.

For the precise operation of halogen lamps Gigahertz-Optik lamp power supplies are recommended.

T<sub>c</sub> (K)

2800

2800

2900

2900

2900

2900

3000

3000

3000

Typical Lam		gin ooui	ce ope	semean	0113.									
	Halog	en Lamp				Inside	Source		Out	side Sou	ırce		OS -	- Iris
Model	Power	UV	Opera	ation at	Sphere I	Diameter D	Depending	g Illumina	nce in kl	x . Spher	e Diame	ter in mm	1)	
	W	Blocker	V	K	150	300	500	T <sub>C</sub> (K)	150	300	500	150	300	500
LH-5	5	$\checkmark$	12	3100	13	3.3	1.2	2850	8.2	2	0.7	4.4	1	0.4
LH-10	10	$\checkmark$	12	3100	21	5.1	1.9	2850	11	2.9	1	6.6	1.6	0.6
LH-35	35	$\checkmark$	12	3100	97	24	8.9	2950	71	17	6.5	39	9.6	3.5
LH-50	50	$\checkmark$	12	3100	156	38	14	2950	116	28	10	62	15	5.6
LH-75	75	$\checkmark$	12	3100	248	61	22	2950	183	45	16	95	23	8.7
LH-90	90	$\checkmark$	12	3100	315	77	28	2950	237	58	21	122	29	11
LH-10-UV	10		6	3100	25	6.2	2.3	3050	16	4.1	1.5	9.9	2.4	0.9
LH-50-UV	50		12	3100	190	46.6	17	3050	143	35	13	77	18	7
LH-100-UV	100		12	3100	436	107	39	3050	333	81	30	179	44	16
LH-250-UV	250		24	3100	-	-	-	-				On Reque	est	
A) T - 1 - 1 - 1								1.124						r

1) Typical values only. Illuminance (Luminance) may vary with port size and additional accessories. Please contact the company for more details

#### Light Detectors and Optometers



Gigahertz-Optik offers a wide range of light detectors and optometers which can be combined with the integrating sphere based light sources for precise radiance and luminance measurement.

**Temperature stabilized** TD-11 light detectors are the right choice to avoid drift in readings caused by changes in ambient temperature.

In applications that require long term stability of the emission spectra, **color temperature controlled operation** of the halogen lamp is possible using one of Gigahertz-Optik's lumi-



nous color detectors. The color temperature stabilization can be done by manual or remote control current variation of the LPS-250 lamp power supply. If the intensity variation in color temperature controlled mode is not acceptable, an iris diaphragm or motorized attenuator can be used to control the light output intensity. Complete remote controlled systems are offered by Gigahertz-Optik.

More information and specifications are available in the *Light Detectors* and *Optometers* sections. The LPS-250 lamp power supply is specially designed for the operation of halogen lamps. It offers a variable voltage from 0 to 24 V . A 16 bit digital to analog converter allows precise current set-up from 0 to 15 A with a resolution of 0.3 mA. The current stability is specified at 0.1x10<sup>-4</sup> A at the nominal current over 8 hours. An on/off ramp function prevents shock of the lamp filament during the on/off procedure. RS232 or RS488 interface allows full remote control operation of single and multiple units. The power supply is offered in a





1/2-19" rack-mount housing. For laboratory use an optional bench top housing is available. Full specifications are shown in the *Integrating Spheres* chapter.

### Spectral Radiance, Luminous and Uniformity

#### **BN-ULS-K190: Spectral Radiance Standard**



The BN-ULS-K190 spectral radiance standard offers high and controllable intensity and a uniform radiant output from 300 to 2500 nm.

The BN-ULS-K190 is built around a compact precision machined aluminum housing featuring an inlet made out of Gigahertz-Optik's white diffuse plastic material, OP.DI.MA.

This material offers very good diffuse reflectance combined with high spectral reflectance

found with electronically controlled intensity methods. To ensure high

intensity output the halogen lamp is placed within a diffuse reflector for best flux coupling efficiency as well as diffuse sphere illumina-

tion for high radiance uniformity at the light output port.

100

0



from 250 to 2500 nm. In comparison to barium sulfate coatings OP.DI.MA. exhibits greater irradiation stability in the ultraviolet to infrared spectral ranges with better mechanical stability as well.

Another key feature is that the light source is externally positioned allowing the use of a variable attenuator mounted between the lamp and sphere. An adjustable shutter eliminates changes in color temperature as

#### Dimensions (mm):

ferent intensities (Iris 100%, 75% and 50% open) and luminance calibration of light detector.



#### Typical Specifications and Ordering Info

Typical Specifica	pical specifications and ordering mornation.									
	Integratin	g Sphere	Light Source		Radiance in mW/(m² sr nm)					
	Sphere Ø	Port Ø	Power	Lamp	Source	Wavelength	Iris 100 %	lris 75 %	Iris 50 %	СТ
BN-ULS-K190-1	190 mm	50 mm	100 W	Halogen	LS-OK30	@ 1100 nm	1230	850	560	3050 K
BN-ULS-K190-2	190 mm	50 mm	50 W	Halogen	LS-OK30	@ 1100 nm	550	380	240	2800 K
Including LPS-25	0 power su	pply, VL-1	101-2 lig	ht detecto	or, P-9710-1	optometer, K	LW-S3 calibr	ation from 30	0 to 2500 nm	at three dif-

250 400 550 700 850 1000 1750

wavelength (nm)

Typical Spectral Radiance at 100%, 75% and 50%

A precise photometrically corrected reference detector is mounted to the integrating sphere for connection to a Gigahertz-Optik optometer to read out luminance values (see Optometer chapter).

The lamp is operated by the LPS-250 lamp power supply for high resolution lamp current control and long term stability (see Integrating Spheres chapter).

Calibration of spectral radiance

а

b



at three different intensity levels is done by Gigahertz-Optics Calibration Laboratory and traceably confirmed in a factory calibration certificate.

210



2500

Dimensions

С

238

110

🕃 Gigahertz-Optik

**Spectral Radiant Power and Irradiance Sensitivity** 

#### **BN-DSR-100 Spectral Radiant Power Sensitivity Standard Detector**



It's 10 x 10 mm active area silicon photodiode is mounted in the 37 mm diameter MD-37 type detector housing. A machined Vgroove and side M6 threaded hole are provided in the housing for detector mounting. See *Light detector* section for more details. Photodiode linearity between incident light and photocurrent signal is up to 1 mA.

The spectral sensitivity range is 200 to 1160 nm.

A 2 m long coaxial cable with BNC connector enables the detector to be used with an optometer or signal amplifier. Alternatively a (type-2) calibration data connector or (type-4) connector for compatibility with Gi-



gahertz-Optik's P-9710 or X1, X9 meters respectively are available.

The BN-DSR-100 is available with either a DKD ISO-EN 17025 calibration from 248,4 to 1160 nm or with a factory calibration from 200 to 1100 nm. See *Calibration* chapter for more details.

The <b>BN-DSR-100</b> calibration	radiant power sensitivity in A/W
standard detector is a precise	in the wavelength range from
transfer standard for spectral	200 to 1160 nm.

 transfer standard for spectral 200 to 1160 nm.
 nector for compatibility

 Typical Specifications and Ordering Information:
 Detector

del		Photodiod	de	Detect	tor	Calibration	
	Туре	Area	Size mm	Aperture	Package	Wavelength Range	Unit
-DSR-100D	Si	100 mm <sup>2</sup>	10 x 10	10 x 10 mm	MD-37	1)	A/W nm
-DSR-100F	Si	100 mm <sup>2</sup>	10 x 10	10 x 10 mm	MD-37	200-1100 nm in 10 nm steps 2)	A/W nm
-DSR-100F						200-1100 nm in 10 nm steps 2)	

2) Factory calibration certificate

#### **BN-DSI-33 Spectral Irradiance Standard Detector**



#### Typical Spectral Sensitivity

The **BN-DSI-33** calibration standard detector is a precise spectral irradiance sensitivity  $[A/(W/m^2)]$  transfer standard for the wavelength range from 250 to 1100 nm.

The 33 mm<sup>2</sup> active area silicon photodiode is mounted in a 37 mm diameter MD-37 type light detector housing. A machined V-groove and side M6 threaded hole allow mounting of the detector. The entrance window is composed of a spectrally neutral broadband 11 mm diameter RADIN\* diffuser.

The photodiode linearity between incident and detector signal is up to 1 mA. The spectral sensitivity range is 250 to 1100 nm. A 2 m long coaxial cable with BNC connector enables the detector to be used with an optometer or signal amplifier. Alternatively a (type–2) calibration data connector or (type–4) connector for compatibility with Gigahertz-Optik's P-9710 or X1, X9 meters respectively are available. The BN-DSR-33 is available with a calibration of its spectral irradiance sensitivity from 250 to 1100 with a factory certificate. See *Calibration* chapter for more details.

\* Gigahertz-Optik Radiation Integrator

Typical Spe	cifications and	Ordering I	nformation:				
Model	P	hotodiode		Detec	ctor	Calibration 1	)
	Туре	Area	Size mm	Aperture	Package	Wavelength Range	Unit
BN-DSI-33	Si+RADIN	33 mm <sup>2</sup>	5.6 x 5.6	11 mm Ø RADIN	MD-37	250-1100 nm in 10 nm steps	A/(W/m <sup>2</sup> )
1) Relative sp	ectral sensitivity	absolute sc	aled at 555 r	าท			



## Page 140 - Calibration Standards & Uniform Light Sources



#### **BN-R: Spectral Reflectance Standards**



In many optical measurement tasks, optically diffuse reflectors for system calibration and/or adjustment are required. These standards should exhibit a maximally diffuse pattern of reflection. Also, in applications involving spectrally broadband light sources and detectors the reflectance characteristic of the standard should be spectrally neutral across the entire spectral bandpass of interest. For calibration of spectrophotometers the absolute spectral reflectance of the standard must be known.

**Gigahertz-Optik's BN-R** Reflectance Standard fits this specification profile nearly perfectly. The standard is made from OP.DI.MA. which stands for Optically Diffuse Material and features:

Typical Specifications and Ordering Information:

©Light and temperature stable highly durable PTFE material

©Optimally diffuse reflectance (Lambertian reflector)

©Different reflectance of 98 %, 50 % and 3 %

©Spectrally neutral reflectance of 98 % +/- 1 % from 400 to 800 nm.

**Different Sizes** of reflectance standards are offered.

The BN-Rxx-D2 offers a reflectance of 2 in. (50.8 mm) diameter. A screw top cover protects the reflectance surface during storage and transportation.

**The BN-Rxx-SQ** reflectance standards are available in 2 x 2 in. (50 x 50 mm) to 18 x 18 in. (457 x 457 mm) sizes. All standards are supplied with a removeable cap

Each BN-R98-S5C Reflectance Standard can be ordered with a calibration certificate that includes a plot of spectral reflec-



Typical Spectral Reflectance of BN-R98, 70,50 and 03

tance and data-set. Data is supplied over the spectral range from 250 nm to 2500 nm in 50 nm increments. Optionally, finer wavelength resolution is available. Calibration is performed using 8°/hemispherical measurement geometry. Gigahertz-Optik calibrations employ transfer standards traceable to the NRC National Research Council of Canada and NIST National Insti-



BN-R50-SQ18, 18 x 18 inch reflectance

Model	Reflect	ing Area	Model 1)	Reflectance	Model 1)	Reflectance	Model 1)	Reflectance
	dime	ension		% @ 555 nm		@ 555 nm		@ 555 nm
	mm	in		0		0		0
BN-R-D2	50.8 Ø	2 Ø	BN-R98-D2		BN-R50-D2		BN-R02-D2	
BN-R-SQ50	50 x 50	2 x 2	BN-R98-SQ50		-		-	
BN-R-SQ100	100 x 100	3.9 x 3.9	BN-R98-SQ100		-		-	
BN-R-SQ200	200 x 200	7.9 x 7.9	BN-R98-SQ200	98 +/- 1 %	-	50 +/- 5 %	-	3 +/- 1.5 %
BN-R-SQ300	300 x 300	11.8 x 11.8	BN-R98-SQ300	-	-	-	-	
BN-R-SQ5	129 x 129	5 x 5	BN-R98-SQ5	-	BN-R50-SQ5	-	BN-R02-SQ5	
BN-R-SQ12	305 x 305	12 x 12	BN-R98-SQ12		BN-R50-SQ12	-	BN-R02-SQ12	
BN-R-SQ18 <sup>2)</sup>	457 x 457	18 x 18	BN-R98-SQ18		BN-R50-SQ18	-	BN-R02-SQ18	
1) Add -C to the	e model for ca	alibration of th	e 8/D hemispherica	l reflectance fro	m 250-2500 nm in	50 nm steps	1	
2) The reflectan	ce plate is bu	ild by two half	S					
Optional calibra	tion available	in 1 nm steps	with data on disk					



#### **General Information & Table of Contents**

#### **General Information**

**Calibration** is the determination of the correlation between an input and an output quantity. All measurement instruments, such as voltmeters, manometers, vernier calipers, etc., must be calibrated to determine the variation of its reading from the absolute quantity.

In light measurement, different types of calibrations are required based on a number of photometric, radiometric and luminous color measurement applications. These calibrations are typically done by comparison of the measurement values of a calibration standard to those of the test device.

The input quantity is provided by standard lamps and light detector standards. Because of the many different measurement quantities involved in light measurement, calibration standards for each quantity are needed. The calibration of the standard itself must be traceable to national or international standards. Since calibration standards are subject to change with use, the validity of the standards must be checked periodically or replaced to maintain the quality of calibration, traceability and stated uncertainties.

In Germany, the Deutsche Kalibrierdienst – DKD (the German accreditation institution) and the Physikalisch-Technische Bundesanstalt (the German national standard laboratory) offer an accreditation service for industrial calibration laboratories where the lab's calibration standards, calibration procedures and the stated re-calibration This accreditation ensures that the traceability of the calibration and the calibration procedure is on an absolute level. The DKD also ensures the international acceptance of its accredited calibration laboratories. Gigahertz-Optik's calibration laboratory is DIN EN ISO/IEC 17025 accredited for the measurement quantities Spectral Sensitivity and Spectral Irradiance under Registration Number DKD-K-10601. The level of accreditation requires annual renewal through actual artifact calibration and intercomparison with the accrediting body. Besides spectral sensitivity and spectral irradiance calibration, Gigahertz-Optik offers optical radiation calibration in other light measurement quantities using calibration standards

intervals are subject to audit.

traceable to international calibration laboratories. By intercomparison to Gigahertz-Optik's inhouse DKD for spectral sensitivity and spectral irradiance, long term stability and traceability of the non-DKD transfer standards is ensured.

Calibrations performed using standards from National Standard Laboratories e.g. NIST, PTB, NPL offer the lowest uncertainties and are therefore the preferable reference. Beside that factory level calibration standards with slightly higher uncertainties are used for some calibrations.

This chapter describes the different calibrations available.

Calibration standards are shown in the 'Calibration Standards & Uniform Light Sources' chapter.

#### Table of Contents

# General InformationCalibration & TraceabilityP. 143Gigahertz-Optik's Calibration Laboratory for Optical Radiation Measurement QuantitiesP. 144DKD Accrediting Authority; PTB, the German National Calibration LaboratoryP. 145

Calibration Certificate	Page
Factory	146
Factory	146
Factory	146
Factory	147
Factory	147
Factory	147
DKD	148
Factory	148
Factory	149
Factory	149
Factory	149
Factory	150
Factory	151
Factory	151
	Factory

## Page 142 - Calibration Service

## Table of Contents

Product Info	ormation					
Model	Calibration of	Туре	Unit	Wavelength Range (nm)	Calibration Certificate	Page
KLW-P4	Light Sources	Luminous Intensity	cd	Photometric	Factory	151
KLW-CT	Light Sources	x,y Chromaticity Values Color temperature	- K	Colorimetric	Factory	151
KLW-ID	Uniform Light Sources	Area Luminance Uniformity	%	Photometric	Factory	151
KDD-S1	Radiometric Detectors	Spectral Radiant Power Sensitivity	A/W	248.4 - 1160	DKD	152 - 153
KDW-S1	Radiometric Detectors	Spectral Radiant Power Sensitivity	A/W	200 - 1800	Factory	152/153
KDW-S2	Radiometric Detectors	Spectral Irradiance Sensitivity	A/W/m <sup>2</sup>	200 - 1100	Factory	153
KDW-S3	Radiometric Detectors	Spectral Radiance Sensitivity	A/W/(m²sr)	350 - 1100	Factory	153
KDW-S4	Radiometric Detectors	Spectral Radiant Intensity Sensitivity	A/W/sr	350 - 1100	Factory	153
KDW-R1	Radiometric Detectors	Integral Radiant Power Sensitivity	A/W	Δλ	Factory	154
KDW-R2	Radiometric Detectors	Integral Irradiance Sensitivity	A/W/m <sup>2</sup>	Δλ	Factory	154
KDW-R3	Radiometric Detectors	Integral Radiance Sensitivity	A/W/(m²sr)	Δλ	Factory	154
KDW-R4	Radiometric Detectors	Integral Radiant Intensity Sensitivity	A/W/sr	Δλ	Factory	154
KDW-P1	Photometric Detectors	Luminous Flux Sensitivity	A/Im	Photometric	Factory	154
KDW-P2	Photometric Detectors	Illuminance Sensitivity	A/lx	Photometric	Factory	155
KDW-P3	Photometric Detectors	Luminance Sensitivity	A/cd/m <sup>2</sup>	Photometric	Factory	155
KDW-P4	Photometric Detectors	Luminous Intensity Sensitivity	A/cd	Photometric	Factory	155
KRW-S1	Reflectance Samples	Reflectance	%	250 - 2500	Factory	155/156
KTW-S1	Transmittance Samples	Transmittance	%	350 - 1100	Factory	155/156
AM-001	Measurement & Qualification	Spectral Irradiance	W/(m <sup>2</sup> nm)	250 - 1100	Factory	156
AM-003	Service	Laser Classification	-	350 - 1100	TÜV/GS	156
AM-004		Transmittance of XXL Samples	%	250 - 1100	Factory	156

#### Traceability

#### Traceability: an Unbroken Chain of Transfer Comparisons

Calibration is a prerequisite for maintaining accuracy in any type of measurement instrument. It is the foundation upon which subsequent measurements are based upon. Optical radiation calibration is typically done using the transfer method where the relationship between the reading of a device under test and that of a calibration standard is compared. The test device reading is then adjusted to that of the standard as needed, recorded and certified .

Since this is a direct comparison qualification of this transfer standard is of the highest importance.

A qualified standard should display an unbroken chain of transfer comparisons originating at a national standards laboratory. For example, the transfer standard of the national laboratory, primary standard (A) is used to calibrate the reference standard (B) at an accredited calibration laboratory. This reference standard is used to calibrate the laboratory work standard (C) to be used daily by the cal lab. This work standard is then used to calibrate the final product (D) or device under test. Accordingly, the calibration path is A-B-C-D. This path is called the chain of traceability.

Each transfer device in the chain should be subjected to periodic examination to ensure its long term stability. The time span between examinations is typically set by the lab performing the calibration and is self-audited.

Accredited calibration laboratories guarantee recalibration cycle times for their standards plus a review of their calibration procedures since they are subject to annual review by an official accreditation authority.

For the optical radiation measurement quantities of *Spectral Irradiance* and *Spectral Responsivity*, the Gigahertz-Optik calibration laboratory offers DKD calibration with direct comparison to its reference standards and fully documented procedures. This type of calibration, which offers the lowest available calibration uncertainty, is normally requested by high level industrial calibration laboratories or institutions who may in turn use the calibrated device as their However, in the majority of applications, end-users only need a simpler more economically priced calibration, since their type of measurement may not demand the lowest possible measurement uncertainty. But they do demand calibration certificates showing a confirmed unbroken chain of traceability to a national standard. For this requirement Gigahertz-Optik offers a "factory calibration" for Spectral Irradiance and Spectral Responsivity and all other calibrations which do not require the higher accreditation level.

own reference standard.

To confirm traceability, every calibration is documented by a calibration certificate, which lists the calibrated device's identification data, calibration procedure, calibration uncertainty, environmental conditions as well as the traceability data back to the national standards laboratory. The certificate is signed by the calibration engineer and stamped by the calibration laboratory manager.



Calibration Hierarchy from the Primary Standard to the Test Equipment



Hierarchy of Standards

**Gigahertz-Optik's Calibration Laboratory** 

#### Gigahertz-Optik's Calibration Laboratory for Optical Radiation Measurement Quantities

Gigahertz-Optik's calibration laboratory for optical radiation measurement quantities owns, uses and maintains lamp, detector and reflector based reference standards traceable to PTB, NRC, NIST and NPL.

<u>Spectral Irradiance  $E(\lambda)$ </u> is the most basic radiometric measurement quantity and can be used to calculate many other quantities such as:

- Integral Irradiance *E*, associated with spectrally broadband detectors
- Photobiological Actinic Irradiance *E<sub>biol</sub>*
- Photosynthetically Active Irradiation *E<sub>PAR</sub>*
- Illuminance E<sub>v</sub>
- Colorimetric Quantities
- Radiant Power, Radiant Intensity, Radiance, Luminous Flux,

Luminous Intensity and Luminance for known geometrical relationships

The DKD proofed reference standard used here are 1000W FELtype quartz-halogen lamps that have been carefully selected after a burn-in procedure of about 80 to 100 hours. The useful spectral range of these sources is 250 to 2500 nm. This type of calibration standard is also offered to our customers under the model number BN-9101 (refer to Calibration Standards & Uniform Light Sources chapter for more information).

Spectral Responsivity of optical radiation detectors is a commonly required calibration and is supplied with each Gigahertz-Optik detector order.

The DKD reference standard used in this type of calibration are Si–Photodiodes with its operating

temperature controlled by a thermal sensor during the calibration procedure. The useful wavelength range of this reference detector is 248 to 1160 nm. Beside that NIST calibrated Si and InGaAs photodiodes are used for factory calibration in the spectral range from 200 to 1800 nm.

Calibrations other than spectral sensitivity and spectral irradiance are performed using calibration standards from NIST and other national labs. By intercomparison to the accredited DKD standards, long term stability and therefore traceability of the non-DKD standards is ensured.

ISO/IEC/EN 17025 (formerly ISO/ IEC Guide 25, known as ANSI/ NCSL Z540-1, and EN45001) accreditation assures the competency of calibration laboratories to carry out specific tests or calibra-

Physi	Deutscher Kalibrierdienst (DKD) Advederungstellt bir der kalisch-Technischen Bundesanstalt (PTB) weinster im
Deu	utschen AkkreditierungsRa
	*
	Akkreditierung
	berungsstalle des Deutschen Kallbrienstenstes alltrechtert hermit is onsolum Gropheche Stahlungspillen
	Gigararia Opix Oniteri Pischerstraße 4
	BETTR Puchtern bei München
	trale Empfindlichkeit, spektrale Bestrahlungsstärke
(bestarabel )	der Unsunde ist. Anlage 03 (1 Gette), 2000-10-28
DAN Registe Akkreditert	Hernunsen, DKD K. 1980-163 Im DKD selt, 1980-66-22
Jas	
pring man	and the second

Accreditation Document for Gigahertz-Optik's Calibration Laboratory

tions and forms the basis of the lab's quality system.

#### Traceability Chart of Gigahertz-Optik's Calibration Laboratory for Optical Radiation Measurement Quantities


## 🖲 Gigahertz-Optik

## DKD, PTB, NIST, NPL

DKD Accrediting Authority founded out of the Western Euro-

pean Calibration Cooperation

(WECC) and the Western Euro-

pean Laboratory Accreditation Cooperation (WELAC) in 1994.

Within the EAL different national

accreditation institutes cooperate

with the goal of international

acceptance of calibration certifi-

cates of the EAL-calibration

laboratories. In November 2000,

34 accreditation institutions from

28 countries, including the PTB,

the accreditation institution of the

DKD, signed a Mutual Recogni-

tion Arrangement (MRA) of the

International Laboratory Accredi-

tation Cooperation (ILAC). More

information about this arrange-

ment and the participating coun-

More information is available on

tries is available online at

www.ilac.org.

The German accreditation institution DKD (Deutscher Kalibrierdienst) was founded by the German trade and industry and the German state, represented by the Physikalisch-Technische Bundesanstalt (PTB), the German national standard laboratory.

The basic idea of the DKD is to transfer as many PTB responsibilities to industry as possible, including the calibration of measurement and testing equipment. The DKD ensures the traceability of measurement and testing equipment to national standards by the accreditation and continuous control of industrial calibration laboratories.

Therefore, calibration carried out by DKD accredited calibration laboratories offers a secured traceable link to national calibra-

The Physikalisch-Technische Bundesanstalt (PTB) is the <u>highest technical authority for metrology in Germany</u>. The PTB's responsibilities are to define, realize, keep and transmit the physical quantities of the SI-system, such as a meter, a second, a kilogram, a candela and many

As part of its responsibilities the Optical Technology Division of NIST's Physics Laboratory develops, improves, and maintains the national standards for radiation thermometry, spectroradiometry, photometry, colorimetry, other standards.

The PTB is the official accreditation institution for DKD calibration laboratories such as the Gigahertz-Optik calibration laboratory for optical radiation measurement quantities. The PTB is also active in getting bilateral

tion standards. An uninterrupted

traceability chain of calibration to

national standards is of critical

importance for instrument and

testing equipment manufacturers

in order to be competitive in

national and international mar-

kets and is absolutely necessary

for any quality management

The qualification of the traceabil-

ity to national standards is the

job of the Physikalisch-Techni-

sche Bundesanstalt (PTB), the

German national standard labo-

ratory. The PTB will define, real-

ize, keep and transmit the physi-

cal quantities of the SI-system,

such as a meter, a second, a

equal standards must be used.

The calibration of measurement

and testing arrangements based

ensure objective results,

kilogram, a candela, etc.

system.

То

and spectrophotometry; provides National measurement standards and support services to advance the use and application of optical technologies spanning the ultraviolet through microwave spectral regions; dis-

NPL's Optical Radiation Measurement (ORM) Group provides services which are the backbone for optical radiation measurements in the UK and internationally. Here the UK's Primary Standards and scales are maintained, and research in measurement science is carried out. ORM anticipates and responds to industrial and academic measurement requirements throughout the IR, Visible, and UV spectra. on SI-units is a basis for correct, comparable, recognizable and therefore measurable values, which can be audited.

Within the DIN ISO 9000 standard the relationship between quality management and calibration are intertwined in part for continuous control of measurement and testing equipment.

Without exception, DKD accredited calibration laboratories fulfill the requirements of DIN EN ISO/ IEC 17025 (general criterions to operate a testing laboratory). DIN EN ISO/IEC 17025 replaced EN 45001 and ISO/IEC Guide 25 in 1999.

The European position of the DKD is noted by its membership in the European Cooperation for Accreditation of Laboratories (EAL) in Rotterdam, which was

#### **PTB - the German National Calibration Laboratory**

acceptance for international standards. Because of their activities in 1995, a Statement of Intent on Traceability of Measurement Standards was signed between the Physikalisch-Technische Bundesanstalt (PTB) and the National Institute of Standards and Technology (NIST) USA. The Equivalence of the National Standards of NIST and PTB for the SI Units of Luminous Intensity and Luminous Flux was officially recognized in April 1999.

More information is available on the internet at <u>www.ptb.de</u>

#### NIST - U.S. National Institute of Standards and Technology

seminates these standards by providing measurement services to customers requiring calibrations of the highest accuracy and performs research and publishes technical reports & procedures to further the base of knowledge.

NIST Physics Laboratory Optical Technology Division Home Page, <u>www.physics.nist.gov</u>

For more information visit the

#### NPL - National Physical Laboratory UK

Measurement and calibration services include the characterization and calibration of: all types of optical radiation sources, optical radiation detectors and associated devices, optical properties of materials and components & aspects of appearance including color, haze and gloss.

Visit NPL ORM Introduction Web Page <u>www.npl.co.uk</u> for more information.

#### NRC - National Research Council Canada

The NRC's Institute for National Measurement Standards Photometry and Radiometry Group maintains photometric, radiometric, spectrophotometric and colorimetric standards, and pro-

vides associated, high-accuracy measurement services to industry, university, and government clients involved with lighting, transportation, manufacturing, telecommunications, public health and safety, and the environment. More information is available on

More information is available on the internet at the NRC INMS Photometry & Radiometry Home Page: <u>www.nrc.ca/inms</u>

## K-xx Calibration & Re-Calibration of Gigahertz-Optik Light Detectors

#### K-xx-I, K-xx-S, K-xx-SR Integral & Monochromatic Calibration

Different types of light detector sensitivity calibrations are available:

#### Integral Calibration:

A broadband light source is used to irradiate the detector under test. The irradiation intensity of the light source is calibrated within the sample detectors spectral sensitivity range in the appropriate units of measurement. By comparing the detectors signal current to the given light intensity the test detector's sensitivity is calibrated.

Typical examples where integral calibration are employed:

- Photometric light detectors where calibration is done with a standard Illuminant A light source at 2856 K.
- Integral radiometric detectors such as UV-A, VISIBLE, Erythema & PAR used in applications with broadband light sources.

#### **Spectral Calibration:**

Ordering Information

A monochromatic light source is used to irradiate the test detector at a specified wavelength in the appropriate units of measurement. By comparing the detectors signal current to the given light intensity the test detector's sensitivity can be calibrated.

Typical examples where monochromatic calibrations are emploved:

- Light detectors used to measure lasers or quasi monochromatic light sources. Calibration is performed at the laser wavelength or the peak wavelength of the quasi monochromatic light.
- Light detectors with narrow band pass filters. Calibration is done at the peak wavelength of sensitivity.

#### **Spectral Calibration Dataset:**

This calibration is identical to the spectral calibration with the except of a tunable monochromatic light source. This allows multipoint calibration of detector sensitivity over a series of different wavelengths. Typically the calibration is done in 10 nm steps within the spectral sensitivity range of the detector assembly. Typical examples for the selection of spectral calibrations are:

· Light detectors used to measure lasers or quasi monochromatic light sources at different wavelengths.



- Light detectors used for the calibration of tunable monochromatic light sources.
- In addition to integral calibrations of broadband detectors when used to measure light sources different than the lamp calibration standard. (See a(z) correction).

#### **Relative Spectral Calibration:** All integral light detectors supplied by Gigahertz-Optik with

certified absolute integral or monochromatic calibrations in-



spectral sensitivity data allows computation of estimated measurement uncertainty as well as calculation of the a(z) calibration correction factor.

On detector re-calibration the relative spectral sensitivity calibration is offered as an option.

- Consult the factory to discuss the appropriate calibration technique for your light detector application.

ordening	ordering information		
K-xx-l	Integral sensitivity calibration of a G-O light detector with a broad band light source. *), **)		
K-xx-S	Spectral calibration of a G-O light detector at a single wavelength or at a series of wavelengths. **)		
K-xx-SR	Relative spectral sensitivity calibration of a light detector. Only available in combination with a K-xx-I or K-xx-S calibration.		
*) Includes one K-xx-SR calibration with new detector order. **) Example: K-UV3701-I for calibration of UV-3701 light detector			

#### a(z) Calibration Correction Factor for Known Light Sources

Integral light detectors are composed of photodiodes with optical edge and bandpass filter combinations used to correct or shape spectral sensitivity. However, the complete detec-

tor's spectral sensitivity, e.g. UV-A, PAR, UV-Erythema, can never



perfectly match the intended spectral sensitivity of the ideal actinic function plus tolerance limits in the filter batch processes exist. As such the measurement uncertainty of an integral detector may vary in applications involving light sources

with emission spectra different than that of the reference lamp used in the detector calibration. The a(z) method developed by Gigahertz-Optik makes it possible to calculate calibration correction factors if the emission spectrum of the calibration reference source, spectral sensitivity of the light detector and the application light source emission spectrum is known.

Background information on the a (z) correction method is available in the Tutorial section.



K-SAZ-02 Computation of uncertainty based on end-user supplied emission spectrum. Excel or ASCII file with 1 nm step must be supplied or can be measured by G-O as an option.

λ 🗕

K-FOV Field-of-View; K-xx-C Current; KF Other Manufacturer Products

#### K-FOV Field-of-View Calibration of Gigahertz-Optik Light Detectors



Besides standard detector sensitivity calibration services, Gigahertz-Optik offers a field-of-view calibration service for G-O light detectors.

The F.o.V. calibration is offered for all irradiance and illuminance detectors employing diffuser windows for a cosine corrected measurement geometry.

The calibration is done with a spot light source at a distance of 2 m (78 inch) from the detector.

The test detector is mounted onto a goniometric rotary table. It's diffuser surface is aligned to the axis of the rotary table.

The signal as a function of the viewing angle is measured and compared with the ideal cosine spatial function. The measured characteristic as well as the calculated  $f_2$  uncertainty is stated in the factory calibration certificate.

#### **Ordering Information**

K-FOV-01 | Field-of-View calibration of irradiance or illuminance light detectors with f2 uncertainty calculation. Factory calibration certificate



#### K-xx-C Current Calibration of Gigahertz-Optik's Optometers

Gigahertz-Optik's optometers are built around precision multigain range current amplifiers to process the light detector signal. All optometers are calibrated and certified using a variable current source which itself is calibrated by an outside accredited calibration laboratory.

Correction factors are calculated based on the calibration values and used to adjust the display readings at each gain range. This current calibration is offered as a re-calibration service for all of the different Gigahertz-Optik optometers.

Calibration uncertainty and traceability information is supplied in the factory calibration certificate.

#### **Ordering Information**

K-xx-C Current calibration and adjustment of Gigahertz-Optik optometers. xx = model number. Factory calibration certificate

#### KF Regular Re-Calibration Service for Other Manufactures Products

Calibration services are available for other light meter manufacturer's products as well. But in order to perform the work some important information must be provided including:

- Spectral sensitivity
- Signal range
- Measurement units

• Old calibration certificate If this data is available a comparable calibration such as KDW-S, -I or –P can be done.

In cases where this information is

not available a one-time set-up procedure for the first calibration must be established. This means our experts must analyze the instrument by measuring it's spectral sensitivity, field-of-view geometry and other parameters. After this evaluation the instrument can be calibrated.

<u>Note</u>: This calibration may only confirm the correlation or noncorrelation between an input and output quantity. An actual adjustment of the meter for direct reading is not always possible since calibration adjustment procedures differ from manufacturer to manufacturer.

Where a simple potentiometer adjustment or an eprom with open data format for programming the correction factor is used, we can supply the calibration and adjust for direct reading. Over the last 15 years we have re-calibrated many manufacturers' light meters. A price list of the regularly calibrated units is available on demand. The list includes the:

- Part/model number
- Manufacturer
- Job description
- Annual recalibration plan.

If your specific instrument is not listed please contact the factory to see if it can be calibrated or to discuss the feasibility and cost involved to perform the one time pre-calibration product qualification.

# Ordering Information KF-xx Calibration of other manufacturers' standard light meters. Please contact the factory for price & description list or to discuss your special calibration requirements.

🖲 Gigahertz-Optik

## KLD-S1 & KLW-S1 Spectral Irradiance of Light Sources

#### **Calibration Traceability**

Since July 1994, the Gigahertz-Optik calibration laboratory for optical radiation measurement quantities has been accredited by the DKD accreditation institution (Registration Number DKD-K-10601) for the calibration of Spectral Irradiance.

For quartz-halogen lamps and incandescent sources in the power range from 500 W to 2000 W, spectral irradiance calibration with an official DKD calibration certificate is available. These lamps are calibrated against one G-O calibration laboratory BN-9101 1000 W FEL Type quartzhalogen lamps (PTB calibration certification for wavelengths from 250 to 2500 nm). The reference



sources are periodically recalibrated by the PTB.

Intercomparison measurements of the source under test, such as the BN-9101 (See *Calibration Standards* section), to a reference standard source are per-

#### KLD Calibration in W/(m<sup>2</sup>nm) with DKD Certificate

to 2500 nm.

The KLD calibration of spectral irradiance with DKD certificate is performed according to fixed accredited calibration procedures and specifications. The calibration is limited for lamps between 500 to 2000 W in the wavelength range from 250 nm

The calibration is done by direct comparison to a PTB Reference Standard and is confirmed in the official DKD calibration certificate supplied with the calibrated source.



formed. The complete calibration procedure follows accreditation regulations and is confirmed by a DKD calibration certificate supplied with the calibrated source.

#### KLW Calibration in W/m<sup>2</sup>nm with Factory Certificate

A more economically priced calibration with slightly higher calibration uncertainties called the KLW spectral irradiance calibration is available which includes a factory certificate. The device data, calibration procedure, calibration uncertainty, environmental conditions as well as the traceability data back to the national standards laboratory are confirmed in the certificate. The lamp power range is unlimited. Wavelength range is from 250 nm to 2500 nm.

Measurement	Wavelength nm	KLD-S1		KLW-S1	
Quantity		Measurement Conditions	Relative Measurement Uncertainty with Reference Standard	Measurement Conditions	Relative Measure- ment Uncertainty
	λ=250	Only for incandescent sources power range 500 W ≤ P ≤ 2000 W	± 10 %	Power range >100 W. Measurement uncertainty may increase depending on lamp type	± 12 %
Spectral Irradiance in W/(m <sup>2</sup> nm)	λ=260		± 7 %		± 8 %
of	$270 \le \lambda < 400$		± 4 %		± 4.5 %
Optical Radiation	$400 \le \lambda < 800$		± 3 %		± 3.5 %
Sources	$800 \le \lambda < 2000$		± 4.5 %		$\pm$ 5.5 %
-	$2000 \leq \lambda \leq 2500$		± 7 %		± 8.5 %

Calibration Steps: 10 nm from 250 to 300 nm; 20 nm from 320 to 800 nm; 50 nm from 850 to 2500 nm

Ordering Info	Ordering Information		
KLD-S1-01	Spectral Irradiance calibration within the wavelength range 250 to 400 nm with DKD certificate		
KLD-S1-02	Spectral Irradiance calibration within the wavelength range 400 to 1100 nm with DKD certificate		
KLD-S1-03	Spectral Irradiance calibration within the wavelength range 1100 to 2500 nm with DKD certificate		
KLD-S1-04	Spectral Irradiance calibration within the wavelength range 250 to 1100 nm with DKD certificate		
KLD-S1-05	Spectral Irradiance calibration within the wavelength range 400 to 2500 nm with DKD certificate		
KLD-S1-06	Spectral Irradiance calibration within the wavelength range 250 to 2500 nm with DKD certificate		
KLD-S1-RP	Set-up charge for non-Gigahertz-Optik sources		
KLW-S1-01	Spectral Irradiance calibration within the wavelength range 250 to 400 nm with factory certificate		
KLW-S1-02	Spectral Irradiance calibration within the wavelength range 400 to 1100 nm with factory certificate		
KLW-S1-03	Spectral Irradiance calibration within the wavelength range 1100 to 2500 nm with factory certificate		
KLW-S1-04	Spectral Irradiance calibration within the wavelength range 250 to 1100 nm with factory certificate		
KLW-S1-05	Spectral Irradiance calibration within the wavelength range 400 to 2500 nm with factory certificate		
KLW-S1-06	Spectral Irradiance calibration within the wavelength range 250 to 2500 nm with factory certificate		
KLW-S1-RP	Set-up charge for non-Gigahertz-Optik sources		

KLW-S2, Spectral Radiant Power (W/nm)

## KLW-S2, KLW-S3 & KLW-S4 Spectral Calibration of Light Sources

Radiant power is the total emitted radiation of light sources such as lamps, lasers, etc.

To measure radiant power the emitted light from the source must be detected independent of emitted direction.

For lamps that emit light in all directions a light integrator such as an integrating sphere or a goniometric scanner is required.

For spot lamps and directional sources, such as lasers, integrating spheres that can collect the light beam through a port in its wall are used.

Gigahertz-Optik's calibration laboratory offers calibration of beam emitter light sources over a restricted power range. Consult the factory to discuss your requirements.



Integrating Sphere for Spot Lamp Measurements

#### Integrating Sphere for Laser Power Measurements

<b>Ordering Inform</b>	Ordering Information		
KLW-S2-01	Spectral Radiant Power of Spot lamps. Contact the factory to discuss calibration details.		
KLW-S2-02	Spectral Radiant Power of monochromatic, directional emitting light sources within the wavelength range 350 to 1100 nm. Maximum beam diameter 10 mm. Maximum power 1000 mW. Factory calibration certificate		
KLW-S2-RP	Set-up charge for non-Gigahertz-Optik sources		

Radiance in a given direction, at a given point of a real or imaginary surface is the radiometric measurement quantity used to calibrate area sources of optical radiation. Gigahertz-Optik's calibration laboratory offers calibration of spectral radiance within the wavelength range 300 nm to 2500 nm.

The calibration is done with a spectral radiometer equipped

## Ordering Information

with a front lens. The spectrometer system is calibrated with an integrating sphere based spectral radiance transfer standard. The photometric quantity, luminance can be calculated using the radiometric calibration values from 380 to 780 nm if required. A factory calibration certificate is supplied.

#### KLW-S3, Spectral Radiance (W/(m<sup>2</sup>sr nm))



Typical set-up to calibrate the spectral radiance of an integrating sphere based uniform light source

Ordering into	Innauon
KLW-S3-01	Spectral Radiance within the wavelength range from 300 to 780 nm in 10 nm steps measured with a double monochromator DC spectrometer with photomultiplier tube. Factory calibration certificate.
KLW-S3-02	Spectral Radiance within the wavelength range from (380) 450 to 1100 nm in 10 nm steps measured with a single monochromator DC spectrometer with silicon detector. Factory calibration certificate.
KLW-S3-03	Spectral Radiance within the wavelength range from 1100 to 1700 nm in 10 nm steps measured with a single monochromator DC spectrometer with InGaAs detector. Factory calibration certificate.
KLW-S3-04	Spectral Radiance within the wavelength range from 1100 to 2500 nm in 50 nm steps measured with a single monochromator AC spectrometer with PbS detector. Factory calibration certificate.
KLW-S3-05	Spectral Radiance within the wavelength range from 300 to 1100 nm (KLW-S3-01 & 02) with factory calibration certificate.
KLW-S3-06	Spectral Radiance within the wavelength range from 300 to 2500 nm (KLW-S3-01, 02 & 04) with factory calibration certificate.
KLW-S3-07	Spectral Radiance within the wavelength range from (380) 450 to 2500 nm (KLW-S3-02 & 04) with factory calibration certificate.
KLW-S3-RP	Set-up charge for non-Gigahertz-Optik sources

#### KLW-S4, Spectral Radiant Intensity (W/(sr nm))

The radiant intensity of a light source, is the emitted light in a given direction. Radiant intensity is the radiometric measurement quantity used to calibrate directionally emitted light from lamps. Radiant intensity is measured with a irradiance detector equipped with precise front aperture then calculated from the measured irradiance and the solid angle resulting from the light source to aperture distance and the aperture diameter. A factory calibration certificate is provided.

Ordering Information		
KLW-S4-01	Spectral Radiant Intensity of Spot lamps. Contact the factory to discuss calibration details.	
KLW-S4-RP	Set-up charge for non-Gigahertz-Optik sources	

## KLW-R & KLW-P Integral Radiometric & Photometric Calibration of Light Sources

#### **Integral Radiometric Calibrations**

#### KLW-R1, Irradiance (W/m<sup>2</sup>)

Irradiance is measured at a specified distance from the light source with a calibrated spec- tral radiometer. The spectrome- ter itself is calibrated in refer- ence to a spectral irradiance		standard which ensures the traceability of the calibration. The integral irradiance is calcu- lated from the measured spec- tral data for the specified wave- length range.	With the current lab irradiance standard lamps available, the spectral radiometer can be calibrated within the wavelength range from 250 to 2500 nm. A factory calibration certificate	is supplied listing the light source data, measurement set- up, traceability and calibration uncertainty.
Ordering Information				
KLW-R1-01	11-01 Irradiance calibration within a specified wavelength range . Contact the factory to discuss calibration details.			
KLW-R1-RP	KLW-R1-RP Set-up charge for non-Gigahertz-Optik sources			

KLW-R2, Radiant Power (W)

Radiant power of spot lamps is measured with a spectral radiometer mounted to an integrating sphere. The spectrometer with integrating sphere is calibrated in reference to a spectral irradiance standard which is

placed at a specified distance to the sphere. The radiant power entering the sphere through a precise aperture in its measurement port is calculated. The integral radiant power is calculated from the

measured spectral data for the specified wavelength range. With the current lab standard lamps available, the spectral radiometer can be calibrated within the wavelength range from 300 to 2500 nm.

A factory calibration certificate is supplied listing the light source data, measurement setup, traceability and calibration uncertainty

Ordering Information	
KLW-R2-01	Radiant power calibration within a specified wavelength range . Contact the factory to discuss calibration details.
KLW-R2-RP	Set-up charge for non-Gigahertz-Optik sources

#### KLW-R3, Radiance (W/(m<sup>2</sup>sr))

Radiance of uniform light sources is measured with a spectral radiometer mounted with a front lens. The spec- trometer with front lens is cali-	The integral radiance is calcu- lated from the measured spec- tral data for the specified wave- length range.	radiance lamps available, the spectral radiometer can be calibrated within the wavelength range from 300 to 2500 nm. A factory calibration certificate	up, traceability and calibration
	With the current lab standard	is supplied listing the light	

#### **Ordering Information** KLW-R3-01 Radiance calibration within a specified wavelength range. Contact the factory to discuss calibration details.

KLW-R3-RP	Set-up charge for non-Gigahertz-Optik sources

## KLW-R4, Radiant Intensity (W/sr)

Radiant intensity of light sources is measured with a spectral radiometer mounted with a precision measurement aperture. The spectrometer is calibrated in reference to a spectral irradiance standard.	ance and the solid angle result-	calculated from the measured spectral data for the specified wavelength range. With the current lab standard lamps available, the spectral radiometer can be calibrated within the wavelength range	from 300 to 2500 nm. A factory calibration certificate is supplied listing the light source data, measurement set- up, traceability and calibration uncertainty.
Ordering Information			

#### KLW-R4-01 Radiant intensity calibration within a specified wavelength range . Contact the factory to discuss calibration details. KLW-R4-RF Set-up charge for non-Gigahertz-Optik sources

#### **Integral Photometric Calibrations**

#### KLW-P1, Illuminance (Ix)

Illuminance of light sources is	calibrated in reference to an
measured with an illuminance	illuminance standard source.
detector and an optometer.	The optometer is calibrated in
The illuminance detector is	reference to a DKD calibrated

current source. A factory calibration certificate is supplied listing the light source data, measurement setup, traceability and calibration uncertainty.

Ordering Information		
KLW-P1-01	KLW-P1-01 Illuminance calibration of light sources. Factory calibration certificate.	
KLW-P1-RP	Set-up charge for non-Gigahertz-Optik sources	

## Calibration Service - Page 151

source.

## KLW-P, KLW-C, KLW-D Photometric, Colorimetric, Directional Calibration of Sources

## **Integral Photometric Calibrations**

#### KLW-P2, Luminous Flux (Im)

Luminous flux of spot lamps is	tector combination is calibrated
measured with an integrating	in reference to an illuminance
sphere, photometric detector	standard lamp which is placed at
and an optometer.	a specified distance to the
The integrating sphere and de-	sphere. The luminous flux enter-

ing the sphere through a precise aperture of the sphere measurement port is then calculated. The optometer is calibrated in reference to a DKD calibrated current

A factory calibration certificate is supplied listing light source data, measurement set-up, traceability and calibration uncertainty.

#### **Ordering Information**

•	
KLW-P2-01	Luminous flux calibration of spot lamps. Contact the factory to discuss calibration details.
KLW-P2-RP	Set-up charge for non-Gigahertz-Optik sources

Luminance is measured with a	brated
luminance detector and an op-	nance
tometer.	optomet
The luminance detector is cali-	ence to

in reference to a lumistandard source. The ter is calibrated in reference to a DKD calibrated current

source A factory calibration certificate is supplied listing light source data, measurement set-up, traceability and calibration uncertainty.

KLW-P3, Luminance (cd/m<sup>2</sup>)

## **Ordering Information**

KLW-P3-RP Set-up charge for non-Gigahertz-Optik sources	KLW-P3-01	Luminance calibration of spot lamps. Factory calibration certificate
	KLW-P3-RP	Set-up charge for non-Gigahertz-Optik sources

#### KLW-P4, Luminous Intensity (cd)

Luminous intensity is measured with an illuminance detector equipped with a precise front aperture and an optometer. The luminous intensity is calcu- lated from the measured illumi	nance and the solid angle result- ing from the light source to aper- ture distance and the aperture diameter. The illuminance detector is cali- brated in reference to an illumi	nance sta optometer ence to a [ source.
lated from the measured illumi-	brated in reference to an illumi-	A factory c

tandard source. The is calibrated in refer-DKD calibrated current

calibration certificate is

supplied listing light source data, measurement set-up, traceability and calibration uncertainty.

#### **Ordering Information** KLW-P4-01 Luminous intensity calibration of spot lamps. Factory calibration certificate KLW-P4-RP Set-up charge for non-Gigahertz-Optik sources

#### **Colorimetric & Directional Calibrations**

#### KLW-CT, Luminous Color (x,y), Color Temperature (K)

The color detector is calibrated The x,y chromaticity values and ence to a DKD calibrated current in reference to an illuminance color temperature of tungsten source. light sources is measured with standard source operated at a a RGB-color detector and an known color temperature. The optometer. optometer is calibrated in refer-

measurement set-up, traceability and calibration uncertainty.

A factory calibration certificate is supplied listing light source data,

## **Ordering Information**

KLW-CT-01 x,y chromaticity values and color temperature calibration of light sources. Factory calibration certificate KLW-CT-RP Set-up charge for non-Gigahertz-Optik sources

#### KLW-ID, Light Intensity Distribution

Uniform light sources based on integrating spheres can be calibrated in regard to their xy luminance/radiance uniformity and hemispherical emittance uniformity (lambertian light source). A luminance detector head with

an optometer is used for the uniformity measurement Precise xy and goniometric positioning stages allows xy and viewing angle alignment of the luminance detector in front of the light emitting area.

The luminance detector is calibrated in reference to a luminance standard source. The optometer is calibrated in reference to a DKD calibrated current source. A factory calibration certificate is

supplied listing light source data, measurement set-up, traceability and calibration uncertainty.

Ordering Information		
KLW-ID-01	Calibration of the xy luminance uniformity of uniform light sources. Factory calibration certificate	
KLW-ID-02	Calibration of the hemispherical luminance uniformity of uniform light sources. Factory calibration certificate	
KLW-ID-03	Calibration of the xy and hemispherical luminance uniformity of uniform light sources. Factory calibration certificate	
KLW-ID-RP	Set-up charge for non-Gigahertz-Optik sources	

**Gigahertz-Optik** 

## KDD-S1 & KDW-S1 Spectral Radiant Power Sensitivity of Light Detectors

BN-9102

## **Calibration Traceability**

Since June 1993, the Gigahertz-Optik calibration laboratory for optical radiation measurement quantities has been accredited by the DKD accreditation institution (registration Number DKD-K-10601) for the calibration of spectral sensitivity of optical radiation detectors within the wavelength range from 248 nm to 1160 nm. Several BN-9102 transfer standards with PTB calibration certificates for the wavelength range from 248 to 1160 nm are available. These reference standards are periodically recalibrated by the PTB. Other detectors are calibrated by comparison measurements to this reference

Besides transfer standards used

## **KDD Calibration with DKD Certificate**

This detector calibration is done by comparison to a PTB reference standard and is documented in an official DKD calibration certificate supplied with the calibrated detector. The complete calibration procedure follows DKD accreditation regulations. During the calibration the detector's operating temperature is stabilized to  $\pm 0.5^{\circ}$ C. Calibrations are offered at the wavelengths listed or in 20 nm steps within the specified wavelength ranges.

for accredited levels calibrations Gigahertz-Optik maintains NIST

calibrated transfer standards for

the wavelength ranges from 200

to 1100 nm and 800 to 1800 nm

which are used for calibrations

requiring factory certificates.





InGaAs standard spectral sensitivity

Measurement	Wavelength	KDD-S1		
Quantity	nm	Measurement Conditions	Relative Measurement Uncertainty	
Spectral Radiant	248.4 ; 265.3 ; 280.4 ; 289.4 ; 302.2 ; 313 ; 334.2 ; 366	1 nW/cm <sup>2</sup> $\leq$ E $\leq$ 10 $\mu$ W/cm <sup>2</sup> 18 °C $\leq$ t $\leq$ 28 °C 1 nm $\leq \Delta\lambda \leq$ 11 nm	± 3%	
Power Sensitivity	380 to 900 in 20 nm steps		± 2%	
	920 to 1040 in 20 nm steps	0.1 μW/cm² ≤ E ≤ 100 μW/cm² 18 °C ≤ t ≤ 28 °C	± 2.5%	
	1060 ; 1080 ; 1100	$1 \text{ nm} \le \Delta \lambda \le 11 \text{ nm}$	± 3%	
	1120 ; 1140 ; 1160		± 4%	

#### **KDW Calibration with Factory Certificate**

Wavelength Dependent Calibration Uncertainty

Calibration of spectral sensitivity with a factory calibration certificate is offered for the wavelength range from 200 nm to 1800 nm in 10 nm increments. The calibration is done by com-

parison to an PTB or NIST traceable transfer standard detector. A factory calibration certificate is supplied listing detector data, measurement set-up, traceability and calibration uncertainty.

wavelength Dependent Calibration Oncertainty				
Measurement	Wavelength	Light Spot	KDW-S1	
Quantity	nm	Diameter	Measurement Conditions	Relative Measurement Uncertainty
	200 to 400 in 10 nm steps		1 nW/cm <sup>2</sup> $\leq$ E $\leq$ 10 $\mu$ W/cm <sup>2</sup> 18 °C $\leq$ t $\leq$ 28 °C 1 nm $\leq \Delta\lambda \leq$ 11 nm	200 - 240 nm ± 7 % 250 - 370 nm ± 4,5 %
Spectral Radiant Power Sensitivity	400 to 1100 in 10 nm steps	3 - 7 mm	0.1 $\mu$ W/cm <sup>2</sup> $\leq$ E $\leq$ 100 $\mu$ W/cm <sup>2</sup> 18 °C $\leq$ t $\leq$ 28 °C 1 nm $\leq \Delta\lambda \leq$ 11 nm	380 - 400 nm ± 3.0 % 410 - 900 nm ± 3.0 % 910 - 1070 nm ± 4.5 %
	1100 to 1800 in 10 nm steps		$0.1 \mu\text{W/cm}^2 \le E \le 100 \mu\text{W/cm}^2$ $18 ^\circ\text{C} \le t \le 28 ^\circ\text{C}$ $2 \text{nm} \le \Delta\lambda \le 22 \text{nm}$	1080 - 1100 nm ± 5 % 1110 - 1800 nm ± 5.5 %

## KDD-S1, KDW-S1, KDW-S2, KDW-S3 & KDW-S4 Calibration of Light Detectors

### KDD-S1 & KDW-S1, Spectral Radiant Power Sensitivity (A/W)

Ordering Info	Ordering Information Calibration with DKD Certificate		
KDD-S1-01	Spectral radiant power sensitivity calibration at all DKD wavelength (see KDD-S1-04) within 248 to 400 nm with DKD certificate		
KDD-S1-02	Spectral radiant power sensitivity calibration at all DKD wavelength (see KDD-S1-04) within 366 to 1160 nm with DKD certificate		
KDD-S1-03	Spectral radiant power sensitivity calibration at all DKD wavelength (see KDD-S1-04) within 248 to 1160 nm with DKD certificate		
KDD-S1-04	Spectral radiant power sensitivity calibration at one of the following wavelength in nm; 248.8, 265.3, 280.4, 289.4, 302.2, 313, 334.2, 366 and 380 to 1160 all 20 nm. DKD calibration certificate		
KDD-S1-05	Spectral radiant power sensitivity calibration at an additional wavelength to KDD-S1-04		
KDD-S1-RP	Set-up charge for non-Gigahertz-Optik detectors		

#### **Ordering Information Calibration with Factory Certificate**

er der nig nitte	
KDW-S1-01	Spectral radiant power sensitivity calibration in 10 nm steps from 200 to 400 nm with factory certificate
KDW-S1-02	Spectral radiant power sensitivity calibration in 10 nm steps from 350 to 1100 nm with factory certificate
KDW-S1-03	Spectral radiant power sensitivity calibration in 10 nm steps from 800 to 1800 nm with factory certificate
KDW-S1-04	Spectral radiant power sensitivity calibration in 10 nm steps from 200 to 1100 nm with factory certificate
KDW-S1-05	Spectral radiant power sensitivity calibration in 10 nm steps from 350 to 1800 nm with factory certificate
KDW-S1-06	Spectral radiant power sensitivity calibration in 10 nm steps from 200 to 1800 nm with factory certificate
KDW-S1-07	Spectral radiant power sensitivity calibration at one wavelength within 200 to 400 nm with factory certificate
KDW-S1-08	Additional wavelength to KDW-S1-07
KDW-S1-09	Spectral radiant power sensitivity calibration at one wavelength within 350 to 1100 nm with factory certificate
KDW-S1-10	Additional wavelength to KDW-S1-09
KDW-S1-11	Spectral radiant power sensitivity calibration at one wavelength within 800 to 1800 nm with factory certificate
KDW-S1-12	Additional wavelength to KDW-S1-11
KDW-S1-RP	Set-up charge for non-Gigahertz-Optik detectors

## KDW-S2, Spectral Irradiance Sensitivity (A/(W/m<sup>2</sup>))

KDW-S3, Spectral Radiance Sensitivity (A/(W/m<sup>2</sup>sr))

Spectral irradiance sensitivity is calibrated with a wavelength tune able monochromatic light source. The light output of the monochromatic light source overfills the active area of the irradiance detector. The spectral irradiance sensitivity of the test device is compared to a spectral irradiance standard detector. A factory calibration certificate is

supplied listing test device data, measurement set-up, traceability and calibration uncertainty.

Ordering Information		
KDW-S2-01	Spectral irradiance sensitivity calibration at one wavelength within 200 to 1100 nm. Factory calibration certificate	
KDW-S2-02	Spectral irradiance sensitivity calibration at an additional wavelength with KDW-S2-01	
KDW-S2-03	Spectral irradiance sensitivity calibration in 10 nm steps from 200 to 400 nm. Factory calibration certificate	
KDW-S2-04	Spectral irradiance sensitivity calibration in 10 nm steps from 350 to 1100 nm. Factory calibration certificate	
KDW-S2-05	Spectral irradiance sensitivity calibration in 10 nm steps from 200 to 1100 nm. Factory calibration certificate	
KDW-S2-RP	Set-up charge for non-Gigahertz-Optik detectors	

Spectral radiance sensitivity of	source.	detector.	and calibration uncertainty.
radiance detectors is calibrated	The spectral radiance sensitivity	A factory calibration certificate is	
with a uniform, wavelength tune	of the test device is compared to	supplied listing test device data,	
able monochromatic light	a spectral radiance standard	measurement set-up, traceability	

# Ordering Information KDW-S3-01 Spectral radiance sensitivity calibration of radiance detectors. Contact the factory to discuss your calibration requirement. KDW-S3-RP Set-up charge for non-Gigahertz-Optik detectors

#### KDW-S4, Spectral Radiant Intensity Sensitivity (A/(W/sr))

Spectral radiant intensity is	from the measured irradiance	ameter.	and calibration uncertainty.
measured with spectral irradi-	and the solid angle resulting	A factory calibration certificate is	
ance detectors. The spectral	from the light source to aperture	supplied listing test device data,	
radiant intensity is calculated	distance and the aperture di-	measurement set-up, traceability	

Ordering Information	Ordering Information	
KDW-S4-01	Spectral radiant intensity sensitivity calibration of irradiance detectors. Contact the factory to discuss your calibration requirement.	
KDW-S4-RP	Set-up charge for non-Gigahertz-Optik detectors	

## KDW-R1, KDW-R2, KDW-R3, KDW-R4 & KDW-P1 Integral Calibration of Detectors

#### **Integral Radiometric Calibration**

#### KDW-R1, Radiant Power Sensitivity (A/W)

brated using a source which in tector through a	precise aperture the detectors	irradiance at the aperture is measured with a spectral radi- ometer. calibrated for absolute irrradiance. The integral radiant power is calculated from the spectral data within the specified	wavelength range. The radiant power entering the detector is calculated using the known aper- ture area. A factory calibration certificate is supplied listing test device data,	measurement set-up, traceability and calibration uncertainty.
Ordering Inform	nation			
KDW-R1-01	Radiant power s	sensitivity within a specified wavelength	n range. Contact the factory to discuss	your calibration requirement
	<u> </u>			

KDW-R1-RP Set-up charge for non-Gigahertz-Optik detectors

The spectral sensitivity of the sample detector is requested. If not available the spectral sensitivity must be measured. See KDW-S1

#### KDW-R2, Irradiance Sensitivity (A/(W/m<sup>2</sup>))

Irradiance sensitivity is calibrated with broadband light source which irradiates the irradiance detector. The irradiance at the detector is measured with a spectral radiometer calibrated in irradiance. The integral irradiance is calculated from the spectral data within the specified wavelength range. A factory calibration certificate is supplied listing test device data,

measurement set-up, traceability and calibration uncertainty.

#### **Ordering Information**

KDW-R2-01 Irradiance sensitivity calibration within a specified wavelength range. Contact the factory to discuss your calibration requirement KDW-R2-RP Set-up charge for non-Gigahertz-Optik detectors The spectral sensitivity of the sample detector is requested. If not available the spectral sensitivity must be measured. See KDW-S1

#### KDW-R3, Radiance Sensitivity (A/(W/m<sup>2</sup>sr))

The radiance sensitivity of radi-	source is calibrated with an ab-	spectral data within the specified	measurement set-up, traceability and calibration uncertainty.
ance detectors is calibrated with	solute calibrated radiance spec-	wavelength range.	
a uniform light source.	tral radiometer. The integral	A factory calibration certificate is	
The spectral radiance of the light	radiance s calculated by the	supplied listing test device data,	
Ordering Information			

#### KDW-R3-01 Radiance sensitivity calibration within a specified wavelength range. Contact the factory to discuss your calibration requirement KDW-R3-RP Set-up charge for non-Gigahertz-Optik detectors

The spectral sensitivity of the sample detector is requested. If not available the spectral sensitivity must be measured. See KDW-S1

#### KDW-R4, Radiant Intensity Sensitivity (A/(W/sr))

#### Ordering Information

ordering morn	Sidering monitation	
KDW-R4-01	Radiant intensity calibration of irradiance detectors. Contact the factory to discuss your calibration requirement	
KDW-R4-RP	Set-up charge for non-Gigahertz-Optik detectors	
The spectral sensitivity of the sample detector is requested. If not available the spectral sensitivity must be measured. See KDW-S1		

#### **Integral Photometric Calibration**

## KDW-P1, Luminous Flux Sensitivity (A/Im)

combination of an integrating sphere with photometric detec-	broadband light source which generates a known luminous flux
Luminous flux detectors are a	

inside the sphere. A factory calibration certificate is supplied listing test device data, measurement set-up, traceability and calibration uncertainty.

Ordering Information	Ordering Information	
KDW-P1-01	Luminous flux sensitivity within a specified wavelength range. Contact the factory to discuss your calibration requirement	
KDW-P1-RP	Set-up charge for non-Gigahertz-Optik detectors	
The spectral sensitivity of the sample detector is requested. If not available the spectral sensitivity must be measured. See KDW-S1.		

## KDW-P2, KDW-P3 & KDW-P4 Photometry; KRW & KTW Reflectance & Transmittance

.....

#### KDW-P2, Illuminance Sensitivity (A/Ix)

Illuminance sensitivity is calibrated by comparing the measured values of the test detector to those of an illuminance standard detector. The reference source is a standard Illuminant A

- ·

1.11  source at 2856K. A factory calibration certificate is supplied listing the test device

data, the measurement set-up, the traceability and the calibration uncertainty.

#### **Ordering Information** KDW DO OL ....

KDW-P2-01	IIIuminance sensitivity calibration. Factory calibration certificate
KDW-P2-RP	Set-up charge for non-Gigahertz-Optik detectors
The spectral sensitivity of the sample detector is requested for the calibration uncertainty evaluation. If not available the spectral sensitivity must b measured. See KDW-S1	

Luminance sensitivity is calibrated by comparing the measured values of the test detector and a luminance standard detector. The reference source is a luminance light source at 2800K.

is calculated from the measured

illuminance and the distance

light source to detector aperture

A factory calibration certificate is supplied listing the test device data, the measurement set-up,

the traceability and the calibration uncertainty.

the traceability and the calibra-

Ordering Information	Ordering Information	
KDW-P3-01	Luminance sensitivity calibration. Factory calibration certificate	
KDW-P3-RP	Set-up charge for non-Gigahertz-Optik detectors	
The spectral sensitivity of the sample detector is requested for the calibration uncertainty evaluation. If not available the spectral sensitivity must be measured. See KDW-S1		

#### KDW-P4, Luminous Intensity Sensitivity (A/cd)

tion uncertainty.

KDW-P3, Luminance Sensitivity (A/(cd/m<sup>2</sup>))

Luminous intensity is derived from illuminance detector measurements. The luminous intensity

**Ordering Information** KDW-P4-01 Luminous intensity calibration. Contact the factory to discuss your calibration requirement. KDW-P4-RP Set-up charge for non-Gigahertz-Optik detectors The spectral sensitivity of the sample detector is requested for the calibration uncertainty evaluation. If not available the spectral sensitivity must be measured. See KDW-S1

#### KRW & KTW, Spectral Reflectance and Spectral Transmittance Calibration

Gigahertz-Optik's calibration laboratory offers calibration of spectral reflectance and spectral transmittance.



**Spectral Reflectance:** 

A double beam photometer with directed 8 degree sample irradiation and hemispherical measurement set-up is used for the calibration of the spectral reflectance. The sample is irradiated with a collimated monochromatic light beam of 8 x 15 mm. The tunable wavelength range is 250 to 2500 nm.

A factory calibration certificate is

supplied listing the test device

data, the measurement set-up,

The photometer is calibrated with spectral reflectance standards which are calibrated by the NRC and traceable calibrated to NIST. A factory calibration certificate is supplied which confirms the reference data of the sample, the calibration measurement values, the calibration uncertainty and the traceability of the calibration.

#### **Spectral Transmittance:**

A very low stray-light double mo-

nochromator with collimated light beam is used to irradiate the sample for the calibration measurement. The tunable wavelength range is 350 to 1100 nm. The light beam is focused to a flat field silicon photodiode. The transmittance measurement set-up is useful for non-diffuse transmitting samples only.

A factory calibration certificate is supplied listing reference data of the sample, calibration measurement values. calibration uncertainty and traceability.





Principal Calibration set-up Spectral Reflectance

Principal Calibration set-up Spectral Transmittance

## Page 156 - Calibration Service

## **Reflectance & Transmittance; AM Measurement and Qualification Service**

Spectral Refl	Spectral Reflectance & Transmittance Ordering Information		
KRW-S1-01	Calibration of 8/D spectral reflectance in 50 nm steps within the wavelength range 250 to 2500 nm. Factory calibration certificate		
KRW-S1-02	Calibration of 8/D spectral reflectance in 1 nm steps within the wavelength range 250 to 2500 nm. Factory calibration certificate		
KRW-S1-RP	Set-up charge for non Gigahertz-Optik samples		
KTW-S1-01	Calibration of spectral transmittance in 1 nm steps from 350 to 1100 nm of non diffuse samples. Factory calibration certificate		
KTW-S2-01	Calibration of spectral transmittance in 50 nm steps from 250 to 2500 nm of non diffuse samples. Factory calibration certificate		
KTW-S1-RP	Set-up charge for non Gigahertz-Optik samples		

#### **Measurement and Qualification Service**

With its technical expertise and experience in light measurements and calibrations Gigahertz-Optik is regularly asked for on-site service measurements

and qualification. Our engineers are specialists in several applications within the thematic Measurement of Light and Measurement with Light.

On this page a short overview of our capabilities is provided. If you are interested in our measurement and qualification service please contact the factory to

Toni Gugg-Helminger, technical

director of Gigahertz-Optik. He is

well known in the field of UV

radiometry through his activities

in the "Thematic Network for

Ultraviolet Measurements"

discuss your requirements.

#### AM-001 UV-VIS Spectral Irradiance Measurements

Gigahertz-Optik has been active in spectral irradiance measurements since 1986.

Based on a mobile double monochromator spectral radiometer, spectral irradiance measurements in the UV-VISIBLE wavelength range from 250 nm up to 780 nm are offered. Measurement strategy, actual calibration and documentation are set-up and performed by

#### AM-003 Laser Classification with TÜV Certificate

Lasers, especially those that cannot be totally shielded from view in the application, need to be classified according to the

European standard EN60825-1: 1994 + A11: 1996 + A2: 2001. Gigahertz-Optik offers laser classification service in coopera-

tion with the TUEV Bayern for low intensity lasers in the range from 350 to 1070 nm. The certificate includes a description of the measurement procedure as well as the laser

committee for safe use of optical

radiation. Since 2001 he is also

publicity appointed expert for

Ultraviolet radiation measure-

ments.

classification.

а

#### AM-004 UV-VISIBLE-NIR Transmission Measurements on XXL Samples

Commercially available photometers are designed for measurement of small sample sizes only. Spectral transmittance measurements on large size samples are not possible without cutting the sample into small pieces that can be accepted by the photometer.

Based on a double monochromator and a tunable light source from 250 to 780 nm used to irradiate the sample with a collimated light beam, Gigahertz-Optik's calibration set-up allows transmission measurement of any size sample.

The detector is built with a 100 mm diameter integrating sphere made out of OP.DI.MA. (see chapters OP.DI.MA. and Integrating Spheres) allowing measurements in the deep ultraviolet spectral range.

The very low stray-light level of the double monochromator and the use of very sensitive photo multiplier detectors enables optical density measurements down to OD4 at wavelength of

250 nm The certificate includes the description of the measurement procedure, spectral transmittance data and comments about the measurement un-





_	
I	Introduction
II II 1	Properties and Concepts of Light and Color
II.1	The wavelength range of optical radiation
II.2. II.3.	Velocity, amplitude, wavelength, and frequency - the measures of a wave
II.3. II.4.	Spectra of various light sources Basic radiometric quantities
II.4. II.4.a.	Definition of solid angle
II.4.a. II.4.b.	Radiant power or radiant flux $\Phi_{e}$
II.4.0. II.4.c.	Radiant intensity $I_{a}$
II.4.d.	Radiance L <sub>e</sub>
II.4.e.	Irradiance E <sub>e</sub>
II.4.f.	Radiant exitance M <sub>e</sub>
II.4.g.	Spectral radiant power $\Phi_1(\lambda)$ , spectral radiant intensity $I_1(\lambda)$ , spectral radiance $L_1(\lambda)$ , spectral irradiance $E_1(\lambda)$ , and spectral radiant
II.5.	Calculation of radiometric quantities - Examples
II.5.a.	Example 1: Isotropic point source
II.5.b.	Example 2: Spot source
II.5.c.	Example 3: The Lambertian surface
II.6.	Spectral sensitivity of the human eye
II.7.	Basic photometric quantities
II.7.a.	Luminous flux $\Phi_{v}$
II.7.b.	Luminous intensity I <sub>v</sub>
II.7.c.	Luminance L <sub>v</sub>
II.7.d.	Illuminance E <sub>v</sub>
II.7.e.	Luminous exitance M <sub>v</sub>
II.7.f.	Conversion between radiometric and photometric quantities
II.8.	Reflection, Transmission, and Absorption
II.8.a.	Reflectance $\rho$ , Transmittance $\tau$ , and Absorptance $\alpha$
II.8.b.	Radiance coefficient q <sub>e</sub> , Bidirectional reflectance distribution (BRDF)
II.9.	The perception of color
II.9.a.	Physiological background Calor addition
II.9.b. II.9.c.	Color addition Color subtraction
II.9.C. II.10.	Colorimetry
II.10. II.10.a.	RGB and XYZ color matching functions
II.10.a. II.10.b.	The $(x,y)$ - and $(u',v')$ -chromaticity diagrams
II.10.c.	Correlated color temperature
III.	Measurement of light with integral detectors
III.1.	The detector's input optics and its directional sensitivity
III.1.a.	Integrating spheres used with integral detectors
III.1.b.	Measurement of radiant power and luminous flux
III.1.c.	Measurement of irradiance and illuminance
III.1.d.	Measurement of radiant and luminous intensity
III.1.e.	Measurement of radiance and luminance
III.1.f.	Measurement of reflection and transmission properties
III.2.	Spectral sensitivity of an integral detector
III.2.a.	Monochromatic radiometry
III.2.b.	Polychromatic radiometry
III.2.c.	Photometry
III.2.d.	Colorimetry
III.3.	The detector's time behaviour
III.4.	The detector's dynamic range
III.5.	Calibration of integral Detectors
III.5.a.	Traceability: an Unbroken Chain of Transfer Comparisons
III.5.b. III.5.c.	ISO/IEC/EN 17025 (formerly ISO Guide 25 and EN45001) Calibration Quantities
III.5.c. III.5.d.	Calibration Standards
IV.	Detector Signal Measurement
V.	Theory and applications of integrating spheres
V.1.	Theory of the ideal integrating sphere
V.2.	Real integrating spheres
VI.	Applications for Light Measurement in Medicine, Technology, Industry and Environmental Science
VI.1.	Phototherapy and Radiation Protection
VI.2.	Plant physiology
VI.3.	UV-Disinfection and Lamp Control
VI.4.	UV Curing and UV Processing
VI.5.	Colorimetry
VI.6.	Photostability
VI.7.	Telecommunication
VI.8.	Lasers & LEDs Measurements
VI.9.	Nondestructive testing
VII.	Appendix
VII.2.	Summary of radiometric and photometric quantities
VII.3.	Sources and references for figures
VII.4. VII.4.a.	Most relevant CIE- DIN- and ISO-publications and regulations DIN Publications
VII.4.a. VII.4.b.	CIE Publications
VII.4.0. VII.5.	National Calibration Laboratories

## Page 158 - Tutorials

## Introduction, Properties and Concepts of Light and Color

#### I. Introduction

Light, or the visible part of the electromagnetic radiation spectrum, is the medium through which human beings receive a major portion of environ-mental information. Evolution has optimized the human eye into a highly sophisticated sensor for electromagnetic radiation. Joint performance between the human eye and visual cortex, a large part of the human brain, dwarfs recent technical and scientific develop-

ments in image processing and pattern recognition. In fact a major part of the information flow from external stimuli to our brain is transferred visually. Photometry deals with the measurement of this visible light energy.

However, optical radiant energy not only encompasses visible 'light' but radiation invisible to the human eye as well. The term optical is used because this radiation follows the laws of geometrical

#### optics.

Radiometry deals with the measurement of all optical radiation inclusive of the visible portion of this radiant energy.

This tutorial is an introduction to the basic nature of light and color, radiometric, photometric, colorimetric, reflection and transmission principles, quantities, symbols and units. Sections covering a sampling of current applications, detectors, electronics and calibration are included. A list of reference sources is provided for future study.

🕒 Gigahertz-Optik

SI (Système International) units are used throughout these tutorials. Many international organizations including the CIE (Commission Internationale de l'Eclairage) have adopted this system of units exclusively. The terminology used follows that of the CIE International Lighting Vocabulary.

#### **II. Properties and Concepts of Light and Color**

Thorough knowledge of the physical nature of light and light perception provides the foundation for a comprehensive understanding of optical measurement techniques. Yet, from a practical point of view there is little necessity to fully understand formation and propagation of light as an electromagnetic wave as long as the reader accepts wavelength as the most important parameter describing the quality of light. The human eye perceives light with different wavelengths as different colors (figure II.1.), as long as the variation of wavelength

is limited to the range between 400 nm and 800 nm (1 nm = 1 nanometer =  $10^{-9}$  m). In the optical range of the electromagnetic spectrum, wavelength is sometimes also given in Ångstrøm (Å=  $10^{-10}$  m). Outside this range, our eye is insensitive to electromagnetic radiation and thus we have no perception of ultraviolet (UV, below 400 nm) and infrared (IR, above 800 nm) radiation.





types of skin can-

cer. As the strength

of radiation effects

on matter does not

change abruptly

with wavelength,

authors

different

#### II.1. The wavelength range of optical radiation



Fig. II.2. Wavelength ranges of electromagnetic radiation.

According to DIN 5031, the term "optical radiation" refers to electromagnetic radiation in the wavelength range between 100 nm and 1 mm. The terms "light" and "visible radiation" (VIS) refer to the wavelength range between 400 nm and 800 nm, which can be perceived by the human eye. Optical radiation with wavelengths shorter than 400 nm is called ultraviolet (UV) radiation and is further subdivided in UV-A, UV-B and UV-C ranges. Similarly, infrared (IR) radiation covers the wavelength range above 800 nm and is subdivided in IR-A, IR-B and IR-C ranges (DIN 5031, part 7).

It must be emphasized that this classification of electromagnetic radiation is a matter of convention and is not based on qualitative properties of the electromagnetic wave itself. Instead, it is largely motivated by the effects of the electromagnetic wave on matter. For instance, the UV-B range covers the wavelengths in the solar spectrum which is particularly responsible for DNA damage and thus causes melanoma and other



main standardization authorities, the CIE and the DIN, agree with their definition Action of the UVA range between 315 nm and 400 nm.

Spectral sensitivity functions, such as the CIE photopic response, have also been defined in other biological effects of optical radiation, such as DNA damage, formation of erythema (sunburn) and of nonmelanoma skin cancer, tanning of the human skin and the photosynthesis process in green plants, have been studied and quantified by spectral sensitivity functions (Fig. ). Especially when related to certain biological reactions, the term "action spectrum" is often used instead of "spectral sensitivity".

Action spectra for selected UV-related effects



Fig. II.3. Action spectra for various biological reactions to UV radiation

#### II.2. Velocity, amplitude, wavelength, and frequency - the measures of a wave

Like all other waves (waves in a string, water waves, sound, earthquake waves ...), light and electromagnetic radiation in general can be described as a vibration (more general: a periodical change of a certain physical quantity) that propagates into space (Fig. II.4.a). The propagation is caused by the fact that the vibration at a certain location influences the region next to this location. For example in the case of sound, the alternating rarefaction and compression of air molecules at a certain location results in periodic changes in the local pressure, which in turn causes the movement of adjacent air molecules towards or away from this location (Fig. II.4.b).

- The **amplitude** is the maximum disturbance of the medium from its equilibrium. In the case of a wave in a horizontal string (Fig. II.4.a), this value is identical with half of the vertical distance between the wave's crest and its trough. In the case of a pressure wave in air (,,sound", Fig. II.4.b), the amplitude is half of the pressure difference between rarefaction and compression.
- The wavelength λ is the distance between two adjacent crests (or troughs) and is given in meters.
- The **period T** of a wave is the time that elapses between the arrival of two consecutive crests (or troughs) at a certain location X. This definition is

obvious that the period of a wave completely defines its frequency and vice versa. The relation between these quantities is given by

v = 1 / T

If we look at a wave as a process that is periodical in space and in time, we can regard the wavelength  $\lambda$  as the distance between two repetitions of the process in space and the period T as the "distance" between two repetitions of the process in time.

A basic relation between wavelength, frequency and velocity results from the following consideration:



In the case of an electromagnetic wave, the mechanism of propagation involves mutual generation of periodically varying electric and magnetic fields and is far more difficult to understand than sound. Yet, the result still can be described as a periodic change of a physical quantity (the strength of the electric and the magnetic field) propagating into space. The velocity of this propagation is generally abbreviated with the letter c (unit: meters per second, m/s) and depends on the nature of the wave and on the medium (see Table II.Ibelow). In order to describe the basic properties of a wave, the following quantities have been defined for all kinds of waves:

identical with the statement that the period is the time the vibration at X takes to complete a full cycle from crest to trough to crest. The period of a wave is given in seconds.

The frequency v of a wave is the number of vibration cycles per second at a certain location X. The unit of frequency is Hertz (Hz) and 1 Hz is the reciprocal of 1 second. As an example, a wave with a period T = 0.25 s takes ¼ of a second to complete a full vibration cycle (crest - trough - crest) at a certain location and thus performs four vibrations per second. Hence its frequency is f = 4 Hz. From this example it is

a a string. (b) Formation and propagation of a compression wave in air, a phenomenon colloquially called sound During the time span a crest needs

build the distance of one wavelength  $\lambda$  from location X to location Y (Fig. II.4.a), the next crest arrives at location X. Thus, this time span is identical with the wave's period T. But when a crest needs the time span T to travel the distance  $\lambda$ , its velocity c amounts to

When a wave passes from one  $c = \lambda / T = \lambda . v$  Equ. II.1

medium to another, its frequency remains the same. If the velocities of the wave in the two media differ, the wavelengths in the two media also differ as a consequence of equation II.1..

As the frequency of a wave does not depend on the medium the wave is passing, it is more convenient to use frequency instead of wavelength to characterize the wave. In acoustics, this is common practice - in most cases the pitch of sound is characterized by its frequency instead of its wavelength in a certain medium (for example air). In optics, the situation is different: In most cases wavelength is used instead of frequency, although this leads to a certain complication: For example, green light has a wavelength of 520 nm in vacuum, but in water its velocity is smaller by a factor of 1.33 and thus, in water the same green light has a wavelength of only 520 / 1.33 = 391.0 nm. Hence, if we want to characterize a wave by its wavelength, we also have to state for which medium the actual wavelength value is given. According to CIE regulations, which are also applied throughout this tutorial, the term "wavelength" refers to "wavelength in air" unless otherwise stated. However, when applying the given wavelength figures to light passing through a medium other than vacuum, one should keep in mind that the light's wavelength changes according to the relation

 $\begin{array}{l} \lambda_{Medium} \,=\, \lambda_{Vacuum} \,\, / \,\, n_{Medium} \,=\, \lambda_{Air} \,\, \cdot \\ n_{Air} \,\, / \,\, n_{Medium} \end{array}$ 

with

$$\begin{split} n_{Air} = c_{Vacuum} \, / \, c_{Air} \ and \ n_{Medium} = \\ c_{Vacuum} \, / \, c_{Medium} \end{split}$$

 $n_{Medium}$  is called the medium's index of refraction and is more commonly used to specify the optical properties of a material than  $c_{Medium}$ .

	Sound	Optical (electromagnetic) radiation		
		at λ= 434 nm	at λ= 589 nm	at λ= 656 nm
in vacuum	-	299792 km/s (n = 1)		
in air	340 m/s	299708 km/s (n = 1.000280)	299709 km/s (n = 1.000277	299710 km/s (n = 1.000275)
in water	1500 m/s	299708 km/s (n = 1.340)	224900 km/s (n = 1.333)	225238 km/s (n = 1.331)

Table II.I Velocities of sound and light in air and in water. For optical radiation, the respective index of refraction is given in parenthesis

## Page 160 - Tutorials

## Properties and Concepts of Light and Color

#### **II.3.** Spectra of various light sources

A spectrum generally describes the variation of a certain physical quantity as a function of wavelength. The term "spectrum" without any further specifications refers to the quantification of the monochromatic intensity as a function of wavelength (the term "spectrum" is also used for other (physical) quantities apart of intensity, but is then always used with a specific prefix. As an example, the strength of a biological reaction (for example erythema - see § VI.1) to light with different wavelengths is described by an "action spectrum"). As an example, the next figure shows spectra of an incandescent bulb, natural sunlight and two types of discharge lamps.

When examining spectral intensity distributions of various light sources, it is possible to distinguish four significant types. These are:

- Monochromatic radiation
- Near monochromatic radiation
- Continuous spectra
- Band spectra

Typical sources of monochromatic radiation are lasers and the output signal from monochromators with narrow bandwidths. Typical sources of near monochromatic radiation are light emitting diodes and band pass filtered sources.

If a mixture of radiation covers a relatively large range of wavelengths without gaps, this radiation has a continuous spectrum. Typical examples of continuous radiation spectra are direct and diffuse sunlight and light emitted by incandescent bulbs. On the other hand, in a band spectrum there are gaps separating individual regions of radiation. If a spectrum has a number of lines of monochromatic intensity,

it is called a line

spectrum. Typical sources emitting a line spectrum are gaseous discharge lamps, such as helium or



ORTH SKY 10.000





Fig. II.5. Emission spectra of natural light from the sun and the sky and of artificial light from incandescent bulbs at different temperatures, from a mercury vapor lamp and from a multi-vapor lamp.

300

450 500

xenon lamps, and metal vapor lamps, such as the mercury vapor lamp. Multi-vapor discharge lamps are used to achieve a more uniform spectral distribution (see Fig. II.5.).

WAVELENGTH - NANOMETERS

550 600 650

700

### **II.4. Basic radiometric quantities**

The whole discipline of optical measurement techniques can be roughly subdivided into the two areas of **photometry** and **radiometry**. Whereas the central problem of photometry is the determination of optical quantities closely related to the sensitivity of the human eye (see § II.6.), radiometry deals with the measurement of energy per time ( = power, given in watts) emitted by light sources or impinging on a particular surface. Thus,

the units of all radiometric quantities are based on watts (W). According to CIE regulations, symbols for radiometric quantities are denoted with the subscript "e" for "energy". Similarly, radiometric quantities given as a function of wavelength are labeled with the prefix "spectral" and the subscript " $\lambda$ " (for example spectral radiant power  $\Phi_{\lambda}$ ).

**Remark:** The definitions of radiometric quantities cannot be under-

Equ. II.2

stood without a basic comprehension of differential quantities. For an intuitive understanding of these quantities, which is the main purpose of this paragraph, the differential quantities  $d\lambda$ , dA and  $d\Omega$  can be regarded as tiny intervals or elements  $\Delta\lambda$ ,  $\Delta A$  and  $\Delta\Omega$  of the respective quantity. As a consequence of the fact that these intervals or elements are very small, radiometric quantities can be considered constant over the range defined by d $\lambda$ , dA and/or d $\Omega$ . Similarly, d $\Phi_e$ , dI<sub>e</sub>, dL<sub>e</sub> and dE<sub>e</sub> can be regarded as small portions which add up to the total value of the respective quantity. In paragraph II.5., the concept of differential quantities and integral calculus is briefly explained for spectral radiometric quantities.

## II.4.a. Definition of solid angle

The geometric quantity of a **solid angle**  $\Omega$  quantifies a part of an observer's visual field. If we imagine an observer located at point P, his full visual field can be described by a sphere of arbitrary radius r (see Fig.II.). Then, a certain part of this full visual field defines an area A on the sphere's surface and the solid angle  $\Omega$  is defined by

#### $\Omega = A \ / \ r^2$

As the area A is proportional to r<sup>2</sup>, this fraction is independent of the actual choice of r.

If we want to calculate the solid angle determined by a cone, as shown in Fig.II.area A is the area of a spherical calotte. However, as the solid angle is not only defined for conical parts of the full visual field, area A can be any arbitrary shape on the sphere's surface.

Although  $\Omega$  is dimensionless, it is common to use the unit **steradian** (sr). The observer's total visual field is described by the whole surface of the sphere, which is given by  $4\pi r^2$ , and thus covers the solid angle

$$\Omega_{\text{total}} = 4\pi r^2 / r^2 = 4\pi \text{ sr} = 12.57 \text{ s}$$



Fig.II.6. The solid angle  $\Omega$  quantifies a certain part of the visual field, seen by an observer located at P

## 🖲 Gigahertz-Optik

Properties and Concepts of Light and Color

#### II.4.b. Radiant power or radiant flux $\Phi_e$

**Radiant power**  $\Phi_e$  is defined by the total power of radiation emitted by a source (lamp, light emitting diode, etc.), transmitted through a surface or impinging upon a surface. Radiant power is measured in watts (W). The definitions of all other radiometric quantities are based on radiant power. If a light source emits uniformly in all directions, it is called an isotropic light source.

Radiant power characterizes the output of a source of electromag-

#### II.4.c. Radiant intensity Ie

**Radiant intensity**  $I_e$  describes the radiant power of a source emitted in a certain direction. The source's (differential) radiant power d  $\Phi_e$  emitted in the direction of the (differential) solid angle element d  $\Omega$  is given by

$$d\Phi_e = I_e d\Omega$$

and thus

$$\Phi_e = \prod_{4\pi} I_e d\Omega$$

#### II.4.d. Radiance L<sub>e</sub>

Radiance  $L_e$  describes the intensity of optical radiation emitted or reflected from a certain location on an emitting or reflecting surface in a particular direction (the CIE definition of radiance is more general. Within the frame of this tutorial, the most relevant application of radiance describing the spatial emission characteristics of a source is discussed). The radiant power d  $\Phi_e$  emitted by a (differential) surface element dA in the direction of

#### II.4.e. Irradiance E<sub>e</sub>

**Irradiance**  $E_e$  describes the amount of radiant power impinging upon a surface per unit area. In detail, the (differential) radiant power d  $\Phi_e$  upon the (differential) surface element dA is given by

$$d\Phi_e = E_e dA$$

Generally, the surface element can be oriented at any angle towards the direction of the beam. However, irradiance is maximised when the surface element is perpendicular to the beam:

 $d\Phi_e = E_{e,normal} dA_{normal}$ 

netic radiation only by a single number and does not contain any information on the spectral distribution or the directional distribution of the lamp output.

Fig. II.7. The radiant power of  $\Phi_e$  of a light source is given by its total emitted radiation.





Fig. II.8. Typical directional distribution of radiant intensity for an incandescent bulb.

the (differential) solid angle element  $d\Omega$  is given by

$$d\Phi_e = L_e \cos(\vartheta) dA d\Omega$$

Equ.II3

Equ.II.5

Thus,

In this relation,  $\vartheta$  is the angle between the direction of the solid angle element d $\Omega$  and the normal of the emitting or reflecting surface element dA.

Note that the corresponding area

element dA normal, which is oriented

perpendicular to the incident beam,

 $dA_{normal} = \cos(\vartheta) dA$ 

with  $\vartheta$  denoting the angle between the beam and the normal of dA, we

 $E_e = E_{e,normal} \cos(\vartheta)$ 

The unit of irradiance is W/m<sup>2</sup>.

is given by

get

From the definition of radiant intensity  $I_e$  it follows that the differential radiant intensity emitted by the differential area element dA in a certain direction is given by

$$dI_e = L_e \cos(\vartheta) dA$$

 $I_e = \prod_{\substack{\text{emitting}\\ \text{surface}}} L_e \cdot \cos(\vartheta) dA$ Equ.II.4

whereby  $\vartheta$  is the angle between the emitting surface element dA and the direction for which  $I_e$  is calculated.

The unit of radiance is  $W/(m^2.sr)$ .



Fig. II.9 – Irradiance is defined as incident radiant power  $d\Phi_e$  per surface area element dA.at P

## Page 162 - Tutorials

## Properties and Concepts of Light and Color

#### II.4.f. Radiant exitance M<sub>e</sub>

**Radiant exitance**  $M_e$  quantifies the radiant power per area, emitted or reflected from a certain location on a surface. In detail, the (differential) radiant power  $d\Phi_e$  emitted or reflected by the surface element dA is given by

 $d\Phi_e = M_e dA$ 

From the definition of radiance follows that the (differential) amount radiant exitance  $dM_e$  emitted or reflected by a certain location on a surface in the direction of the (differential) solid angle element  $d\Omega$  is given by

$$dM_e = L_e \cos(\vartheta) d\Omega$$

and consequently

$$M_e = \prod_{2\pi \, sr} L_e \, \cos(\vartheta) \, d\Omega$$

The integration is per- Equ.II6 formed over the solid angle of  $2\pi$  steradian corresponding to the directions on one side of the surface and  $\vartheta$  denotes the angle

between the respective direction and the surface's normal. The unit of radiant exitance is  $W/m^2$ . In some particular cases,  $M_e=E_e$  (see § II.8.a).

## II.4.g. Spectral radiant power $\Phi_{\lambda}(\lambda)$ , spectral radiant intensity $I_{\lambda}(\lambda)$ , spectral radiance $L_{\lambda}(\lambda)$ , spectral irradiance $E_{\lambda}(\lambda)$ , and spectral radiant exitance $M_{\lambda}(\lambda)$

The radiometric quantities discussed above are defined without any regard to the wavelength(s) of the quantified optical radiation. In order to quantify not only the absolute amount of these quantities but also the contribution of light from different wavelengths, the respective spectral quantities are defined. Spectral radiant power is defined as a source's radiant power per wavelength interval as a function of wavelength. In detail, the source's (differential) radiant power d  $\Phi_e$  emitted in the (differential) wavelength interval between  $\lambda$  and  $\lambda$ +d  $\lambda$  is given by

$$d\Phi_e = \Phi_\lambda(\lambda) d\lambda$$

This equation can be visualised geometrically (see Fig. II.10.). As  $d\lambda$  is infinitesimally small, spectral radiant power  $\Phi_{\lambda}(\lambda)$  is approximately constant in the interval between  $\lambda$  and  $\lambda$ + $d\lambda$ . Thus, the product  $\Phi_{\lambda}(\lambda) d\lambda$  equals the area under the graph of  $\Phi_{\lambda}(\lambda)$  in the interval between  $\lambda$  and  $\lambda$ + $d\lambda$ . This area describes the contribution of this very wavelength interval to the total value of radiant power  $\Phi_{e}$ , which is graphically represented by the total area under the graph of spectral radiant power  $\Phi_{\lambda}(\lambda)$ . Mathematically, this can be expressed by the integral

$$\Phi_e = \int_0^\infty \Phi_\lambda(\lambda) d\lambda$$

The unit of spectral radiant power is  $W\!/nm$  or  $W\!/\text{\AA}$ 

The other spectral quantities are defined correspondingly and their units are given by the unit of the respective quantity, divided by nm or Å (see

Table VII.IV and Table VII.V). Generally, a radiant quantity can be calculated from the respective spectral quantity by integration over wavelength from  $\lambda=0$  to  $\lambda=\infty$ . However, this integration is often restricted to a certain wavelength range, which is indicated by the respective prefix. For instance,

## UVA irradiance is defined as $E_{e,UVA} = \frac{{}^{400\,nm}_{}}{{}^{315\,nm}_{}} (\lambda) d\lambda$

as the UVA range is defined from  $\lambda = 315$  nm to  $\lambda = 400$  nm.



Fig.II.10. Relation between spectral radiant power  $\Phi_{\lambda}(\lambda)$  and radiant power  $\Phi_{o}$  visualized at a hypothetical example. Radiant power emitted in the wavelength interval between  $\lambda$  and  $\lambda+d\lambda$  is given by the area of the shaded rectangle, which amounts to  $\Phi_{\lambda}(\lambda) d\lambda$ . The total amount of radiant power  $\Phi_{e}$  emitted over the whole spectrum is given by the area under the curve describing  $\Phi_{\lambda}(\lambda)$ , which is mathematically expressed by an integral.

#### **II.5.** Calculation of radiometric quantities - Examples

A small source emits light equally in all directions (spherical symmetry). Its radiant power equals  $\Phi_{e,source}=10$  W.

If we are interested in the characteristics of this source in a distance r that is much larger than the geometric dimensions of the source itself, we can neglect the actual size of the source and assume that the light is emitted from a point. As a rule of thumb, this approximation is justified if distance r is at least 10 times larger than the dimensions of the light source.

b/ An infinitesimal surface element dA at distance r and perpendicular to the beam occupies the solid angle

$$\mathrm{d}\Omega = \mathrm{d}\mathrm{A} \,/\,\mathrm{r}^2$$

and thus the infinitesimal radiant power  $d\Phi_{e,\text{imp}}$  impinging onto dA can be calculated by

$$d\Phi_{e,imp} = I \ d\Omega = \Phi_{e,source} / 4\pi \ sr$$
$$dA / r^2 = \Phi_{e,source} / 4\pi r^2 \cdot dA$$

Thus, the irradiance at distance r amounts to

 $E_e = \Phi_{e,source} / 4\pi r^2$ 

This result can also be obtained by the following argument: At distance r, all the radiant power  $\Phi_{e,source}$  emitted by the source II.5.a. Example 1: Isotropic point source

passes through the surface of a sphere with radius r, which is given by  $4r^2\pi$ . As the light source emits light symmetrically in all directions, the irradiance has the same value at every point of this sphere. Thus, irradiance E of a surface at a certain distance r and oriented perpendicular to the beam can be calculated from its definition:

 $E_e$  = radiant power impinging upon a surface / area of this surface =  $\Phi$ <sub>e.source</sub> /  $4\pi r^2$ 

which is identical with the result above.

**Remark:** The fact that E is proportional to  $r^2$  is generally known under the name *"inverse square law*". However, it only holds true

for distances much larger than the geometric dimensions of the source, which allows the assumption of a point source. In other cases, a source with considerable geometric dimensions might possibly be replaced by a "virtual" point source, and then the "inverse square law" still holds true when distance r is measured from this virtual point source (see Example 2). However, when the source cannot be assumed point like and every point of the source emits light in more than a single direction, the "inverse square law" no longer holds true. As an example, this is the case for fluorescent tubes



Remark: As a virtual point source

located at the cone's vertex pro-

duces the same spatial radiation

distribution as the flashlight's bulb

together with its concave mirror,

the "inverse square law" holds true

for this configuration. However,

the distance r which the law relates

to has to be measured from the

position of the virtual point source.

Properties and Concepts of Light and Color

#### II.5.b. Example 2: Spot source

In a simple flashlight, a concave mirror reflects light from a small bulb (radiant power  $\Phi$  = 200 mW) into a divergent cone (see figure below). Assuming that the mirror reflects without any losses and uniform distribution of power over the cone,

Note that the flashlight does not emit light symmetrically in all directions, therefore the equations derived in Example 1 cannot be used.

a/ In a distance of 25 cm from the flashlight's front window, the whole radiant power of 200 mW (= 0.2 W) impinges on a circle with a radius of 0.05 m. If we assume that irradiance is constant all over this circle and we neglect the fact that the surface is not everywhere strictly perpendicular to the beam, we can calculate the irradiance at a distance of 25 cm from the flashlight's front window

E = radiant power impinging upon

a surface / area of this surface  $== 0.2 / 0.05^2 \pi W / m^2$  $E\approx\underline{25~W}\,/\,m^2$ 

#### **II.5.c.** Example 3: The Lambertian surface

By definition, a Lambertian surface either emits or reflects radiation into all directions of a hemisphere with constant radiance Le (Fig.II.12). From Equ.II.4 in paragraph II.4.d. follows that the directional distribution of radiant intensity is given by

$$I_{e}(\vartheta) = I_{e\,0} \cdot \cos(\vartheta)$$

with

$$I_{e,0} = \bigsqcup_{\substack{\text{emitting}\\ \text{surface}}} L_e \cos(0) dA = \bigsqcup_{\substack{\text{emitting}\\ \text{surface}}} L_e dA$$

whereby Ie,0 denotes radiant intensity emitted in the direction perpendicular to the surface and  $I_e(\vartheta)$ denotes radiant intensity emitted in a direction enclosing the angle  $\vartheta$ with the surface's normal. Calculating the surface's exitance Me from Equ.II.6 in paragraph II.4.f.

#### II.6. Spectral sensitivity of the human eye

The sensitivity of the human eye to light of a certain intensity varies strongly over the wavelength range between 380 and 800 nm. Under daylight conditions, the average normal sighted human eye is most sensitive at a wavelength of 555 nm, resulting in the fact that green light at this wavelength produces the impression of highest

"brightness" when compared to light at other wavelengths. The spectral sensitivity function of the average human eye under daylight conditions (photopic vision) is

b/ In order to determine the flashlight's radiant intensity, we have to determine the solid angle determined by the cone. Following the definition of solid angle and approximating the area of the spherical calotte by the area of a circle with a radius of 5 cm (= 0.05 m), we get

$$\Omega = A_{\text{Circle}} / r^2$$

with r describing the distance of the circle form the cone's vertex.

From Fig. II.11, we get

and

and

 $\vartheta d\phi$ , we get

Equ.II7

$$r = x + 0.25 m$$

x / x+0.25 = 0.03 / 0.10

from which we calculate

x = 0.107 mr = 0.357 m

by use of the relation  $d\Omega = \sin(\vartheta) d$ 

The respective relations for photometric quantities (see § II.6.) characterizing a Lambertian surface can be derived by replacing the index

Reflecting Lambertian surfaces are widely used in light measurement for well defined, perfectly diffuse

scattering fully independent of the

direction of the incoming beams.

Thus, the radiance reflected from a

certain location on the surface in a

certain direction is proportional to

the total radiant power impinging

onto the reflecting surface. This

allows the realization of detector

sensitivity of the human eye under

dark adapted conditions (scotopic

luminous efficiency function  $V'(\lambda)$ ,

becomes technically relevant. By

convention, these sensitivity func-

tions are normalized to a value of 1

As an example, the photopic sensi-

tivity of the human eye to mono-

chromatic light at 490 nm amounts

in their maximum.

vision), defined by the spectral

"e" by the index "v".

Thus, the cone defines a solid angle given by

$$\Omega = A_{Circle} / r^2 = 0.05^2 \pi / 0.357^2 + 0.0616 sr$$

and the flashlight's radiant intensity amounts to

$$I = \Phi / \Omega = 0.2 / 0.0616 \text{ W} / \text{sr} = 3.25 \text{ W} / \text{sr}.$$



Fig. II.11 - Calculating the irradiance caused by a flashlight

geometries for radiant power, exitance and irradiance (or luminous flux, luminous  $M_{e} = \prod_{\substack{a = r}} L_{e} \cos(\vartheta) \, d\Omega = L_{e} \int_{0}^{2\pi} \int_{0}^{2} \cos(\vartheta) \sin(\vartheta) \, d\vartheta \, d\varphi = L_{e} \cdot \pi \begin{array}{c} \text{exitance} & \text{and} \\ \text{illuminance}, \end{array}$ which have to be determined by an integration over

all directions of a solid angle of  $4\pi$ or  $2\pi$ . Lambertian reflection is especially desired for the coating of integrating spheres, which are widely used for detector input optics or for output optics of radiance or luminance standards.



Ideal diffuse reflection (lambertian surface)



Diffuse reflection with directional components

Fig.II.12. Constant spatial distribution of radiance Le after ideal diffuse reflection at a Lambertian surface

defined by the CIE spectral lumito 20% of its sensitivity at 555 nm. nous efficiency function  $V(\lambda)$ . As a consequence, when a source Only in very rare cases, the spectral

of monochromatic light at 490 nm emits five times as much power (expressed in watts) than an otherwise identical source of monochromatic light at 555 nm, both sources produce the

Fig. II.13. Spectral luminous efficiency functions V  $(\lambda)$  for photopic vision and  $V'(\lambda)$  for scotopic vision, as defined by the CIE.

impression of same "brightness" to the human eye.



## Page 164 - Tutorials

## Properties and Concepts of Light and Color

#### **II.7. Basic photometric quantities**

One of the central problems of optical measurements is the quantification of light sources and lightning conditions in numbers directly related to the perception of the human eye. This discipline is called "Photometry", and its significance leads to the use of separate physical quantities, which differ from the respective radiometric quantities only in one respect: Whereas radiometric quantities simply represent a total sum of radiation power at various wavelengths and do not account for the fact that the human eye's sensitivity to optical radiation depends on wavelength, the photo-

metric quantities represent a weighted sum with the weighting factor being defined by either the photopic or the scotopic spectral luminous efficiency function (see § II.6). Thus, the numerical value of photometric quantities directly relates to the impression of "brightness". Photometric quantities are distinguished from radiometric quantities by the index "v" for "visual", and photometric quantities relating to scotopic vision are denoted by an additional prime, for example  $\Phi_{v}$ '. The following explanations are given for the case of photopic vision, which describes

power. The unit of luminous flux is

lumen (lm), and at 555 nm, where

the human eye has its maximum

sensitivity, a radiant power of 1 W

corresponds to a luminous flux of

683 lm. In other words, a mono-

chromatic source emitting 1 W at

the eye's sensitivity under daylight conditions, thus being relevant for the vast majority of lighting situations (photopic vision takes place when the eye is adapted to luminance levels of at least several candelas per square meters, scotopic vision takes place when the eye is adapted to luminance levels below some hundredths of a candela per square meter. For mesopic vision, which takes place in the range in between, no spectral luminous efficiency function has been defined yet). However, the respective relations for scotopic vision can be easily derived when

exactly 683 lm. The value of 683

lm / W is abbreviated by the sym-

bol  $K_m$  (the value of  $K_m = 683 \text{ lm}/$ 

W is given for photopic vision. For

scotopic vision, K<sub>m</sub>'=1700 lm/W

has to be used). However, a mono-

chromatic light source emitting the

same radiant power at 650 nm,

replacing V( $\lambda$ ) by V'( $\lambda$ ) and replacing  $K_m\,($  = 683  $lm\,/\,W$  ) by K'\_m (= 1700 lm / W) (see definition in § VII.2).

As the definition of photometric quantities closely follows the corresponding definitions of radiometric quantities, the corresponding equations hold true - the index "e" just has to be replaced by the index "v". Thus, not all relations are repeated. Instead, a more general formulation of all relevant relations is given in the Appendix.

where the human eye is far less

sensitive and  $V(\lambda) = 0.107$ , has a

luminous flux of 0.107\*683 lm =

73.1 lm. For a more detailed expla-

nation of the conversion of radio-

metric to photometric quantities,

see paragraph II.7.f.

#### II.7.a. Luminous flux $\Phi_v$

Luminous flux  $\Phi_v$  is the basic photometric quantity and describes the total amount of electromagnetic radiation emitted by a source, spectrally weighted with the human eye's spectral luminous efficiency function  $V(\lambda)$ . Luminous flux is the photometric counterpart to radiant

## 555 nm has a luminous flux of

Luminous intensity I<sub>v</sub> quantifies the luminous flux emitted by a source in a certain direction. It is therefore the photometric counterpart of the radiometric quantity "radiant intensity" Ie. In detail, the source's (differential) luminous

II.7.b. Luminous intensity I<sub>v</sub>

#### II.7.c. Luminance L<sub>v</sub>

Luminance L<sub>v</sub> describes the measurable photometric brightness of a certain location on a reflecting or emitting surface when viewed from a certain direction. It describes the luminous flux emitted or reflected from a certain location on an emitting or reflecting surface in a par-

#### II.7.d. Illuminance E<sub>v</sub>

Illuminance E<sub>v</sub> describes the luminous flux per area impinging upon a certain location of an irradiated surface. In detail, the (differential) luminous flux  $d\Phi_v$  upon the (differential) surface element dA is given by

#### II.7.e. Luminous exitance M<sub>v</sub>

Luminous exitance M, quantifies the luminous flux per area, emitted or reflected from a certain location on a surface. In detail, the (differential) luminous flux  $d\Phi_v$ emitted or reflected by the surface

 $d\Phi_v = I_v \cdot d\Omega$ 

ment  $d\Omega$  is given by

ticular direction (the CIE definition of luminance is more general. Within the frame of this tutorial, the most relevant application of luminance describing the spatial emission characteristics of a source is discussed).

 $d\Phi_v = E_v \cdot dA$ 

Generally, the surface element can

be oriented at any angle towards

the direction of the beam. Similar

to the respective relation for irradi-

ance, illuminance Ev upon a surface

 $d\Phi_v = M_v \cdot dA$ 

The unit of luminous exitance is 1

element dA is given by

 $\Phi_{v} = I_{v} d\Omega$ 

The unit of luminous intensity is lumen per steradian (lm / sr), which is abbreviated with the expression "candela" (cd):

1 cd = 1 lm / sr

In detail, the (differential) luminous flux  $d\Phi_v$  emitted by a (differential) surface element dA in the direction of the (differential) solid angle element  $d\Omega$  is given by

 $d\Phi_v = L_v \cos(\theta) \cdot dA \cdot d\Omega$ 

with arbitrary orientation is related

to illuminance E<sub>v.normal</sub> upon a

surface perpendicular to the beam

 $E_v = E_{v,normal} \cos(\vartheta)$ 

with  $\theta$  denoting the angle between the direction of the solid angle element  $d\Omega$  and the normal of the emitting or reflecting surface element dA.

The unit of luminance is

$$1 \text{ Im m}^{-2} \text{ sr}^{-1} = 1 \text{ cd m}^{-2}$$

with  $\vartheta$  denoting the angle between the beam and the surface's normal. The unit of illuminance is **lux** (lx), and

lm m<sup>-2</sup>, which is the same as the unit for illuminance. However, the abbreviation lux is not used for luminous exitance

and thus flux  $d\Phi_v$  emitted in the direction of the (differential) solid angle ele-

by



## Properties and Concepts of Light and Color

#### II.7.f. Conversion between radiometric and photometric quantities

<u>Monochromatic radiation</u>: In the case of monochromatic radiation at a certain wavelength  $\lambda$ , a radiometric quantity  $X_e$  is simply transformed to its photometric counterpart  $X_v$  by multiplication with the respective spectral luminous efficiency V( $\lambda$ ) and by the factor  $K_m = 683 \text{ Im} / \text{W}$ . Thus,

$$X_v = X_e * V(\lambda) * 683 \text{ lm} / \text{W}$$

with X denoting one of the quantities  $\Phi$ , I, L, or E.

Example: An LED (light emitting diode) emits nearly monochromatic radiation at  $\lambda = 670$  nm, where V ( $\lambda$ ) = 0.032. Its radiant power amounts to 5 mW. Thus, its luminous flux equals  $\Phi_v = \Phi_e * V(\lambda) * 683 \text{ lm / W} = 0.109 \text{ lm} = 109 \text{ mlm}$ 

As V( $\lambda$ ) changes very rapidly in this spectral region (by a factor of 2 within a wavelength interval of 10 nm), for accurate results the LED's light output should not be considered monochromatic. However, using the relations for monochromatic sources still results in an approximate value for the LED's luminous flux which might be

#### II.8. Reflection, Transmission, and Absorption

**Reflection** is the process by which electromagnetic radiation is returned either at the boundary between two media (surface reflection) or at the interior of a medium (volume reflection), whereas **transmission** is the passage of electromagnetic radiation through a medium. Both processes can be accompanied by **diffusion** (also called **scattering**), which is the process of deflecting a unidirectional beam into many directions. In this case, we speak about diffuse reflection and diffuse transmission (Fig. II.14). When no diffusion occurs, reflection or transmission of an unidirectional beam results in an unidirectional beam according to the laws of geometrical optics (Fig. II.15). In this case, we speak about regular reflection (or specular reflection) and regular transmission (or direct transmission). Reflection, transmission and scattering leave the frequency



Fig. II.14 - a-c: Direct, mixed and diffuse reflection d-f: direct, mixed and diffuse transmission

<u>Polychromatic radiation</u>: If a source emits polychromatic light described by the spectral radiant power  $\Phi_{\lambda}(\lambda)$ , its luminous flux can be calculated by spectral weighting of  $\Phi_{\lambda}(\lambda)$  with the human eye's spectral luminous efficiency function V( $\lambda$ ), integration over wavelength and multiplication with with K<sub>m</sub> = 683 lm / W, so

$$\Phi_{v} = K_{m} \int_{\lambda} \Phi_{\lambda}(\lambda) \cdot V(\lambda) \, d\lambda$$

In general, a photometric quantity  $X_v$  is calculated from its spectral radiometric counterpart  $X_\lambda(\lambda)$  by the relation

$$\mathbf{X}_{v} = \mathbf{K}_{m} \int_{\lambda} \mathbf{X}_{\lambda}(\lambda) \cdot \mathbf{V}(\lambda) \, \mathrm{d}\lambda$$

with X denoting one of the quantities  $\Phi$ , I, L, or E.

of the radiation unchanged. Exception: The Doppler effect causes a change in frequency when the reflecting material or surface is in motion. **Absorption** is the transformation of radiant power to another type of energy, usually heat, by interaction with matter.



Fig. II.15 - When directly reflected or directly transmitted, an unidirectional beam follows the laws of geometrical optics: direct reflection (left):  $\alpha_{in} = \alpha_{out}$ , direct transmission (right):  $n_1 \cdot \sin(\alpha_{in}) = n_2 \cdot \sin(\alpha_{out})$  with  $n_1$  and  $n_2$  denoting the respective medium's index of refraction

#### II.8.a. Reflectance $\rho$ , Transmittance $\tau$ , and Absorptance $\alpha$

In general, reflection, transmission and absorption depend on the wavelength of the affected radiation. Thus, these three processes can either be quantified for monochromatic radiation (in this case, the adjective "spectral" is added to the respective quantity) or for a certain kind of polychromatic radiation. For the latter, the spectral distribution of the incident radiation has to be specified. In addition, reflectance, transmittance and absorptance might also depend on polarization and geometric distribution of the incident radiation, which therefore also have to be specified.

The reflectance  $\rho$  is defined by the

ratio of reflected radiant power to incident radiant power. For a certain area element dA of the reflecting surface, the (differential) incident radiant power is given by the surface's irradiance  $E_e$ , multiplied with the size of the surface element, thus

$$d\Phi_{e \text{ incident}} = E_e dA$$

and the (differential) reflected radiant power is given by the exitance  $M_e$ , multiplied with the size of the surface element:

$$d\Phi_{e,reflected} = M_e dA$$

$$\rho = \frac{d\Phi_{e,reflected}}{d\Phi_{e,reflected}} = \frac{M_e \cdot dA}{E_e \cdot dA} = \frac{M_e}{E_e}$$

 $M_e = \rho E_e$ 

or

Total reflectance is further subdivided in **regular reflectance**  $\rho_r$  and **diffuse reflectance**  $\rho_d$ , which are given by the ratios of regularly (or specularly) reflected radiant power and diffusely reflected radiant power to incident radiant power. From this definition, it is obvious that

 $\rho=\rho_r+\rho_d$ 

The **transmittance**  $\tau$  of a medium is defined by the ratio of transmitted radiant power to incident radiant power. Total transmittance is further subdivided in **regular** 

#### transmittance $\tau_r$ and diffuse transmittance $\tau_d$ , which are given by the ratios of regularly (or directly) transmitted radiant power and diffusely transmitted radiant power to incident radiant power. Again,

 $\tau=\tau_r+\tau_d$ 

```
The absorptance \alpha of a medium is defined by the ratio of absorbed radiant power to incident radiant power.
```

Being defined as ratios of radiant power values, reflectance, transmittance and absorptance are dimensionless.

## Properties and Concepts of Light and Color

Ouantities such as reflectance and transmittance are used to describe the optical properties of materials. The quantities can apply to either complex radiation or to monochromatic radiation.

The optical properties of materials

are not a constant since they are dependent on many parameters

- thickness of the sample •
- surface conditions

such as:

• angle of incidence

#### temperature

tion

· the spectral composition of the radiation (CIE standard illuminants A, B, C, D65 and other illuminants D)

radiance coefficient generally is

valid for just one specific directional distribution of incident radia-

The unit of radiance coefficient and

BRDF is 1/steradian. The BRDF is

often abbreviated by the Greek

letter  $\rho$ , which bears the danger of

mixing the BRDF up with reflectance (see foregoing paragraph).

polarization effects

The measurement of optical properties of materials using integrating spheres is described in DIN 5036-3 and CIE 130-1998.

Descriptions of the principle measurements are presented in paragraph III.1.f below.

## **II.8.b.** Radiance coefficient q<sub>e</sub>, Bidirectional reflectance distribution function (BRDF) difference is that the BRDF is a

function of the directions of the

incident and the reflected beam

(Fig. ). In detail, the (differential)

irradiance dEe impinging from a

certain direction causes the re-

flected radiance dLe in another

 $dL_e = BRDF \cdot dE_e$ 

This BRDF depends on more argu-

ments than the radiance coefficient.

However, its advantage is the si-

material's reflection properties for

of incident radiation, whereas the

all possible directional distributions

distinguished from all the other

impressions received when seeing.

The insertion of the term

"unstructured" into this definition

also separates the texture of ob-

served objects from the sensation

Thus the texture of a textile, for

instance, is not included in the

The definition also calls for obser-

vation with a "single" eye which is

"unmoving", conditionally exclud-

ing other factors such as spatial

sensation, the perception of the

location of objects, their direction,

and even their relative movement

from the perception of color. Since

single-eyed observation of an un-

of color.

color

multaneous description of the

direction, which is given by

The radiance coefficient qe characterizes the directional distribution of diffusely reflected radiation. In detail, the radiance coefficient depends on the direction of the reflected beam and is defined by the ratio of the radiance reflected in this direction to the total incident irradiance. In general, the reflected radiance is not independent from the directional distribution of the incident radiation, which thus has to be specified.

In the USA, the concept of Bidirectional reflectance distribution function BRDF is similar to the radiance coefficient. The only

#### **II.9.** The perception of color

Color sensations are human sensory perceptions, and color measurement technology must express them in descriptive and comprehensible quantities. DIN 5033, Part 1, defines color as follows:

"Color is the visual sensation, associated with a part of the field of view that appears to the eye to be without structure, through which this part can be distinguished from another unstructured neighbouring area when observed with a single, unmoving eye".

This rather complicated but unambiguous definition of color allows the visual sensation of "color" to be

#### **II.9.a.** Physiological background

From the fact that spectral decomposition of white light produces the perception of different colors, it can be deduced that color perception is closely connected to the wavelength of light (Fig. II.17.). As an example, light with a wavelength of 650 nm wavelength is perceived as "red" and light with a wavelength of 550 nm is perceived as "green". However, there are colors, such as purple, which cannot be directly related to a certain wavelength and therefore do not occur in the spectral decomposition of white light.

The perception of color is formed in our brain by the superposition of the neural signals from three different kinds of photoreceptors which are distributed over the human eye's retina. These photoreceptors

are called cones and are responsible for photopic vision under daylight conditions. Scotopic (night) vision is caused by photoreceptors called rods, which are much more sensitive than cones. As there is only one kind of rods, night vision is colorless.

The three different kinds of cones differ in their spectral sensitivity to electromagnetic radiation, which is shown in Fig. for the average normal sighted human eye. If monochromatic radiation irradiates the eye, as it is the case with spectral decomposition of white light, the wavelength determines which types of cones are excited. For instance, monochromatic light at 680 nm exclusively excites one type of cones, whereas the two other types are insensitive at this

ing surface's normal, and the azimuth angles  $\varphi_i$  and  $\varphi_r$ , which are measured in the plane of the reflecting surface. moving object with an unmoving

eye does not allow for the perception of gloss, the evaluation of gloss is excluded from the perception of color.

In general, unlike mass, volume or temperature, color is not merely a physical property of an object. It is, rather, a sensation triggered by radiation of sufficient intensity. This can be the radiation of a selfemitting light source, or it can be reflected from a surface. This radiation enters the eye, where receptive cells convert it into nervous stimulation, which is in turn transmitted to the appropriate part of the brain, where it is experienced as color. The sensation of color depends not only on physical laws, but also on the physiological processing of the radiation in the sense organs. Visual conditions, luminance (brightness) and the state of the eye's adaptation are amongst the contributory factors.

Color manifests itself in the form of light from self-emitting light sources, surface colors (of non-self emitting light sources) and in the intermediate form of the luminescent colors of dyestuffs such as optical brightening agents and dayglow paints that absorb photons from a short wavelength part of the spectrum and emit the energy in a part of the spectrum with longer wavelengths.

wavelength. The brain interprets signals from only this type of cones - in the absence of a signal from the other cones - as the color "red".

100

75

Therefore, these cones are called "red cones". Similarly, the two other types of cones are called "blue cones" and "green cones".



Green Red

Cones C

Ro





Fig. II.16 - Geometry used for the definition of the bidirectional

reflectance distribution function (BRDF). The BRDF depends on

the directions of incident and reflected radiation, which are given

by the angles  $\vartheta_i$  and  $\vartheta_r$ , which are measured relative to the reflect-



Properties and Concepts of Light and Color

#### **II.9.b.** Color addition

As discussed above, monochromatic light of a certain wavelength might predominately excite a single type of cones, thus producing the color perception of "blue", "green" or "red". Depending on the actual wavelength, monochromatic light might also excite two types of cones simultaneously, thus producing the perception of another color. Red and green cones, for instance, are both excited by monochromatic light of 580 nm, and a signal from these two types of cones - with the simultaneous absence of a signal from blue cones - produces the color perception of "yellow".

However, our visual system cannot discriminate between monochromatic and broadband radiation as long as the excitation of the three types of cones remains the same. Thus, the perception of "yellow" can also be produced by a broadband spectrum between 550 nm and 700 nm as long as green and vellow cones are comparably stimulated and blue cones are not stimulated at all. Similarly, the perception of "cyan" is produced by simultaneous stimulation of blue and green cones, whereas the perception of "magenta" (or purple) is caused by simultaneous stimulation of blue and red cones (Fig. II.17). Simultaneous stimulation of all three types of cones results in the perception of "white".

This fact has an important consequence: Consider a light source consisting of three single sources with the colors red, green and blue. If it is possible to vary the intensities of the three single sources individually, all possible colors can be produced. This is the main idea of color cathode ray tubes commonly used in TV and computer monitors - every pixel (a point on the monitor) consists of three smaller individual spots in the colors red, green and blue (Figure II.18). As these individual spots are so close together, the human eve cannot resolve them. Instead, they produce the perception of a certain color by superposition of their respective intensities. For instance, the pixel appears yellow when only the red and the green spot are emitting light, and the pixel appears white when all three spots are emitting light. The entirety of colors produced by color addition forms the RGB color space, as they are based on the three (additive) primary colors red, green and blue.

Fig. II.18 - The effect of color addition demonstrated with white light from an overhead projector before (top) and after (bottom) passing through a ma-



genta filter. To the left, the respective spectral decomposition is shown, whereas the circle to the right shows the resulting color impressions. It can be clearly seen that the filter strongly absorbs light from the green part of the visual spectrum, whereas blue and red light pass the filter with low attenuation. The impression of magenta is produced by simultaneous pres-

ence of light from the blue and red regions of the visible spectrum, whereas light from the green region is missing.



Fig. II.19 - An RGB monitor consists of tiny red, green and blue spots. Variation of their brightness produces the impression of different colorsby color addition.

#### **II.9.c.** Color subtraction

Whereas color addition describes the perception of different colors caused by a superposition of red, green and blue light sources, the concept of color subtraction is based on the absorption of white light by filters or pigments. As an example, a yellow filter absorbs wavelengths below about 500 nm, corresponding to blue light, but transmits longer wavelengths corresponding to green and red light. Thus, when irradiated with white light the filter transmits only wavelengths which stimulate the green and red cones, whereas the blue cones are not stimulated. As discussed above, this results in the perception of the color "yellow". Similarly, a surface (better: pigments on a surface) absorbing wavelengths below about 500 nm

and reflecting wavelengths above appears yellow when irradiated with white light. So, when irradiated with white light filters (or pigments) absorbing blue light appear yellow, filters (or pigments) absorbing green light appear magenta and filters (or pigments) absorbing red light appear cyan. As the effect of filters on transmitted light is the same as the effect of pigments on reflected light, the following conclusions derived for pigments are also valid for filters. What happens if two pigments are combined? The combination of a yellow pigment, which absorbs short (blue) wavelengths with a cyan pigment, which absorbs long (red) wavelengths, leaves only medium (green) wavelengths to be reflected when irradiated with

white light. So, the combination of yellow and cyan pigments results in green reflected light. Similarly, the combination of yellow and magenta pigments results in red and the combination of cyan and magenta results in green reflected light. In next figure, the effect of color subtraction is demonstrated for filters.

Ideally, a combination of yellow, cyan and magenta pigments should result in total absorption of the whole visible wavelength range and thus in the perception of a black surface.

However, in reality the absorption properties of these pigments are never ideal, thus four-colorprinting uses a black pigment in addition. Colors produced by a combination of cyan, yellow, magenta and black form the so called **CYMK color space**.



Fig. II-20 - Overlapping arrangement of yellow, cyan and magenta color filters on an overhead projector. In the overlapping regions, color subtraction results in green, red and blue light.

#### **II.10.** Colorimetry

The basic problem of colorimetry is the quantification of the physiological color perception caused by a certain **spectral color stimulus function**  $\phi_{\lambda}(\lambda)$ . When the color of a primary light source has to be characterised,  $\phi_{\lambda}(\lambda)$  equals the source's spectral radiant power  $\Phi_{\lambda}$ ( $\lambda$ ) (or another spectral radiometric

quantity, such as radiant intensity or radiance). When the color of a reflecting or transmitting object (for example a filter) has to be characterised,  $\phi_{\lambda}(\lambda)$  equals the incident spectral irradiance impinging upon the object's surface, multiplied by the object's spectral reflectance, its spectral radiance coefficient or its spectral transmittance. As colors of reflecting or transmitting objects depend on the object's illumination, the CIE has defined colorimetric standard illuminant A is defined by a Planckian blackbody radiator at a temperature of 2856 K, and the CIE Standard Illuminant  $D_{56}$  is representative of average daylight with a correlated color temperature of 6500 K (for the definition of color temperature, see below).

## Page 168 - Tutorials

## Properties and Concepts of Light and Color

#### II.10.a. RGB and XYZ color matching functions

According to the tristimulus theory, every color which can be perceived by the normal sighted human eye can be described by three numbers which quantify the stimulation of red, green and blue cones. If two color stimuli result in the same values for these three numbers, they produce the same color perception even when their spectral distributions are different. Around 1930, Wright and Guild performed experiments during which observers had to combine light at 435.8 nm, 546.1 nm and 700 nm in such a way that the resulting color perception matched the color perception produced by monochromatic light at a certain wavelength of the visible spectrum. Evaluation of these experiments resulted in the definition of the standardised RGB color matching functions  $\overline{r}(\lambda) \overline{g}(\lambda)$ and  $\overline{b}(\lambda)$  which have been transformed into the CIE 1931 XYZ color matching functions  $\overline{x}(\lambda)$ 

 $\overline{y}(\lambda)\overline{z}(\lambda)$  These colour matching functions define the CIE 1931 standard colorimetric observer and are valid for an observer's field of view of 2°. Practically, this observer can be used for any field of view smaller than 4°. For a field of view of 10°, the CIE specifies another set of colour matching  $\overline{x}_{10}(\lambda) \ \overline{y}_{10}(\lambda) \ \overline{z}_{10}(\lambda) \ f u n c$ 

tions This set defines the CIE 1964 supplementary standard colorimetric observer, which has to be used for fields of view larger than  $4^{\circ}$ .

Although RGB and XYZ color matching functions can be equally used to define three parameters which numbers uniquely describe a certain color perception, the XYZ color matching functions are preferred as  $\overline{y}(\lambda)$  they have positive values for all wavelengths (Fig. II.21). In addition, is equal to the CIE spectral luminous efficiency function V( $\lambda$ ) for photopic vision. The XYZ tristimulus values of a cer-

$$X = k \int_{\lambda} \phi_{\lambda}(\lambda) \cdot \overline{x}(\lambda) d\lambda \text{ spec-color}$$
$$Y = k \int_{\lambda} \phi_{\lambda}(\lambda) \cdot \overline{y}(\lambda) d\lambda$$

$$Z = k \prod_{\lambda} \phi_{\lambda}(\lambda) \cdot \overline{z}(\lambda) d\lambda$$

its coordinates defined by

4X

stimulus function  $\phi_{\lambda}(\lambda)$  are calculated by

 $u' = \frac{11}{X + 15Y + 3Z}$   $v' = \frac{11}{X + 15Y + 3Z}$ 

Although this definition of the

9Y

#### II.10.b. The (x,y)- and (u',v')-chromaticity diagrams

Although the XYZ tristimulus values define a three-dimensional color space representing all possible color perceptions, for most applications the representation of color in a two-dimensional plane is sufficient. One possibility for a two-dimensional representation is the **CIE 1931 (x, y) chromaticity diagram** with its coordinates x and y calculated from a projection of the X, Y and Z values:

$$x = \frac{X}{X + Y + Z} \qquad y = \frac{Y}{X + Y + Z}$$

Although widely used, the (x, y) chromaticity diagram has a major disadvantage of non-uniformity as geometric distances in the (x, y) chromaticity diagram do not correspond to perceived color differences. Thus, in 1976 the CIE defined the uniform (u', v') chromaticity scale (UCS) diagram, with

coordinates u' and v' does not the provide a strict correspondence gra between geometric distances and perceived color differences, there are far less discrepancies than in

the CIE (x, y) chromaticity diagram.



Fig. II.22 - The CIE 1931 (x,y) chromaticity diagram and the CIE 1976 (u', v') chromaticity diagram.

#### **II.10.c.** Correlated color temperature

The correlated color temperature is used to characterize the spectral distribution of optical radiation emitted by a light source. This characterisation corresponds to the projection of a two-dimensional chromaticity diagram onto a onedimensional scale and thus is very coarse. In detail, the correlated color temperature is given in Kelvin (K) and is the temperature of the blackbody (Planckian) radiator whose received color most closely resembles to that of a given color stimulus.

As a (simplified) rule of thumb,

spectral distributions dominated by long (reddish) wavelengths correspond to a low correlated color temperature whereas spectral distributions with dominated by short (bluish) wavelengths correspond to a high correlated color temperature. As an example, the warm color of incandescent lamps has a correlated color temperature of about 2800 K, average daylight has a correlated color temperature of about 6500 K and the bluish white from a Cathode Ray Tube (CRT) has a correlated color temperature of about 9000 K.

constant k depends on the colori $k = \frac{100}{|E_{\lambda}(\lambda) \overline{y}(\lambda) d\lambda} \quad \begin{array}{l} metric \\ t \ a \ s \ k \ \vdots \\ W \ h \ e \ n \\ spectral \\ color \ stimulus \ \phi_{\lambda}(\lambda) \ describes \ a \\ spectral \ radiometric \ quantity \ of \ a \\ primary \ light \ source, \ k = 683 \ lm/W \\ tion \qquad and \ consequently \ Y \ yields \ the \\ \end{array}$ 





Fig. II.21 - XYZ color matching functions as defined by the CIE 1931 stan-

dard colorimetric observer.  $\overline{x}(\lambda)$  (solid black line) consists of a short- and a long-wavelength  $\overline{y}(\lambda)$  part, and (solid gray line) is

identical with the CIE spectral luminous efficiency function  $V(\lambda)$ .

#### III. Measurement of light with integral detectors

Spectroradiometry - the measurement of radiation intensity as a function of wavelength - is the only way to provide full spectral information about optical radiation emitted by a light source or impinging upon a surface. Obtaining this information has its price: Spectroradiometers are highly sophisticated optical measurement devices and in general, their proper calibration, operation and maintenance is rather time consuming. However, for the vast majority of applications, integral detectors (the term "integral" describes the fact that

the output signal of an integral detector is proportional to the wavelength integral over the measured quantity's spectral distribution, multiplied with the detector's spectral sensitivity (see § III.2)) offer an economical and user friendly alternative: In most cases, it is not necessary to determine the exact spectral distribution of the measured quantity, and it is sufficient to use a detector especially designed to match a certain predefined spectral sensitivity function. As an example, the spectral sensitivity of photometric detectors is matched to the CIE spectral luminous sensitivity function  $V(\lambda)$ , and detectors for solar UV irradiance potentially harmful to the human skin are matched to the CIE erythema action spectrum.

As integral detectors provide just a single output signal (usually voltage or photocurrent), they are much easier to characterise than spectroradiometers. The main parameters determining the usability and the quality of an integral detector are

• The detector's input optics, which determines its directional sensitivity

- · The detector's spectral sensitivitv
- The dynamic range, over which the detector's output is proportional to the input signal's intensity
- · The detector's time behaviour

Refer to § III.5. for more info about calibration laboratory. More information is also available about our calibration services and calibration standards as well as Uniform Light Sources.

function of solid angle, and

therefore the detector's field of

view has to be limited to a small

angle. This can be achieved by

baffles and/or lenses arranged in

Refer also to § III.1.d and III.1.e.

a tube.

#### III.1. The detector's input optics and its directional sensitivity

Basically, the design of a detector's input optics is determined by its desired directional sensitivity, which in turn depends on the radiometric or photometric quantity to be measured:

• The determination of a light source's radiant and luminous flux requires constant directional sensitivity over the solid angle of  $4\pi$  steradian or over the hemispherical solid angle of  $2\pi$  steradian. This is achieved by an integrating sphere with the light source placed either inside the sphere or directly at the sphere's entrance port. Refer also to § III.1.b.

• The determination of irradiance and illuminance requires a detec-

#### **III.1.a.** Integrating spheres used with integral detectors

In an ideal case, the inner surface of an integrating is a perfect diffuse Lambertian reflector (see § II.4.c). Thus, the directional distribution of reflected radiation is independent from the directional distribution of incident radiation, and no specular reflection occurs.



Fig. III.1. Ideal multiple Lambertian reflections inside an integrating sphere

Due to its geometry, an ideal integrating sphere is characterised by constant irradiance (or illuminance)) at all locations of it's inner surface. Furthermore, the level of this irradiance (illuminance solely depends on the total amount of radiant power (luminous flux) entering the sphere and is independent from its directional distribution.

However real surfaces do not show perfect Lambertian reflection properties. Although minimised by the properties of the respective material, a certain amount of specular reflection still occurs. Baffles, placed at specific locations inside the sphere, are used to prevent major measurement errors by specular reflection. Moreover, at the input and exit ports, where the coating material is missing, radiator's directional sensitivity proportional to the cosine of the angle of incidence, which can be achieved either by a flat field detector or by the entrance port of an integrating sphere. Refer also to § III.1.c.

· Radiant and luminous intensity. radiance and luminance are quantities which are defined as a

tion is far from being ideally reflected. For these reasons, the quality of measurements performed with integrating spheres strongly depends on the sphere's coating material, on the exact position of baffles and on the size of the ports in relation to the sphere's diameter. As a general rule of thumb, the total area of entrance and exit ports should not exceed 5% of the sphere's internal surface Numerous standard setups are used for the determination of radiometric and photometric quantities, defining the arrangement of the sphere's entrance and exit ports and internal baffles (see § III.1.b. to III.1.f). Apart from their directional sensitivity, integrating spheres offer additional advantages:

• The high number of internal reflections generally eliminates a detector's sensitivity to the polarisation of incident radiation.

- · For the characterisation of powerful light sources, an integrating sphere can be used for attenuation in order to prevent saturation effects of the detector. As this attenuation results in an increase of internal temperature, the light source's maximum power is limited by the sphere's temperature range of operation.
- In general, geometric alignment of source and integrating sphere is not very critical, which simplifies calibration and measurement procedures.

For more detailed information about the theory and application of integrating spheres, see chapter V.

#### III.1.b. Measurement of radiant power and luminous flux

Radiant power and luminous flux of lasers and spot sources

Lasers, LEDs, spot lamps, endoscopes, optical fibres and other sources emit radiation with various directional distributions. As long the emission is limited to a hemispherical ( $2\pi$  steradian) solid angle, the source can be attached to the entrance window of an integrating sphere and does thus not interfere with the sphere's internal reflec-



tions.

The entrance port has to be large enough to ensure that all radiation from the source enters the sphere. A baffle is necessary to shield the detector from direct irradiation by the source.

Fig. III.2. Integrating sphere used for laser power measurements



III.2. Integrating sphere used for radiant power and luminous flux

As an alternative, radiant power and luminous flux of collimated (parallel) beams can be directly measured by flat field detectors as long as the detector's active area exceeds the beam's cross section. Despite the simple measurement setup, this method has significant disadvantages in comparison to the use of an integrating sphere:

- The detector might be possibly sensitive to the beam's polarisation.
- The detector's active area might be possibly inhomogeneous in its sensitivity. In this case, it is important to ensure equal illumination during calibration and measurement.
- Alignment of the detector relative to the beam is critical.

#### Radiant power and luminous flux of lamps

Lamps emit radiation in all directions of the full ( $4\pi$  steradian) solid angle. Therefore, a lamp has to be placed inside an integrating sphere in order to determine its total radiant power or luminous flux. As a consequence, the lamp itself and its accessories interfere with the sphere's internally reflected radiation and thus causes a source of measurement error, which can be accounted for by use of an auxiliary lamp (see below).

Integrating spheres used to measure the radiant power or luminous flux of lamps must be well suited for the lamp under test to reduce measurement uncertainty. One important design parameter is that the diameter of the hollow sphere should be about ten times (twice for tube lamps) the maximum dimension of the lamp. For example, an integrating sphere set-up to measure the luminous flux of fluorescent lamps with 120 cm (47 in) length should be at least 2 m (79 in) in diameter. Furthermore, the diameter of the sphere limits the maximum power of the lamp.

In actual measurements, the lamp must be placed in the centre of the hollow sphere. This is typically accomplished using a tube holder, which carries the power and measurement leads into the sphere. A socket at the end of the tube holds and connects the lamp. To get the lamp in the centre position, hinged integrating spheres that open and have large diameters of more than 50 cm (20 in) are used. Spheres with smaller diameters may offer a large diameter port to mount the lamp in the centre of the sphere. The port is normally closed with a cap during the measurement. The port cap's inside surface should be coated with the same diffuse coating as the hollow sphere surface. The detector is placed at a port on

the integrating sphere. It must be baffled against direct irradiation by the lamp.

For precise measurements, the lamp must be aged before testing. The burn-in time depends on the lamp type. The burn-in time for tungsten lamps should be 2-5 hours (IEC 64) and for arc lamps about 100 hours (IEC 81) is recommended

In precise luminous flux measurement applications an auxiliary lamp with baffle(s) is recommended. The diffuse illumination generated by the auxiliary lamp can be used to reduce the negative effects of the lamp under test and its accessories according to the relation



- Φ<sub>X</sub> : luminous flux of the test lamp
- $\Phi_N$ : luminous flux of the calibration lamp
- Y<sub>X</sub>: measurement signal of the test lamp (with auxiliary lamp switched off)
- Y<sub>N</sub> : measurement signal of the calibration lamp (with auxiliary lamp switched off)
- Y<sub>HN</sub> : measurement signal of the auxiliary lamp (with calibration lamp switched off)
- Y<sub>HX</sub> : measurement signal of the auxiliary lamp (with test lamp switched off)



Fig. III.3. Experimental setup for radiant power and luminous flux measurements of a lamp. The auxiliary lamp is used to reduce measurement uncertainties caused by the interference of the lamp under test and its accessories with the sphere's internally reflected radiation.

III.1.c. Measurement of irradiance and illuminance

According to Equ.II.5 in paragraph II.4.e., a detector for irradiance or illuminance of a surface has to weight the incident radiation according to the cosine of its angle of incidence. This can be either achieved by

• an integrating sphere especially designed for irradiance (or illuminance) measurements (see figure below) or

• a cosine diffuser, an optical element which shows purely diffuse transmission regardless of the directional distribution of incident radiation (Fig. III.5).

In both cases, the ideal directional

cosine response can only be approximately achieved. Deviations of a real detector's directional response from the ideal cosine response are quantified by the detector's **cosine error function**, which is given by



Light Source	Approximate Average Illuminance (lx)
overcast night	0,0001
full moon	0,1
office light	500
clear bright sky	70000 - 85000

Table III.1 – Some avarage illuminance values



In this equation,  $S(\theta)$  denotes the detector's signal caused by a ray of light impinging upon the detector's



entrance optics at an angle  $\theta$ , measured relative to the normal (see Fig. II.9). S(0) denotes the detector's signal caused by the same ray of light impinging vertically upon the detector's entrance optics.

Fig. III.5 - Irradiance detector heads with cosine diffuser and waterproof version for underwater and outdoor use

Fig. III.4. Integrating sphere design for measurement of irradiance or illuminance of a horizontal surface. The baffle prevents direct illumination of the detector, and the knife edges at the sphere's entrance port prevent shading by the sphere's wall, which would distort the detector's cosine response.sources.

#### III.1.d. Measurement of radiant and luminous intensity

Radiant and luminous intensity describe the directional distribution of a source's emitted radiation. For determination of this directional distribution, the relative position between source and detector has to be varied. The **goniophotometer** is a mechanical setup allowing the variation of the source's orientation and/or the detector's position, whereby the distance between source and detector is kept constant. As the source's directional characteristics often depends on its internal temperature distribution and thus on its position relative to the vertical, for accurate measurements of radiant and luminous intensity it is not recommended to rotate the source around a horizontal axis.

As radiant and luminous intensity are defined by the surface integral

of radiance and luminance (see Equ. II.4), the emitting source has to be completely in the detector's field of view. Ideally, both quantities have to be determined with a setup that allows the source to be considered point like. As a crude rule of thumb, the distance between detector and source should be at least ten times the largest geometric dimension of the source. For precise measurements, special

care has to be taken to minimize reflections at the lamp's surrounding (walls, ceiling, the goniophotometer itself) in the direction of the detector. Blackening of the surrounding, the use of additional baffles and the reduction of the detector's field of view are proper precautions.

#### III.1.e. Measurement of radiance and luminance

Radiance and luminance describe the directional distribution of the radiance emitted or reflected by a certain area element. Similar to radiant and luminous intensity, radiance and luminance can be determined with a goniophotometer, but the detector is placed much closer to the emitting or reflecting surface and the detector's field of view is limited to a few degrees. Thus, only radiation from a small part of the source's surface enters the detector (Fig. III.6).

Light Source	Approximate Average Luminance (cd/m <sup>2</sup> )		
self-luminous paints	0,02 10-3		
Candle flame	1		
computer screen	100		
overcast daytime sky	1000		
clear bright sky	5000-6000		

Table III.2 – Some average luminance values

#### **III.1.f.** Measurement of reflection and transmission properties

**Reflectance**  $\rho$  (for incident radiation of given spectral composition, polarization and geometrical distribution) is used to describe the optical properties of materials (see  $\delta II.8$ )

Ratio of the reflected radiant or luminous flux to the incident flux in the given conditions.

The measurement of reflectance is made in comparison to a reflection standard (reflectance  $\rho_N$ ) with a

**Diffuse Reflectance**  $\mathbf{r}_{d}$  is used to describe the optical properties of  $\rho_{d}$  = materials (see § II.8).

Ratio of the diffusely reflected part of the (whole) reflected flux, to the incident flux.

The measurement of diffuse reflectance is made in comparison to a reflection standard (reflectance  $r_N$ ) with a collimated or conical radiation beam.

The signals of the detector will be calculated as follow:

**Transmittance**  $\tau$  (for incident radiation of given spectral composition, polarization and geometrical distribution) is used to describe the optical properties of materials (see § II.8).

Ratio of the transmitted radiant or luminous flux to the incident flux in the given conditions.

The measurement of transmittance is made with a collimated or coni-

collimated or conical radiation beam. The signals of the detector will be calculated as follow:

$$\rho = \frac{I(X)-I(stray)}{I(N)-I(stray)} \rho_N$$

I(X): signal with sample irradiation I(N): signal with standard irradiation

I(X) - I(stray) - ρ[I(mi) - I(stray)]

 $I(N) - I(stray) - \rho_N [I(mi) - I(stray)]$ 

I(X): signal with sample irradiation I(N): signal with standard irradiation I(stray): signal with open measurement port

I(mi): signal with irradiance of a mirror

cal radiation beam. The signals of the detector will be calculated as follow:

$$\tau = I(X) / I(open)$$

I(X): signal with sample irradiation I(open): signal with open measurement port



Fig. III.7. Integrating Sphere Total Reflection Measurement Set-up



Fig. III.8. Integrating Sphere Diffuse Reflectance Measurement Set-up



Fig. III.9. Integrating Sphere Total Transmittance Measurement Set-up

## Page 172 - Tutorials

## **Measurement of Light**

**Diffuse Transmittance**  $\tau_d$  is used to describe the optical properties of materials (see § II.8).

Ratio of the diffusely transmitted part of the (whole) transmitted flux, to the incident flux.

The measurement of transmittance is made with a collimated or conical radiation beam. The signals of the detector will be calculated as follow:

#### III.2. Spectral sensitivity of an integral detector

Within the normal range of operation of an integral detector, the relation between the input signal (the spectral radiometric quantity to be measured)  $X_{\lambda}(\lambda)$  entering the detector and its corresponding output signal Y has to fulfil the following condition of **linearity**:

Let  $Y_1$  be the detector's response to the input signal  $X_{\lambda l}(\lambda)$  and  $Y_2$  the detector's response to the input signal  $X_{\lambda 2}(\lambda)$ . Then, the detector's response to the superimposed input signal  $X_{\lambda l}(\lambda) + X_{\lambda 2}(\lambda)$  is given by  $Y_1+Y_2$ . Moreover, the detector's response is proportional to the input signal and therefore, the response to the input signal  $a X_{\lambda I}$  $(\lambda)$  is given by  $a \cdot Y_1$  (whereby a denotes an arbitrary positive number). A detector might possibly show a certain dark signal  $Y_0$ (usually dark current or dark voltage), which is a nonzero output signal even when the detector is not exposed to any radiation at all. In this case, Y,  $Y_1$  and  $Y_2$  have to be replaced by Y-Y<sub>0</sub>,  $Y_1$ -Y<sub>0</sub> and  $Y_2$ -Y<sub>0</sub>. Deviations from this behaviour are called nonlinearities and cause measurement errors. However, it is possible to experimentally determine a detector's nonlinearities and

## ${}_{d} = \frac{I(X) - t.I(stray)}{I(open) - I(stray)}$

I(X): signal with sample irradiation I(open): signal with open measurement port and close output port I(stray): signal with open measurement port and open output port

to correct for them. An example of

a nonlinearity effect is the satura-

tion of a detector's output signal at

high radiation levels, which poses

the upper limit of a detector's range

When nonlinearity effects can be

neglected, the detector's output

signal under arbitrary polychro-

matic radiation can be regarded as

a superposition of the detector's

output signals under monochro-

matic radiation. This leads to the

In detail, the CIE defines a detec-

tor's spectral sensitivity (also:

concept of spectral sensitivity.

spectral responsivity) s(λ) by

 $s(\lambda) = \frac{1}{X_{\lambda}(\lambda)} \frac{dY}{d\lambda}$ 

whereby  $X_{\lambda}(\lambda)$  denotes the spectral

radiometric quantity defining the

detector's input signal and dY

denotes the (differential) increase

of the output signal caused by the

input radiation in the (differential)

wavelength interval between  $\lambda$  and

 $\lambda$ +d $\lambda$ . When linear behavior of the

detector can be assumed, the detec-

O f -  $Y = \int_{\lambda} X_{\lambda}(\lambda) \cdot s(\lambda) d\lambda$  ten, the

tor's signal Y is given by

of operation.



Fig. III.10. Integrating Sphere Diffuse Transmittance Measurement Set-up

spectral sensitivity function  $s(\lambda)$  is described by the product of a reference value  $s_m$  and the **relative spectral sensitivity**  $s_r(\lambda)$ :

$$s_r(\lambda) = s_m \cdot s_r(\lambda)$$

In many cases,  $s_m$  is given by the maximum of  $s(\lambda)$ , thus  $s_f(\lambda)$  is normalised to a value of 1 in its maximum. Another possibility is the normalisation of  $s_f(\lambda)$  to a total wavelength integral value 1, which is achieved by the definition of

$$s_m = s(\lambda) d\lambda$$

In terms of relative spectral sensitivity the detector's output signal Y is given by

$$Y = s_m X_{\lambda}(\lambda) \cdot s_r(\lambda) d\lambda$$

This integral relation is equivalent to the definition of photopic quantities, whereby the detector's relative spectral sensitivity  $s_r(\lambda)$  corresponds to the CIE spectral luminous efficiency function V( $\lambda$ ) and  $s_m$  corresponds to  $K_m = 683$  lm/W (see § II.7.f). Similarly, the calculation of effective radiation doses relevant for certain biological reactions is based on a corresponding relation containing the respective biological action spectrum. For instance, the erythemal action spectrum is used for definition of **Sunburn Unit**, which is used for quantification of erythemally active solar UV irradiance (see § VI.1).

This correspondence allows the direct determination of photopic quantities or biologically active radiation by an especially designed integral detector. In particular, the detector's relative spectral sensitivity  $s_r(\lambda)$  has to be matched closely to the CIE spectral luminous efficiency function  $V(\lambda)$  or to the respective action spectrum. For the determination of chromaticity coordinates or correlated color temperature, it is necessary to simultaneously use three detectors with their spectral sensitivities especially adapted to the color matching functions defined by the CIE 1931 standard colorimetric observer (see § II.10.a).

Gigahertz Optik uses different combinations of photodiodes and filters to achieve proper spectral sensitivities for detectors used in photometry, radiometry and colorimetry.

#### III.2.a. Monochromatic radiometry

For radiometric characterisation of monochromatic or near monochromatic radiation of a known wavelength, a detector's spectral sensitivity does not necessarily have to match a certain predefined shape. Thus, a photodiode can be used without any spectral correction filters as long it is sensitive at the respective wavelength.

Typical tasks of monochromatic radiometry are the laser power measurements, characterisation of LEDs with near monochromatic light output and power measurements in fibre optical telecommunication. Gigahertz Optik offers

• laser power meters equipped with a flat field detector (for

lasers with collimated beams ) or with an integrating sphere (for lasers with non-collimating beams and LEDs),

- integrating spheres equipped small area photodiodes, whose low capacitance results in a detector time constant in the order of nanoseconds. Thus, these detectors are perfectly suitable for laser pulse analysis with high time resolution.
- detectors equipped with integrating spheres with unique baffle design for measurements in fibre optics telecommunication. Additional adapters for standard fibre optic connectors are available.



Fig. III.11. Sensitivity ranges of various types of photodiodes

#### **III.2.b.** Polychromatic radiometry

The determination of total radiation power over a certain spectral range requires the detector's spectral sensitivity function to closely match a rectangular shape. Gigahertz Optik offers absolutely calibrated irradiance and radiant power meters equipped with a cosine diffuser or an integrating sphere, whose spectral sensitivity is

optimised for UVA, UVB, UVC, visible (VIS) and near infrared (NIR) ranges.

#### **III.2.c.** Photometry

For photometric measurements, the detector's relative spectral sensitivity  $s_r(\lambda)$  has to match the CIE spectral luminous efficiency function V  $(\lambda)$  as close as possible. In order to quantify a detector's inevitable spectral mismatch, the CIE recommends the evaluation index  $f_1$ ', which is defined by

#### **III.2.d.** Colorimetry

For the determination of a color stimulus X, Y and Z values as defined by the CIE 1931 standard colorimetric observer, the same stimulus has to be measured by three different detectors, whose spectral sensitivity functions have to be adapted to the CIE 1931 XYZ color matching functions (see § II.10.a). However, as the  $x(\lambda)$  color matching function consists of two separated regions of sensitivity, the X value is often determined by two detectors. In this case, altogether four detectors are needed for the determination of a stimulus' X, Y and Z values. As the color match-

#### **III.3.The detector's time behaviour**

A detector's time resolution is limited by its response to an instantaneous change of the input signal. Due to electrical capacities of the light sensitive element and the electronics, the output signal does not change instantaneously as well but gradually increases or decreases until it reaches its final value. The detector's rise time is defined by the time span required for the output signal to rise from a certain low percentage (usually 10%) to a certain high percentage (usually 90%) level of the maximum value when a steady input is instantaneously applied. Accordingly, fall time is defined by the time span required for the output signal to drop from a certain high

percentage (usually 90%) to a certain low percentage (usually 10%) of the maximum value when a steady input is instantaneously removed.

Typically, the detector's response to an instantaneous change of the input signal exponentially approaches the final value. In that case, the detector's time behaviour is best described by the time constant  $\tau$ , which is the time span required for the output signal to vary from its initial value by 63% of its final change (the value of 63% is derived from 1 - 1/e, which equals 0.63). The temporal change of the output signal Y(t) from its initial value Y<sub>0</sub> to its final value Y<sub>f</sub> is then given by

$$Y(t) = Y_0 + (Y_f - Y_0) \cdot e^{-\frac{t}{\tau}}$$

Gigahertz Optik's integral detectors use photodiodes, which are typically characterised by time constants of µs. As most variable light sources change their intensity levels in significantly longer time scales, the detector's time constant is not really an issue for most applications. However, especially lasers are often pulsed with a frequency in the order of 10<sup>9</sup> Hz (for example in telecommunication), which corresponds to signals periods in the order of 1 ns. In that case, the relatively slow response of normal photodiodes prevents the accurate characterisation of the

laser signal's time characteristics. For this application, Gigahertz Optik offers the LPPA-9901 detector, which uses a photodiode with an especially small capacity. This allows to reduce the LPPA-9901's time constant to a value of 5 ns.



 $\left\| s_{r}^{*}(\lambda) - V(\lambda) \right\| d\lambda$ 

 $V(\lambda) d\lambda$ 

 $S_A(\lambda) V(\lambda) d\lambda$ 

where  $s_{r}^{*}(\lambda)$  is given by

metric measurements.



where  $S_A(\lambda)$  is the spectral distribution of the CIE standard Illuminant A (see § II.10.), which is the recommended photometric calibration source. High quality photometric detectors show a value for f1' below 3%, whereas a value of  $f_1$ ? above 8% is considered as poor quality. The DIN 5032, part 7 requires a spectral mismatch of f1'

 $\leq$  3% for "Class A" instruments and  $f_1$ '  $\leq 6\%$  for "Class B" instruments. Gigahertz Optik offers high quality illuminance, luminance and luminous flux detectors meeting Class A level  $(f_1' = 3\%)$  and, as an economical alternative, detectors meeting class B level ( $f_1$ ' = 5%).



#### III.4. The detector's dynamic range

In general, a detector fulfils the condition of linearity (see § III.2.) only for a limited range of the input signal level. There are two effects which define the boundaries of this **dynamic range**:

• At very low levels of the input signal, the detector's output is largely dominated by noise. Noise is a random temporal fluctuation of the output signal which occurs even when the input signal is constant. The absolute level and the frequency distribution of these variations depends on the physical properties of the detector and the subsequent electronics. For many detectors, noise is largely independent from the absolute level of the input signal and can be neglected for input signals above a certain minimum level. However, for very low input signals, the output signal is dominated by

noise and does no longer quantify the physical quantity which should be determined. The lower limit of the measurement range, which is posed by noise, is quantified by the noise equivalent input. The CIE defines the noise equivalent input as the value of the respective physical quantity (radiant power or luminous flux, irradiance or illuminance, ...) that produces an output signal equal to the root mean square noise output. As the shape of the noise signal depends on the temporal resolution that can be achieved of the recording electronics (often characterised by the electronics' time constant), the noise equivalent input is defined for a stated frequency and bandwidth. Unless otherwise stated, a 1 Hz bandwidth is usually considered. Depending on the detector's characteristics, its noise level can be reduced by

longer detector integration times or by averaging subsequent measurements of the same input signal.

• At high levels of the input signal, the detector's output signal no longer increases proportional to its input signal, and thus the detector no longer fulfils the condition of linearity (see § III.2.). Instead, physical limits of the light sensitive element and / or the electronics cause saturation of the output signal, which increases less than proportional to the input signal and finally reaches a constant level. To a certain extent, subsequent correction of the detector's output signal can account for the effects of saturation and thus extend the detector's dynamic range. This correction has to be based on a thorough laboratory investigation of the detector's dynamic behaviour and still leads to higher measurement uncertainties at high levels of the input signal.

The detector dynamic range depends on the photodiode type The overall measurement system dynamic range will depend on both the detector and electronic meter's range capabilities. For example, a typical silicon photodiode is capable of measuring more than 2 mA of current before saturating, however the upper current measurement range of the meter may be limited to  $200 \,\mu$ A.

This range covers extremely low intensity levels, for instance the quantification of erythemally active UV radiation, or very high intensity levels, which are used for industrial UV curing processes.

#### **III. 5. Calibration of integral Detectors**

Calibration is the determination of the correlation between an input and an output quantity. All measurement instruments, such as voltmeters, manometers, vernier calipers, etc., must be calibrated to determine the variation in reading from the absolute quantity. In radiometry, the input quantity is provided by standard lamps and optical radiation detector standards. Because of the many different measurement quantities involved, calibration standards for each quantity are required if an optical radiation calibration laboratory hopes to cover the whole range of possible calibrations. A 'traceable' lab calibration standard should show an unbroken chain of links to national

(better international) standards. But this in itself does not guarantee accuracy or the ability of the lab to meet its calibration uncertainty claims. Since calibration standards are subject to change with age and use, a means to periodically check the calibration of the standards themselves must be in place. Occasionally the standards must be replaced in order to maintain the quality of calibration and traceability. The end user of the calibrated product may be required to audit the calibration facility to ensure its competency and traceability. In Germany, the Deutsche Kalibrierdienst - DKD (the German accreditation institution) and the Physikalisch-Technische Bundesanstalt

(the German national standard laboratory) offer an accreditation service for industrial calibration laboratories where the lab's calibration standards, calibration procedures and the stated recalibration intervals are subject to audit. This accreditation ensures that the traceability of the calibration is on an absolute level. The DKD also ensures the international acceptance of its accredited calibration laboratories. Refer to Appendix VI.6 for more information on national calibration organizations.



Fig. III.14. GO Calibration Engineer

#### III.5.a Traceability: an Unbroken Chain of Transfer Comparisons

C a libration is the most important prerequisite for accuracy in measurement instrumentation. It is the foundation upon which subsequent measurements are based upon. Optical radiation calibration is typically done by the transfer method where the relationship between the value indicated by a measuring instrument and the value represented by a calibration standard is compared with the former

reading adjusted as needed, re-

corded and certified.

Since the reading of a meter-undertest is directly compared against that of the transfer standard, the qualification of this standard is of the highest importance.

A qualified standard should display an unbroken chain of transfer comparisons originating at a national standards laboratory. For example, the transfer standard of the national laboratory, primary standard (A) is used to calibrate the reference standard (B) at an accredited calibration laboratory. This reference standard is used to calibrate the laboratory work standard (C) to be used daily by the cal lab. This work standard is then used to calibrate the final product (D) or device under test. Accordingly, the calibration path is A-B-C-D. This path is called the chain of traceability. Each transfer device in the chain should be subjected to periodic examination to ensure its long-term stability. The lab performing the calibration typically sets the time span between examinations and is self audited.

#### III.2.b. Polychromatic radiometry





Accredited calibration laboratories guarantee recalibration cycle times for their standards plus a review of their calibration procedures since they are subject to review by an official accreditation authority.

Fig. III.16 - Hierarchy of Standards

#### III.5.b. ISO/IEC/EN 17025 (formerly ISO Guide 25 and EN45001)

The aims of the General Requirements for the Competence of Calibration and Testing Laboratories are to provide a basis for use by accreditation bodies in assessing competence of laboratories; establish general requirements for demonstrating laboratory compliance to carry out specific calibrations or test; and assist in the development and implementation of a laboratory's quality system. \* Without exception, DKD accredited calibration laboratories fulfill the requirements of the European standard EN 45001 (general criteria to operate a testing laboratory, May 1990). Outside of Europe this standard is not compulsory. Instead of this the ISO/IEC Guide 25 (General requirements on the competence of testing and calibration laboratories, December 1990) is recognized. In content, EN 45001 and ISO/IEC Guide 25, known as ANSI/NCSL Z540-1 in the United States, is identical. This is the basis for the mutual appreciation between the European cooperation for Accreditation (EA) and its extra-European partners. In 1999 ISO/ IEC 17025 took the place of EN 45001 and ISO/IEC Guide 25 which eliminated any formal differences. ISO/IEC/EN 17025 is compatible with A2LA and NVLAP requirements. \*ISO 17025 web page : http://

www.fasor.com/iso25

#### **III.5.c** Calibration Quantities

#### Spectral Irradiance W cm<sup>-2</sup> nm<sup>-1</sup>

Irradiance (W/m<sup>2</sup>) measured as a function of wavelength (nm), is known as spectral irradiance. This type of source calibration is performed with a spectral measurement device or spectroradiometer as compared to a reference standard. The spectral range of calibration depends on the source and spectral zone of interest. A typical QH lamp may be spectrally scanned from 200 to 2500 nm using a fixed wavelength increment or variable bandwidth depending on the required resolution.

#### Spectral Radiance

#### W cm<sup>-2</sup> sr<sup>-1</sup> nm<sup>-1</sup>

Radiance  $(W/cm^2 \cdot sr)$  measured as function of wavelength is called spectral radiance. Radiance in a given direction, at a given point of a real or imaginary surface is the optical unit used to calibrate optical radiation sources. Calibration is normally performed with a spectral measurement system or spectroradiometer equipped with a radiance lens assembly that has been calibrated with an integrating sphere based radiance standard. The spectral range of calibration will depend on the source and the spectral range of interest. A full spectral scan may cover from 350 to 2500 nm.

#### **Spectral Responsivity**

Optical radiation detectors, photodetectors, photodiodes, exhibit changes in sensitivity at different wavelengths. This spectral responsivity can be measured as relative responsivity in percent (%) versus wavelength (nm) across the active wavelength bandpass of the photodevice. For example a silicon device scan could cover the wavelength range from 250 to 1100 nm at a set increment. Or a GaAsP photodiode from 250 to 700 nm. The increment setting could span from 1 to 50 nm depending on the required resolution. Also, single point response at a particular wavelength may be all that's required for some applications. Calibrations are performed by transfer comparison and certified against qualified reference standards.



Fig. III.18. InGaAs Detector with sphere. Relative Spectral Response Plot

#### Illuminance Sensitivity lux / foot-candles

Calibration of the illuminance response of photopic detectors is normally performed as a transfer comparison from a photopic reference standard. The photometric responsivity of the reference standard can be qualified through radiometric measurement using red, blue and green filtered photodetectors. However this is a complicated procedure left to advance radiometry labs. Illuminance sensitivity calibrations allow direct reading of the photopically corrected detector in lux or foot-candles. Very often a tungsten source is used for illuminance calibrations. If the photopic

detector spectral response does not match the CIE photopic curve too a high degree, measurement errors will occur when measuring different type sources.

## Luminance Sensitivity cd/m<sup>2</sup> & fL

Luminance responsivity of photopic detectors equipped with field limiting input optics is accomplished by comparison to a luminance reference standard detector. A uniform field of luminance is produced as the calibration source using an integrating sphere or a source with an optically diffuse material in front of it. Luminance detector's field of view is confined

1,5

Λ

380 430 480 530 580 630 680 730 780

sensitivity

only.

to a narrow angle so that the detection area is overfilled with a sample of the uniform luminance field. Luminance detectors are calibrated to measure in the optical units of candela per square meter and footlamberts.

#### Color Sensitivity

Broadband colorimetric detectors are calibrated by comparison to reference standards based on CIE tristimulus values using a light source of known color temperature. Color temperature, luminance and illuminance calibrations may be included depending on the color meters capability. The color meter is calibrated to display the color chromaticity coordinates x,y and /or u', v' of the light source under test.

--- x short

-- x long

- · 7

#### Irradiance Sensitivity W/m<sup>2</sup> & W/cm<sup>2</sup>

Broadband irradiance detector calibrations are performed by transfer comparison to reference standards with consideration to the spectral characteristics of the detector to be tested. Reference detectors are calibrated against spectral irradiance measurements using a double monochromator spectroradiometer, itself calibrated using traceable spectral irradiance standards. Irradiance detectors are calibrated to read out in the optical units of watts per square meter or watts per square centimeter over a specific wavelength range.



#### Fig. III.19. CIE Scotopic and Photopic Function

#### Spectral Reflectance

Calibration of the spectral reflectance of materials is accomplished by comparison to reference reflectance standards which themselves are used to set-up calibration of the spectrophotometric instrument which actually performs the measurement. Single or double beam spectrophotometers can spectrally range from 250 to 2500 nm, with adjustable wavelength increments. When coupled to an integrating sphere; total hemispherical, diffuse and specular reflectance can be separately measured with the spectrophotometer. Without the sphere the in-line set-up of the spectropho-

## tometer measures the normal specular reflectance component





Fig. III.22. 8 Degree Reflectance Measurement Set-up

#### Spectral Transmittance

ength ( nm )

Fig. III.20. Color Detector Tristimulus Functions

Calibration of the spectral transmittance of materials is accomplished by comparison to reference transmission standards which themselves are used to set-up calibration of the spectrophotometric instrument which actually performs the measurement. Single or double beam spectrophotometers can spectrally range from 250 to 2500 nm, with adjustable wavelength increments. When coupled to an integrating sphere; total hemispherical, diffuse and regular (specular) transmittance can be separately measured with the spectrophotometer. Without the sphere the in-line set-up of the spectrophotometer measures the

#### Fig. III.21. BLUE Spectral Response Irradiance Detector

nath ( nm )

320 340 360 380

regular reflectance component only. Calibration is performed as percent transmission versus wavelength.

400 420 440 460 480 500 520 540





## **III.5.d Calibration Standards** Calibration standards are employed

to generate an input quantity for the equipment used in the calibration. Since the calibration standard supplies a signal of known quantity, the difference of the output signal of the equipment to the signal of the calibration standard can be evaluated. From these differences calibration correction factors can be calculated allowing absolute readings when the output signal is corrected by these values. For photometric and radiometric measurement quantities different calibration standards are needed: Photometric – Radiometric Quantity:

- Luminous Flux Radiant Power Luminous Intensity – Radiant Intensity
- Luminance Radiance
- Illuminance Irradiance

Equivalent photometric and radiometric quantities exist where the measurement and therefore calibration geometry is the same. The only difference is the radiometric or photometric responsivity of the detection system. This means most calibration reference standards can

be used for both, photometric and radiometric calibration, if the calibration data is available. For very precise or close tolerance calibrations specially selected calibration standards are needed. Typically calibration standards are used as transfer standards, meaning they transfer the values of the primary standard to a lab standard for subsequent transfer to a device under test. For traceable calibrations an unbroken chain of transfer comparisons back to the national primary standard is certified. Calibration uncertainty is of course

dependent on the calibration hierarchy of the standard. Since the calibration transfer is a real hardware transfer of the standard itself, careful handling and operation of the calibration standard is extremely important. In imaging applications the uniformity of response or transmittance is critical. So light sources with a uniform luminous area are needed to determine the nonuniformity of a lens system or visual imaging detection system

#### **Source Based Standards**

Every optical radiation detection or measurement system needs to be calibrated in reference to an optical radiation source. There are two possible ways to handle the calibration:

- The source may be calibrated in the required quantity and the difference between the input signal, generated by the source, and the output signal of the detection system can be determined using the calibration data of the source
- The uncalibrated source may be operated under stable conditions and the calibration done by comparing the reading of the detection system with a calibrated detection system (reference standard). The reference standard must have the same measurement geometry and the same spectral response as the unit to be calibrated.

The most common optical radiation source used for calibration standards is the tungsten halogen lamp

#### **Detector Based Standards**

Due to the high levels of maintenance and care required to operate optical radiation source based calibration standards, detector based standards are very attractive alternatives. The detector has the advantage of long-term absolute and mechanical stability, especially true of semiconductor detectors. The use of detector-based standards is very common in monochromatic

**Spectral Irradiance Standards** 

Tungsten Halogen lamps are the 'workhorse' of spectral irradiance standards.

FEL type lamps with a filament support arm are recommended for high intensity BLUE light and UV applications.

Sylvania calibration grade lamps are recommended for visible and near IR applications where the best long term stability is required. In order to qualify for calibration as a standard, each lamp must undergo a minimum 15-hour burn-in procedure and must display a satisfactory burn-in data trend during this period. The calibrated tungsten reference source provides spectral irradiance data from 250 to 2500 nm covering many typical UV-Vis-IR radiometric and photometric applications.

The lamp is normally provided in a housing and socket made from

cate. Comparing the lamp output against other in-house reference standard sources or against suitable reference detection systems must be periodically done to check stated lamp calibration uncertainty. In radiometric applications, where the spectral characteristic of the source is used, the source should be operated in current controlled mode, to ensure the stability of the spectral characteristic. The minimum specification for current stability should be held at 10<sup>-4</sup> A. In photometric applications or radiometric applications with broadband detectors, intensity controllable standards can be used radiometric applications such as the calibration of laser power meters for telecommunication testing. But because of surface reflections, polarization effects, beam mis-

alignment and beam 'bounce-back'

errors, the use of detector based

calibration standards must be care-

The use of spectrally broadband

detectors as calibration standards is

ceramic or other material which

ensures long-term stability and

protection. Filament targeting aids

may be provided for best measure-

ment accuracy in the calibration

fully considered.

laboratory.

since its emission spectrum is close

to a Planckian radiator (blackbody

source). Other sources where opti-

cal radiation is produced by means

of an element heated to incandes-

cence by electrical current are also

in use. Filament position and stabil-

ity of the tungsten halogen lamp is

critical plus it has a limited life-

time. Therefore the lamp should

only be operated in the position

specified in the calibration certifi-

if changes in the spectral emission characteristics are not critical. If the tungsten halogen lamp is used as a spot source the exact location on the filament used during the calibration of the source, must be subsequently used. In luminance, radiance and imaging uniformity calibrations, tungsten halogen lamps must be fitted with a diffuse screen or placed within an integrating sphere. Sphere based luminance and radiance standards offer higher uniformity and a better diffuse function.

For calibrating luminance and

Fig. III.24. Diffuse Screen & Integrating Sphere

mostly limited to photometric applications where detectors with a precise filter corrected photometric spectral response are available. Calibration is performed by comparison of the output signal of the reference detector to that of the device to be calibrated. The same stable source of optical radiation is used during the calibration procedure. For monochromatic calibra tions a monochromatic radiation source is needed. If a detector's spectral responsivity is to be measured over its entire active bandpass, a tungsten halogen lamp with a monchromator attached to it can be used to create monochromatic radiation at all of the different required wavelengths.

2500



Fig. III.25. FEL Calibration Standard Lamp



radiance meters with a limited

field-of-view, a diffuse transmitting

screen can be used at the sphere

output. In imaging applications the

uniformity and the diffuse function

of currently available screen mate-

rials are not precise enough so the

open output port of the sphere is

If the intensity of the tungsten

halogen lamp is not high enough,

which happens especially in the

UV range, arc lamps such as xenon

lamps may be used. But the in-

crease in intensity can affect cali-

typically used.



bration uncertainty.



## Page 178 - Tutorials

## 🕞 Gigahertz-Optik

## **Measurement of Light**

#### Luminance Standards

Reference sources of luminance are used to calibrate the uniformity of imaging systems and the luminance output of luminance meters, spot exposure meters and other photometric equipment.

The standard is constructed around the integrating sphere of various diameters which provide the highly uniform diffuse luminance at the exit port required for these types of calibrations. The spheres may be coated with barium sulfate or ma-



Fig. III.27. Luminance Standard

#### Spectral Radiance Standards

Reference sources of radiance are used to calibrate radiance detectors and other radiometric equipment. The standard is constructed around the integrating sphere of various diameters which provide the highly uniform diffuse radiance at the exit port required for these types of

chined from optically diffuse plastics. Seasoned tungsten halogen sources are typically used with lamp power supplies and temperature stabilized photometric reference detectors to form the complete system. Control feedback loop techniques control the luminance output intensity and help prolong the useable lifetime of the system. Any change in ambient and sphere body temperature affecting the output signal is eliminated through the temperature stabilized reference detector. This also reduces system warm-up time.

An optimally designed sphere layout is capable of less than  $\pm$  0.7% non-uniformity over 90% the port opening which can be as large as 100 mm in diameter. Angular uniformity of less than  $\pm$  5% within  $\pm$ 40° enables luminance output calibration of detection systems with wide acceptance angles. Luminance outputs can range from 0.5 to 35000 cd/m2. Some stan-



Fig. III.28. Typical Luminance Uniformity Response Plot

dards may offer a variable luminance output requiring more sophisticated electronics, multiple lamps and exhaust fans. In order to qualify as a calibration standard the system itself must be calibrated by a competent calibration facility. Luminance output, uniformity and angular uniformity must be measured and certified.

stabilized reference detector. This

#### re calibrations.

The spheres may be coated with barium sulfate or machined from optically diffuse plastics. Seasoned tungsten halogen sources are typically used with lamp power supplies and temperature stabilized photometric reference detectors to form the complete system. Control feedback loop techniques control the luminance output intensity and help prolong the useable lifetime of the system. Any change in ambient and sphere body temperature affecting the output signal is eliminated through the temperature



also reduces system warm-up time. An optimally designed sphere layout is capable of less than  $\pm$ 0.7% non-uniformity over 90% the port opening which can be as large as 100 mm in diameter. Angular uniformity of less than  $\pm$  5% within ±40° enables luminance output calibration of detection systems with wide acceptance angles. Some standards may offer a variable radiance output requiring more sophisticated electronics, multiple lamps and exhaust fans. In order to qualify as a calibration standard the system itself must be calibrated by a competent calibration facility. Radiance output, uniformity and angular uniformity must be measured and certified.

Fig. III.29. Variable Radiance Standard

#### **Spectral Responsivity Standards**

Due to their long term stability and broad spectral coverage, silicon photodiodes are used as reference spectral standards by national and private calibration laboratories worldwide.

These photodiodes with active areas as large as 100 mm<sup>2</sup>, are mounted into machined housings to protect and precisely fix the detector in a calibration set-up in concert with targeting aids. Some housings may include an integral temperature sensor to monitor thermal characteristics during test sessions. Or to ensure best measurement uncertainty, temperature stabilization using cooling jackets that maintain the device temperature to within  $\pm 0.5$ °C are employed. UV enhanced Si devices offer spectral coverage from 250 to >1100 nm. Calibration with certification from an accredited traceable calibration facility is required to qualify the device for use as a reference standard.



Fig. III.30. Typical Spectral Radiance Plot

#### **Reflectance Standards**

White optically diffuse reflectance standards traceably calibrated for spectral reflectance over a spectral range from 250 to 2500 nm are used in the calibration of reflectance meters, optical distance measurement systems, densitometers, spectrophotometers and other optical and imaging systems. Qualifications of a reflectance standard include light and temperature stability and durability, near Lambertian diffuse reflectance and up to 98% spectrally neutral reflectance over the spectral range of interest. Processed PTFE machined and cut into various shapes and thicknesses is currently used for reflectance standards. High reflectance white, black and gray shades at varying reflectance values are available.

To maintain the quality of a calibrated standard it is normally mounted into a protective housing with a removable lid to keep the material clean and covered when not in use.



#### **IV. Detector Signal Measurement**

A typical light detector or photoactive device converts impinging photons into a current or voltage proportional to the incoming signal.

The detector connects to an electronic meter for amplification, possible conversion from an analog to digital signal (ADC), calibration and display of the measurement result. Together, the meter, photodetector and accessory components form an optometer, radiometer, photometer, color, laser or optical power meter and reflection/ transmission measurement systems. A radiometer consists of a voltage or current meter coupled with a radiometric type detector. Photometers employ the same meters used with photometric type detectors. Multi-channel color meters

are used with colorimetric detectors to display multiple quantities. The optometer is a term used to indicate that the meter can be used with either radiometric or photometric type detector heads. Microprocessor controlled units capable of measuring currents down to tenths of picoamperes up to a few milliamperes are available. This allows full utilization of the sensitivity range of most photosensitive devices. Measurement methodology might employ 16-bit signal digitization by means of an analog to digital converter (A/D) with sampling rates in the microseconds. Selectable averaging calculation of the sampled results from microseconds to seconds provides more measurement flexibility for fast events or low-level signals. Operation of the device can be accomplished through a logical menu structure with user input via frontpanel keyboard or through computer control via RS232 or IEEE computer interface.

The quantity or optical unit measured will depend on the detector type, how it's configured in the way of filtering and input optic, and its calibration. Radiometers are available in hand-held mobile or bench-top models for laboratory use. Self-contained cordless models are used for remote dynamic monitoring where a standard detector that connects to the meter via a cable might foul. Capabilities such as dynamic measurement range, operating modes (example: CW, dose, pulse energy) and features (example: auto-ranging, backlit

display, digital interface, datalogging) separate the different models. Usually the application determines what specific capabilities are important to have in the radiometer system. For example, in a UV curing production process where multiple stations must be monitored, a multi-channel radiometer with settable min/max reading feature, RS232 or IEEE interface and remote multiplexed detectors would be desirable.

The following is a list of various features, modes of operation and specifications offered in current light meters. Note that available features and functions will vary depending on the type of meter and manufacturer.

#### **Operating Modes & Features:**

**CW**: Continuous wave is a run of continuous type measurements. The measurement frequency depends on the *integrating time* and the max. *sample rate*. of the meter.

**CW Min/Max**: CW measurement where the min. or max. value that occurred during the measurement run will be displayed. The min. or max. value can be reset with the RESET switch.

**CW Level Check**: CW measurement where the measurement values are compared against min.-max. threshold values. The threshold values are entered into the meter by the user.

**CW Level Minimium** / **Maximum**: Menu to adjust the threshold values for CW Level Check.

**Run/Hold**: To freeze a measurement value on the display and stop the continuous measurement.

**Relative Ratio** (%): Measurement value as the relative ratio of a reference value (stored in the optometer) or a reference measurement value (2-channel optometer required).

**Relative Ratio Factor**: Measurement value as the relative ratio factor of a reference value (stored in the optometer) or a reference measurement value (2-channel optometer required).

Attenuation (dB or dBm): Measurement value as the logarithmic ratio factor (attenuation) of a reference value e.g. dBm (stored in the optometer) or a reference measurement value e.g. dB (2-channel optometer required).

**Dose:** CW measurement values integrated over the dose measurement time. A preset dose measurement time or a max. dose value will stop the measurement.

**Data Logger**: Each measurement value of a CW measurement will be stored individually in the optometer's memory. Each measurement may be manually or automatically initiated by a preset measurement cycle time. Measurement data can be outputted through computer interface.

**Color**: Chromaticity coordinates x,y and  $u^{*},v^{*}$  and the correlated color temperature are calculated from the ratio of the detector's signals.

**Peak Maximum**: Each CW measurement interval consists of a certain number of samples (number depends on integration time and sampling rate). Peak Maximum is the most positive sample of one measurement interval. A new Peak Maximum is calculated and displayed for each measurement interval.

**Peak Minimum**: Each CW measurement interval consists of a certain number of samples (number depends on integration time and sampling rate). Peak Minimum is the most negative sample of one measurement interval. A new Peak Minimum is calculated and displayed for each measurement interval.

**Peak to Peak**: Each CW measurement interval consists of a certain number of samples (number depends on integration time and sampling rate). Peak to Peak is the difference of the most positive to the most negative sample of one measurement interval. A new Peak to Peak value is calculated and displayed for each measurement interval.

**I-Effective**: Measures and calculates the energy of light pulses based on the Schmidt-Clausen formula. The input signal is sampled with the max. sampling rate for one measurement interval (Pulse Measurement Time). First the pulse-energy is calculated by integrating the samples. I-Effective is calculated by using the pulse-energy and the peak-value of the measurement interval using the following formula:

I-effective = peak-value \* pulse-energy / (peak-value \* C + pulse-energy)

C = IF-Time Constant (between 0.1s and 0.2s, depending on application) IF Time Constant: Factor C for calculation of I-Effective (Schmidt-

Clausen).

**Pulse Energy**: Measures and calculates the energy of light pulses. The input signal is sampled with the max. sampling rate for one measurement

interval (Pulse Measurement Time). The energy is calculated by integrating these samples.

**Pulse Measurement-Time**: Measurement interval for I-Effective and Pulse Energy measurements.

**Remote RS232**: enables RS232 interface of the device. RS232 is a standard for Asynchronous Transfer between computer equipment and accessories. Data is transmitted bit by bit in a serial fashion. The RS232 standard defines the function and use of all 25 pins of a DB-25 type connector. Minimally configured, 3 pins (of a DB-9 type connector) are used, namely: Ground, Transmit Data and Receive Data. On PCs, the RS-232 ports labeled as "serial" or "asynch" and are either 9 or 25 pin male type.

**Remote IEEE488**: Interface IEEE488 of the device enabled. IEEE488 is a standard for Parallel Transfer between computer equipment and measurement instruments. Data is transmitted in parallel fashion (max. speed 1MByte/s). Up to 31 devices (with different addresses) can be connected to one computer system.

**USB**: a communication standard that supports serial data transfers between a USB host computer and USB-capable peripherals. USB specifications define a signaling rate of 12 Mbs for full-speed mode. Theoretically 127 USB-capable peripherals are allowed to be connected to one USB host computer. The connected devices may be powered by the host computer. **Auto Range**: when activated, the measurement range is switched by the device automatically to the optimal value (depending on the input signal).

#### Specifications:

**Slew-rate**: how fast a signal changes. For example, a rate of 5 Volt/ms means that the signal changes with a value of 5 Volts every ms.

**Rise-time**: Time needed for a signal to change from 10% to 90% of its final value.

Fall-time: Time needed for a signal to change from 90% to 10% of its start value.

**Input Ranges / Measurement Range**: To achieve a dynamic measurement capability greater than six decades, different levels of measurement ranges (Gains) for the "current to voltage input amplifier" are necessary. Gains can span from 1V/10pA to 1V/1mA (depending on the device). **Linearity**: The linearity of an optometer can be described as follows:

Reading a value of 10nA, with a max. gain error of 1%, the possible error is +/-0. InA. Together with an additional offset error of 0.05nA, the total measurement uncertainty would be 10nA +/-0.15nA or 1.5%.

At a reading of only 1nÅ in the same gain range, the gain error would be 1% of 1nA or 0.01nÅ. The offset error would still be 0.05%. The total measurement uncertainty would be 1nA +/-0.06nA or 6%. The offset error is minimal with our optometers since these meters offer an internal offset compensation or allow an offset zero setting from the menu. Here the only offset error is from the display resolution or the nonlinearity of the analog-digital converter (ADC).

**Measurement Accuracy / Linearity**: The max. possible error of a measurement result can be calculated as follows:

Total Error: Gain Error + Offset Error

Gain Error: Displayed (or readout) result X (Gain Error (in percent) / 100)

Offset Error: Constant value depending on measurement range

The Offset Error can be nearly eliminated be using offset compensation.

**Manual Range**: with autorange disabled, the measurement range can be manually fixed to a certain value. The device is not allowed to switch measurement ranges automatically. Manual range adjustment can be useful in cases where input signals are changing rapidly.

**Calibration Factor**: Optical sensors transform optical signals into current. This current is measured by the device. <u>The calibration factor determines the</u> relationship between the measured current and the calculated and displayed measurement result (optical signal).

**Offset**: The Offset value is subtracted from the measured signal to calculate the result. Offset can be set to zero or to the measured CW-value. Offset is useful to compensate for the influence of ambient light or if the measurement value is very small relative to the adjusted measurement range.

**Integration Time**: Time period for which the input signal is sampled and the average value of the sampled values is calculated (>CW). Integration time should be selected carefully. For example, if multiples of 20 ms (50 Hz) are selected as the integration interval, errors produced by the influence of a 50Hz AC power line can be minimized.

Sampling Rate: The rate which specifies how often the input signal is measured (sampled). The CW-value is calculated using the average value of all samples of one measurement interval (integration time). A sampling rate of 100ms means that 10000 samples per second are taken. If the measurement interval (integration time) is 0.5 s, there are 5000 samples used to get the CW value.

Some errors cannot be compensated because they are produced by the nonlinearity of the ADC (Analog Digital Converter) and the display resolution.

Maximum Detector Capacitance: The input current-to-voltage ampflifier is sensitive to input capacitance. If the input capacitance is too large, the amplifier may oscillate. The maximum detector capacitance is the largest value of capacitance for which the amplifier will remain out of oscillation. Measurement Range: The measurement range is typically specified by the resolution and the max. reading value. But the user should note that for a measurement with a max measurement uncertainty of 1%, the min. measurement value should be a factor of 100X higher than the resolution. On the other hand, the max. value may be limited by the detector specifications such as max. irradiation density, max. operation temperature, detector saturation limits, etc., and therefore the manufacturer's recommended measurement values should be adhered to.

#### Radiometer Schematic

Input Device + Filter + Amplifier / Processor / Display / Outputs Analog Signal Extension Digital Signal

Fig. IV.1. Radiometer Schematic
**Integrating Spheres** 

## V. Theory and applications of integrating spheres

Integrating spheres are very versatile optical elements, which are designed to achieve homogenous distribution of optical radiation by means of multiple Lambertian reflections at the sphere's inner surface. The primary radiation source can be located either inside the sphere or in front of the source's entrance port. In the latter case, only the optical radiation entering the sphere is relevant for the sphere's internal radiation distribution.

As long as we restrict ourselves to those regions which are shielded from direct irradiation by the primary source and are thus only illuminated by reflections at other of the inner surface, the theory of the ideal integrating sphere leads to two important conclusions: surface is proportional to the total radiant power either emitted by a source inside the sphere or entering the sphere through its entrance port. Geometrical and directional distribution of the primary source's radiation do not influence irradiance levels as long as direct illumination of the respective location is prevented. This property becomes especially important when an integrating sphere is used as the input optical element of a detector for radiant power (see § III.1.b).

• Radiance reflected by a region of the sphere's inner surface shielded from direct illumination is constant in its directional distribution and independent from the specific location where the reflection occurs. Thus, the



Fig. V.1. Integrating sphere used as a standard source for optical radiation. Multiple Lambertian reflections inside the sphere result in a homogenous radiance and exitance distributions at the sphere's exit port.

bv

sphere's exit port can be used as an ideal Lambertian source as optical radiation leaving the sphere is characterised by homogenous radiance and exitance distributions. This property becomes especially important when a sphere is used as a standard calibration source.

• Irradiance of the sphere's inner

# V.1. Theory of the ideal integrating sphere

The ideal integrating sphere, a theoretical construction which allows the explanation of the sphere's basic principle of operation, is characterised by the following properties:

- Its entrance and exit ports are infinitesimally small.
- All objects inside the sphere, light sources and baffles, are also infinitesimally small and their influence on optical radiation after its first reflection at the sphere's inner surface can be neglected.
- Its inner surface is a perfectly homogenous Lambertian reflector, and its reflectance ρ is independent from wavelength. For a more detailed discussion of reflective materials largely fulfilling these properties, see § II.5.c. and III.1.a.

During the following considerations, the symbol index describes the order of reflection. So,  $E_0$  denotes the irradiance caused directly by the light source, whereas  $E_1$ ,  $E_2$ ,



Fig.V.2. Geometry of an ideal integrating sphere of radius R.

... denote the irradiance caused by light from the source after one, two, ... reflections. Total irradiance is then given by the infinite sum

$$E_{total} = E_0 + E_1 + E_2 + \dots$$

For convenience, the index "e", denoting radiometric quantities, is omitted. However, if the reflectance  $\rho$  of the sphere's coating material is independent from wavelength, the derived relations also hold true for photometric quantities, which would be denoted by the index "v".

Lets consider an ideal integrating sphere of radius R, consisting of a hollow perfect Lambertian reflector with infinitesimally small entrance and exit ports. An inhomogeneous radiation source produces direct irradiance levels  $E_0$  (the term "direct irradiance" refers to the fact that E<sub>0</sub> is directly caused by the source without any reflections) which depend on the respective location at the sphere's inner surface (Fig.V.2). As a first step, we want to calculate the irradiance E<sub>1</sub> of the sphere's inner surface, produced by the radiance L1 after the first reflection. Due to the Lambertian reflection property of the sphere's material, the radiation reflected by a certain area element dA is characterised by a constant directional radiance distribution L. According to

Equ. II.7 in paragraph II.5.c, the area element's exitance  $M_1$  is related to the reflected radiance  $L_1$  by

$$M_1 = L_1 \pi$$

and is further related to the element's direct irradiance  $E_0 \; \mbox{by}$ 

 $M_1 = \rho E_0$ 

whereby  $\rho$  denotes the total reflectance of the sphere's inner surface.

As a consequence,

$$L = \frac{\rho E_0}{\pi} \qquad Equ.V.1$$

Although L does not depend on the direction relative to the surface element dA, it still depends on the location at the sphere's inside, which is a consequence of the generally irregular direct illumination by the light source.

If we want to calculate the radiant power emitted by the area element dA and impinging upon another area element dA', we have to calculate the solid angle of dA', as seen from dA (Fig.V.2). As dA' is tilted by an angle  $\varepsilon$  relative to the line of sight between the two area elements, dA' occupies the solid angle d\Omega', as seens from dA:

$$\Omega' = \frac{\cos(\varepsilon) \, \mathrm{d}A'}{\mathrm{d}^2}$$

d

with d denoting the distance between dA and dA'.

According to Equ.II.3 in paragraph II.4.d., the radiant power emitted by dA into the solid angle  $d\Omega'$  and thus impinging upon dA' is given

A: 
$$E_{1} = \prod_{\text{inner surface}} \frac{E_{0} \rho}{\pi} \frac{1}{4 R^{2}} dA = \frac{\rho}{4 \pi R^{2}} \prod_{\text{inner surface}} E_{0} dA = \frac{\rho \Phi_{0}}{4 \pi R^{2}}$$

B: 
$$E_{2} = \prod_{\text{inter}} \frac{E_{1} \rho}{\pi} \frac{1}{4 R^{2}} dA = \frac{\rho}{4 \pi R^{2}} \prod_{\text{inter}} E_{1} dA = \frac{\rho}{4 \pi R^{2}} E_{1} \cdot 4 \pi R^{2} = \rho E_{1} = \frac{\rho^{2} \Phi_{0}}{4 \pi R^{2}}$$

 $L \cos(\varepsilon) dA d\Omega' = L dA \frac{\cos^2(\varepsilon) dA'}{d^2}$ 

and dividing this expression results in the (infinitesimal) irradiance  $dE_1$ of the sphere's inner surface at the location of dA' which is caused by a single reflection of direct radiation from the source at the area element dA:

$$dE_1 = L \frac{\cos^2(\epsilon)}{d^2} dA = \frac{E_0 \rho}{\pi} \frac{1}{4 R^2} dA$$

using Equ. V.1 and the relation  $d = 2 R \cos(\varepsilon)$ , which can be easily seen from Fig.V.2

In order to obtain the irradiance  $E_1$ at the location of dA', caused by a single reflection of the source's radiation at the whole inner surface of the sphere, the above expression for dE<sub>1</sub> has to be integrated over the sphere's inner surface: *Formula A* 

whereby  $\Phi_0$  denotes the total radiant power emitted by the source and impinging upon the sphere's inner surface.

Note that the irradiance of the inner surface after the first reflection is independent from the actual location on the sphere, which holds true despite the inhomogeneous direct irradiance caused by direct illumination from the source. Deriving the irradiance  $E_2$  caused by the source's radiation after two reflec-

# **Integrating Spheres**

tions in the same way, we get

Formula B

Generally, the irradiance of the sphere's inner surface caused by the source's radiation after k reflections is given by

$$E_k = \frac{\rho^k \Phi_0}{4 \pi R^2}$$

and the total irradiance is thus given by Formula C

# V.2. Real integrating spheres

Due to the simplifications assumed for an ideal integrating sphere, the relations derived in paragraph IV.1 cannot be directly used in practical applications. Instead, they have to be altered for the following reasons:

- The reflectance ρ might depend on wavelength. This results in a wavelength dependent sphere multiplier K and thus in a spectral distortion of the primary source's output. Thus, the relations for the ideal sphere, which have been formulated for radiometric quantities, can no longer directly be applied. Instead, the sphere's behaviour for monochromatic radiation has to be determined by the respective relations for spectral radiometric quantities. If desired, radiometric quantities describing the sphere's radiation output can be determined by subsequent wavelength integration of the respective spectral radiometric quantities.
- Intensity considerations pose a lower limit for the size of the entrance and exit ports, as the radiant power entering or exiting a sphere is proportional to the

In this expression, only  $E_0$  actually depends on the respective location on the sphere's inner surface. As a consequence,  $E_{total}$  is independent from the actual location of the sphere's inner surface as long as we assure that  $E_0 = 0$  at this location. This means that no direct radiation from the source reaches the location, which can be obtained by baffles. In this case, total irradi-

Formula C:

area of the respective port. As a

result, these ports might consid-

erably reduce the amount of light

reflected at the sphere's inner

surface, which can be accounted

for by a modified sphere multi-

 $K = \frac{\rho}{\left[1 - \rho \left(1 - a\right)\right]}$ 

In these relations, a denotes the

relative share of the area of all

ports and other non-reflecting areas

sum of all non - reflecting areas

 $\boldsymbol{A}_{\text{sphere}}$ 

below shows the dependence of

the sphere multiplier on reflectance

 $\rho$  for different values of a. It can be

clearly seen that even a small varia-

tion of reflectance might cause

significant change in the sphere

For this reason, a slight wavelength

dependency of p may result in a

on the sphere's total inner surface:

 $\frac{\Phi_{0}}{A_{sphere}} \cdot \frac{\rho}{\left[1 - \rho \left(1 - a\right)\right]} = \frac{\Phi_{0}}{A_{sphere}} \cdot K$ 

plier:

with

a =

multiplier.

ance is proportional to the total amount of radiant power  $\Phi_0$  reaching the sphere's inner surface directly from the source:

$$E_{total} = \frac{\Phi_0}{A_{sohere}} \cdot \frac{\rho}{1 - \rho} = \frac{\Phi_0}{A_{sohere}} \cdot K$$

As the constant K describes the enhancement of irradiance relative to the average irradiance of a nonreflecting sphere, it is called "sphere multiplier" and, for an ideal sphere, solely depends on the coating material's reflectance  $\rho$ .

$${}_{1} + E_{2} + \ldots = E_{0} + \frac{{}^{\infty} \rho^{k} \Phi_{0}}{{}_{k=0} 4 \pi R^{2}} = E_{0} + \frac{\Phi_{0}}{A_{sphere}} \frac{{}^{\infty} \rho}{{}_{k=0} \rho^{k}} = E_{0} + \frac{\Phi_{0}}{A_{sphere}} \cdot \frac{\rho}{1 - \rho}$$

strong wavelength dependency of the sphere multiplier.

 $E_{total} = E_0 + E$ 

- Objects inside the sphere, for example the light source itself, cannot generally be neglected in their influence on the reflected optical radiation. A possible solution is the determination of the light source's influence by means of an auxiliary lamp (see paragraph III.1.b).
- Baffles inside the sphere and deviations of the coating material's reflectance properties from perfect Lambertian reflection cause further deviations of the sphere's behaviour from the relations derived in chapter 0. Their influence can only be simulated by numerical Monte Carlo simulations, which basically use ray tracing techniques to follow the paths of a large number of individual photons.

Apart from these factors, integrating spheres are also subject to temporal variations of their optical properties, which are primarily caused by degradation of their coating material. Especially the traditional coating material Barium sulphate (BaSO<sub>4</sub>) ages significantly when exposed to UV radiation.

Optically diffuse material (OP.DI.MA) is an optical grade plastic especially designed to work as a volume reflector. It has been designed to replace barium sulfate as a coating for integrating spheres in UV and high temperature applications. Its reflective properties depend on its thickness, generally specified at 10 mm, which is the recommended minimum thickness for lighting engineering.

Apart from its temporal stability, OP.DI.MA offers additional advantages. Using different additives, its reflection factor can be adjusted to any value between 3% (deep black) and 99% (brilliant white), whereby uniform reflectance over a wide spectral range and over large geometrical areas can be achieved. Like other plastics, it can be processed by turning, drilling, sawing and milling and is available in raw blocks, plates and foils in various sizes for this purpose.



Fig. V.3. Dependence of the sphere multiplier K on reflectance  $\rho$  for different values of the share of non-reflecting areas on the sphere's total inner surface.

# **Light Measurement Applications**

## VI. Applications for Light Measurement in Medicine, Technology, Industry and Environmental Science

For most technical applications of light, authorities like the International Commission on Illumination (CIE) or the Deutsche Industrienormen (DIN) have developed welldefined standards regarding its measurement. In virtually all areas connected with light, there is a strong demand for high quality measurement instruments. Many of these instruments must be specially designed and manufactured for the specific application. Moreover, these instruments must be calibrated against national standardization authorities, such as the National Institute of Standards and Technology (NIST) in the United

States or the Physikalisch-Technische Bundesanstalt (PTB) in Germany.

Gigahertz Optik not only offers a wide variety of absolutely calibrated light detectors, but also offers its experience in light measurement technology for the development of specialized solutions based on customer requirements. Gigahertz Optik's accredited calibration facility provides accurate, state of the art absolute calibration of instruments and secondary standard light sources (see § III.5).

#### VI.1. Phototherapy and Radiation Protection

85% of all sensory perceptions are optical in origin but optical radiation is not only involved in the process of human vision, it has many other biological effects as well.

The photobiological effects of optical radiation, especially in the ultraviolet and blue (400 to 500nm) spectral regions, can be therapeutic. For example, it is used in photo-therapy to treat a variety of skin diseases and in postnatal treatment of Hyperbilirubinemia. For proper dosimetry, irradiance  $(W/m^2)$  and irradiance dose  $(J/m^2)$  delivered by UV sources in phototherapy processes need to be monitored and

controlled through accurate measurements. These measurements are typically performed with a spectrally and spatially qualified UV-A, UV-B and UV-B<sub>311</sub> radiometer.

However, optical radiation also poses a potential health hazard for both human skin and eyes. For example, overexposure to ultraviolet and blue 'light' can cause common sunburn, photokeratitis (welder's eye) and burning of the retina or cornea.

Because of the dramatic increase in global UV radiation and the cumulative nature of the harmful effects, the additional risk of UV exposure by artificial sources is a concern.

The efficiency of protective de-

vices like sun creams, UV blocking fabrics and sunglasses are the subjects of study.

Photobiologists, industrial hygienists, health and safety officers measure UV irradiance  $(W/m^2)$  and irradiance dose  $(J/m^2)$  of solar and artificial light sources in the lab, field and in the work place in order to study both the harmful and helpful effects of light and establish safe guidelines for its use. It is important to note that UV levels and subject exposure times typically vary so datalogging over some time period is commonly employed.

Because Gigahertz-Optik is actively involved in the "Thematic

Network for Ultraviolet Measurements" funded by the Standards, Measurements and Testing program of the Commission of the European Communities, the detector and instrument designs are at the highest available level. The CIE, Commission Internationale de l'Eclairage, is reviewing many of the concepts put forth by the European Commission in an effort to internationally standardize the evaluation of UV radiometric measurement instrumentation much like the way photometric instruments are characterized now.

# Incoherent Optical Radiation Protection

Even though there are many wide ranging and highly positive effects of light there are also negative effects to consider. Naturally occurring optical radiation, especially in the UV range of the solar spectrum, poses a potential health risk to outdoor workers and others who spend a significant amount of time outdoors. The most serious longterm consequence of UV exposure is the formation of malignant melanoma of the skin, a dangerous type of cancer. In the US, skin cancer is the most frequently contracted type of cancer, and since the 1970s, the incidence rates of malignant melanoma have more then doubled. As a similar development can be found for other countries, national and supranational networks of solar UV detectors have been established recently to monitor solar UV levels and the World Meteorological Organization is currently preparing guidelines for their characterization, calibration and maintenance.

In simple terms, incoherent optical radiation is optical radiation in the range of wavelengths between 100 nm and 1 mm, other than that emitted by lasers. The effect of incoherent optical radiation on the skin and the eye is being afforded increasing attention. The reasons

for this are to be found in the rising exposure to radiation from sunlight, particularly in the UV range, and the growing use of high powered lamps in radiation therapy, radiation cosmetics, UV radiation curing, UV sterilization, vehicle headlamps, lighting equipment, etc. The high proportions of UV and blue light in the emission spectra of these lamps can, in addition to their desired effects, also result in radiation damage through both direct and indirect contact if the maximum permitted exposure levels are exceeded.

The shallow depth of penetration of optical radiation restricts the health hazards primarily to the eye and skin.



Malignant Melanoma Rates 1973 to 1998

Fig.VI.1. Incidence rates of malignant melanoma in the US since 1973.



Fig.VI.2. Optical Radiation Health Risks

# Page 184 - Tutorials

# **Light Measurement Applications**

## **Relevant Radiation Quantities**

When evaluating the harm that might be caused by incoherent optical radiation, it is the effective radiance (or the time integral of the radiance) that is critical for the retina, whereas for the skin, cornea and lens of the eye the critical quantity is the effective irradiance (or the exposure, also known as the dose) that can, for instance, arise at a workplace or in some other location where time is spent.

<u>Photobiologically effective radiance (W/( $m^2$  sr))</u>

$$L_{biol} = \int_{0}^{\infty} L_{e\lambda}(\lambda) * s(\lambda)_{biol,rel} * d\lambda$$

with  $L_{e\lambda}(\lambda)$ : spectral radiance of the radiation sources

<u>Photobiologically effective irradiance (W/m<sup>2</sup>)</u>

$$E_{biol} = \int_{0}^{\infty} E_{e\lambda}(\lambda) * s(\lambda)_{biol,rel} * d\lambda$$

with  $E_{e\lambda}(\lambda)$ : spectral irradiance of

the radiation sources

Photobiologically effective exposure (dose, J/m<sup>2</sup>)

$$H_{biol} = \int_{0}^{t_1} E_{biol} * dt$$

with  $s(\lambda)_{biol,rel}$  stands for the relevant spectral response functions of the skin and eye.

If exposure limits are given in guidelines as effective radiance, Limit, or as effective irradiance, E<sub>limit</sub>, then the following conditions should be maintained:

 $E_{biol} \le E_{limit}$  or  $L_{biol} \le L_{limit}$ 

If the exposure vaues are given as the time integral of the radiance Li or as the exposure (dose), H, then the maximum permissible exposure duration, t, can be calculated:

$$t = L_i / L_{biol}$$
 or  $t = H / E_{biol}$ 

#### ACGIH / ICNIRP Spectral Weighting Functions for Assessing UV Radiation Hazards

The spectral weighting function for the acutely harmful effects of UV radiation, was developed by the American Conference of Governmental Industrial Hygienists (ACGIH) and the International Commission on Non-Ionising Radiation Protection (ICNIRP)

If one examines the spectral curve describing this function, it is seen that the spectral effectiveness in the UV-C and UV-B ranges is very high, and that it falls drastically in the UV-A range. The reason for this is that the function is derived from the functions relating the radiation to erythema (skin reddening) and photokeratoconjunctivitis (corneal inflammation). The range

of wavelengths from 315 to 400 nm (UV-A) corresponds to a rectangle function representing total UV-A. Threshold Limit Values given for the maximum permissible exposure of the skin define the range of wavelengths as 200 (180) to 400 nm in reference to the ACGIH-ICNIRP function. The limits of maximum permissible exposure for the eye in the range 200 (180) to 400 nm and 315 to 400 nm (UV-A) are defined separately. By definition ACGIH-ICNIRP UV-C/B is measured in effective irradiance according to the spectrally weighted function and the UV-A level is assessed by measurement of the total UV-A irradiance (no

#### Blue-Light Hazard Photochemical Risks to the Retina

If optical radiation with wavelengths between 380 and 1400 nm of sufficient intensity reaches the retina it can cause photochemical and thermal injury. Radiation in the "blue" part of the spectrum from 380 to 700 nm (effectively 380 to 550 nm) triggers photochemical reactions, if the photon energy in the radiation is high enough, converting chemically unstable molecules into one or more other molecule types. The spectral curve of the blue light hazard response function is shown in the following diagram. ICNIRP 1997 gives the following limits for the effective

 $\begin{array}{l} \mbox{radiance of the BLH function:} \\ L_{BLH} * t \leq 100 \mbox{ J*cm}^{-2} * \mbox{sr}^{-1} \mbox{ for } t \leq 10.000 \mbox{s} \\ L_{BLH} \leq 10 \mbox{ mW} * \mbox{cm}^{-2} * \mbox{sr}^{-1} \mbox{ for } t > 10.000 \mbox{s} \\ L_{BLH} = \mbox{effective radiance} \end{array}$ 

t =duration of exposure

The blue light hazard function generally applies to exposure periods of more than 10 s. For shorter exposure times, the thermal retinal injury function applies.









#### Thermal Injury to the Eye -(RTH - Retina Thermal Hazard)

If the retina is exposed during short periods to high radiation intensities, a temperature rise to  $45^{\circ}$ C leads to hyperthermia, to  $60^{\circ}$ C causes coagulation, and to over  $100^{\circ}$ C results in vaporization. Removing the heat depends for the most part on the capacity of the irradiated zone to transfer heat, and thus on the size of the image of the radiation source on the retina. The diagram above illustrates the spectral response function for thermal damage to the retina according to ICNIRP.

In the spectral range between 380 and 500 nm, the effect of the RTH function is larger than the BLH function by a factor of 10. Whereas the latter rapidly falls to zero above 500 nm, the thermal function continues on to 1400 nm. Since no industrially useable radiation sensors with spectral sensitivity from 380 to 1400 nm exist, an acceptable simulated match using silicon photodiodes is in use. In this context it is quite adequate to measure the range up to 1200 nm, since various light sources exhibit no more than 4% difference in the integrated totals to 1200 nm and to 1400 nm. This statement is also confirmed by ICNIRP in their working paper /1/.



For radiation sources whose emissions lie primarily in the near infrared range (IR-A) between 780 and 1400 nm, and that generate a visual luminance of less than 10 cd/m<sup>2</sup>, the visual stimulus is so weak that the aversion reflex is not activated. In such applications the measurement of radiance must, according to ICNIRP, take place exclusively in the IR-A region.

 $L(\lambda)$ : spectral radiance of the radiation source being measured, RTH  $(\lambda)$ : Retina Thermal Hazard Function,  $\alpha$  = apparent radiation source.

Limits are also prescribed for the RTH function. Thus, for the case where

 $10\mu \le t \le 10s$ 

$$\begin{split} L_{haz} &\leq 50/(~\alpha^*t^{~0,25})~(kW^*m^{-2}*sr^{-1}~) \\ L_{haz} &= effective~radiance~for~the \\ RTH~function, \end{split}$$

a = size of the light source ex-

pressed in radians For t < 10  $\mu$ s the limit must not be any greater than  $L_{haz}$  for t= 10  $\mu$ s. For t > 10  $\mu$ s the limit must not be any greater than  $L_{haz}$  for t= 10 s. *Metrological Considerations* 

# UV-Erythema

The typical symptom of UV erythema is acute skin inflammation caused by UV radiation (sunburn). It used to be thought that erythema was only caused by radiation components in the UV-B range of wavelengths. Present opinion is that UV-A plays a part in causing erythema because there is so much more of it present. Medical investigations have shown that intensive exposure to UV in leisure time and at work increases the risk of skin cancer. Children in particular should be protected from strong UV radiation, as the skin stores the information about the UV dose

Radiance is the quantity relevant to the evaluation of BLH and RTH hazards. The latest draft standards (IEC 825-1, November 1998), and ICNIRP (printed in Health Physics 1999) express views as to the angle of the measurement field of radiance meters. The applicable figures related to exposure durations are:

t<10s an  $\alpha$  of 1.7mrad <sup>1)</sup>; t=10s...100s an  $\alpha$  of 11mrad <sup>2)</sup> t=100s...10000s an  $\alpha$  of 1.1\*t <sup>0,5</sup>

t> 10000s an  $\alpha$  of 100mrad <sup>2)</sup>

<sup>1)</sup> Dominance of thermal damage to the retina

<sup>2)</sup> Dominance of blue light hazard

For RTH IR-A evaluation ANSI/ IESNA RP-27.1-96 recommends a field of view of 11 mrad, and of 100 mrad for very large radiation sources.

 /1/ ICNIRP: Guidelines of limits of exposure to broad-band incoherent optical Radiation (0,38μm to 3 μm) (September 1997)(0,38μm to 3 μm) (September 1997)

received in the first years of life, and this can be an important factor in the development of skin tumors in later years.

Sunburn occurs in fair-skinned people (skin type 2) with a UV dose of as little as 250 J/m<sup>2</sup>. Our table (following F. Greiter: Sonne und Gesundheit, (Sun and Health), published by Gustav Fischer Verlag 1984) lists the various exposure duration's for minimal skin reddening for different skin types.



Fig. VI.5. Light Source - Subtended Angle - Retina







Fig. VI.7. Erythemal Spectral Function

Skin type	Description	Identification	Reaction to the sun Sunburn Tanning		Exposure duratior ( min )
I	Skin: noticeably light; Freckles: strong; Hair: reddish; Eyes: blue, rarely brown; Nipples: very pale	Celtic type(2 percent)	Only very painful	No reddeningwhite after 1 to two days, skin peels	5 to 10
II	Skin: somewhat darker than I Freckles: rarely; Hair: blonde to brown; Eyes: blue, green and grey; Nipples: light	Light skinned European (12 percent)		HardlySkin peels	10 to 20
111	Skin: light to light brown, fresh Freckles: none; Hair: dark blonde, brown; Eyes: grey, brown; Nipples: darker	Dark skinned European (78 percent)	Moderate	Average	20 to 30
IV	Skin: light brown, olive; Freckles: none; Hair: dark brown; Eyes: dark; Nipples: dark	Mediterranean type (8 per- cent)	Hardly	Fast and deep	40

Table VI.1. Skin Type Categories

# Page 186 - Tutorials

# **Light Measurement Applications**

# Phototherapy; UV-A, UV-B and UV-B<sub>311</sub> Phototherapy

UV is widely used by dermatologists in the treatment of certain skin diseases like Psoriasis and Vitiligo. Whole body exposure booths and hand and foot units employing light sources which emit broadband UV-A. UV-B. narrowband 311nm UVB and combinations of UV-A and UV-B are used to irradiate the patient.

In PUVA phototherapy, also called photochemotherapy, UV-A is applied in combination with a photosensitizing agent which is taken in pill form or applied topically to the skin. This medication called psoralen, giving rise to the acronym PUVA, makes the skin more sensitive and responsive to the UV-A (315-400nm) wavelengths

Due to the risks of premature skin ageing and skin cancer from prolonged exposures, also with consideration to skin type, PUVA is only recommended for moderate to severe cases of Psoriasis. As a side note, psoralen is also being used as a photosensitizer in UV sterilization of blood.

normally administered without a photosensitizing agent. It is considered safer than UV-A for wavelengths between approx. 290 to 315 nm, since it does not penetrate as deeply into the skin and is more energetic allowing shorter overall exposure times. However, it is generally accepted that wavelengths below 290 nm produce more ervthema which can actually inhibit the therapeutic effects of the longer wavelengths.

As a result, narrowband UV-B sources emitting at predominantly 311-312 nm, have been developed. They emit right in the wavelength zone of most effectiveness while producing less erythemal interference than broadband UV-B sources

This is generally known as a TL-01 source. A TL-12 UV-B source with a slightly wider band of emittance between 280-350 nm, peaking at about 305 nm is also in use. For more information contact the National Psoriasis Foundation and the American and European Academies of Dermatology.

Dose, used here as irradiance accu-

in a 'bilibed' or protected isolette

and exposed to fluorescent lights

designed or filtered to emit in the

blue spectrum. A recent develop-

ment is the 'biliblanket' that delivers blue light through fiber optics

and can be wrapped around the

infant. Radiometric measurements

of bililights are important in order

Efforts to standardize an action

spectral function and measurement

procedures for bilirubin are in

process. Due to early work in this

field, the units of microwatts/cm<sup>2</sup>/

nm were wrongly adopted for

radiometric measurement of

bililights. To be technically correct

the units of watts/cm<sup>2</sup> should apply.

to ensure proper dosimetry.

UV-B broadband treatment is

## **Bilirubin Phototherapy**

Newborn jaundice or neonatal hyperbilirubinaemia, a yellowish appearance of the skin and whites of the eyes, is present to some degree in almost all newborn infants. This is caused by an elevated level of bilirubin molecule in the blood which results from immaturity of the liver function combined with the destruction of red blood cells present. When these levels are very high, one method of clearing the jaundice is by exposing the newborn to light in the blue spectral region between 400 to 550 nm. The light interacts with the bilirubin, converts it to a substance excreted back into the bloodstream which can then be excreted in the feces. The newborn is placed nude

#### VI.2. Plant physiology

The study and understanding of the interrelation of optical radiation and plants, seeds and soil is critically important for our existence. Research and control of biochemical factors require a precise and predictable measurement technology.

The absorption of optical radiation in the range of wavelengths be-

#### Photosynthesis

Photosynthesis is one of the most important biochemical processes on the planet. In the process of photosynthesis green plants absorb carbon dioxide from the atmosphere and water from the soil,

radiation energy to build sugar, releasing oxygen and water into the atmosphere. This process can bedescribed by the following assimilation formula:

mulated over time, is normally measured in phototherapy applications

joules/cm<sup>2</sup> = watts/cm<sup>2</sup> x seconds

(dose/energy) = irradiance x time

In the research & development stage or field service, direct irradiance may be monitored to discern

any variation in output through lamp or delivery system degradation but most of today's phototherapy equipment is equipped with sensors and electronics which allow delivery of pre-selected doses of UV

Third party checks of these internal dosimeters by qualified UV radiometers is recommended to ensure proper dosimetry and safety.



Fig. VI.8. Narrowband 311nm & Broadband UV-B Source Spectra



Fig. VI.9. Bilirubin Spectral Function

tween 300 nm and 930 nm initiates photochemical reactions in plants that are essential for plant growth. The three most important reactions of plants to optical radiation are:

Photosynthesis, Phototropism, Photomorphogenesis

The occurrence of photosynthesis in plants is characterized by the green color of their leaves. This is due to chlorophyll which is absorbed with the photosynthetically active radiation. Accordingly, the phere and water from the soil, combining them with the aid of  $6CO_2 + 12H_2O_{\overline{674 \, kal}} \rightarrow C_6H_{12}O_6 + 6O_2 + 6H_2O$  active radiation. Accordingly, the absorption of the quanta of radiation energy in the chlorophyll molecules raises the electrons to a higher energy state. As they return to their initial state, the energy released is converted into chemical energy.



# Light Measurement Applications

## **Photosynthesis**

In general plant physiology, the term Photosynthetically Active Radiation (PAR) refers to the radiation in the range of wavelengths between 400 nm and 720 nm. This is the energy that is absorbed by the assimilation pigments in blue-green algae, green algae and higher order plants. The wavelengths for the lower limit (400 nm) and an upper limit (720 nm) are not entirely rigid. Photosynthetic reactions have, for example, been established in some algae at wavelengths shorter than 400 nm. In general, the lower limit depends on the structure and the thickness of the leaf as well as on the chlorophyll content. Some research projects have shown 700 nm as the upper wavelength limit.

In DIN 5031, Part 10 (currently in the draft phase) the spectral response function for photosynthesis is defined, and this is illustrated graphically below. For plant physiology, this range can be divided into three narrower bands:

- 400 nm to 510 nm: strong light absorption by chlorophyll, high

#### Ultraviolet Radiation Effects

The weakening of the ozone layer has been discussed in public for more than a decade. It presents a serious challenge to plant physiology. Even above Europe, a reduction in the total amount of ozone of 3-6% per decade (since 1978) has been established, which correlates with a measured increase of up to 7% in the level of UV-B radiation in high alpine areas with clean air. In March of 1993 a 15% disappearance of ozone was observed, so

that in general an increase in UV-B radiation must be expected. UV-B radiation penetrates the

morphogenetic effect

morphogenetic effect

effect

510 nm to 610 nm: weak light

absorption by chlorophyll, no

610 nm to 720 nm: strong light

absorption by chlorophyll, high

morphogenetic and ontogenetic

This response function can be

considered as a mean spectral

response function. A number of

different investigations have shown

that the spectral absorption spectra

of various plant types can be very

different. These differences can

also occur, in a single plant, e.g. in

leaves of different ages or with

different thicknesses, chlorophyll

content, etc.. It should also be

noted that the spectral response

function for photosynthesis is

defined with avoidance of mutual

cell shading, experimenting with a

young, thin leaf or with a thin laver

The spectral distribution of the

response function for photosynthe-

sis might give the impression that visible radiation in the green range

centered around 550 nm contrib-

utes very little to the photosyn-

of algae suspension.

tissues and leads to molecular changes in DNA, proteins, lipids and phytohormones. At high levels of UV radiation, oxygen radicals are formed, leading to oxidation of proteins and lipids. The result of this is that growth, photosynthesis, and finally productivity and yield are impaired. Some field trials have provided evidence that in the presthetic process, and therefore is of minor importance. Just the contrary has been demonstrated by experiment. It is precisely this green radiation that yields the greatest productivity and efficiency in densely populated arrangements of plants or in thick suspensions of micro-organisms. This discovery is important for investigations into the yields of plants in the lower layers of wooded areas or of greenhouse stocks, or in deep water (e.g. in sea plants). Classical investigations into plant physiology have indicated that photosynthetic bacteria possess special pigments with strong absorption bands in vivo at 750 nm (chlorobium chlorophyll in the green chlorobacteria) or at 800, 850, 870 and 890 nm. In contrast to the blue-green algae, green algae and the higher plants, the absorption spectrum of the photosynthetic bacteria also extends into the UV region as far as about 300 nm.



Fig. VI.10. Phototropism (blue) & Photosynthesis (green)

ence of an ozone reduction of 25%, the UV-sensitive soy bean variety Essex, unlike the insensitive Williams variety, undergoes a reduction in photosynthesis, and therefore of yield, of up to 25%. This effect of UV-B radiation (280 nm-313.3 nm) is internationally known as "generalized plant damage", and is evaluated using the UV-B response function according to Caldwell. This GPD response function incorporates the degree of damage,

linear growth, the cell division rate and other factors. So in the fields of plant physiology and crop cultivation it is necessary not only to investigate the positive photosynthetic effects of optical radiation, but also the negative effects, mostly due to UV radiation, if the activity and protection mechanisms of plants are to be understood and manipulated.

# Phototropism Phototropism describes the effect of plant growth. The regions of maximum effect lie in the blue range between 380 nm and 520 nm the effect of causing parts of plants to move. Photomorphogenesis Photomorphogenesis

intensities in the range of wave-680 nm (short wavelength red) is of Photomorphogenesis describes the of the spectrum encourages linear growth, while blue radiation yields lengths from 690 nm to 780 nm way in which plants are formed great importance for the plant's under the influence of optical rasmall, strong plants. To be more (long wavelength red) to the range biological processes. of wavelengths from 560 nm to diation. Radiation in the red region precise, the ratio of the radiation Measurement Aim, Measurement Methods

The photochemical processes involved in plant physiology are understood as quantum processes. Associated measuring techniques should also treat them as such. The most important measurements for plant physiology are:

- Analysis of the efficiency of energy conversions in photosynthesis
- Determination of the rate of

photosynthesis (yield factor) when exposed to radiation sources having different emission spectra

- Comparison of the rate of photosynthesis in various plant types cultivated under various radiation conditions
- Determination of the protective mechanism and the stress processes of plants in relation to UV

radiation and high levels of heat radiation (infrared radiation)

The effect of radiation of various wavelengths on the growth processes taking place within plants can be represented in a number of ways. The rate of photosynthesis is defined as the ratio of the quantity of assimilated carbon dioxide  $(CO_2)$  molecules to a suitable ra-

diation input quantity. These quantities are:

- the irradiance in W/m<sup>2</sup>, i.e. the radiant power per unit area of the irradiated object
- or, alternatively, the photosynthetic photon irradiance  $E_{p,sy.}$ . This magnitude is also frequently referred to as the quantum flux density.

# **Light Measurement Applications**

# Photosynthetic Photon Irradiance E p,sy

The radiation conditions used in determining the rate of photosynthesis and the photosynthetic potential of various plant or algae types are not the same in all research institutions. Results obtained under very different radiation conditions, using detector heads with non-uniform rectangular (radiometric) characteristics, and then relating them to one another, may lead to false conclusions. This is because the varying spectra of the radiation sources in use are ignored in obtaining the measurement.

The solution is to evaluate the irradiance with a sensor with an appropriate spectral response function. It is presently assumed that the number of light quanta absorbed is responsible for plant growth, which implies that it is quantum magnitudes effective in plant biology that need to be measured. The most important magnitude is the photosynthetic photon irradiance E  $_{\rm p.sy.}$ 

The photosynthetic photon irradiance  $E_{p,sy}$  is defined as follows: where:

$$\mathbf{E}_{p,sy} = \left| \mathbf{E}_{p,\lambda}(\lambda) d\lambda = \frac{1}{h.c} \right| \mathbf{E}(\lambda) \lambda d\lambda$$

 $E(\lambda)$  is the spectral irradiance of the light source

 $\lambda$  is the wavelength of the radiation E <sub>p,sy</sub> ( $\lambda$ ) is the spectral photon irradiance = number of photons per second, per unit area and wavelength.

h is Planck's constant c is the velocity of light.

# VI.3. UV-Disinfection and Lamp Control

UV radiation can have harmful effects on human skin and eyes, especially during indoor application of high-energy UV irradiators. There is however a positive aspect to UV's hazardous effect on living organisms. Ultraviolet treatment of drinking and wastewater is a wellestablished, economical and efficient method for killing germs,



Fig. VI.11. UV treatment of wastewater

bacteria, mold and fungus. Its use is becoming more widespread than traditional water treatment techniques employing chlorine and ozone for reasons of cost and environmental factors.

Recently, a field study performed in homeless shelters in New York, Birmingham and New Orleans (TB UV Shelter Study, TUSS) has shown that UV treatment of room air with upper room irradiators leads to a drastic reduction of tuberculosis infection rate.

The CIE divides ultraviolet optical radiation into three ranges:

- UV-A: 315 to 400 nm (skin pigmentation)
- UV-B: 280 to 315 nm (vitamin D synthesis, erythema)
- UV-C: 200 to 280 nm (germicidal action, absorption maximum of DNA). Below 230 nm, UV radiation has enough energy to break chemical bonds.

Short wavelength high energy ultraviolet radiation in the UV-C

The unit of photosynthetic photon irradiance, E  $_{p,sy}$ , is defined as follows:

$$[E_{p,sy}] = 1E.s^{-1}.m^{-2} = 1Mol.s^{-1}.m^{-2}$$

where 1 E = 1 Mol =  $6.02 \times 10^{23}$ photons (the most commonly used unit is  $\mu$ Mol s<sup>-1</sup>m<sup>-2</sup>).

The limits of integration need to be specified for integration according to the formula. If, for example, the photosynthetic photon irradiance is to be measured in the range of wavelengths between 400 nm and 700 nm, 320 nm and 500 nm to 900 nm, the integration is carried out in the corresponding spectral segments.

This numerical integration can be performed implicitly by means of an integral measuring head. Such a

spectral range from 100 to 280 nm is used in the germicidal/ bactericidal sterilization of air and water. UV-C at 253.7 nm is also employed in eprom erasure and the cleaning of sensitive surfaces in the semiconductor industry. UV curing is another area where UV-C is applied.

#### UV-C Light Sources

Due to its high and pre-dominantly monochromatic output at 253.7 nm,



- © The incident radiation must be evaluated in accordance with the cosine of the angle of incidence, i.e. using a cosine diffuser
- © The spectral sensitivity of the measuring head must be adapted to the *l*/l<sub>r</sub> function. l<sub>r</sub> is the reference wavelength, and for the 400-700 nm, 320-500 nm and 590-900 nm ranges it is always the upper limit wavelength, i.e. 700 nm, 500 nm and 900 nm.

The spectral sensitivity of the sensor should be zero outside the responsive spectral zone of interest.

low pressure mercury is the light source of choice in these applications. Medium and high pressure Hg as well as metal halide and other broadband UV sources are also used, especially in UV curing. *Light Source Life-time* 

The useful lifetime of high power UV-C sources is limited. UV-C intensity must be monitored to ensure process control.



Fig.VI.12. Upper room UV irradiators help lower tuberculosis infection rates.

linear ageing, UV output needs to be continuously monitored and controlled.

These high UV levels place special demands on the measurement devices used in this application. That component of Ultraviolet energy useful for curing makes up only a small part of the spectral bandwidth within the lamp's total emission spectrum and the bare detector's spectral sensitivity.

Therefore, optical bandpass filters are used to limit the detector's sensitivity to the spectral range of interest.

Conventionally designed UV irradiation detectors show drift and instability over time due to the hostile ambient conditions found in the UV-curing process. Solarization, 'fogging'' effects and even delamination of the filter elements and other optical components can

VI.4. UV Curing and UV Processing

UV curing is a process in which photocureable chemicals applied to substrates are irradiated with high energy UV or Visible radiation for curing. This energy accelerates polymerization (cross-linking) and consequently the hardening or drying process. The irradiated energy needs to be controlled, since too low a dose will not cure the product, whereas too high a dose will damage it.



typically measured as

over time.

 $J/cm^2 = W/cm^2 x$  seconds

High-power UV sources are used in this process. Because of non-

irradiance

# Tutorials - Page 189 Light Measurement Applications

# 🖲 Gigahertz-Optik

occur. These effects not only can change the detector's absolute sensitivity but can also change its spectral sensitivity. On recalibration a change in absolute sensitivity may be noted and adjusted but unless a complete spectral test is perfomed a change in spectral sensitivity can go undetected. So what is thought to be a newly recalibrated detector very often will produce erroneous readings when returned to the end user.

A new detector design has been developed based on the integrating element RADIN<sup>TM</sup>, which is not only able to withstand the high UV and temperature conditions of the UV-curing process but also maintain stability and measurement accuracy over long term use. Critical components in the detector are not exposed to direct irradiation but only see a fraction of it.

RADIN is a trade name of Gigahertz-Optik.

The detector response which best matches the absorption spectrum of the photocureable chemical in use is selected. This way the detector spectrally emulates the product to be cured.

The lamp(s) used in the system were selected by the equipment manufacturer for optimal curing within this active bandpass.

When lamp replacement becomes necessary the replacement lamps should be the same in spectral and absolute output as the old ones so that the established process parameters are not invalidated.



Fig. VI.15. UV Curing Detector

It should be noted that information on the spectral response function of the detector in use should be provided along with any statement of measured magnitude to properly 'frame' the results. UV detectors from different manufacturers can have very different spectral responses. This means that they will not read the same under the same test conditions.

Due to the many errors involved with UV measurement, even two detectors from the same manufacturer can read much differently.

Normally in the field, readings within  $\pm$  10% are considered acceptable in the UV-A range.

Uncertainties get progressively worse as you move to the shorter wavelengths.

It is important to remember that the UV meter is after all a scientific instrument which is asked to perform reliably and repeatably in very hostile environments.

Maintaining calibration cycles at the manufacturer recommended interval is necessary. If unacceptable levels of change are seen on recalibration, the cycle time should be shortened (staircase method). This way you end up with a recalibration program tailored to your specific requirements.

Also consider having a second instrument on hand which is used only for an in-house calibration check of the working production unit(s).

# VI.5. Colorimetry

Color is the attribute of visual perception consisting of any combination of chromatic and achromatic content. This attribute can be described by chromatic color names such as yellow, orange,

#### **Color and Illuminance Measurement**

In many applications involving the measurement of color or of the color temperature of self-emitting light sources, the same measurement geometry is used as for illuminance. Appropriate absolute calibration of the measuring system allows the illuminance of a reference plane in Lux (lx) to be determined, in addition to the colorimetric parameters. If the incident light is falling diffusely, this measurement requires the measuring system to have a field of view adapted to the cosine function. Only in this way can the laws for the incidence of diffuse radiation from one or

brown, red, pink, green, blue, purple, etc., or by achromatic color names such as white, grey, black, etc., and qualified by bright, dim, light, dark or by combinations of such names. Perceived color depends on the spectral distribution of the color stimulus, on the size, shape, structure and surroundings of the stimulus area, on the state of adaptation of the observer's visual system, and on the person's experience of prevailing and similar situations of observation. For more details about theory, see paragraph II.9 of this tutorials.



Devices of class A, with a total uncertainty of measurement of

7.5 % for precise measurements. Devices of class B, with a total uncertainty of measurement of 10 % for operating measurements.

Since there are no equivalent regulations for colorimeters, some of the regulations in DIN-5032 can also be usefully applied to illuminance measuring colorimeters. HCT-99

Gigahertz-Optik's HCT-99

# Page 190 - Tutorials

# **Light Measurement Applications**

### **Color and Luminous Flux Measurement**

Luminous flux is the quantity used to define all of the emitted radiation in all directions by a light source in the photometric unit, Lumens (lm). One of its purposes is to reference the efficiency of incandescent lamps, arc lamps, light emitting diodes, etc., as this is derived from the relationship between the input electrical power and the luminous flux.

beam it is possible to measure the luminous flux with a photodetector assuming that the diameter of the beam is less than that of the detector measurement aperture. If the light beam is highly divergent, or if a  $4\pi$  radiation characteristic must be considered, a measurement geometry must be used that ensures that all of the radiated light is evaluated, regardless of the direction in which it is emitted. The measurement geometry most

In cases where the light source emits in an approximately parallel

# **Color and Luminous Intensity Measurement**

The quantity of luminous intensity specifies the light flux emitted by a light source in a particular direction within a specified solid angle in the photometric units of Candela (cd). One area where it is applicable is when lamps and projectors are used in imaging systems (lens systems, reflectors), and the subsequent distribution of luminous intensity from the illumination or spotlight

#### **Color and Luminance Measurement**

The quantity of luminance is used to evaluate the intensity of light from surface emitters in the photometric units of Candela/square metre (cd/m<sup>2</sup>). A defined angular field of view for the color measuring device is needed in order to measure luminance. This can be accomplished using either steradian tubes or lens systems.

#### **Color Temperature Measurement**

Color temperature is a simplified way to characterize the spectral properties of a light source. While in reality the color of light is determined by how much each point on the spectral curve contributes to its output, the result can still be summarized on a linear scale.

Low color temperature implies warmer (more yellow/red) light while high color temperature implies a colder (more blue) light. Daylight has a rather low color temperature near dawn, and a higher one during the day. Therefore it can be useful to install an electrical lighting system that can supply cooler light to supplement daylight when needed, and fill in with warmer light at night. This also correlates with human feelings towards the warm colors of light coming from candles or an open fireplace at night.

#### Standard unit for color temperature is Kelvin (K).

The kelvin unit is the basis of all temperature measurement, starting with 0 K (=  $-273.16^{\circ}$  C) at the absolute zero temperature. The

system must be calculated.

In order to measure luminous intensity, the field of view of the color detector must be restricted to the desired solid angle. This is usually accomplished using steradian adapter tubes that limit the detector head's field of view. It is important that the inner walls of these tubes are designed to exhibit low reflectance. Steradian tubes



often used for highly divergent sources is a hollow body, ideally formed as a hollow sphere, with a diffusely reflecting interior wall.



known in Germany as Ulbricht spheres. The figure below illustrates the principle of its construction.

Such "integrating spheres" are

Fig. VI.16. Color and Luminous Flux Measurement Instrument with a 150 mm Integrating Sphere

that attach to the front end of the detector can be used for this purpose.



Fig. VI.17. Typical Measurement Geometries

Fig. VI.18. Color Detector Head for Measurement of Luminous Intensity and Luminance,

- 3400 K, Tungsten lamp
- 5500 K, sunny daylight around noon

For many color measurement tasks it is important to determine the color temperature of luminous objects. According to DIN 5031-P.5, the color temperature  $t_c$  of a radiator requiring characterization is the temperature of a Planckian radiator at which it emits radiation

of the same color type as that of the radiator being characterized. The color temperature is calculated and displayed by the meter. The calculation of color temperature is performed using an algorithm according to Qiu Xinghong, which enables very good research results for the color temperature range from 1667°K to 25000°K to be obtained.





"size" of one kelvin is the same as that of one degree Celsius, and is defined as the fraction 1/273.16 of the thermodynamic temperature of the triple point of water, which

Light sources are sometimes described by their correlated color temperatures (CCT). The correlated color temperature of a source is the temperature of a black body radiator that is most similar to the source. A blackbody radiator is an ideal surface that absorbs all energy incident upon it, and re-emits all this energy. The spectral output distribution of an incandescent (tungsten) lamp approximates a blackbody at the same temperature. Correlated color temperature is typically presented using the absolute centigrade scale, degrees Kelvin (K).

Some typical color temperatures are:

- 1500 K, Candlelight
- 3000 K, 200 W incandescent lamp
- · 3200 K, sunrise / sunset

positions 0° Celsius at 273.16 K.

# VI.6. Photostability

The current ICH (International Conference for Harmonization) guidelines specify that drug and drug products must be phototested to ensure that exposure to light does not cause photochemical degradation of the product or packaging. The product under test must receive a measured dose of both UV-A (200 watt-hours per square meter) and Visible (1.2 million luxhours) optical radiation exposure. This requires both radiometric and photometric measurements in terms of illuminance in lux and UV-A (315 to 400 nm) irradiance in W/m<sup>2</sup> multiplied by exposure time in hours

It is important to note that total or absolute UV-A is implied. No effective UV-A spectral function is specified. Ideally for total UV-A measurements, the perfect broadband UV-A detector would have a flat square-wave spectral shape starting at 315 to 400 nm for 100% response at each wavelength across this spectrum with no response outside this bandpass. Most currently available UV-A detectors have a 'bell' shaped spectral response which, if uncorrected through calibration or redesign of spectral function, will read >25% too low on the UV-A fluorescent source, and >40% too low for Xenon + glass ID65 type light sources.

Note that UV-A fluorescent and Xenon or Metal Halide simulated ID65 light sources are the only sources specified in the ICH guidelines.

A closer approximation to an ideal UV-A broadband detector has recently been developed for photobiological and photostability applications by Gigahertz-Optik. Compared to the ideal UV-A spectral function the typical detector total area error is 34% while the Gigahertz-Optik 'flat' UV-A detector is only 14%.

The guidelines also state that to ensure spectral conformity of the light source(s) a phototester 'may rely on the spectral distribution specifications of the light source manufacturer'. It has been found in actual practice that either the spectral data is not available or typical data is not reliable due to ageing effects of the source and other factors. This is another important reason for using photodetectors with the best spectral match to the ideal functions.

Most often the phototesting is performed in a photostability chamber with long fluorescent light sources mounted above the products under test. For larger profile products, light sources may also be mounted along the sides of the chamber to fully immerse the target. Since this is an extended source type of measurement rather than a point source configuration, the detector angular responsivity should be cosine corrected using a diffuser. This way the incoming light signals are properly weighted according to the cosine of the angle of incidence.

Then the detector properly emulates the target in the way the light signal is received.

Profiling the photostability chamber for uniformity over the exposure plane is an important procedure since products placed in different areas inside the chamber should be uniformly exposed to the same light levels. Moving the detector or using multiple detectors in multiplex mode maps the exposure levels at various locations across the exposure plane.

Some of the photostability chambers manufactured today are equipped with internal light sensors to continuously monitor the light and UV-A output.

Maintaining accuracy and reliability in on-line continuous monitoring of UV applications is a daunting challenge. Without proper protection engineered into the detector, changes due to solarization, temperature effects and ensuing calibration drift can occur. It is advisable to do a third party check using a qualified radiometer/photometer.



Fig. VI.19. Typical UV-A Spectral Function



Fig. VI.20. Flat UV-A Spectral Function

## VI.7. Telecommunication

An ongoing revolution occurring in the field of telecommunications is the development of small laser diodes and high capacity optical fibres. Without optical fibre telecommunication devices the highly convenient availability of huge amounts of information at comparatively low costs, as provided by the Internet, would not be possible.

The measurement of the power output of laser diodes or fibers is a daily routine in the field of telecommunication components testing. Optical power meters using a bare detector claim high sensitivity but at a cost of potential measurement inaccuracies caused by the effects of polarization, local saturation, signal 'bounce-back' and beam misalignment. Also, the use of large size photodiodes required to reduce source to detector misalignment, increases cost.

A welcome alternative is the integrating sphere which is able to collect all of the source optical radiation output independent of beam geometry. In the world of photonics, the integrating sphere is well known for its ability to reliably and accurately measure total flux from fibers, laser diodes, lasers, LEDs and any other optical radiation or light source. Since all of the incoming signal is captured and reflected inside the sphere multiple times before reaching the baffled detector mounted to it, the adverse effects of polarization, local saturation, signal 'bounceback' and beam misalignment are reduced.

Fig. V1.21. During the last two decades, optical fibre capacity has increased by a factor of about 1000. For comparison, commercial state of the art wire connections range in the region of about 0.1 Gigabit per second (Gb/s).



# Page 192 - Tutorials

# **Light Measurement Applications**

## **VI.8. LEDs Measurements**

Presently, a slow but steady large scale technological change is taking place: The traditional incandescent bulb is being replaced more and more by special semiconductor devices called light emitting diodes or LEDs. Over the past decade, LEDs have caught up in efficiency and now offer an economical alternative to incandescent bulbs even for bright signal lamps such as traffic and automotive lighting. A high percentage of an incandescent bulb's total light output is lost when passed through a coloured filter. In contrast, an LED emits light of only the desired color, thus no filtering is necessary and consumption of electrical energy can be reduced by up to

V1.9 LASER Measurements

The most commonly encountered monochromatic source is the laser Because of its monochromatic and coherent radiation, high power intensity, fast modulation frequency and beam orientated emission characteristics, the laser is the primary source used in fiber optic communication systems, range finders, interferometers, alignment systems, profile scanners, laser scanning microscopes and many other optical systems.

Traditional monochromatic radiometric applications are found in the range of optical spectroscopy with narrow band-pass filtered detectors and scanning monochromators used as monochromatic detection systems or monochromatic light sources.

Optical radiation describes the segment of electromagnetic radiation from l=100 nm to l=1 mm. Most lasers used in measurement instrumentation and fiber optic telecommunications systems work predominantly in the 200 to 1800 nm wavelength range.

vices as sources of artificial light is restricted by comparatively high production costs. However, the Because of the monochromatic emission spectrum and fixed output wavelength, detectors used to measure laser power do not need a radiometric broadband characteristic. This means that the typical spectral sensitivity characteristic of Si or InGaAs photodiodes can be

90%. Low power consumption and

a typical LED lifetime of 100,000

hours (compared to about 1000

hours for incandescent bulbs),

drastically reducing maintenance,

often equates to significant overall

cost reduction when LEDs replace

traditional lighting. As an exam-

ple, the city of Denver, which

recently has replaced some 20000

incandescent bulbs in traffic light

signals with LED devices, esti-

mates the total savings to about

\$300 per signal, calculated for the

At the current level of technology,

the broad application of LED de-

lifetime of an LED device.

correction. For absolute power measurements the bare detector's spectral response can be calibrated at a single wavelength or over its complete spectral range (typically done in 10 nm increments).

The corresponding calibration factor for that specific wavelength is selected when making the laser power measurement. Some meters offer the capability of selecting a wavelength by menu on the display. The meter then calculates the reading by applying the calibration factor for the wavelength selected and displays the measurement result.

• Lasers with collimated (parallel) beams are typically measured with a flat-field detector, whose active size is larger than the laser beam diameter. Because of the high power of lasers, the responsivity of the detector may have to be reduced by an attenuation used without requiring spectral filter. But there is a risk of meas-

urement errors due to polarization effects, surface reflections from optical surfaces in the light path and misalignment of the beam on the detector. • Lasers with non-collimated (divergent) beams cannot be measured with a flat-field detector because of the different an-

gles of incidence. The power output of these lasers is typically measured with detectors combined with an integrating sphere which collects all incoming radiation independent of the angle of incidence.

• Here are more unique features offered by the integrating sphere: Through multiple internal reflections, the sphere offers high attenuation for high power measurements. The max. power is limited by the sphere's upper operating temperature limit.

Also through multiple internal reflections, measurement errors caused by polarization effects with flat-field detectors do not occur

The sphere port diameter can be enlarged by increasing the sphere diameter which allows measurement of larger diameter beams

• Laser Stray-light: Although very useful. laser radiation can pose a health risk to the human eye. Even stray-light from lasers may be hazardous due to the typically high power levels found. The EN 60825 standard describes the risk and measurement methods for risk classification. Laser stravlight can be assessed with the use of a detector head with a 7 mm dia. free aperture to mimic the open pupil.

There are two typical measurement strategies for laser power detection:

#### V1.10 Non-Destructive Testing

The American Society for Nondestructive Testing defines NDT as the examination of an object with technology that does not affect the object's future usefulness. The term NDT includes many methods that can:

- · Detect internal or external imperfections
- · Determine structure, composition or material properties
- Measure geometric characteristics

Liquid Penetrant Testing (PT), Magnetic Particle Testing (MT) and Visual and Optical Testing

(VI) are test methods used to detect defects in materials with the aid of optical radiation or light.

The light levels used in these operations are critical to the integrity of the inspection process so radiometric and photometric measurements are made for quality control purposes.

American Society for Testing and Materials (ASTM), MIL and DIN standard practices exist to help ensure uniformity in these examinations.

Liquid Penetrant Testing using the dye penetration examination process is a widely used method for

the detection of surface defects in nonporous metal and non-metal materials. Two different methods are in use:

#### **Dve Penetration Process:**

A colored liquid or dye is applied to the surface of the test object which, through capillary action, penetrates into any existing surface defect(s). After removing any excess, an absorptive white layer is applied, drawing the colored liquid out of the defect making it visible. Adequate illumination of the test object with white light is critical to create good contrast

**Fluorescent Penetrating Agent:** 

For highest sensitivity, a fluorescent dye is used as the penetrating liquid and the test is carried out under ultraviolet lighting. UV-A sources known as 'blacklights' are most commonly used. To reliably test with fluorescent agents, an adequate level of UV-A irradiance containing a very low proportion of white (visible) light must be generated at the object under test.

Magnetic Particle Testing and of course Visual and Optical Testing both rely on ensuring adequate light levels for quality control of the examination.

use when power consumption is a critical parameter as when batteries 90 uminous Performance (lumens/watt) or solar cells must be used to 80 power the lamps. 70 Mercury 400W 60 50 40 30 20

Fig. VI.22. Efficiency of red, green, white and blue LEDs has dramatically increased during the last



# Light Measurement Applications / Appendix

DIN EN 1956, ASTM and MIL Standards exist that describe the general conditions and standard practices for the penetrant test examinations, including the procedures to be followed. The minimum requirements for the illumination or irradiation conditions, test procedures to be used for checking these levels and suitable measurement equipment specifications are also covered.

It is particularly emphasized in these standards that the calibration of the radiometer and photometer used to measure the illuminance and irradiance must be carried out with the aid of calibration standards that can be traced back to national standards. The test certificate must document the calibration testing.

The calibration method must also be considered.

Many of the UV-A radiometers used in this application are calibrated at a single point at the peak of the detector spectral response, typically 360 nm or simply adjusted to some reading on a particular light source. To reduce measurement errors due to light sources with different spectral outputs, Gigahertz-Optik uses the integral calibration method where the detector is calibrated to a measured UV-A integrated spectral irradiance standard.

To reduce spectral errors even further, the Gigahertz-Optik UV-A detector exhibits a nearly flat response across the UV-A bandpass with a sharp cut-off at 400 nm to eliminate visible stray light from contaminating the UV reading. The spectral response function of

the photometric sensor is very important for the same reasons. Spectral errors when measuring lux or foot-candles can occur when testing light sources different from the source used for calibration. A detector that very closely matches the CIE photopic function is required for accurate photometry. The Gigahertz-Optik photopic sensor's spectral function is within DIN Class B limits of <6% fidelity to the CIE photopic curve.

The detector spatial response (angular response) is another important factor and potential error source.

Since the detector is fully immersed in light from all directions, including any ambient contribution, it should be cosine corrected, using a diffuser. This way the incoming light signals are properly weighted according to the cosine of the incident angle. The detector receives the light signals in the same way as a flat surface does, so in effect the detector emulates the sample under test. If the detector spatial response does not closely match the true cosine function, significant errors in readings will result

UV sources pose a potential health hazard risk to the skin and eye. UV-A sources used in PT emit some levels of the most harmful UV-C and UV-B rays. The UV-A rays are considered less of a risk, but the ACGIH/ICNIRP guidelines do state Threshold Limit Values for UV-A at 1 mW/cm2 for an eighthour exposure period. For UV-B, the TLV is much less at 0.1 Effective W/cm<sup>2</sup>. So UV exposure of workers in PT environments should be tested to ensure safety as well as for quality control.



# VI.11. Transmission & Reflection

'Measurement with Light' refers to the use of optical radiation as a tool for performing a measurement task. Reflectance and transmittance meters employ both light sources and a detection system. A spectrophotometer is a good example of this type of instrument. Light describes optical radiation visible to the human eye over the wavelength range from 380 to 780 nm. The eye's sensitivity to light varies over this spectral range peaking at 555 nm. This same CIE

defined V( $\lambda$ ) photometric action function applies to any application where light must be evaluated for visual purposes including reflection and transmission. DIN 5036-part 3 and CIE 130-1998 recommend an integrating sphere with a minimum diameter of 50 cm for the measurement of photometric material properties such as light transmittance/reflectance, diffuse transmittance/reflectance and regular transmittance/reflectance.

#### VII.1. Relevant quantities, their symbols and units Unit(s) Quantity Symbol 1 nanometer = 1 nm = $10^{-9}$ m / 1 Ångstrøm = 1 Å = $10^{-10}$ m Wavelength λ Power Р 1 Watt = 1 WSolid angle Ω 1 steradian = 1 sr $\Phi_{e}$ Radiant power or radiant flux 1 Watt = 1 W Radiant intensity Ie 1 W sr<sup>-1</sup> L<sub>e</sub> 1 W sr<sup>-1</sup> m<sup>-2</sup> Radiance 1 W m<sup>-2</sup> Irradiance Ee Radiant exitance 1 W m<sup>-2</sup> Me Luminous flux $\Phi_v$ 1 lumen = 1 lmphotopic: 1 lm corresponds to $\Phi_e = 1/683$ W at $\lambda_m = 555$ nm scotopic: 1 lm corresponds to $\Phi_e = 1/1700$ W at $\lambda'_m = 507$ nm 1 candela = 1 cd = 1 lm / srLuminous intensity I<sub>v</sub> $1 \text{ Im sr}^{-1} \text{ m}^{-2} = 1 \text{ cd m}^{-2} = 1 \text{ nit}$ Luminance L $1 \text{ stilb} = 1 \text{ sb} = 1 \text{ cd } m^{-2}$ $l a postilb = l a sb = l/\pi cd m^{-2}$ $1 \text{ lambert} = 1 L = 10^4 / \pi cd m^{-2}$ $1 \text{ footlambert} = 1 \text{ fl} = 3.426 \text{ cd } m^{-2}$ Illuminance E<sub>v</sub> $1 \text{ lux} = 1 \text{ lx} = 1 \text{ lm m}^{-2}$ $1 \text{ phot} = 1 \text{ ph} = 10^4 \text{ lx}$ 1 footcandle = $1 \text{ fc} = 1 \text{ lm ft}^2 = 10.764 \text{ lx}$

# Page 194 - Tutorials

# Appendix

Quantity	Symbol	Unit(s)
Luminous exitance	M <sub>v</sub>	1 lm m <sup>-2</sup>
Spectral radiant power	$\Phi_{\lambda}(\lambda)$	1 W nm <sup>-1</sup>
Spectral radiant intensity	$I_{\lambda}(\lambda)$	1 W sr <sup>-1</sup> nm <sup>-1</sup>
Spectral radiance	$L_{\lambda}(\lambda)$	1 W sr <sup>-1</sup> m <sup>-2</sup> nm <sup>-1</sup>
Spectral irradiance	$E_{\lambda}(\lambda)$	$1 \text{ W m}^{-2} \text{ nm}^{-1}$
Spectral radiant exitance	$M_{\lambda}(\lambda)$	1 W m <sup>-2</sup> nm <sup>-1</sup>

Table VII.IV. Units in italic are not SI units, not consistent with CIE regulations and should not be used !

## VII.2. Summary of radiometric and photometric quantities

Quantification of electromagnetic radiation	Radiometric quantity	Spectral quantity	Photometric quantity	quantity depends on
emitted by a source in total	radiant power Φ <sub>e</sub> W	spectral radiant power $\Phi_{\lambda}(\lambda)$ W nm <sup>-1</sup>	luminous flux $\Phi_v$ lm (lumen)	-
emitted in a certain direction	radiant intensity I <sub>e</sub> W sr <sup>-1</sup>	spectral radiant intensity $I_{\lambda}(\lambda)$ W sr <sup>-1</sup> nm <sup>-1</sup>	$I_{v}$ $I_{v}$ $I_{r} = cd$	direction
emitted by a location on a surface	radiant exitance M <sub>e</sub> W m <sup>-2</sup>	spectral radiant exitance $M_{\lambda}(\lambda)$ W m <sup>-2</sup> nm <sup>-1</sup>	$\begin{array}{c} \text{luminous exitance} \\ M_{\nu} \\ \text{lm m}^{-2} \end{array}$	position on source's surface
emitted by a location on a surface in a certain direction	radiance L <sub>e</sub> W sr <sup>-1</sup> m <sup>-2</sup>	spectral radiance $L_{\lambda}(\lambda)$ W sr <sup>-1</sup> m <sup>-2</sup> nm <sup>-1</sup>	luminance $L_v$ $lm sr^{-1} m^{-2} = cd m^{-2}$	position on source's surface and direction
impinging upon a surface	irradiance E <sub>e</sub> W m <sup>-2</sup>	spectral irradiance $E_{\lambda}(\lambda)$ $W m^{-2} nm^{-1}$	illuminance $E_v$ $lm m^{-2} = lx$	position on irradiated surface

*Table VII.V – Radiometric and photometric quantities* 

# **Radiometric quantities:**

In the following relations, X has to be replaced by one of the symbols  $\Phi$ , I, L or E:

$$X_{e} = \int_{0}^{\infty} X_{\lambda}(\lambda) d\lambda \qquad \text{or} \qquad X_{e,\text{range}} = \int_{\lambda_{1}}^{\lambda_{2}} X_{\lambda}(\lambda) d\lambda$$

with  $\lambda_1$  and  $\lambda_2$  denoting the lower and the upper limit of the respective wavelength range (for instance, UVA)

## Photometric quantities:

In the following relations, X has to be replaced by one of the symbols  $\Phi$ , I, L or E:

Photopic vision:  $X_v = K_m \cdot \int_0^{\infty} X_{\lambda}(\lambda) \cdot V(\lambda) d\lambda$  with  $K_m = 683 \text{ Im / W}$  Scotopic vision:  $X_v = K'_m \cdot \int_0^{\infty} X_{\lambda}(\lambda) \cdot V'(\lambda) d\lambda$  with  $K'_m = 1700 \text{ Im / W}$ 

#### Basic integral relations between radiometric and photometric quantities:

In the following, x has to be replaced either by e (denoting radiometric quantities) or v (denoting photometric quantities).

$$\Phi_{x} = \prod_{4\pi} I_{x} d\Omega \qquad I_{x} = \prod_{\substack{\text{emitting} \\ \text{surfaces}}} L_{x} \cos(\vartheta) dA \qquad M_{x} = \prod_{2\pi} L_{x} \cos(\vartheta) d\Omega$$

#### VII.3. Sources and references for figures

Fig. II.1: http://www.cameraguild.com/technology/colorimetry.htm

Fig. II.3: http://sedac.ciesin.org/ozone/docs/AS.html

Fig. II.5: adapted from http://www.salsburg.com/lightcolor/lightcolor.html

Fig.II.6: adapted from http://whatis.techtarget.com/

definition/0,,sid9\_gci528813,00.html

Fig. II.11: http://omlc.ogi.edu/classroom/ece532/class1/

intensity\_flashlight.html

Fig. II.15: adapted from http://www.cameraguild.com/technology/ colorimetry.htm

Fig. II.16: http://math.nist.gov/~FHunt/appearance/brdf.html

Fig. II.17: http://lsvl.la.asu.edu/askabiologist/research/seecolor/

rodsandcones.html

 $Fig. \ II.19: \ http://www.cs.princeton.edu/courses/archive/fall99/cs426/lectures/raster/img013.gif$ 

Fig. II.22: http://home.wanadoo.nl/paulschils/10.02.htm

- Fig. VI.1: http://www.coolibar.com/skin-cancer-in-the-us.html
- Fig. VI.11: http://www.mindfully.org/Water/UV-Disinfection-Wastewater.htm
- Fig. VI.12: http://www.news.ucf.edu/FY2001-02/011205.html Fig. VI.22: http://www.bell-labs.com/history/physicscomm/images/
- br\_v\_t6w.gif

Fig. VI.23: http://hyperphysics.phy-astr.gsu.edu/hbase/electronic/leds.html

#### VII.4. Most relevant CIE- DIN- and ISO-publications and regulations

#### **VII.4.a. DIN Publications**

DIN 4512-8, Ausgabe:1993-01 Photographische Sensitometrie; Bestimmung der optischen Dichte; Geometrische Bedingungen für Messungen bei Transmission DIN 4512-9, Ausgabe:1993-01

Photographische Sensitometrie; Bestimmung der optischen Dichte; Spektrale Bedingungen

# DIN 5030-2, Ausgabe:1982-09

Spektrale Strahlungsmessung; Strahler für spektrale Strahlungsmessungen; Auswahlkriterien DIN 5031 Beiblatt 1, Ausga-

be:1982-11 Strahlungsphysik im optischen

Bereich und Lichttechnik; Inhaltsverzeichnis über Größen, Formelzeichen und Einheiten sowie Stichwortverzeichnis zu DIN 5031 Teil 1 bis Teil 10

#### DIN 5031-2, Ausgabe:1982-03

Strahlungsphysik im optischen Bereich und Lichttechnik; Strahlungsbewertung durch Empfänger DIN 5033-7, Ausgabe:1983-07

Farbmessung; Meßbedingungen für Körperfarben

#### DIN 5037 Beiblatt 1, Ausgabe:1992-08

Lichttechnische Bewertung von Scheinwerfern; Vereinfachte Nutzlichtbewertung für Film-, Fernsehund Bühnenscheinwerfer mit rotationssymmetrischer Lichtstärkeverteilung

DIN 5037 Beiblatt 2, Ausgabe:1992-08

Lichttechnische Bewertung von Scheinwerfern; Vereinfachte Nutzlichtbewertung für Film-, Fernsehund Bühnenscheinwerfer mit zu einer oder zwei zueinander senkrechten Ebenen symmetrischer Lichtstärkeverteilung

#### DIN 5039, Ausgabe:1995-09

Licht, Lampen, Leuchten - Begriffe, Einteilung

DIN 5042-1, Ausgabe:1980-10 Verbrennungslampen und Gasleuchten; Einteilung, Begriffe

DIN 5043-1, Ausgabe:1973-12 Radioaktive Leuchtpigmente und Leuchtfarben; Meßbedingungen für die Leuchtdichte und Bezeichnung der Pigmente

DIN 19010-1, Ausgabe:1979-03 Lichtelektrische Belichtungsmesser; Skalen, Kalibrieren

#### DIN 58141-5, Ausgabe:1993-11

Prüfung von faseroptischen Elementen; Bestimmung der Faserbruchrate von Licht- und Bildleitern

#### **DIN 58141-10, Ausgabe:1997-02** Prüfung von faseroptischen Elementen - Teil 10: Bestimmung der Beleuchtungsstärke und des effektiven Öffnungswinkels von Kaltlichtauellen

#### ISO 31-6, Ausgabe:1992-09

Größen und Einheiten; Teil 6: Licht und verwandte elektromagnetische Strahlung

ISO 8599, Ausgabe:1994-12

Optik und optische Instrumente -Kontaktlinsen - Bestimmung des Spektral- und Licht-Transmissionsgrades

#### VII.4.b. CIE Publications

**13.3-1995:** Method of measuring and specifying colour rendering of light sources New edition (including Disk D008)

**15.2-1986:** Colorimetry, 2nd ed. **16-1970:** Daylight

**17.4-1987:** International lighting vocabulary, 4th ed. (Joint publication IEC/CIE)

**18.2-1983:** The basis of physical photometry, 2nd ed.

**19.21-1981:** An analytic model for describing the influence of lighting parameters upon visual performance, 2nd ed., Vol.1.: Technical foundations

**19.22-1981:** An analytic model for describing the influence of lighting parameters upon visual performance, 2nd ed., Vol.2.: Summary and application guidelines

**38-1977:** Radiometric and photometric characteristics of materials and their measurement

**39.2-1983:** Recommendations for surface colours for visual signal-ling, 2nd ed.

**40-1978:** Calculations for interior lighting: Basic method

**41-1978:** Light as a true visual quantity: Principles of measurement

**44-1979:** Absolute methods for reflection measurements

**46-1979:** A review of publications on properties and reflection values of material reflection standards

**51.2-1999:** A method for assessing the quality of daylight simulators for colorimetry (with supplement 1-1999)

**52-1982:** Calculations for interior lighting: Applied method

**53-1982:** Methods of characterizing the performance of radiometers and photometers

**55-1983:** Discomfort glare in the interior working environment

**59-1984:** Polarization: Definitions and nomenclature, instrument polarization

**60-1984:** Vision and the visual display unit work station

**63-1984:** The spectroradiometric measurement of light sources

**64-1984:** Determination of the spectral responsivity of optical radiation detectors

**65-1985:** Electrically calibrated thermal detectors of optical radiation (absolute radiometers) **69-1987:** Methods of characteriz-

ing illuminance meters and luminance meters: Performance, characteristics and specifications

**70-1987:** The measurement of absolute luminous intensity distributions

**75-1988:** Spectral luminous efficiency functions based upon brightness matching for monochromatic point sources, 2° and 10° fields **76-1988:** Intercomparison on

measurement of (total) spectral radiance factor of luminescent specimens

78-1988: Brightness-luminance relations: Classified bibliography
82-1989: CIE History 1913 - 1988
84-1989: Measurement of luminous flux

**85-1989:** Solar spectral irradiance **86-1990:** CIE 1988 2° spectral luminous efficiency function for photopic vision

**87-1990:** Colorimetry of selfluminous displays - A bibliography

**95-1992:** Contrast and visibility **96-1992:** Electric light sources -State of the art - 1991

**98-1992:** Personal dosimetry of UV radiation

101-1993: Parametric effects in

colour-difference evaluation 105-1993: Spectroradiometry of

pulsed optical radiation sources **106-1993:** CIE Collection in photo-

biology and photochemistry (1993):

106/1: Determining ultraviolet action spectra

106/2: Photokeratitis

106/3: Photoconjunctivitis 106/4: A reference action spectrum

for ultraviolet induced erythema in human skin

106/5: Photobiological effects in plant growth

106/6: Malignant melanoma and fluorescent lighting

106/7: On the quantification of environmental exposures: limitations of the concept of risk-tobenefit ratio

106/8: Terminology for photosynthetically active radiation for plants **108-1994:** Guide to recommended practice of daylight measurement (including disk)

**109-1994:** A method of predicting corresponding colours under different chromatic and illuminance adaptations

**114-1994:** CIE Collection in photometry and radiometry

114/1: Survey of reference materials for testing the performance of spectrophotometers and colorime-

ters

114/2: International intercomparison on transmittance measurement

- Report of results and conclusions

114/3: Intercomparison of luminous flux measurements on HPMV lamps

114/4: Distribution temperature and ratio temperature

114/5: Terminology relating to non-selective detectors

114/6: Photometry of thermally sensitive lamps

**116-1995:** Industrial colour difference evaluation

**118-1995:** CIE Collection in colour and vision

118/1: Evaluation of the attribute of appearance called gloss

118/2: Models of heterochromatic brightness matching

118/3: Brightness-luminance relations

118/4: CIE guidelines for coordinated research on evaluation of colour appearance models for reflection print and self-luminous display image comparisons

118/5: Testing colour appearance models: Guidelines for coordinated research

118/6: Report on colour difference literature

118/7: CIE guidelines for coordinated future work on industrial colour-difference evaluation

**121-1996:** The photometry and goniophotometry of luminaries

**124-1997:** CIE Collection in colour and vision, 1997

124/1: Colour notations and colour order systems

124/2: On the course of the disability glare function and its attribution to components of ocular scatter

124/3: Next step in industrial colour difference evaluation - Report on a colour difference research meeting

**125-1997:** Standard erythema dose **127-1997:** Measurement of LEDs

**130-1998:** Practical methods for the measurement of reflectance and transmittance

134-1999: CIE Collection in photobiology and photochemistry, 1999 134/1: Standardization of the terms UV-A1. UV-A2 and UV-B

134/3: Recommendations on

photobiological safety of lamps. A

135-1999: CIE Collection in vision

and colour and in physical meas-

urement of light and radiation,

135/2: Colour rendering (TC 1-33

135/3: Supplement 1-1999 to CIE

134/2: UV protection of the eye

review of standards

135/1: Disability glare

closing remarks)

1999

# Appendix

51-1981: Virtual metamers for assessing the quality of simulators of CIE illuminant D50 135/4: Some recent developments

in colour difference evaluation 135/5: Visual adaptation to complex luminance distribution

135/6: 45°/0° spectral reflectance factors of pressed polytetrafluoroethylene (PTFE) powder

**138-2000:** CIE Collection in Photobiology and Photochemistry, 2000

138/1: Blue light photochemical

retinal hazard

138/2: Action spectrum for photocarcinogenesis (non-melanoma skin cancers)

138/3: Standardized protocols for photocarcinogenesis safety testing 138/4: A proposed global UV index

**139-2001:** The influence of daylight and artificial light on diurnal and seasonal variations in humans a bibliography (also available as disk) **142-2001:** Improvement to industrial colour difference evaluation **148:2002:** Action spectroscopy of skin with tunable lasers

**149:2002:** The use of tungsten filament lamps as secondary standard sources

**151:2003:** Spectral weighting of solar ultraviolet radiation

**CIE Draft Standard DS 010.3-2002:** Photometry - The CIE system of physical photometry **CIE Draft Standard DS** 012.2:2002: Standard method of assessing the spectral quality of daylight simulators for visual appraisal and measurement of colour

CIE Draft Standard DS 013.2:2002: International standard global UV index

**CIE Draft Standard DS 015:2002:** Lighting of work places - outdoor work places

## **VII.5** National Calibration Laboratories

## **DKD – German Accreditation Institution**

The German accreditation institution DKD (Deutscher Kalibrierdienst) was founded by German trade and industry and the German state represented by the Physikalisch-Technische Bundesanstalt (PTB), the German national standards laboratory. The basic idea of the DKD is to transfer as many PTB responsibilities to industry as possible, including the calibration of measurement and testing equipment. The DKD ensures the traceability of measurement and testing equipment to national standards by the accreditation and continuous auditing of industrial calibration laboratories. Therefore, calibrations carried out by DKD accredited laboratories offer a secured traceable and well-documented link to national calibration standards. An uninterrupted traceable chain of calibration links to national standards is absolutely necessary for acceptance of measurement devices by any quality management sys-

tem. The qualification of the traceability to national standards is the job of the Physikalisch-Technische Bundesanstalt (PTB), the German national standards laboratory. The PTB will define, realize, keep and transmit the physical quantities of the SI-system, such as a meter, a second, a kilogram, a candela, etc. To ensure objective results, equal standards must be used. The calibration of measurement and testing arrangements based on SI-units is a basis for correct, comparable, recognizable and therefore measurable values, which can be audited. Within the DIN ISO 9000 ff. standard the relationship between quality management and calibration are intertwined in part for continuous control of measurement and testing equipment. Without exception, DKD accredited calibration laboratories fulfill the requirements of the European standard EN 45001 (general criteria to operate a testing laboratory, May 1990). Outside of Europe this standard is not compulsory. Instead of this the ISO/IEC Guide 25 (General requirements on the competence of testing and calibration laboratories, December 1990) is recognized. In content, EN 45001 and ISO/IEC Guide 25 are identical. This is the basis for the mutual appreciation between the European cooperation for Accreditation (EA) and its extra-European partners. In 1999 ISO/IEC 17025 took the place of EN 45001 and ISO/IEC Guide 25 which eliminated any formal differences.

Existing DKD calibration laboratories automatically qualify for ISO/IEC/EN 17025 conformance. DKD homepage: <u>http://</u> www.dkd.info/

The European position of the DKD is noted by its membership in the European Cooperation for Accreditation of Laboratories (EAL) in Rotterdam, which was founded out of the Western European Calibration Cooperation (WECC) and the Western European Laboratory Accreditation Cooperation (WELAC) in 1994. Within the EAL different national accreditation institutes cooperate with the goal of international acceptance of calibration certificates of the EALcalibration laboratories. In November 2000, 34 accreditation institutions from 28 countries, including the PTB, the accreditation institution of the DKD, signed a Mutual Recognition Arrangement (MRA) of the International Laboratory Accreditation Cooperation (ILAC). More information about this arrangement and the participating countries is available online at

http://www.ilac.org.

## PTB – Physikalisch-Technische Bundesanstalt

The Physikalisch-Technische Bundesanstalt (PTB) is the highest technical authority for metrology in Germany. The PTB define, realize, keep and transmit the physical quantities of the SI-system, such as a meter, a second, a kilogram, a candela, etc. The PTB is the offi-

cial accreditation institution for DKD calibration laboratories for optical radiation measurement quantities such as Gigahertz-Optik. The PTB is also actively working on bilateral acceptance on national standards. Because of their activities in 1995 a Statement of Intent on Traceability of Measurement Standards was signed between the Physikalisch-Technische Bundesanstalt (PTB) and the National Institute of Standards and Technology (NIST) USA. The Equivalence of the National Standards of NIST and PTB for the SI Units of Luminous Intensity and Luminous Flux was officially recognized in April 1999.

PTB homepage: http://www.ptb.de/

NRC – National Research Council Canada

The NRC's Institute for National Measurement Standards Photometry and Radiometry Group maintains photometric, radiometric, spectrophotometric and colorimetric standards, and provides associated, high-accuracy measurement services to industry, university, and government clients involved with lighting, transportation, manufac-

turing, telecommunications, public health and safety, and the environment.NRC INMS Photometry & Radiometry Home Page Last Upd a t e d : 2 0 0 1 - 0 7 - 1 8 (http://www.nrc.ca/inms/ phot rad/prei.html)

Appendix

#### NIST – U.S. National Institute of Standards and Technology

The Optical Technology Division of NIST's Physics Laboratory has the mandate to provide a high quality national measurement infrastructure to support industry, government, and academia who are reliant upon optical technologies for their competitiveness and success. As a part of this mandate, the Division has the institutional responsibility for maintaining two SI base units: the unit for temperature, the kelvin, above 1234.96 K and the unit of luminous intensity, the candela. As part of its responsibilities the Division: Develops, improves, and maintains the national standards for radiation thermometry, spectroradiometry, photometry, colorimetry, and spectrophotometry; provides National measurement standards and support services to advance the use and application of optical technologies spanning the ultraviolet through microwave spectral regions for diverse industrial, governmental, and scientific uses; disseminates these standards by providing measurement services to customers requiring calibrations of the highest accuracy and contributes to the intellectual reservoir of technical expertise by publishing descriptions of NIST developed advances in appropriate scientific journals and books; conducts basic, long term theoretical and experimental research in photophysical and photochemical properties of materials, in radiometric and spectroscopic techniques and instrumentation, and in application of optical technologies in nanotechnology, biotechnology, optoelectronics, and in diverse industries reliant upon optical techniques. NIST Physics Laboratory Optical Technology Division Home Page, Last updated: April 2002

( h t t p : / / www.physics.nist.gov/ Divisions/Div844/ about otd.html)

#### NPL - National Physical Laboratory UK

The NPL is UK's National Standards Laboratory for Physical Measurements. NPL's Optical Radiation Measurement (ORM) Group provides services which are the backbone for optical radiation measurements in the UK and internationally.

Here the UK's Primary Standards and scales are maintained, and pioneering research in measurement science is carried out. ORM anticipates and responds to industrial and academic measurement requirements throughout the IR, Visible, and UV spectra, providing a comprehensive range of Measurement and Calibration Services, Instrumentation Products, Training and Consultancy.

Some of the range of Measurement and Calibration Services, traceable to national standards, available in this field, includes the characterization and calibration of: ∉#All types of optical radiation sources

- Dptical radiation detectors and associated devices
- ∉ Dptical properties of materials and components
- ∉#Aspects of appearance including colour, haze and gloss

The development of NPL's Primary Standards and Measurement Scales, enables the UK to maintain the highest accuracy optical measurement references in the world as well as to enable the fostering of new ideas and techniques. Areas in which NPL is a recognized world leader include the development of the first cryogenic radiometer and the use of lasers for radiometry. NPL ORM Introduction Web Page: http://www.npl.co.uk/ optical\_radiation/ © Crown Copyright 2002 Appendix

## **VII.5** National Calibration Laboratories

See chapter Calibration Services in this catalogue or on Gigahertz-Optik's homepage



🖲 Gigahertz-Optik