

**Real-Time Spectral Imaging:
introducing the ButterflEYE VIS**

S128



Short facts

The Cubert S128 is based on a highly integrated filter-on-chip technology. This design combines up to 25 single spectral channels with QVGA resolution. We integrated this with a state of the art intelligent camera and completed the whole setup with our industry leading spectral camera software.

This package enables data acquisition, data storage and data processing directly on the camera. Altogether we deliver to you the most integrated and lightweight spectral camera available on the market. Together with our set of accessories you get the fastest access to UAV based imaging.

You have the choice of two options, ranging from 470 to 1000 nm enabling applications in remote sensing and everywhere else.

Filter-on-chip spectral imager

Principal applications

- UAV applications
- Precision farming
- Medical applications
- Remote sensing
- Quality control
- Vegetation monitoring
- 3D-hyperspectral surface models
- Spectral mobile mapping

Special features

- Optional 16 or 25 Channels
- Control panel for computerless operation
- Data storage on camera SD Card
- Wireless remote operation



S128 ButterflEYE VIS

Technical specifications*

Camera properties	
Detector	Si CMOS
Digitization	10 bit
Measurement time	down to 100 μs
Camera interface	USB, Power, GigE, E-SATA
Hyperspectral cube rate	up to 10 cubes/s
Sensor resolution	2 megapixel
Shutter	global
Data processing	Smart Camera
Storage	SD drive
Optical properties	
Objective	selectable
Mount	C-mount objective
Ground resolution	selectable mm-m
Physical properties	
Environment conditions	dry / non condensing
Operating temperature	0 - 40 °C
Weight	380 g
Power	DC 5 V, 15 W
Spectral properties	
Wavelength range	450-600 nm, 16 channels
Spectral Imaging	Snapshot
Channel width	20 nm

*this information may be subject of changes

What you should know

The ButterflEYE cameras uses a unique filter on chip technology which opens up a sweet spot between multi-chip multispectral cameras and full-blown hyperspectral cameras. With a medium spectral resolution of 16 to 25 channels the device enables a spatial resolution higher than QVGA.

Everything is combined in a smart camera module which enables not only the data storage directly on the device, but also application related postprocessing on the camera itself.

The device features computerless operation with an action-cam-like operation scheme making it easy to set up and use it in the field. With our spectral imaging software we bring you a versatile tool for data acquisition and processing, and offer full access to remote operation.

